



# TWIN ROTARY ASSEMBLIES

JD 62-6430  
CAB, WOC

Current as of 01/01/2016



1246

## PARTS LISTING WITH MOUNTING AND OPERATING INSTRUCTIONS

**Tiger Corporation**  
3301 N. Louise Ave.  
Sioux Falls, SD 57107  
1-800-843-6849  
1-605-336-7900

06011005

# TO THE OWNER / OPERATOR / DEALER

All implements with moving parts are potentially hazardous. There is no substitute for a cautious, safe-minded operator who recognizes the potential hazards and follows reasonable safety practices. The manufacturer has designed this implement to be used with all its safety equipment properly attached to minimize the chance of accidents.

**BEFORE YOU START!!** Read the safety messages on the implement and shown in this manual. Observe the rules of safety and use common sense!

**READ AND UNDERSTAND THIS MANUAL! Non-English speaking operators will need to GET THE MANUAL TRANSLATED as needed!**



# DANGER

**FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTIONS CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.**



1. Study and understand Operator's Manuals, Safety Decals, and Instructional Decals for tractor and implement to prevent misuse, abuse, and accidents. Practice before operating in a confined area or near passersby.

● Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children

2. Allow no children on or near folding mower or tractor. Allow no riders on tractor or implement. Falling off may cause serious injury or death from being run over by tractor or mower or contact with rotating blades.

3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seat belt securely fastened to prevent injury and possible death from falling off or tractor overturn.

● Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, & Ear Plugs are recommended.

4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain area is clear before lowering or folding

5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding mowers. Put Booms securely in Transport Rest.

● Folding and Boom Mowers have raised center of gravity. Slow down when turning and on hillsides.

6. Make certain that SMV sign, warning lights, and reflectors are clearly visible. Follow local traffic codes.

7. Never operate with Cutting Head or Folding Section raised if passersby, bystanders, or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Guards or mower structure.

8. Before dismounting, secure implement in transport position or lower to ground.

● Put tractor in park or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent crushing by entanglement in rotating parts which could cause injury or death.

● Never mount or dismount a moving vehicle. Crushing from runover may cause serious injury or death.



02967827

Warranty Information: Read and understand the complete Warranty Statement found in this manual. Fill out the Warranty Registration form in full and return it within 90 days. Make certain the Serial Number of the machine is recorded on the Warranty Card, and form that you retain.



# FORWARD

This manual contains information about many features of the Tiger mowing and roadside maintenance equipment. Some of these include: Safety precautions, Assembly instructions, Operations, Maintenance and Parts. This manual will also assist you in the proper break-in, daily care, and troubleshooting of your new mower.

We recommend that you read carefully the entire manual before operating the unit. Also, time spent in becoming fully acquainted with its performance features, adjustments, and maintenance schedules will be repaid in a long and satisfactory life of the equipment.

## **Troubleshooting - Please, before you call, help us to help you!**

Please look at the equipment to observe what is happening, then:

- Classify the problem
  - Hydraulic, electrical or mechanical - Read the trouble shooting section
  - Tractor or Truck chassis - Contact vehicle dealer
  
- If unable to correct the problem yourself, contact your local Tiger Dealer after gathering:
  - Machine model \_\_\_\_\_
  - Serial number \_\_\_\_\_
  - Dealer name \_\_\_\_\_
  - Detailed information about the problem including results of troubleshooting

**Attention Owner / Operator / Dealer:** It is your obligation to read, and understand, the warranty information section located at the back of this manual denoting that the purchaser understands the safety issues relating to this machine and has received and will read a copy of this manual.

If at any time, you have a service problem with your Tiger mower, Contact your local dealer for service and parts needed.

MANUFACTURED BY:

**Tiger Corporation**

3301 N. Louise Ave.

Sioux Falls, SD 57107

1-800-843-6849

1-605-336-7900

www.tiger-mowers.com

DISTRIBUTED BY:

\_\_\_\_\_

1- \_\_\_\_\_ - \_\_\_\_\_ - \_\_\_\_\_

1- \_\_\_\_\_ - \_\_\_\_\_ - \_\_\_\_\_



# TABLE OF CONTENTS

SAFETY SECTION_____	1
ASSEMBLY / MOUNTING SECTION_____	2
OPERATION SECTION_____	3
MAINTENANCE SECTION_____	4
PARTS SECTION_____	5
COMMON PARTS SECTION_____	6
WARRANTY INFORMATION_____	7



1012

**This symbol means:**

**CAUTION – YOUR SAFETY IS AT RISK!**

When you see this symbol, read and follow the associated instructions carefully or personal injury or damage may result.

Tiger is a registered trademark.







# SAFETY

# SAFETY SECTION

# SAFETY

## General Safety Instructions and Practices

A safe and careful operator is the best operator. Safety is of primary importance to the manufacturer and should be to the owner / operator. Most accidents can be avoided by being aware of your equipment, your surroundings, and observing certain precautions. The first section of this manual includes a list of Safety Messages that, if followed, will help protect the operator and bystanders from injury or death. Read and understand these Safety Messages before assembling, operating or servicing this mower. This equipment should only be operated by those persons who have read the Manual, who are responsible and trained, and who know how to do so safely and responsibly.



1000

The Safety Alert Symbol combined with a Signal Word, as seen below, is used throughout this manual and on decals which are attached to the equipment. The Safety Alert Symbol means: “**ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**” The symbol and signal word are intended to warn the owner / operator of impending hazards and the degree of possible injury when operating this equipment.

**Practice all usual and customary safe working precautions and above all -- remember safety is up to YOU! Only YOU can prevent serious injury or death from unsafe practices.**

DANGER!



Indicates an imminently hazardous situation that, if not avoided, WILL result in DEATH OR VERY SERIOUS INJURY.

WARNING!



Indicates an imminently hazardous situation that, if not avoided, COULD result in DEATH OR SERIOUS INJURY.

CAUTION!



Indicates an imminently hazardous situation that, if not avoided, MAY result in MINOR INJURY.

**IMPORTANT!**

Identifies special instructions or procedures that, if not strictly observed, could result in damage to, or destruction of the machine, attachments or the environment.

**NOTE:** *Identifies points of particular interest for more efficient or convenient operation or repair.* (SG-1)

READ, UNDERSTAND, and FOLLOW the following Safety Messages. Serious injury or death may occur unless care is taken to follow the warnings and instructions stated in the Safety Messages. Always use good common sense to avoid hazards. (SG-2)

**SAFETY INSTRUCTIONS**





# SAFETY

**PELIGRO!**



Si no lee Ingles, pida ayuda a alguien que si lo lea para que le traduzca las medidas de seguridad. (SG-3)




**¡ LEA EL INSTRUCTIVO!**

**DANGER!**



Never operate the Tractor or Implement until you have read and completely understand this Manual, the Tractor Operator's Manual, and each of the Safety Messages found in the Manual or on the Tractor and Implement. Learn how to stop the tractor engine suddenly in an emergency. Never allow inexperienced or untrained personnel to operate the Tractor and Implement without supervision. Make sure the operator has fully read and understands the manuals prior to operation. (SG-4)



**WARNING!**




Always maintain the safety decals in good readable condition. If the decals are missing, damaged, or unreadable, obtain and install replacement decals immediately. (SG-5)

**WARNING!**



Make certain that the "Slow Moving Vehicle" (SMV) sign is installed in such a way as to be clearly visible and legible. When transporting the Equipment use the Tractor flashing warning lights and follow all local traffic regulations. (SG-6)



**WARNING!**



Operate this Equipment only with a Tractor equipped with an approved roll-over-protective system (ROPS). Always wear seat belts. Serious injury or even death could result from falling off the tractor--particularly during a turnover when the operator could be pinned under the ROPS. (SG-7)



**WARNING!**




Do not modify or alter this Implement. Do not permit anyone to modify or alter this Implement, any of its components or any Implement function. (SG-8)

**DANGER!**



BEFORE leaving the tractor seat, always engage the brake and/or set the tractor transmission in parking gear, disengage the PTO, stop the engine, remove the key, and wait for all moving parts to stop. Place the tractor shift lever into a low range or parking gear to prevent the tractor from rolling. Never dismount a Tractor that is moving or while the engine is running. Operate the Tractor controls from the tractor seat only. (SG-9)



# SAFETY

**DANGER!**



Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in serious injury or death.

(SG-10)



**DANGER!**



Never allow children to operate or ride on the Tractor or Implement.

(SG-11)



**WARNING!**



Do not mount the tractor while the tractor is moving. Mount the tractor only when the tractor and all moving parts are completely stopped.

(SG-12)



**DANGER!**



Start tractor only when properly seated in the tractor seat. Starting a tractor in gear can result in injury or death. Read the tractor operators manual for proper starting instructions.

(SG-13)



**DANGER!**



Never work under the Implement, the framework, or any lifted component unless the Implement is securely supported or blocked up to prevent sudden or inadvertent falling which could cause serious injury or even death.

(SG-14)



**DANGER!**



Do not operate this Equipment with hydraulic oil leaking. Oil is expensive and its presence could present a hazard. Do not check for leaks with your hand! Use a piece of heavy paper or cardboard. High-pressure oil streams from breaks in the line could penetrate the skin and cause tissue damage including gangrene. If oil does penetrate the skin, have the injury treated immediately by a physician knowledgeable and skilled in this procedure.

(SG-15)




# SAFETY

## WARNING!



The operator and all support personnel should wear hard hats, safety shoes, safety glasses, and proper hearing protection at all times for protection from injury including injury from items thrown by the equipment. (SG-16)



## CAUTION!



**PROLONGED EXPOSURE TO LOUD NOISE MAY CAUSE PERMANENT HEARING LOSS!** Tractors with or without an Implement attached can often be noisy enough to cause permanent hearing loss. We recommend that you always wear hearing protection if the noise in the operator's position exceeds 80db. Noise over 85db over an extended period of time will cause severe hearing loss. Noise over 90db adjacent to the operator over an extended period of time will cause permanent or total hearing loss. *Note:* Hearing loss from loud noise [from tractors, chain saws, radios, and other such sources close to the ear] is cumulative over a lifetime without hope of natural recovery. (SG-17)



## WARNING!



Transport only at safe speeds. Serious accidents and injuries can result from operating this equipment at unsafe speeds. Understand the Tractor and Implement and how it handles before transporting on streets and highways. Make sure the Tractor steering and brakes are in good condition and operate properly.



**Before transporting the Tractor and Implement, determine the safe transport speeds for you and the equipment. Make sure you abide by the following rules:**

1. Test the tractor at a slow speed and increase the speed slowly. Apply the brakes smoothly to determine the stopping characteristics of the Tractor and Implement. As you increase the speed of the Tractor the stopping distance increases. Determine the maximum safe transport speed for you and this equipment.
2. Test the equipment at a slow speed in turns. Increase the speed through the turn only after you determine that it is safe to operate at a higher speed. Use extreme care and reduce your speed when turning sharply to prevent the tractor and implement from turning over. Determine the maximum safe turning speed for you and this equipment before operating on roads or uneven ground.
3. Only transport the Tractor and Implement at the speeds that you have determined are safe and which allow you to properly control the equipment.



**Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes. When operating down a hill or on wet or rain slick roads, the braking distance increases: use extreme care and reduce your speed. When operating in traffic always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy.** (SG-19)




# SAFETY

**WARNING!**



Never attempt to lubricate, adjust, or remove material from the Implement while it is in motion or while tractor engine is running. Make sure the tractor engine is **OFF** before working on the Implement.

(SG-20)



**WARNING!**



Periodically inspect all moving parts for wear and replace when necessary with authorized service parts. Look for loose fasteners, worn or broken parts, and leaky or loose fittings. Make sure all pins are properly secured. Serious injury may occur from not maintaining this machine in good working order. (SG-21)



**WARNING!**



Always read carefully and comply fully with the manufacturers instructions when handling oil, solvents, cleansers, and any other chemical agent. (SG-22)



**DANGER!**



Never run the tractor engine in a closed building or without adequate ventilation. The exhaust fumes can be hazardous to your health.

(SG-23)

**DANGER!**



**KEEP AWAY FROM ROTATING ELEMENTS** to prevent entanglement and possible serious injury or death. (SG-24)



**DANGER!**



Never allow children to play on or around Tractor or Implement. Children can slip or fall off the Equipment and be injured or killed. Children can cause the Implement to shift or fall crushing themselves or others. (SG-25)

# SAFETY

## DANGER!



**NEVER use drugs or alcohol** immediately before or while operating the Tractor and Implement. Drugs and alcohol will affect an operator's alertness and coordination and therefore affect the operator's ability to operate the equipment safely. Before operating the Tractor or Implement, an operator on prescription or over-the-counter medication must consult a medical professional regarding any side effects of the medication that would hinder their ability to operate the Equipment safely. **NEVER** knowingly allow anyone to operate this equipment when their alertness or coordination is impaired. Serious injury or death to the operator or others could result if the operator is under the influence of drugs or alcohol. (SG-27)



## DANGER!



Operate the Tractor and/or Implement controls only while properly seated in the Tractor seat with the seat belt securely fastened around you. Inadvertent movement of the Tractor or Implement may cause serious injury or death. (SG-29)

## WARNING!



Mow only in conditions where you have clear visibility in daylight or with adequate artificial lighting. Never mow in darkness or foggy conditions where you cannot clearly see at least 100 yards in front and to the sides of the tractor and mower. Make sure that you can clearly see and identify passersby, steep slopes, ditches, drop-offs, overhead obstructions, power lines, debris and foreign objects. If you are unable to clearly see this type of items discontinue mowing. (SGM-1)

## DANGER!



There are obvious and hidden potential hazards in the operation of this Mower. **REMEMBER!** This machine is often operated in heavy brush and in heavy weeds. The Blades of this Mower can throw objects if shields are not properly installed and maintained. Serious injury or even death may occur unless care is taken to insure the safety of the operator, bystanders, or passersby in the area. Do not operate this machine with anyone in the immediate area. Stop mowing if anyone is within 100 yards of mower. (SGM-2)



## DANGER!



All Safety Shields, Guards and Safety devices including (but not limited to) - the Deflectors, Steel Guards, Gearbox Shields, PTO integral shields, and Retractable Door Shields should be used and maintained in good working condition. All safety devices should be inspected carefully at least daily for missing or broken components. Missing, broken, or worn items must be replaced at once to reduce the possibility of injury or death from thrown objects, entanglement, or blade contact. (SGM-3)

# SAFETY

## DANGER!



The rotating parts of this machine have been designed and tested for rugged use. However, the blades could fail upon impact with heavy, solid objects such as metal guard rails and concrete structures. Such impact could cause the broken objects to be thrown outward at very high velocities. To reduce the possibility of property damage, serious injury, or even death, never allow the cutting blades to contact such obstacles. (SGM-4)

## WARNING!



Extreme care should be taken when operating near loose objects such as gravel, rocks, wire, and other debris. Inspect the area before mowing. Foreign objects should be removed from the site to prevent machine damage and/or bodily injury or even death. Any objects that cannot be removed must be clearly marked and carefully avoided by the operator. Stop mowing immediately if blades strike a foreign object. Repair all damage and make certain rotor or blade carrier is balanced before resuming mowing. (SGM-5)



## WARNING!



Many varied objects, such as wire, cable, rope, or chains, can become entangled in the operating parts of the mower head. These items could then swing outside the housing at greater velocities than the blades. Such a situation is extremely hazardous and could result in serious injury or even death. Inspect the cutting area for such objects before mowing. Remove any like object from the site. Never allow the cutting blades to contact such items. (SGM-6)

## WARNING!



Mow at the speed that you can safely operate and control the tractor and mower. Safe mowing speed depends on terrain condition and grass type, density, and height of cut. Normal ground speed range is from 0 to 5 mph. Use slow mowing speeds when operating on or near steep slopes, ditches, drop-offs, overhead obstructions, power lines, or when debris and foreign objects are to be avoided. (SGM-7)

## WARNING!



Avoid mowing in reverse direction when possible. Check to make sure there are no persons behind the mower and use extreme care when mowing in reverse. Mow only at a slow ground speed where you can safely operate and control the tractor and mower. Never mow an area that you have not inspected and removed debris or foreign material. (SGM-8)

## WARNING!



Do not put hands or feet under mower decks. Blade Contact can result serious injury or even death. Stay away until all motion has stopped and the decks are securely blocked up. (SGM-9)



## DANGER!



Replace bent or broken blade with new blades. NEVER ATTEMPT TO STRAIGHTEN OR WELD ON BLADES SINCE THIS WILL LIKELY CRACK OR OTHERWISE DAMAGE THE BLADE WITH SUBSEQUENT FAILURE AND POSSIBLE SERIOUS INJURY FROM THROWN BLADES. (SGM-10)

## WARNING!



Do not mow with two machines in the same area except with Cab tractors with the windows closed. (SGM-11)



# SAFETY

## DANGER!



Rotary Mowers are capable under adverse conditions of throwing objects for great distances (100 yards or more) and causing serious injury or death. Follow safety messages carefully.

### STOP MOWING IF PASSERSBY ARE WITHIN 100 YARDS UNLESS:

- Front and Rear Deflectors are installed and in good, working condition;
- Mower Head is running close to and parallel to the ground without exposed Blades;
- Passersby are outside the existing thrown-object zone;
- All areas have been thoroughly inspected and all foreign material such as rocks, cans, glass, and general debris has been removed.



**NOTE:** Where there are grass and weeds high enough to hide debris that could be struck by the blades, the area should be: inspected and large debris removed, mowed at an intermediate height, inspected closely with any remaining debris being removed, and mowed again at desired final height. (SFM-6)

## WARNING!



Each Rear Wheel must have a minimum of 1,000 pounds contact with the surface to prevent lateral instability and possible tip-over which could result in serious bodily injury or even death. Widen the wheel tread and add weights if needed. Refer to the mounting instructions or call Customer Service if you need assistance with Counterweight Procedure. (SFL-3)



## WARNING!



Do not operate Mower if excessive vibration exists. Shut down PTO and the Tractor engine. Inspect the Mower to determine the source of the vibration. If Mower blades are missing or damaged replace them immediately. Do not operate the mower until the blades have been replaced and the Mower operates smoothly. Operating the Mower with excessive vibration can result in component failure and broken objects to be thrown outward at very high velocities. To reduce the possibility of property damage, serious injury, or even death, never allow the Mower to be operated with blades missing. (SFL-4)

## WARNING!



Do not let the Blades turn when the Mower Deck is raised for any reason, including clearance or for turning. Raising the Mower deck exposes the Cutting Blades which creates a potentially serious hazard and could cause serious injury or even death from objects thrown from the Blades. (SRM-7)



## WARNING!



Never leave Tractor and Implement unattended while the implement is in the lifted position. Accidental operation of lifting lever or a hydraulic failure may cause sudden drop of unit with injury or death by crushing. To properly park the implement when disconnecting it from the tractor, lower the stand and put the retaining pin securely in place, or put a secure support under the A-Frame. Lower the implement carefully to the ground. Do not put hands or feet under lifted components. (SPT-1)

# SAFETY

## WARNING!



Be particularly careful when transporting the Implement with the Tractor. Turn curves or go up hills only at a low speed and using a gradual steering angle. Rear mounted implements move the center of gravity to the rear and remove weight from the front wheels. Make certain, by adding front ballast, that at least 20% of the tractor's weight is on the front wheels to prevent rearing up, loss of steering control or Tractor tip-over. Slow down on rough or uneven surfaces to prevent loss of steering control which could result in property damage or possible injury. Do not transport unless 3-Point lift lever is fully raised and in the latched transport position. Dropping implement in transport can cause serious damage to the tractor and/or Implement and possibly cause the operator or others to be injured or killed. (S3PT-2)

## WARNING!



The rotating parts of this machine continue to rotate even after the Tractor has been turned off. The operator should remain in his seat for 60 seconds after the brake has been set, the PTO disengaged, the tractor turned off, and all evidence of rotation has ceased. (SBM-5)

**“Wait a minute...Save a life!”**

## DANGER!



There are obvious and hidden potential hazards in the operation of this Implement as in all power-driven or pulled equipment. REMEMBER! This machine is often operated in rough terrain conditions that include tall grass, weeds, gullies, holes, slopes, hidden obstructions and the like. Serious injury or even death may occur unless care is taken to assure the safety of the operator and bystanders in the area. Do not operate this machine with anyone in the immediate area. (S3PT-7)

## WARNING!



Relieve hydraulic pressure prior to doing any maintenance or repair work on the Implement. Place the Implement on the ground or securely blocked up, disengage the PTO, and turn off the tractor engine. Push and pull the Remote Cylinder lever in and out several times prior to starting any maintenance or repair work. (S3PT-9)



## DANGER!




This Implement is wider than the Tractor. Be careful when operating or transporting this equipment to prevent the Implement from running into or striking sign posts, guard rails, concrete abutments or other solid objects. Such an impact could cause the Implement and Tractor to pivot violently resulting in loss of steering control, serious injury, or even death. Never allow the Implement to contact obstacles. (S3PT-12)

## DANGER!



The flail cutter shaft is designed for standard rotation (same rotation as the tractor wheels during forward travel). **Never operate the cutter shaft in the reverse rotation.** Operating this mower in reverse rotation may cause objects to be thrown out the front of the mower head.



# SAFETY

**WARNING!**



Engine Exhaust, some of its constituents, and certain components contain or emit chemicals known to the state of California to cause cancer and birth or other reproductive harm.

**WARNING!**



Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and birth or other reproductive harm. **Wash hands after handling!**

Tiger mowers use balanced and matched system components for blade carriers, blades, cutter-shafts, knives, knife hangers, rollers, drive-train components and bearings. These parts are made and tested to Tiger specifications. Non-genuine “will fit” parts do not consistently meet these specifications. The use of “will fit” parts may reduce mower performance, void mower warranties and present a safety hazard. Use genuine Tiger mower parts for economy and safety.

SEE YOUR  DEALER

In addition to the design and configuration of this Implement, including Safety Signs and Safety Equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of the machine. Refer also to Safety Messages and operation instruction in each of the appropriate sections of the Tractor and Equipment Manuals. Pay close attention to the Safety Signs affixed to the Tractor and Equipment. (SG-18)

# SAFETY

**DO NOT LUBRICATE WITH AUTOMATIC GREASE GUN. GREASE WITH HAND GREASE GUN ONLY.**

P/N22839

PART NO.  
LOCATION

22839  
MOWER DECK



22840  
INSIDE OF CAB



24028

24028  
MOWER DECK




10" x 5.5" 31522  
MOWER DECK  
18.25" x 10" 31523  
HYDRAULIC TANK

# SAFETY

PART NO.  
LOCATION




42350  
MOWER DECK



33743  
INSIDE OF CAB



42399  
MOWER DECK




42400  
MOWER DECK

# SAFETY



PART NO.  
LOCATION

6T3217  
MOWER DECK



6T3219  
INSIDE OF CAB


6T3220  
FRONT PUMP MOUNT



6T3221  
INSIDE OF CAB

# SAFETY


**NOTICE:**  
Engine will not start when mower is engaged.



6T3222

PART NO.  
LOCATION


6T3222  
INSIDE OF CAB



INSIDE OF CAB



6T3224  
MOWER DECK



6T3230  
INSIDE OF CAB

# SAFETY

PART NO.  
LOCATION



6T3233  
HYDRAULIC TANK



6T3234  
INSIDE OF CAB



6T3236  
MOWER DECK  
HYDRAULIC TANK



6T3243  
INSIDE OF CAB



# SAFETY

PART NO.  
LOCATION

**GREASING INSTRUCTIONS**  
**CUTTER SHAFT BEARING**  
**GREASE EVERY 8 HRS. OR DAILY**

NOTE: If unusual environmental conditions exist-extreme temperatures, moisture, or contaminants-more frequent lubrication is required.

6T3249A

6T3249A  
MOWER DECK

**GREASING INSTRUCTIONS**  
**GROUND ROLLER BEARING**  
**GREASE EVERY 8 HRS. OR DAILY**

NOTE: If unusual environmental conditions exist-extreme temperatures, moisture, or contaminants-more frequent lubrication is required.

6T3281

6T3261  
MOWER DECK

 **WARNING**

**DO NOT OPERATE MOWER**  
**WITH SAFETY SHIELD REMOVED.**

TB1011

TB1011  
MOWER DECK

# SAFETY



## Tiger Corporation

800-843-6849  
www.tiger-mowers.com


Description	Application	General Specification	Recommended Lubricant
Tractor Hydraulics	Reservoir	JD-20C	Mobilfluid® 424
Mower Hydraulics Cold Temperatures 0°F Start-up Normal Temperatures 10°F Start-up Normal Temperatures 15°F Start-up High Operating Temperatures Above 90°F Ambient	Reservoir	ISO 46 Anti-Wear/ Low Temp JD-20C ISO 46 Anti-Wear ISO 100 Anti-Wear	Mobil DTE® 15M Mobilfluid® 424 Mobil DTE® 25 Mobil DTE® 18M
Flail Rear Gearbox	Reservoir	PAO Synthetic Extreme Pressure Gear Lube	Mobilube SHC® 75W-90, Mobil 1 Synthetic Gear Lubricant
Cutter Shaft and Ground Roller Shaft (Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Drive Shaft Coupler (Rotary and Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Boom Swivel, Boom Cylinder Pivots (Rotary and Flail Boom Type)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Deck Boom Pivot & Deck Stop Adjustment (Rotary and Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Deck Spindle (Rotary)	Grease Gun	Tiger Spindle Lubricant	Mobilith SHC 220

**For Mobil product information, availability, or technical information, call 1-800-662-4525.**

Tiger PN 34852

34852  
HYDRAULIC TANK

# SAFETY



50023 MANUAL CANISTER

ITEM	PART NO.	QTY.	DESCRIPTION
	<b>50023</b>	<b>AVAIL</b>	<b>MANUAL CANISTER COMPLETE</b>
1	00776031	1	ROUND MANUAL CANISTER
2	33997	1	DECAL, SHEET, MANUAL CANISTER
3		*	DECAL
4		*	DECAL
5	*	AVAIL	SPECIFIC PRODUCT MANUAL
6	33753	1	E M I SAFETY MANUAL
7	34296	1	FRONT ADHESIVE PAD
8	34297	1	REAR ADHESIVE PAD
9	6T1823	4	ZIPTIE 14" LONG

**NOTE:**

The manual canister can be bolted, zip tied or adhered to a variety of surfaces. Locate a protected area within the view of the operator. Then select an installation method and attach the canister. **CAUTION - AVOID DRILLING HOLES INTO UNKNOWN AREAS**, wires and other parts may be located behind these areas. When adhering the canister to a surface, thoroughly clean that surface before installing the canister.

# SAFETY

## FEDERAL LAWS AND REGULATIONS

This section is intended to explain in broad terms the concept and effect of federal laws and regulations concerning employer and employee equipment operators. This section is not intended as a legal interpretation of the law and should not be considered as such.

### Employer-Employee Operator Regulations

U.S. Public Law 91-596 (The Williams-Steiger Occupational and Health Act of 1970) OSHA

#### This Act Seeks:

“...to assure so far as possible every working man and woman in the nation safe and healthful working conditions and to preserve our human resources...”

#### DUTIES

Sec. 5 (a) Each employer-

(1) shall furnish to each of his employees employment and a place of employment which are free from recognized hazards that are causing or are likely to cause death or serious physical harm to his employees;

(2) shall comply with occupational safety and health standards promulgated under this Act.

(b) Each employee shall comply with occupational safety and health standards and all rules, regulations and orders issued pursuant to this Act which are applicable to his own actions and conduct.

#### OSHA Regulations

OSHA regulations state in part: “At the time of initial assignment and at least annually thereafter, the employer shall instruct every employee in the safe operation and servicing of all equipment with which the employee is, or will be involved.”

#### Employer Responsibilities:

To ensure employee safety during Tractor and Implement operation, it is the employer's responsibility to:

1. Train the employee in the proper and safe operation of the Tractor and Implement.
2. Require that the employee read and fully understand the Tractor and Implement Operator's manual.
3. Permit only qualified and properly trained employees to operate the Tractor and Implement.
4. Maintain the Tractor and Implement in a safe operational condition and maintain all shields and guards on the equipment.
5. Ensure the Tractor is equipped with a functional ROPS and seat belt and require that the employee operator securely fasten the safety belt and operate with the ROPS in the raised position at all times.
6. Forbid the employee operator to carry additional riders on the Tractor or Implement.
7. Provide the required tools to maintain the Tractor and Implement in a good safe working condition and provide the necessary support devices to secure the equipment safely while performing repairs and service.

#### Child Labor Under 16 Years of Age

Some regulations specify that no one under the age of 16 may operate power machinery. It is your responsibility to know what these regulations are in your own area or situation. (Refer to U.S. Dept. of Labor, Employment Standard Administration, Wage & Home Division, Child Labor Bulletin #102.)

# **ASSEMBLY SECTION**

# ASSEMBLY

**Before attempting to mount your Tiger mower, it is important to read and understand all of the Safety Messages in the Safety Section of this manual.**

Check complete shipment list against the packing list to make sure there are no shortages. Make certain the tractor model is the appropriate one for the mower received!



Always use a floor jack, hoist or fork lift to lift and raise heavy parts.

Read and understand the entire Assembly Section instructions before attempting to mount your Tiger mower. Refer to the Parts Section of this manual for detailed illustrations to locate all parts. (ASM-C-0001)

## TRACTOR PREPARATION


- A. Remove right and left hand steps.
- B. Disconnect battery cables from both batteries.
- C. Remove engine side panels, or raise hood to access front pulley.
- D. Remove plugs from tractor casting where mainframe and pump mount will be attached.
- E. Remove any front weights and weight supports.
- F. Raise the tractor onto jack-stands and remove the right and left rear wheels.

(ASM-JD-0001)

## CRANKSHAFT ADAPTER

If necessary remove the four capscrews from the crankshaft pulley. Then install the crankshaft adapter to the pulley with capscrews and lockwashers as shown in the Parts Section.

(ASM-JD-0051)



# ASSEMBLY

## FRONT CRANKSHAFT PULLEY

Tiger has found that the front crankshaft pulley used by JD will not allow for the installation of a front drive system. You will need to order a different pulley, washer and bolt from John Deere to allow for a front drive to be installed on your tractor.

Inspect the front pulley on your tractor to verify you have the correct pulley needed to mount the spacer plate. If your pulley has the (4) four holes needed to mount the spacer, your pulley is the correct one needed. If your pulley does not have the (4) four holes in the pulley, you will need to order the correct pulley, washer and bolt from John Deere.



### PARTS REQUIRED TO PURCHASE FROM JOHN DEERE:

Pulley from JD - R516320

Washer from JD - R517237

Bolt from JD - R516648

Torque on the pulley bolt with locktite is 369 lb-ft.



### Solution:

1. Clean nose of crankshaft using TY16285 clean and cure primer.
2. Apply a light 2-3mm bead of TY15969 retaining compound around the leading edge of the crankshaft nose.
3. Dip damper mounting capscrew in clean SAE30 engine oil (Always use a new capscrew).
4. Position damper/pulley on the crankshaft and thread capscrew up tight (do not rely on the capscrew to pull the pulley straight onto the taper).
5. Tighten capscrew to specification 500Nm (369lb-ft) (the engine will most likely have to be pinned).
6. Measure run-out on the pulley, spec is 0.003" or less.




# ASSEMBLY

## DRIVESHAFT & FRONT PUMP MOUNTING

Install spacer plate on tractor engine using bolts and lockwashers as shown in Uarts Uection. Grease sleeve section of the driveshaft and install from the side of the engine compartment. Once you have the sleeve section in place, bolt to spacer plate using bolts and lockwashers as shown in Uarts Uection. Install shaft end of driveshaft through opening and into driveshaft sleeve. Shaft and sleeve yokes should be aligned, if shaft does not insert easily in sleeve, turn shaft 180°, and then install. Align the notch^s on the shaft and yoke tube as shown in picture below. **Shaft end must be installed in correct orientation, failure to do so may result in damage to tractor and/or driveshaft.** After installation of shaft end, install pump mount. Next, install pump. After pump is secured, install driveshaft in to pump shaft. The end of driveshaft should be no more than 1/2" away from contact with pump housing. Tighten crimping bolt on driveshaft. Lube driveshaft & check all hoses, flanges, the pump, pump mount, driveshaft and mounting plate to ensure all fasteners are tightened before operation.

**CAUTION: DO NOT START THE TRACTOR UNTIL ALL HOSES ARE ATTACHED, TANK IS FILLED WITH PROPER OIL AND BALL VALVES ARE OPEN! STARTING AT THIS TIME WILL CAUSE SERIOUS DAMAGE TO THE PUMP. (ASM-JD-0007)**



## ADJUSTING REAR WHEELS

Raise rear of tractor onto jack-stands. **Follow the instructions in the tractor owners manual for adjusting tires and rims.** The back wheels **MUST** be adjusted to the widest setting. **NOTE:** This may require switching the wheels to opposite sides of tractor. Also take note of any width restrictions when transporting by trailer. (For ease of installation, it is best to leave the rear wheels removed during installation of the mower.)






# ASSEMBLY


## CABLE CONTROL LEVER STAND

On the corner cab post, mark a point at 1-3/8" from the windshield and 22 1/2" from the floor; then cut a 3/4" diameter hole through the outer plastic shell. This will expose a threaded steel boss to attach the control box support bracket.

The rear corner of the cable control stand is placed approximately 5 3/4" from the edge of the mat. The front edge of the stand is up against the corner cab post and the door sill lip of the mat. Before you mark or drill any holes, check for support plates or wires under the mat & the cab floor. NOTE: Cutting into plates or wires makes more work for everyone and could be dangerous. When you know where the wires/plates lie, mark one of the mounting holes. Drill a 3/8" hole through the mat and through the floor of the cab. Next, lift the mat up and mark the other two holes on the cab floor. Drill the holes through the floor. Mark the mat and drill the other two 3/8" holes. Use a 1" hole saw and cut a 1" hole through the mat over each 3/8" hole. Secure the stand to the floor with the spacers, capscrews and nylock nuts provided.



### UNDER FLOOR OF CAB



Cut a 1 3/4" hole in the floor to route the cables and wires through. It needs to have a 1/4" clearance for the trim lock. Before you mark or drill any holes, check for support plates or wires under the cab floor.

NOTE: Cutting into plates or wires makes more work for everyone and could be dangerous. Look under the floor for cables and plates that you need to avoid. The hole should be approximately 4 1/2" from the door sill and 4 3/4" from the lip of the mat under the console. Install the trim lock around the metal edges of the hole, then route the control cables and wires through the hole.



Next, wrap the cables with the 6" split hose at the point they pass through the hole, and secure the zip ties. Apply RTV sealer in and



# ASSEMBLY

## SWITCHBOX WIRING (CABLE)

Power for the switchbox is accessed through the port located on the lower right rear of the cab. A John Deere plug is used, part number RE67651. DO NOT connect the plug to the cab port until the wiring is completed. The wires in the plug are colored RED, BLACK and ORANGE. The RED wire will always be hot, so it needs to be capped. Attach connector 34538 to end of RED wire and tape wire back on itself. The BLACK and ORANGE wires are hot when tractor key is turned to "on". Connect the BLACK wire of the plug to the BLACK wire from the switchbox. Then connect the ORANGE wire of the plug to the RED wire from the switchbox.


The two GREEN wires must be connected to the neutral safety wire by cutting the neutral safety wire and connecting one GREEN wire to one end and the other GREEN wire to the other. Refer to the switchbox schematic and wiring diagram for additional information.

**STANDARD MODELS:** Neutral Safety wire is a brown wire located under steering column. Cut a slot in the right side of column to access, WATCH OUT for existing wires.


**PREMIUM MODELS:** Neutral Safety wire is the blue #6076AA wire located under right hand console. Route wires under the console.

After connecting the power to the switch box, wrap the cables with split hose and route through the 1 $\frac{3}{4}$ " hole. Next, wrap the cables with the 6" split hose at the point they pass through the hole, and secure the zip-ties. Apply RTV sealer in and around individual cables and split hose, inside and outside of the cab for a water tight seal.

Route the tilt switch MetriPak connector to the tilt switch. Connect the MetriPak shroud to the tower of the tilt switch. Then, route the brake valve MetriPak connector to the brake valve. Connect the MetriPak shroud into the tower of the brake valve. Check with the switchbox schematic for additional information. (ASM-JD-0009)



JOHN DEERE  
PLUG



POWER /  
NEUTRAL SAFETY


CABLES /  
METRIPAK WIRES



# ASSEMBLY

## MANUAL SWITCHBOX MOUNTING

The switchbox is to be secured to the operator's side of the control handles, or valve stand. Refer to the Parts Section for assembly and components needed.




(ASM-C-0053)

## HYDRAULIC PORTS (PREMIUM)

These ports are located under the tractor rear remotes and are located as shown in the image below. Refer to the Parts Section for additional information.


(ASM-JD60-7030-0002)



# ASSEMBLY

## HYDRAULIC PORTS (STANDARD)

These ports are located at the rear of the tractor, under the lift valve, where the valve mounting bracket attaches to the tractor. The load sense port is on top, then the pressure and finally the return port, as shown in the image below. Refer to the Parts Section for additional information. (ASM-JD60-7030-0004)



## HYDRAULIC LINE PLUMBING: PRESSURE LINE INSTALLATION

The hydraulic pressure line will be plumbed into the rear of the tractor remote valve. Locate the pressure port on the rear remotes and remove the plug (refer to the Hydraulic Ports illustration and the Parts Section pages for position of the pressure port). After the plug is removed then install 27mm adapter. Next connect a 1/2" hose from the tractor remote valve to the Tiger valve. (ASM-27mmPRESSURE-0001)

## RETURN LINE INSTALLATION

The return line will be plumbed next to the pressure line on the tractor remote valve. Locate the return port and remove the plug (refer to the Hydraulic Ports illustration and the Parts Section for the position of the return port). After the plug is removed then install 27mm adapter or elbow. Next connect a 1/2" hose from the tractor remote valve to the


## LOAD SENSE LINE INSTALLATION

The load sense line will be plumbed into the bottom of the tractor remote valve (refer to the Hydraulic Ports illustration and the Parts Section pages for the position of the load sense port). Locate the plug on the tractor rear remotes for the load sense, and remove the plug. Install a 14mm adapter or elbow and run a 1/4" hose from the remotes to the Tiger valve. Refer to the Parts Section pages for an exploded diagram of the tractor remote valve hookup.



# ASSEMBLY

## MANUAL LIFT VALVE PORTS




(ASM-C-0057)



# ASSEMBLY

## VALVE MOUNTING

Locate the existing holes on top of the tractor remote valve at the rear of the tractor. Spacers are needed under the valve mounting bracket to raise the valve mounting system to the required height. Secure the bracket to the tractor with hardware shown in the Parts Section of the manual. Attach the valve mounting plate to the valve mounting bracket on the rear of the tractor as shown below. Align the holes for the cables on the Husco control valves and center the Danfoss valve on the valve plate. Then align the holes on the valve with the plate holes and secure the lift valve on top of the mounting plate. Route the hydraulic lines from the lift valve to the hydraulic cylinders as noted on the lift valve page of the Parts Section. Install the control cables to the valve and the mounting plate on the Husco valves. On the Danfoss valves, attach the electrical control cables. (ASM-JD7X30-0001)



## FILLING HYDRAULIC RESERVOIR

Refer to the Maintenance Section for filling specifications and hydraulic oil requirements.

**NOTE: Starting or running your Tiger mower before filling reservoir will cause serious damage to hydraulic pump.**


## MAINFRAME INSTALLATION

With an overhead hoist and / or jack-stands, raise one side of the frame up to the correctly matching mounting holes. Install capscrews and all other hardware as shown in mainframe Parts Section to secure the sides of the mainframe to the tractor casting, DO NOT tighten at this time. Remove the capscrews one at a time and apply a thread locking agent. Reinsert the capscrews and tighten / torque to values noted in the torque chart located in the Maintenance Section of this manual. (ASM-C-0003)



# ASSEMBLY

## TWIN MOWER HYDRAULIC DIAGRAM



## SIDE HYDRAULIC TANK INSTALLATION

Install all fittings and tubes into tank and tank filter as shown in the Parts Section illustration. Insert tank sight glass into front side of tank.

Place the tank in the mounting bracket on the main frame as shown in the Parts Section. Secure the tank with the tank channel mount by placing the channel mount on top of the tank and the washers over the holes. Thread the tie bolts through the washers and holes to the threaded holes on the mainframe. Tighten the tank channel mount by using the hex heads on the end of the tie bolts.

Install the filter gauge into the filter housing so that it points to the rear of the tractor and is clearly visible to the operator. The tank breather cap is ready for use as the tank is filled. Some of the for<sup>^</sup>mentioned items may be already installed. (ASM-MOTOR HYDRO-0001)






# ASSEMBLY

## **\*NOTE ON HUSCO CONTROL VALVES\***

Manual, cable controlled (Husco control valve) boom mowers require check valves with integral restricting orifice (#06502036) installed in the control valve work ports that are connected to the gland ends of the main and secondary boom cylinders. This check valve allows oil to free flow into the gland end of the main and secondary boom cylinders, but restricts flow out of the cylinder, thereby providing proper boom control. This check valve, #06502036 (Vendor #1968R-.063) is similar in appearance to hose adapter #33271 and Adapter #34396, with .06 orifice. These components can be identified as follows, and are to be installed per Úarts Úection for the lift valve. (ASM-HUSCO-0001)



## **GENERAL HOSE INSTALLATION**

Refer to the Úarts Úection for detailed information about hoses and fittings for this application.

When mounting the suction hose between the pump and the tank, the stainless steel bands that are provided must be used. CAUTION: DO NOT use regular hose clamps for this purpose.




# ASSEMBLY

## WEATHER-PACK/METRI-PACK ASSEMBLY

These instructions apply to both Weather-Pack and Metri-pack connectors.

**NOTE: Use the specific tool for the type of connector you are assembling.**


(ASM-C-0009)




1. Apply seal to cable, before stripping insulation.



2. Align seal with cable insulation.



3. Put terminal in crimping tool, then



4. Crimp and visually inspect for a good

## HOSE COVERING

Secure hoses together with zip ties wherever loose. Wrap the hoses with the hose covers as illustrated in the parts book. Where hoses may contact the frame or other edges, wrap with split hose and secure with hose clamps or zip ties. On non-~~cab~~ cab units the pressure and return hoses from the control valve will also need to be routed inside the protective clear hose wrap.

## SOLENOID BRAKE VALVE

Install a solenoid valve mounting bracket with the supplied hardware. While installing fittings to the brake valve, the electrical coil on the spool must be removed to make room. When reinstalling the coil, it is important to use no more than 5 ft. lbs. (or 60 in. lbs.) torque. Over torque to the coil will result in hydraulic failure of spool. (ASM-C-0017)

## TEMPERATURE GAUGE MOUNTING (OPTIONAL)

Mount the temperature gauge where it is clearly visible to the operator. Attach the green (-) wire from the negative post on the gauge to a grounded bolt on the tractor frame. Remove paint if needed to make a good ground. Remove the pipe plug from the side of the hydraulic reservoir and install the temperature sensor using thread sealing tape. Run the white wire from the (s) sensor post of the gauge to the temperature sensor




# ASSEMBLY

## INSTALLING NATIONAL PIPE FITTINGS

Whenever installing a pipe fitting, wrap the threads clockwise (looking at the end) with teflon tape. In this way, the tape will be tightened when installed. NOTE: It is not necessary to tape O-ring fittings, or those installed in swivels.

## INSTALLING O-RING FITTINGS


Installing straight, 45 degree and 90 degree O-ring fittings requires that the O-ring, washer and nut (A) be up against the swivel body (B). Insert the swivel and turn in until the swivel is pointed in the right direction and O-ring contact is made. Hold swivel in set direction with a wrench and turn the O-ring nut away from the swivel body and carefully tighten. (ASM-C-0002)



# ASSEMBLY


## CONTINUOUS DUTY SOLENOID SWITCH

To mount the solenoid switch, use the existing holes in location shown below. The bottom hole may need to be ground to obtain the correct hole spacing to match the solenoid switch mount. Secure with provided 3/8" x 1" capscrews, lockwashers, and hex nuts.



Route wires to and from the Continuous Duty Solenoid Switch as shown below.

- A.) ORANGE 10 GA. wire from terminal (A) to +12V battery fusible link.
- B.) RED 14 GA. wire from terminal (B) to tractor plug in cab.
- C.) BLACK 14 GA. wire from terminal (C) to -12V battery post.
- D.) RED 10 GA. wire from terminal (D) to switchbox.
- E.) RED 14 GA. wire from terminal (D) to temperature gauge. (optional). (ASM-JD-0083)



# ASSEMBLY

## COOLER MOUNTING - SIDE TANK

Mount the cooler mounting brackets on the top rear side of the side hydraulic tank. Locate the bolt plates on the top of the tank and secure the appropriate cooler bracket to the tank with the hardware provided. Attach the screen and cooler to the brackets. Refer to the Parts Section to attach the hoses and adapters to the cooler. (ASM-C-0092)




# ASSEMBLY

## TRAVEL LOCK MOUNTING

Install the travel lock bracket with pin and clip on the draft beam. Slide the draft beam and align the travel lock bracket hole with the mounting hole on the mainframe. Install the capscrew, lockwasher and hex nut as shown in the picture.

Raise the deck/flail to it's upright position (Deck ear touches to stop bolt as shown in the picture). Drill a 13/16" hole to the deck/flail ear through the draft beam as shown below. Insert the supplied pin and clip through the hole. (ASM-SIDE TRVL LOCK-0001)



# ASSEMBLY


## COMBO LIFT DRAFT BEAM INSTALLATION

Install ½" O-ring breather into butt port of inboard cylinder. Install fittings in the rod end of the cylinder according to the diagram in the commons section. These fittings should be positioned to face the butt end of the cylinder.

Next turn the clevis onto the rod of the cylinder until it is tight against the shoulder and lock into place with locking bolt on clevis.

The inboard cylinder can now be installed into the main frame mast with the pin, flat-washers and R-clips as shown below. Use teflon tape on all fitting and hose connections.

Install all fittings in the outboard cylinder and adjust to point towards the butt end of the cylinder. Attach the hoses as specified in the parts book. Slide the cylinder into the draft beam from the outside of the draft beam and attach cylinder to the draft beam with clevis pin and rollpins.



## DRAFT BEAM MOUNTING

Pull the inboard cylinder piston rod down to the extreme extended position. Slide the draft beam under the cylinder, and align clevis hole with draft beam hole nearest to the tractor. Install pin and secure with rollpins.

Using inboard cylinder as a pivot point, slide draft beam under tractor and install draft






# ASSEMBLY

## DECK MOUNTING

Check that all grease zerks have been installed in the draft beams pivot arm, left linkage arm, right linkage arm, and cylinder mounting ears.

Using a clevis pin and roll pins, connect the pivot arm to clevis on draft beam. **NOTE:** Make sure the longer distance between the cutout and the end of the pivot arm is closest to the draft beam pivot ears on the center tube as shown in the diagram below. Also make sure the cutout on the pivot arm faces into tube of draft beam.



Slide other end of pivot arm with short distance between the cut-out and the end of the pivot arm, into the cylinder clevis. Next, line up the holes of the left and right lift linkage arms outside of the cylinder clevis holes. Connect with linkage pin, shims (as required), boss, capscrew, lockwasher and hex nut as shown.

To connect the bonnet to the draft beam, slide the extension arms of the draft beam between the mounting ears on the inner end of the bonnet. Line up the holes and secure with swivel pin, capscrew, lockwasher, and hex nut (both sides). See parts book illustration.

Next, slide the left and right linkage arms up to the slotted ear on the side of the deck. Secure with linkage pin, shims, boss, capscrew, lockwasher and hex nut.

## STOP BOLT ADJUSTMENT

Extend the outboard cylinder all the way out. Adjust the stop adjustment bolt (located on the top of the draft beam) out until it is up against the bonnet. Lock the bolt down with the  $\frac{3}{4}$ " hex nut.

**NOTE:** When the outboard cylinder is fully extended, the bonnet or deck should either be up against the stop or if travel locks are installed, it should be up against the travel lock. It may be necessary to use either external or internal slugs on the cylinder to get the correct stroke. If the cutter head is against the stop and the cylinder has stroke remaining, serious damage will occur.




# ASSEMBLY

## CABLE LIFT DRAFT BEAM INSTALLATION

Install ½" O-ring breather into butt port of inboard cylinder. Install fittings in the rod end of the cylinder according to the diagram in the commons section. These fittings should be positioned to face the butt end of the cylinder.

Next turn the clevis onto the rod of the cylinder until it is tight against the shoulder and lock into place with locking bolt on clevis.


The inboard cylinder can now be installed into the main frame mast with the pin, flat-washers and R-clips as shown below. Use teflon tape on all fitting and hose connections.



## DRAFT BEAM MOUNTING

Pull the inboard cylinder piston rod down to the extreme extended position. Slide the draft beam under the cylinder, and align clevis hole with draft beam hole nearest to the tractor. Install pin and secure with R-clips.

Using inboard cylinder as a pivot point, slide draft beam under tractor and install draft beam pin. Align hole in draft beam pin with holes in mainframe boss and install cap-screw, lockwasher and hex nut.



Install the fittings in the butt end of the outboard cylinder, as shown in the commons section. These should be positioned to face the rod end of the cylinder. Next, install the O-ring breather in the rod end of the cylinder.

Install the outboard cylinder in the hole in the draft beam as shown above. Install the



# ASSEMBLY

## DECK MOUNTING AND LIFT ASSEMBLY

Install the upper sheave bracket on the outboard cylinder and tighten securely against piston rod shoulder. Tighten the set screw, and align the draft beam.

Install the lower sheave bracket on the draft beam with a  $\frac{3}{4}$ " capscrew and two hex nuts as shown in the diagram on the next page.

Align the deck with the draft beam mounting hole and install the outer draft beam pin. Align the holes in the draft beam pin with the holes in the boss and secure with capscrew, lockwasher and hex nut.


Pass the lift cable through upper sheave bracket and attach to turn buckle with turn buckle pin and cotter key. Attach turnbuckle to draft beam with turn buckle pin and cotter key.

Place the cable in the upper sheave bracket with the cable on top of the wheel. Secure wheel with sheave pin (with grease zerk) and R-clip. Place lift cable in lower sheave below the wheel and install sheave with pin (with grease zerk) and R-clip. Then install the

The cable can now be attached to the deck mounting bracket with the shackle. Tighten shackle pin securely. **NOTE: DO NOT tighten the turnbuckle at this time!**

**Refer to the commons section for further referYnce and part numbers.**

(ASM-CBL DRFT BEAM-0002)



## TURNBUCKLE ADJUSTMENT

Extend the outboard cylinder until the deck touches the stop on the draft beam. Hold the deck in this position to adjust the lift cable tension. Adjust turnbuckle until cable is tight.

Lower and raise the deck to check adjustment. The mower deck should reach it's stop on the draft beam at the same time the outboard cylinder reaches it's extreme extended position.



# ASSEMBLY

## 3-POINT DECK TILT CYLINDER

Remove the support cylinder from the left rear three point arm and replace with the cylinder, clevis ends, and pin furnished in the kit. See Úart• Úection for parts and assembly.  
(ASM-3-PT DECK CYL-0001)

## DECK / MOTOR FEEDLINE

Install the 1" hose with the 90 degree flange on the front side of the motor to the inside upper oil port of the solenoid valve. Secure to motor with flange kit, and install swivel fittings on the other end. Install the other 1" hose with the 60 degree flange on the back side of the motor to the inside lower oil port of the solenoid valve.

Install split hoses around hydraulic hoses where they contact sharp edges, or any other edges that may rub hoses.

Be sure that all grease zerks are installed in the draft beam pin bosses. Grease all areas of the draft beam according to the instructions in the T aintenance Úection. Re-check all fittings for tightness and be sure teflon tape has been used at all connections.

Fill hydraulic tank with fluid as recommended in the T aintenance Úection. **BE SURE TO OPEN THE BALL VALVES.** Start the tractor and operate the inboard cylinder through the entire stroke and the outboard cylinder through the bottom  $\frac{3}{4}$  stroke repeatedly to clear the lines of air. **DO NOT run outboard cylinder out to full stroke until stop bolt has been adjusted!**

Check for oil leaks at all fittings and connections using a piece of paper or cardboard. If a leak is found, you must shut down the tractor and set the cutter head on the ground. Before attempting to fix the leak, you must actuate the lift valve handles several times to relieve any pressure in the lines. **DO NOT USE HANDS TO CHECK FOR FLUID LEAKS!**



# ASSEMBLY

## TWIN ROTARY MOWER INSTRUCTIONS

### HOW TO REMOVE REAR MOWER


1. REST REAR MOWER SO GROUND SUPPORTS IT FRONT & REAR.
2. TURN TRACTOR OFF. THERE SHOULD BE NO HYDRAULIC PRESSURE IN HOSES AT LOCATIONS 1,2,3 & 4.
3. DISCONNECT 2 FROM 1.
4. DISCONNECT 3 FROM 4.
5. CONNECT 4 INTO 1.
6. CONNECT 2 INTO 3.

**CAUTION: DO NOT START THE TRACTOR UNTIL ALL HOSES ARE ATTACHED, TANK IS FILLED WITH PROPER OIL AND BALL VALVES ARE OPEN! STARTING AT THIS TIME WILL CAUSE SERIOUS DAMAGE TO THE PUMP.**

**CAUTION: NEVER DISCONNECT ONLY 2 FROM 1 WITHOUT CONNECTING 4 INTO 1.**

**CATCH AND CONTAIN ANY HYDRAULIC OIL WHEN DISCONNECTING FITTINGS.**

(ASM-C-0033)



# ASSEMBLY

## FINAL PREPARATION FOR OPERATION

Place operator's safety and operation decals on the steering column and side cover where they are clearly visible to the operator. These decals should be understood by each operator of the machine in conjunction with the Safety and Operation Section of this book. The decals are to remain in good condition as a reminder to the operator, and should be replaced if damaged.

Double check that all pivot points have been greased. Secure all hoses together with zip ties and wrap with split hose sections where friction may occur on the hose.



**BEFORE** starting or operating the tractor you must read and understand the Safety and Operation Sections of this manual completely.

**Before operating the mower**, the cutter head and draft beam should be slowly moved throughout the full range of motion. Watch for any condition that would cause pinching or excess stress on the hoses. The steering and front axle travel should also be carefully moved through their full range of motion. If any condition occurs in which the hoses contact the tires, the steering and / or front axle travel may need to be limited as described in the tractor operator's manual. This should also be done if the tires rub, or are extremely close to any other part of the mower such as the hydraulic tank or draft beam. This may include adding shims, or adjusting stop bolts in the tractor front to solve the problem. While checking motion, you should also check that the control circuits are connected according to the operator's decal for the valve handles.

## MOWER TESTING

Take the tractor to a place free of loose objects on the ground. Operate the cylinders through their full range of motion again, to clear the lines of air. Follow the instructions in the Operation Section to operate the mower. Vibration of the mower should be minimal at all times. After a 5 minute test run, the knife bolts should be retorqued and once again after the first few hours of operation.

**If any parts of this Assembly Section, or any other section of this manual are not clearly understood you must contact your dealer or the address on the front of this manual for assistance!** (ASM-C-0022)



# OPERATION SECTION

UJ ^!aa } ÁU^&a } ÁÆ

# OPERATION

## TIGER TWIN ROTARY MOWER OPERATING INSTRUCTIONS

OPERATION

Va^iÁ, q ÁU[ cæ^Á [ , ^iÁæ^Á æ ~ æc^i^áÁ æ@ ~ ææ Á æ^iæ^Á Á q^i^áÁ [ i^iÁ•ÉV@Á, q Á [ , ^iÁ [ •æ] • { æ Á [ ç ] æ^Á^Á } d [ i^i^áÁ æ@^i^áÁæq i^Á^ [ ç^Á@áæ |æ^Á ] } ^æç ] • Á^Á^Á { áq ææ } Á Áæçæç^Áæ á i^ [ ç^Á@áæ |æ^Á ] ÉQÁ [ ÉÁ^c^i^ [ q^Á Á @QÁ [ •æ ] Á Á@Á [ , ^iÁ Á Á^Á^Á } d [ i^i^áÁ^Áæ@Á^ [ ç^Á^ç^i^ÉV@ { [ , ^iÁ Á^ ~ q ] ^áÁ æ@æc^Á æ } q^ Á^æç ÉÁ [ ç^æç^Á^i^æç i^É @ |á Éæ q^Á c@ |Á æc^Á æ^ i^Á Á [ i^ çæ^Á ] ^iæ |æ q^Á æ • i^á^ Á [ ç^æç ] ÉQ , ^ç^i^É [ Á @ |áq^ Á Á^ÉÁ Áæ& iæ ÉOÉSSÁ æc^Á ~ q { ^ } oæ } á •æc^Á æ } q^ Á^æç Á ~ oÁ^Á æ ææ^áÁ Á@Á } æ Á [ [ áÁ ] ^iæ ] æ^Á ] áæ ] Áæç |Á ^É

QÁ Á@Á ] ^iæ |q^Á • [ ] • ææç Á Á^Á } [ , i^á^æ^i^Á Á^Á [ ç ] ææ ] ^iæ q^ Á@æ æá • Áæ q^Á Áæ^Á^ç^i^ i^æ [ ] æ^Á^i^æç ç ] Á Á } • i^Á } ^•^i^É c@ i^Éæ q æ Éæ q^Á [ ] ^i^Á Á^Á [ q^ b |áÁ |Áæ æ^áÁ^Á@ { [ , ^i^Éæç |Á |Á@ [ , } Á àæ&ÉOÁ [ ç ] ^iæ Á@Á [ , ^iÁ Á^ •æ q^Á • Éæ æ • i^á^ Éæ ^•Á |Áq^ • ç & Áæ^ , æq^ Á^ÉÁ^ç^Á @Á } É

V@ Á^æç ] Á Á@Á ] ^iæ |q^Á æ ~ æ^Á Á^ • q^ ^áÁ Áæ qææ^Á Éæ • d^ & Éæ q^Á áá^ ææ^Á ] ^iæ |Á Á@Á æ^Áæ } á [ ] ^iÁ • Á^ Á@Á [ , ^i^Éæç i^Á^Á ] çæ^áÁ Á@Á^æç ] Áæ^Á ç ] ááÁ Á^Á • Á^Á Áæç^á æ^Áæ^Á Áæ • q^ oæ^ ç ] ææ q^ Á@Á ] ^iæ ] Á Á^ [ , ^iÁ q^ áÁ^Á [ ç ] ^ææÉU [ { ^Á æç i^Á æ Á @ , Á @ |á Á^ [ ç^áÁ^ ^ } @ & Á^ æ^Áæç ÉO ÖXÖUÁ ] ^iæ Á@Á } q^ æ@ ~ oæ |Á æc^Á ~ q { ^ } oæ Á |æ^Áæ } á Á [ [ áÁ ] ^iæ ] æ & ] áæ ] ÉV@Á ] ^iæ |Á ~ oÁ^Áæ qæáÁ æ@^Á } q^ q^ áÁæç |Á ] ^iæ } Áæ q^Á Áæc^Á |æç^Á^Á^ i^ á^á^ } q^ Á ] ^iæ } ÉU [ ] ^iÁ ] ^iæ } Éæ Á^æç^áÁ Á@Á } æ ÉÁ q^Á@ ] Á } • i^Á^æ^Á Á^Áæ^Áæ } áæ æç i^Á • Á^ Á@Á [ , ^iÉ

**READ AND UNDERSTAND THE ENTIRE OPERATING INSTRUCTIONS AND SAFETY SECTION OF THIS MANUAL AND THE TRACTOR MANUAL BEFORE ATTEMPTING TO USE THE TRACTOR AND IMPLEMENT.** QÁ [ ^Á [ Á [ ç ] á^i^æ q^Á q^ Á Á@Á • d^ & ç ] • Éæ ] çæç [ ^iÁ^æ^Áæç q^ |á^áÁ^æç |Á |Áæ ~ |Á ç ] |æ ææ ] ÉU æ & [ • Á^æç ] ç ] Á Á^Á æc^Á á } • Áæ q^Á æc^Á Á • æ^Á^Á } çæ^áÁ Á@Á } æ^Áæ } á ç • Áæ q^Á Á@Á ] ^i^Á } áÁæç ] ÉÁ (OPS-U-0001)

ÜÖÇÉÉÁ^ÖÖÜÜVÖÉÖÉæ áÁUŠŠUY Á@Á [ ] , q^ ÁUæc^Á Á • æ^Á^Á^i^Á ~ Á b |Á : á^æç æ Á & ; Á } i^Á^æ^Á Áæ^Á } Á Á [ ] , Á@Á } q^ Áæ q^Á • d^ & ç ] • Áæ q^Á Á@Á Üæc^Á Á • æ^Á^Á^É , æ^Á^Á^Á [ [ áÁ ] { [ ] Á^ } • Á^ Áæ [ æÁæ æá • ÉÁ



**PELIGRO**

Uá [ Á^Á^Á • i^Á Áææ^áææ^á } Á^Á Á [ Á^Á } á^Á^Á : çæç { ^áææ Á^Á^Á^ } iææ ÉÖÉD







# OPERATION

OPERATION

## 2. OPERATOR REQUIREMENTS


Ùæ^Á] ^ìæä } Á -Á@Á } ãÁ Á@Á^• ] [ ] • ãäc Á -ÁÁ ~ æáá áÁ ] ^ìæä : ÈÖÖÁ ~ æáá áÁ ] ^ìæä : Á@æ Á^æáá ä } á^• çä ä • Á@Á ] [ ^ ( ^ ) çä ä Áæäq : ÁÚ ] ^ìæä : ç Á æ ~ æ Áæ ä Á Á ç ] ^ìæä } & ^ á Á Á ] [ ^ ( ^ ) çä ä Áæäq : [ ] ^ìæä } Áæ ä Áæ ] Áæ • [ &ææ ä Áæ c Á ] æäc • ÈÖÖ Áæááä } Á Á @ Á æ c Á ^ • æ ^ • Á ] çä ä Á á Á Á @ Á æ ~ æ ç • æ c Á ä } • Áæ Áæ æ ^ á Á Á @ Á ] [ ^ ( ^ ) çä ä Áæäq : ÈÖÖ Áæ ~ Á æ ç Á -Á@Á ] ^ìæä } Áæ ä Áæ á Á -Á @ Á ^ ~ ä { ^ } çä Á ] çä { ] ^ ç Á } á^• ç [ ä È ] • ~ | çä ä ç ç | ä á Á Á æ ç Á Á ] Áæ { ] [ ^ ç Á ç ] çä ä } È

ÇÁ@Á ] ^ìæä : Áæ } [ ç Áæ Á@ Á æ ~ æ Á Á Á @ { • ^ | ç Á Á Á Á ^ Á ] çä { ] [ ^ ç Á } á^• çä ä Á@Á ] ^ìæä } Á -Á@ Á ^ ~ ä { ^ } çä Á Á @ Á ^ ] [ ] • ãäc Á -Á@Á ~ ] ^ìæä : Á Á Áæááä ä Á ç ] çä Á@Á æ ~ æ È æ c Á ] æäc • Èæ ä [ ] ^ìæä \* Á • ç & ç } • Á Á @ Á ] ^ìæä : È


Ùæ^Á] ^ìæä } Á -Á ~ ä { ^ } ç Á ~ á Á Á @ Á @ Á ] ^ìæä : Á ^æáá } [ ç á Á Á • [ ] æ Á : [ ç & ç ^ Á ~ ä { ^ } ç Á Ú Ö Ç ± Á @ Á á Á } áä } • Á @ Á Áæäc • È ] ^ìæä \* È Á ç ä ä \* È ä Á Á } æä \* Á @ Á ~ ä { ^ } ç Á Ú Ö Ç Á Á • á } á Á ] [ ç ä Á ] ^ìæä : Á ] [ ç & ç } Áæ ä Á & ^ á Á @ Á ] [ ] , ä \* Á æ c Á ^ æ K

### PERSONAL PROTECTIVE EQUIPMENT (PPE)

- ~ Çä æ • Á ^æ Áæ c Á ] ç • •
- ~ Pæ á Á æ
- ~ Ù ç Á Á ] Á Áæ c Á ] [ ç ^ æ
- ~ Ö ] ç ^
- ~ P^æ ä \* Á ] [ ç & ç }
- ~ Ö ] • ^ Á æ ä \* Á Ö ] çä \*
- ~ Ù • ] äæ : Á [ Á Ö ç : Á T æ \ Á ç á ^ } á • Á [ ] [ ] ^ìæä \* Á ] áä } • È (OPS-U-0002)



POXOUA • Á Á ~ • Á Á Á ç ] [ Á { ^ áæ æ Á Á ç ] [ Á Á Á @ Á ] ^ìæä \* Á @ Viæäq : Áæ ä Á ] [ ^ ( ^ ) ç Ö Ö • • Áæ ä Á Á ç ] [ Á á Á æ ^ & Á Á ] ^ìæä : ç æ ç ä ^ • Áæ ä Á ] [ ä ä æä } Áæ ä Á @ Á ^ ] [ Á Á æ ^ & Á @ Á ] ^ìæä : ç Áæ ä äc Á ] [ ] ^ìæä Á @ Á ~ ä { ^ } ç Áæ æ È Ö Ö ± Á Á ] ^ìæä \* Á @ Á æ c Á ] Á Á ] [ ^ ( ^ ) ç ä } Á ] ^ìæä : Á ] Á ^ • & ä ç } Á Á ç Á È Ö È ~ } ç Á ^ á áæä } Á • ç } • ç æ Á ^ á áæä ] [ • • ä } æ Á \* æ á ä \* Á ~ Á æ Á - Á & Á - Á @ Á ^ á áæä } Á @æ , [ ~ ] á Á @ ä Á æ ä äc Á Á ] ^ìæä Á @ Á ~ ä { ^ } ç Áæ æ È Ö Ö Ç \ } [ , ä \* Á Á ] , Áæ [ ] ^ Á Á ] ^ìæä Á @ Á ~ ä { ^ } ç @ } Á @ á Á ç ^ • Á ] & [ ] ä ä æä } Á Á ] æ á È Á ] ä ~ Á b ] Á Á Á æ æ Á Á @ Á ] ^ìæä : Á Á @ Á • & ] á Á ~ | ç Á @ Á ] ^ìæä : Á Á } á Á @ Á ç ± ^ } & Á Á ~ • Á Á Á ç ] [ Á Á Ö Ö Ç





# OPERATION

## 3.4 Front End Weight

021 q a ~ { A -GEA At caAta&d iA a @A ~ •0A^A a& ca& aA } A@Ata&d iA [ ] oA } aAcaAta& a •E&O [ ] oA } a  
 , a @A A& a&a&a&A A a& ca& A c^i& \* A& } d [ iA a A A i^c^ } oA@Ata&d iA [ { A^a&a \* A } A @A A i&a \* E&O @  
 + [ ] oA } aA A [ A @E&a&a A a @A } ca& a a ~ { A -GEA At caA a @A A^a&@aA } A@At [ ] oA a •E&O [ ] c  
 , a @A a A a @A a i& A& A^A ~ i& @ a A @ [ \* @A A e c q i a a A a&d i A a& a • @ E&OPS-U- 0005

## 4. GETTING ON AND OFF THE TRACTOR

0^ i^A^a& \* A } d A@Ata&d iE&O A ] a& iA ~ •0A^a& a& { ] |c^ A } a^ • ca& a A @A ] |c^ } a& a A a&d i  
 [ ] a& iA a& ~ a& E&O a& A a& oA^ a& iA a& ~ a& A [ oA [ ] |c^ A } a^ • d [ a&E& ] • |c& A e c q i a a A a& a& iA i  
 a& [ ] |c^ A c [ ] a& a& E&OPS-U- 0007



O [ A [ oA [ ~ } oA iA a { [ ~ } oA@Ata&d iA @A@Ata&d iA A [ ca \* E& [ ~ } c  
 c@Ata&d iA ]^ A @] A@Ata&d iA a& a& A [ ca \* A a& a& A& { ] |c^ |  
 • d ] ] a& E&OPS-U- 0007



### 4.1 Boarding the Tractor

W^ A [ c@ca a • a& a A ~ a ] a& A ca& a& a& a A c^ • A i A ~ ] [ ] oA @] A [ ca& a \* A@Ata&d iE&O a& A^ A& } d [ |  
 |c^ • A i A ~ ] [ ] oA @] A [ ~ } ca \* A@Ata&d iE&O a& A [ ~ • A i A @A ] a& i q A^ a& a& a A^ & i^ A@A^ a& a& c  
 a& [ ~ a A [ ~ E

B^ c^ A a& [ , A a& a^ • A i A a& A } A@Ata&d iA iA ca& @ a A ~ a { ^ } d&U a& A& a& A a& a& A ~ a& a& A  
 • A i a ~ | A b i^ a& A i A a& A [ A ca& a& A ~ a& a& A \* A ca& A c^ iE&O A@A ] a& i q A^ • ] [ ] • a& a& A i A i a& a& A c d a  
 i a& i • A ca& A a& a • E&OPS-U- 0008



B^ c^ A a& [ , A& @ a i^ A i A ] a& a& A } E& i A [ { A& [ ^ A A A@Ata&d iA i  
 Q ] |c^ } d&A ~ a& E& i E& i A^ a& E i a& @ a i^ A } @ A a& A a& i^ a& a  
 i^ • ] [ ] • a& A& a& A ] a& a& A@A ] |c^ } oA a& a& |c^ ] a& a& } E& A @  
 @ a& A^ a& a& a& a& a& a& a& A ] a& i q A^ a& ~ a& E& a& } A i a& a& A  
 ] [ ] a& A ] a& a& A @A@Ata&d iA a& A Q ] |c^ } d& a& a& A @ • a& a& A a& \*  
 a^ ] ~ • @ A A a& @ a& a& a& a& a& a& } d [ • A a& a& E&OPS-U- 0008



B^ c^ A a& [ , A& @ a i^ A i A c@iA a^ • ] • A i A a& A } A@Ata&d iA i A Q ] |c^ } d  
 ca& a& A ~ a& a& A ~ |c& A i a& ~ a& b i^ A i A a& a& A a& a& E&OPS-U- 0008



O [ A [ oA [ ~ } oA iA a { [ ~ } oA@Ata&d iA @A@Ata&d iA A [ ca \* E& [ ~ } c  
 c@Ata&d iA ]^ A @] A@Ata&d iA a& a& A [ ca \* A a& a& A& { ] |c^ |  
 • d ] ] a& E&OPS-U- 0007



OPERATION



# OPERATION



W^A^c^d^ ^A^e^ c^ } A^ @^ } A^ [ ] ^ | ^ A^ a^ a^ A^ A^ @^ A^ i^ a^ d^ i^ A^ ^ a^ a^ A^ A^ } c^ a^ } E^ A^ V^ @^  
^ c^ @^ . ^ A^ { ^ . A^ a^ A^ A^ e^ a^ a^ [ ^ . A^ A^ [ ^ i^ A^ a^ c^ A^ U^ O^ E^ H^ D



U^ c^ a^ i^ a^ d^ i^ A^ } | ^ A^ @^ } A^ [ ] ^ | ^ A^ a^ a^ A^ A^ A^ @^ A^ i^ a^ d^ i^ A^ ^ a^ a^ A^ U^ c^ a^ } \* A^ e^  
d^ a^ d^ i^ A^ A^ a^ a^ A^ a^ A^ . | c^ A^ b^ i^ ^ A^ | A^ ^ a^ a^ A^ U^ a^ a^ A^ @^ A^ i^ a^ d^ i^ A^ } ^ | ^ a^ }  
{ a^ } a^ A^ | A^ | [ ] ^ | ^ A^ c^ a^ } A^ . d^ } & c^ } . E^ A^ U^ O^ E^ H^ D



Start only from seat in park or neutral. Starting in gear kills.

OPERATION

## 6. CONNECTING THE MOWER TO THE TRACTOR

W^ A^ c^ d^ ^ ^ A^ e^ c^ } A^ @^ } A^ [ ] ^ | ^ A^ a^ a^ A^ A^ A^ @^ A^ i^ a^ d^ i^ A^ ^ a^ a^ A^ A^ } | ^ A^ . c^ } \* A^ e^  
\* | ^ } a^ A^ c^ ^ | A^ | A^ a^ } A^ } A^ | & . E^ A^ U^ O^ E^ H^ D A^ a^ a^ A^ a^ A^ a^ A^ [ { A^ } a^ | A^ @^ A^ [ , ^ | A^ A^ & A^ a^ A^ | a^ a^ A^ A^ } A^ } & c^ [ a^  
a^ c^ ^ ^ } A^ @^ A^ i^ a^ d^ i^ A^ } A^ } A^ a^ A^ [ , ^ | A^ a^ . E^ A^ O^ P^ S^ -^ R^ -^ 0^ 0^ 0^ 1

### 6.1 Connecting Mower Hydraulics

O^ r^ a^ e^ @^ b^ @^ A^ A^ P^ [ . ^ . A^ | { A^ @^ A^ O^ i^ a^ ^ A^ a^ c^ ^ A^ A^ A^ @^  
@^ a^ i^ a^ | a^ A^ [ d^ | A^ } A^ @^ A^ U^ [ c^ a^ ^ A^ ^ a^ a^ E^ A^ U^ ^ A^ | A^ |  
Figure Ops-1252 E^ A^ U^ A^ & ^ A^ @^ A^ @^ . ^ A^ | ^ c^ ^ . A^ }  
^ a^ e^ @^ @^ . ^ A^ a^ c^ a^ A^ . A^ } A^ | c^ a^ } a^ . E^ A^ O^ P^ S^ -^ R^ -^ 0^ 1^ 0^ 4



O^ c^ [ a^ A^ | } c^ a^ s^ a^ a^ a^ c^ ^ A^ i^ a^ d^ i^ A^ } ^ | ^ A^ a^ a^ A^ A^ } a^ a^ \* A^ @^ a^ i^ a^ | a^ A^ } A^ a^ } . E^ A^ U^ O^ E^ H^ D  
@^ . ^ A^ | } } ^ & c^ } . E^ A^ U^ A^ | a^ c^ ^ A^ @^ a^ i^ a^ | a^ A^ | ^ . . ^ | A^ a^ | ^ A^ | ^ | { a^ \* A^ a^ c^ } a^ } & A^ | A^ } a^ . E^  
W^ A^ A^ | [ c^ ^ . A^ } a^ A^ ^ A^ | [ c^ & c^ } A^ @^ } A^ | c^ a^ } \* A^ @^ A^ | [ ] ^ | ^ } c^ a^ } c^ a^ a^ c^ ^ A^ i^ a^ d^ i^ A^ } ^ | ^ a^  
[ | A^ | a^ A^ } A^ e^ . ^ A^ | a^ } . A^ b^ i^ ^ A^ [ { A^ } | } . A^ | A^ & a^ a^ } E^ A^ U^ O^ E^ H^ D



# OPERATION

OPERATION

## 7.1 Tractor Pre-Operation Inspection/Service

Ü^Δ|Δř Å@Ä|æř |Ä] |æř |q Ä æ ˜ æÄř Å} • |^Äæ  
 ř [ ] |^c^Ä |^É ] |æř } ř • |^&ř } ř ä Å & @ ä ˜ |ä  
 • |çæ^Ä ř Ä | | | { ^ äæ&ř | äq \* Äř Åc@  
 { æ ˜ æř | | • Ä^ř { { ^ äæř } • ÉV@Äř |||, q \*  
 æ^Ä [ { ^ Ä Åc@ ř { • Åc@Ä ˜ ä^Äæř Ä |çæ^Äq ä  
 q • |^&ř } K




- ˜ Vā^Äř } äæř } ÉäÄ |^•˜ |^
- ˜ Y @^|Ä ˜ \* ř |o^Ä
- ˜ Üc^|q \* Äq \ æ ^
- ˜ UVUÄ @ |äÄ
- ˜ ÜT X Ä ä } ř ř |äq äq ř ä q ä q ä q
- ˜ Viæř |q Äř @ ř ä^Ä |äq ř äq ä Ä } & ř } æ
- ˜ Viæř |Ä |æř |äq ř ř Ä [ [ äÄř ] äæř } Ä
- ˜ Viæř |ÄUUÜ |äq ř ř Ä [ [ äÄř ] äæř }
- ˜ ÜUUÜ |äq ř ř Åc@ Äæ ^ äÄ [ • äq }
- ˜ P [ Äæř |Ä qÄ^æ • Ä
- ˜ Üææř |Ä^Ä ř ä |ä Ä
- ˜ Ö) \* ä ^ Ä qÄ^Ä |äq äÄř } äæř }
- ˜ Ö) \* ä ^Äř [ |äq |äq |äq äÄř } äæř } Ä
- ˜ U [ , |Ä |äq äÄř äÄq^Ä
- ˜ U [ , |Ä^c^|q \* Äř äÄq^Ä
- ˜ Ø ^Äř } äæř } ř äÄq^Ä
- ˜ Ü ˜ äq } qÄ ä |äæř } ř äÄq^Ä äÄ [ q o
- ˜ ÖÄÄc^Äř } äæř } OPS-U-0030

## 7.2 Mower Pre-Operation Inspection/Service

Ö^| |^Äæř [ , |Ä • ^É | | ] |^c^Ä |^É ] |æř } ř ä Å |çæ^Ä ř Ä ˜ ä^äÄř Å} • |^Äc@Ä [ , |Ä |äq ř äq [ [ äÄq ä  
 • æ^Ä [ |äq \* Äř } äæř } ÉV@æ æ^äÄq äÄ |Ä | | \ ) Ä æö Å c @ |äÄ^Ä^ æ^äÄq äÄ |Ä^ |æ^äÄř { ^ äæř | ÉÄ |  
 ^} • |^Äc@Ä [ , |Ä |äq äæ^Äř |Ä |æř } Éř } ä & ö @ Äř |||, q \* É OPS-R-0007



U |ä äæř |äq • |^&Äř |Ä [ çä \* Ä æö Äř |Ä ^æÄq äÄ^ |æ^Ä c@ }  
 } ^& • æ^Ä äÄq c@ |ä ä^Ä |çæ^Äq æö ÉÄř [ |Ä |Ä [ • ^Äæ c } ^ |É [ ]  
 [ |Ä | | \ ) Ä æö Éq äÄ^æ ^ Ä |Ä [ • ^Äæq \* ÉÄř æ^Ä |äÄ |Ä q • Äc@^  
 ææç@ \* Äc@ä, æ^ÉÄ |äq ˜ |ä b |Ä æ Ä & x |Ä [ { Ä [ qæ æä q \* Åc@  
 { æç^Ä ř Ä [ [ äÄ [ |äq \* Ä |ä^ |ÉÄ |äq





# OPERATION

OPERATION

V@Á] ^|æ[ i q Á æ ~ æ Á æ á Á æ ^ Á æ } • Á æ á Á æ }  
 c@Á } á Á } æ Á } [ | cæ } ó } d ~ & cæ } • Á } Á @ Á æ  
 æ á Á : [ | ^ Á • ^ Á Á @ Á ~ á { ^ } d Á æ æ æ Á @ • ^  
 á } [ | cæ } ó } æ ^ Á æ : ^ Á } Á @ Á } ] | { ^ } ó } Á [ | á  
 & } á á } Á Á } • ^ Á @ Á } [ | { æ } Á Á æ æ æ ^ Á Á  
 c@Á ] ^|æ[ Á Á Á Á Á • É

“ Ö ) • ^ Á Á Á æ ^ Á á } • Á Á Á Á | æ Á Á } á Á \* á | É  
 Ü ] | æ Á Á { á • á \* É á æ æ ^ á É æ á Á | á |  
 á ^ & æ É OPS-U- 0011\_A



Op-14

**NOTE:** The mower Operator's Manual and affixed Decals contain important instructions on the safe and proper use of the mower. Maintain these important safety features on the mower in good condition to ensure the information is available to the operator at all times.

## ÖUÖT ÖÄÜUÖT ÖSY

“ Ö ) • ^ Á Á } á á } Á Á [ ~ ] cæ \* Á æ ^ Á | á { ^ } d  
 “ Ö ) • ^ Á Á } á á } Á Á æ ^ Á Á { á | É  
 “ Ö ) • ^ Á Á | | cæ } á Á & ^ , • Á Á Á Á [ • á á } Á á á  
 æ Á Á [ | | Á | Á | ~ ^ á É  
 “ Ö ) • ^ Á Á á } • Á Á Á Á | | æ Á Á } á Á æ cæ ^ á Á æ @  
 • & ^ • É  
 “ Ö ) • ^ Á Á æ ^ Á Á Á [ | | Á | Á { [ ~ ] cæ á Á cæ á cæ |  
 æ á Á cæ á , æ Á á Á | [ | ^ Á á } cæ ^ á Á æ á  
 cæ @ ^ á É OPS-R-0099



Ops-1250



Ü | á cæ ^ Á @ á | æ | á Á | • • ^ Á Á | á | Á Á | á \* Á Á ^ Á æ cæ } æ & Á Á Á } æ Á [ | Á } Á @ Á Q ] | { ^ } d  
 Ü | æ Á @ Á [ , ^ Á Á æ Á } Á @ Á | ~ } á Á | Á & ^ | ^ Á ~ ] [ | cæ á Á } Á [ & • Á | Á cæ á • É á ^ } \* æ ^  
 c@ Á Ü V U É æ á Á : } Á Á @ Á } \* á ^ É Á • cæ á Á ~ | Á @ Á } d [ | Á cæ ^ Á | Á Á ^ • cæ Á ^ cæ ^ Á Á Á  
 d Á | á cæ ^ Á | • • ^ Á Á | á | Á Á cæ cæ \* Á Á æ cæ } æ & Á Á Á } æ Á [ | Á Ü Ö T É D



Þ ^ cæ ^ Á Á cæ ^ } cæ Á á | á Á á | á Á • d Á | Á { [ cæ Á æ | á Á | { Á @ Á Q ] | { ^ } cæ @ Á Á Á Á  
 { [ cæ } Á Á @ Á Á cæ | Á } \* á ^ Á Á } } á \* É Ü Ö T É D

VY Ö Ü V Ö Ü Y

U ] ^ | æ } Á ^ & cæ } Á É F

# OPERATION

OPERATION

PYUOCVNSOASQOAPUJOOVQJ P

- " Ô@&Á f|Á @á:æ |æÁ |æ•Á æ| }\*Á @••É &|æ á^!•Áæ áÁæ \*•É **IMPORTANT!**ÁÖUÁUV ~•^Á [ ~|Áæ á•Áç Á&@&Áç |Á çÁ^æ •ÉÁV•^Áæ ] æ&Á -Á@æç Á çÁ^!Á |Áæáà| æáÁç Á&@&Áç | @á:æ |æÁ çÁ^æ •ÉÁ
- " Q•] ^&Á@Áç } ááá } Á -Á@Áçç^Á ^|á ( ^) É
- " Ö)• ^Áæç \*Á çÁ [| | ^| | Áç ] } ^&cá
- " Q•] ^&Áç } ááá } Á -Á • @ \*• É OPS-R-0100\_A



**WARNING**

Ö| Á [ ö ] ^!æ Áç Ö ~ ç { ^ } ö @ @ á:æ |æÁ çÁ^!Á çÁ^æ ç \* ÉÁU ç æ áÁ^ |Áæ^Áç [| • ç^Áæ áÁç çÁ^!Á^ } &Áç ~|áÁ^!Á^ } çÁçæ æáÉÖ [ ] | ç&@&Áç |Á^æ •Á çÁ [ ~|Áæ áÁç çÁç | ^•• ^Á çÁç d^æ •Áç { à^æ •Á çÁç ^Áç ~|áÁ^ } ^dæ Áç Á çÁ çÁ^æ •Áç ~^Áç æ ^ ç &| áá \* Á ç \* ^ } ^ÉÁ | Á&@&Áç | Áç • ^Á ç ÉÁPWÁç Á } æÖPÖÖÖ UÖÖÁ ç Á^ [ ç^Áç | Áç | Áç •• ^ÉÁV ^æÁ çÁç ] ^ } ^dæ | Á [| ç^É •æ^ç Á | æ •• Á ç áÁ • ^Öæáà| æáÁç Á&@&Áç | Áç çÁ^ } &Á -Á çÁ^æ •ÉÁ ç [ ~ Á • ] ^&Áç çÁ ÉÜÖT UXÖÁç ÁPUÜÖÁ ç Áç çÁ^!Á çÁ^æ çÁ^æ Ö çÁ çÁç [ ^Á^ } ^dæ Áç Á ç Éçç^Áç çÁç b | Á^æ çÁç { ^áæ | Á^ Áç ] @ • çÁç Á [| , | á^æ çÁç áÁ çÁ^!Á çÁç | Áç | &á^ | Áç ÉÁç ÖÉí D



VY ÖÁUVÖÿ


U| ^!æç } Á^&ç } ÁÉG

# OPERATION

OPERATION

## OPERATION

- 1. Turn the engine off.
- 2. Turn the fuel valve to the OFF position.
- 3. Turn the fuel valve to the ON position.
- 4. Turn the fuel valve to the OFF position.
- 5. Turn the fuel valve to the ON position.
- 6. Turn the fuel valve to the OFF position.
- 7. Turn the fuel valve to the ON position.
- 8. Turn the fuel valve to the OFF position.
- 9. Turn the fuel valve to the ON position.
- 10. Turn the fuel valve to the OFF position.



1. Turn the engine off. 2. Turn the fuel valve to the OFF position. 3. Turn the fuel valve to the ON position. 4. Turn the fuel valve to the OFF position. 5. Turn the fuel valve to the ON position. 6. Turn the fuel valve to the OFF position. 7. Turn the fuel valve to the ON position. 8. Turn the fuel valve to the OFF position. 9. Turn the fuel valve to the ON position. 10. Turn the fuel valve to the OFF position.

OPS-R-215

### WARNING

1. Turn the engine off. 2. Turn the fuel valve to the OFF position. 3. Turn the fuel valve to the ON position. 4. Turn the fuel valve to the OFF position. 5. Turn the fuel valve to the ON position. 6. Turn the fuel valve to the OFF position. 7. Turn the fuel valve to the ON position. 8. Turn the fuel valve to the OFF position. 9. Turn the fuel valve to the ON position. 10. Turn the fuel valve to the OFF position.

### WARNING

1. Turn the engine off. 2. Turn the fuel valve to the OFF position. 3. Turn the fuel valve to the ON position. 4. Turn the fuel valve to the OFF position. 5. Turn the fuel valve to the ON position. 6. Turn the fuel valve to the OFF position. 7. Turn the fuel valve to the ON position. 8. Turn the fuel valve to the OFF position. 9. Turn the fuel valve to the ON position. 10. Turn the fuel valve to the OFF position.

# OPERATION

## OPERATION

ÜUVOEÿÁÒÈÈÁÐÙÚÓÒVQÍÞ

- " Q•] ^&0À|ææ^•Áæ} áÀ|ææ^Áæ| |ø ÁŒ |ÁŒ [ •^)^ •• æ} áÀç&•• æ^Á^ æÈÚ| æÈ ÁŒ €»ÁŒ ÁŒ æ^ÁŒ | &@&á} \* Á^æ æÈÜ^| æÈÁáæ æ^áÈÁ, [!] È æ} áÀ{ æ•á} \* Áà|ææ^•Áæ Á& [ ] |çÁ•^ø ÁŒ { æ} æ} ÁŒ | çÈ Áææ} &È
- " Ö)~!^Áà|ææ^Á&æ|æ|ÁŒ} •Áæ^ÁŒ í~^áÁŒ ]!:]^!ÁŒ]^æææ} •È
- " Ö)~!^Á^ àà^!Á^~^&Œ!•Áæ^ÁŒ ÁŒ [•æ} Áæ} á} [ Ááæ æ^áÈÜ^| æÈÁ, [!] Èá![\^] Èæ} á} { æ•á} \* Á^&ç} •ÁŒ { ^áæ^È
- " Ö)~!^Á@á:æ |æÁŒ^•Áæ^ÁŒ [ ] |ç ÁŒ } ^&çá ç Áç@Áçá:æ |æÁŒ [ ç |ÈÁç&ÁŒ!Áçá:æ |æ |ç•ÁŒ [ ] \* Áç^•Áæ} áÀæ} \* ÈÖUÁÞUVÁ•^ [~!Áç} á•ÁŒ &@&ÁŒ!ÁŒ çæ•ÈV^ÁŒ} æ& [ Áçæ^ ÁŒ] æ^!ÁŒ!Á&æáà| æáÁŒ &^&ÁŒ! @á:æ |æÁŒ çæ•È
- " Q•] ^&0À|ÁŒ} áæ} ÁŒ Á& ÁŒ æÁ ç^•Áæ} áÀæá, æ^È OPS-R-216



**WARNING**

O[ ÁŒ [ ç ] çÈ} á•ÁŒ!Áç^} á^!ÁŒ [ , ^!ÁŒ&•ÈÁçæ^Áç [ ] çæ&ç} Á^~ |ç á} áÀá} •ÁŒ çÈ ÁŒ ç^} ÁŒ çÈÁç} ÁŒ çÈÁç} çÈ ÁŒ} çÈÁŒ [ ç ] Áç ÁŒ } ]^ á} áÀç@ÁŒ&•Áæ^ÁŒ&^!ç ÁŒ [ &^áÁŒ ] ÈÁŒ




# OPERATION

OPERATION

## 7.3 Cutting Component Inspection

OPS-U-0031



### Damaged Pan

**Cause:** Blade Pan contacts an immovable object while mower was in motion.

**Remedy:** Inspect the area before mowing to determine where the immovable objects are located and place visible hazard markers to identify the areas. Avoid mowing in the area where immovable foreign objects exist.

### Notches and Gouges

**Cause:** Blade contacting foreign objects

**Remedy:** Inspect the area to be mowed and remove foreign objects that could cause damage to the blades

### Excessive Blade Wear

**Cause:** Mower height set too low. Blade used past intended life.

**Remedy:** Replace blades more often. Adjust mower height for mowing Conditions to eliminate blade-to-ground contact


Op-22



OPS-U-0032

- " 1/2" MAXIMUM (12.7mm)
- " Original Blade Edge
- " 1/2" MAXIMUM (12.7mm)
- " Original Blade Edge
- " 1/2" MAXIMUM (12.7mm)
- " Original Blade Edge

OPS-U-0032



**NOTE:** Replace Blades in pairs after no more than 1/2" (12.7mm) wear  
Op-23

# OPERATION

OPERATION

## 7.4 Blade Bolt Inspection

Q•] ^&0|æ^Á0| |0P^ææÁææ Á|!Á ^æÁæ Á| | | , ^áK

### Excessive Blade Bolt Wear


**Cause:** Blade Bolt contacts a foreign or solid object while Blade is in motion.

**Remedy:** Inspect the area before mowing to determine where the foreign objects are located and place visible hazard markers to identify the areas where immovable foreign objects exist, and avoid hitting the objects.

### Notches and Gouges

**Cause:** Blade Bolt contacting foreign objects.

**Remedy:** Inspect area to be mowed and remove foreign objects that could cause damage to the blade bolt.



**⚠ DANGER**

Q•] ^&0|æ^Á0| |0P^ææÁææ Á|!Áæ} [!| æÁ ^æÁÛ0ÚŠ0Ï0Á0Ú VP Á0Š0Ï0Á0Ú ŠVÙÁ }  
 0@ Á0|ææ^ Á T 000V0ŠY Áæ0| Á|ææ Á| |0 Áæ K

- ~ Xā ā| ^&ææ • Á| Á
  - ~ Qš@ Á & • • ^áææææ } Á|ææ Á| |0 Á } [!| Á - Á| Á
  - ~ Q0|ææ^ Á0| |0æ Á ~ \* ^ • Á| & @ ] ^áæææ É
- 0ææ ^ Á Á| |æ Áææ } [!| æ Á } [!| Á|ææ Á| |0 Á æ Áææ Á| Áææ d [ ] @ Áææ ^ Á - Á0| Á|ææ Áæ á Á 0 & @ } Á -  
 0@ Á| [ \ ^ } Á æ Á } @ @ æ Áæ • Á Á| á ~ • Á| áá Á 0| ^ Á| Áææ É

**Always replace Blade Bolts with new bolts whenever replacing the Blades. OPS-U-0037**

VY 0 ÄÜV0EÜY

U] ^!ææ } ÁÚ & @ } ÁÉÍ

# OPERATION

## Tractor PRE-OPERATION Inspection



Mower ID# \_\_\_\_\_ Make \_\_\_\_\_

Date: \_\_\_\_\_ Shift \_\_\_\_\_



Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.

**OPERATION**

Item	Condition at Start of Shift	Specific Comments if not O.K.
The flashing lights function properly		
The SMV Sign is clean and visible		
The tires are in good condition with proper pressure		
The wheel lug bolts are tight		
The tractor brakes are in good condition		
The steering linkage is in good condition		
There are no visible oil leaks		
The hydraulic controls function properly		
The ROPS or ROBS Cab is in good condition		
The seatbelt is in place and in good condition		
The 3-point hitch is in good condition		
The drawbar pins are securely in place		
The PTO master shield is in place		
The engine oil level is full		
The brake fluid level is full		
The power steering fluid level is full		
The fuel level is adequate		
The engine coolant fluid level is full		
The radiator is free of debris		
The air filter is in good condition		

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or MOWER**

*(Faint, illegible text)*

VY 0 ÄÜVOCËÿ

U] ^!|æä } Ä^&ç } ÄËï

# OPERATION

## Rotary Mower PRE-OPERATION Inspection



Mower ID# \_\_\_\_\_ Make \_\_\_\_\_  
 Date: \_\_\_\_\_ Shift \_\_\_\_\_



**Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.**

**Table 1:**

Item	Condition at Start of Shift	Specific Comments if not O.K.
The Operator's Manual is in the canister on the mower		
All safety decals are in place and legible		
The hitch connection bolts & pins are tight		
There are no cracks in hitch		
The hydraulic cylinders pins are tight		
There are no leaking or damaged hoses		
The mower deck is clear of cut grass and debris		
Chain guards/deflectors are in place & in good condition		
Blade carrier retaining nut is tight		
Blades are not chipped, cracked or bent		
Blade bolts are tight		
Wheel lug nuts are tight		
Transport locks are in good condition		

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or MOWER**

**OPERATION**







# OPERATION

## 7.7 Raising the Mower

W a \* A @ A a d i A E [ a A @ & @ & ] d [ | A ^ c ^ i E A a a ^  
c @ A [ , ^ i A ~ A @ A i [ ^ ] a A a [ ^ O A E i A s ^ A c @  
^ ] [ ^ \* @ A A ^ a s a s ^ A i [ ^ ] a A a ^ c a s ^ E  
OPS-R-0042\_A



OPERATION

## 7.8 Driving the Tractor and Implement

U c o f ~ A i a a \* A s a A [ , A ] ^ a A s a A i a a ^ a f A s & ^ a A [ ^ i A ] ^ a A @ A a s a a \* A s [ ] | c ^ A s [ ] d [ | A ~ A @  
d a e d i A s a A } a E A [ c a \* A [ , | A s a A ^ c a a l A s [ A i ^ c ^ ] o A @ A a s d i A [ { A ^ a a \* A ] A s a A [ ^ A ^ c ^ i a \* A s [ ] d [ | E  
V @ A i a s d i A @ ^ | a A ^ c ^ i A a A [ ] ^ i a e a A s a A ] ^ a ^ A c e s a s [ ] o A ^ A a e ^ i A c a a l a A i A s @ & A a l A i ^ c ^ ] o c @  
[ ] ^ i a s i A [ { A d [ ] a \* A ^ a l A s i a \* A s A { ^ i \* ^ } & E A A @ A [ , ^ i A c ^ i a \* A i A ] \* a ^ A s a e ^ A ] ^ i a s a \* E a d [ ]  
c @ A i a s d i A [ { ^ a a e ^ i A s a s @ A i a s d i A a l A ^ A a a s | o A s [ ] d [ | E

U i f [ { A c } ] ^ A a o A @ A i a s d i A s a A } a A s a A [ , A ] ^ a ^ A i A s a c i { a ^ A @ , A c @ A i a s d i A a o A s A s a s @ a A [ , ^ i  
c a a l ^ A s a i } E A O ^ c i { a ^ A @ A a e ^ A ] ^ a A i A a s a a A i [ ] ^ i A s [ ] d [ | A ~ A @ A i a s d i A @ ] A s a a \* A c i } ^ E A O E [ ,  
a a a a a ] a s A ^ a s a s & A i A @ A } a A @ ] A c } a \* E


V A s e [ a A c ^ i c ] ^ E A i a ^ A c @ A i a s d i A a o A s a A s a A s a A ] ^ a ^ E A ^ a s a f A @ ] A [ ] ^ i a s a \* A c ^ i A i [ ^ \* @  
\* i [ ^ ] a E s [ ^ a \* A s a s @ A i A [ ] ^ E a a s i } a \* A s [ ] ^ i E A V i a s d i A @ ^ i A c ^ i a A ] a s a \* A @ ^ | a A ^ A s & ^ a e ^ a  
, @ ] A [ i a \* A ] A s & a ^ A i A [ ^ \* A i [ ^ ] a A A a ^ & A s @ A [ ^ a a a c A A s ] a \* E

W A ^ c d ^ { ^ A s e c a } A @ ] A [ ] ^ i a s a \* A ] A c ^ i A [ ] ^ E S ^ A ] A c @ A i a s d i A s a A [ , A ^ a s A @ ] A [ a \* A s [ , } @ E A O U  
P U V A s a o f i A ^ A E ^ @ ^ i A s [ , } @ E A O OPS-U-0014\_A

## 7.9 Crossing Ditches and Steep Inclines

Y @ ] A s [ ^ a \* A s a s @ ^ A a o A c ^ i A s a s \ A i A [ a \* A ]  
^ c a s A s & a ^ E A s A [ ^ a ^ A c e s a s @ A i a s d i A E [ a c  
a s { A s a s [ c f { A ^ E A V @ A c ] ^ A A s a ^ a ^ A ] ^ i a s a }  
s a s A s e ^ A i a a ^ A s a s a A i A c @ A i a s d i A s a A [ , ^ i E

OPS-R-0020\_A



VY @ A U V O E Y

U ] ^ i a s a } A ^ a c a } A E E F


# OPERATION

OPERATION

## 7.10


Y @ } A&[ ] -[ ] c^aA ~oAe} Aq &[q ^A | Aã&@Zã[ A [ c  
æ ] | | æ@A [ { Aæ Aæ \* ^A } @&@ A ^ | ^ ) aæ | æA |  
• dæ @A } Aæ Aæ æ ^A æ A && ' E

Y @ } A&[ ••q \* A ~ &@A | | æ E@A [ ] | ^ ^ ) oA @ ~ | a  
à^A ~ | | A [ , ^ ^ aA | Aæ [ , ^ | A & ) c^A A | ææ Aæ a  
æãã^aA ææææ OPS-R-0021\_A



Q &[q ^• Aæ aAã&@• A @ ~ | aA^Aæ ] | | æ@ aAæ [ ] \* Aæ  
| q ^A } @&@ Aæ Aæ } ^ Aæ A @ , } EãV @ A c ] ^ A ~  
] æA } a|A^a ~ &^A@A [ ••æææ A Aæ æ æ ^ E@A @  
\* | æãæ } c^A A [ A c^ ^ ] Aææ ~ &@Aæ Aæ ] | | æ@  
q &^æ^• A@A [ ••æææ A Aæ ææ d | A [ | E ç^ | E ^ | ^ & c  
æ } Aæ c^ | } æ^A&[ ••q \* A ææA

Y @ } A [ ] ^ | ææ \* A@ A | ææ d | Aæ aA [ , ^ | Aæ&[ ••  
• | | ^• Aæ aA &[q ^• EãV @ ~ \* @Aã&@• Eãæ aA c@ |  
~ } ^ ç^ ) Aæ | | ææ A&[ ] aææ } • EãV A [ ] | | cæ oA A ææ ææ  
• ~ ææ } c^A & A A [ ] ~ } aA^æææ &^A@ææ^A&[ ] ææc  
, æ@A@A [ ] ~ } aA æ Aææ • ^ A [ q Eã [ & • Aæ aA c@ |  
a^a|æ A | A^A@ [ , } A ~ oA [ { A } a^ | A@A [ , ^ |  
|^ ~ | ç \* A A [ ••æ | ^ A b | ^ Aæ aD | A [ ] | ^ | c Aæ æ æ ^ E  
O | [ ~ } aA&[ ] ææææ [ A | | a ~ &^ Aæ ^ ç^ | ^ A @ & A | ææ  
[ ] A@A [ , ^ | Aæ | ç^ Aæ aA | A@A [ , ^ | Aæ | ææ^•  
|^ ~ | ç \* A A [ ••æ | ^ Aæ æ æ ^ Aæ aA | ^ { æ | ^ A ^ æ E  
OPS-R-0022\_A



# OPERATION

## 8. OPERATING THE TRACTOR AND IMPLEMENT

THE OPERATOR MUST COMPLETELY UNDERSTAND HOW TO OPERATE THE TRACTOR AND IMPLEMENT AND ALL CONTROLS BEFORE ATTEMPTING TO OPERATE.

Á@Á] ^íæ íÁ ~•oÁ^æáÁ a  
~} a^•oá aÁ@ÁÚæc Áá aÁ] ^íæí ÁÚ^&ç} •Á Á@Á ]|^ ^} oá aÁæç íÁ] ^íæí íÁ ç} ç} ÉÁV@•  
{ ç} ç} Á ~•oÁ^Á^æáÁ aÁç] íæí aÁÁ Á} ^Á] ^íæí íÁ @ Áç} [ oÁ^æáÁ^ç^Á] , Á { ^[] ^ÁÁ] ^íæí Á@  
á ]|^ ^} oá aÁæç íÁ æç} oÁ { ]|^Á] ^íæí \*Á•d ~ &ç} •É

Ó-í|^Áæç \*Á} ^Á] ^íæí } É@Á] ^íæí íÁ ~•oÁ^Á { ^Áæ çááÁ æ@Á@Áæ^áÁ Á^Á ]|^ ^áÁÁ aÁ} ^  
[ àæí^•Á} aÁæç aÁÁ] } çá ^áÁ æç ÁÁ} •|^Áæç ÁÁ @Á] ^íæí íÁ ~•oá aÁ} Éá aÁ ~ ç { ^} ÉÁ] ^áæç  
æç} ç} Á @ ~|^ÁÁ^áæí Á íÁ} Á^áíá É[ ~ •oÁ^íæí ÉÁ] Á[] •Éá aÁæç •á•á } aÁ} aÁ} á ç} Á@Á^áæí  
OPS-U- 0015



OíÁ[ oÁ [ , Á æç [ Á æç ^•Á @Áæ ^Áæ^çÁç&] ç} æçÁæíæçí •Á æçÁ } aÁ , •  
&í •áÉÁ



T [ , Á ]|^ ÁÁ } aÁ} •Á @|^Á [ ~ Áç^ÁÁ æçÁæ æçáÁ ÁÁæíá @Á] Á æçá ~ æÁæçáæç  
íá ç} ÉÁ^ç^Á [ , ÁÁæ} ••Á] ÁÁ \*\* ÁÁ } aÁ} •Á @|^Á [ ~ Áç} [ oÁ^áæí^Á^Áæ^Áæç  
HÉÁ^ÁçÉÁ DÁ Á] } oá aÁÁ @Áæ^Á Á@Áæç íÁ} aÁ [ , ^íæí æ^Á^ÁæçÁ [ ~ Áç}  
&^æí^Á^Á} aÁ} ç} Áæç •á•á ÉÁç^] Á[] •Éáæç •ÉÁ[] É ~ ÉÁ ç^] @æáÁ à•d ~ &ç} •É  
] [ , ^íÁÁ •ÉÁ^áíá } aÁ íÁ} Á àá& ÉÁ [ ~ Áæ^Á } æíÁÁ ÁÁæí^Á^Á@•^Áç ]|^ ÁÁ }  
áá& } ç} ^Á [ , ç} ÉÁ



Çç[ áÁ [ , ç} ÁÁç^Á^Áá&ç} Á @} Á [ ••æíÉÁç@& ÁÁ æ^Á^Á@|^Áæ^Á [ ]  
] •í } •Áç} aÁ@Á [ , ^íÁ} aÁ •Áç^Á^Áç^Á @} Á [ , ç} ÁÁç^Á^Áç^Á [ , Á ]|^ ÁÁæç  
•í [ , Á í [ ~ } aÁ ^áÁ @|^Á [ ~ Áç} Áæ^Á] ^íæí Áá } d [ Á@Áæç íÁ} aÁ [ , ^íÉ  
Áç^Á [ , ÁÁæçáæç [ ~ Áç^Á [ ç} ] ^ç^Á} aÁ { [ ç^Á^áíá } aÁ íÁ } Á æíæç  
ÇÖT EFD



# OPERATION


OPERATION



T æ ^ A ç æ ã ä Å à b & o E ã ~ & @ æ A ã ^ E æ æ ã ã E ã [ ] ^ E ã ; A & @ æ æ • E æ æ ã ã & { ^ A } æ æ \* | ä Å A @ [ ] ^ ã æ æ \* Å æ o Å - Å @ Å [ , ^ ã @ æ æ ã V @ • ^ ã ã { • Å ã ~ | ä Å @ } Å , ã \* Å ~ o æ ^ Å @ Å @ ~ • ã \* Å æ \* | ^ æ ã ; Å ^ | & ä ã • Å @ æ Å @ ã ã æ ã • E ã ~ & @ æ ã æ æ } Å Å ç ç ^ { ^ | ^ æ æ æ ã ã ~ Å æ ä Å ã ~ | ä Å • | ç ã Å ^ | ä ~ • Å b | ^ Å | Å ç ^ } Å ^ æ æ ã ã • } ^ & o Å @ Å ~ æ æ \* Å æ æ Å | Å ~ & @ Å à b & o Å ^ | ^ Å [ , ã \* E Û { [ ç ^ Å } Å ã Å à b & o Å [ { Å @ Å æ ã ã ^ ç ^ Å } , Å @ Å ~ æ æ \* Å | æ æ • Å | Å [ } æ æ Å ~ & @ { • E } Ö T Ü D



Ü | æ ^ Å [ , ^ | • Å æ ^ Å æ æ ã ã Å } à | Å æ ç ^ | • Å Å } ä ä } • Å - Å @ [ , ã \* [ à b & o Å | Å | Å ^ æ ã æ æ } & • Å ç ç Å ^ ç ^ | Å [ | ^ D æ ä æ æ ã \* Å ^ | ä ~ • Å b | ^ | Å ^ æ æ ã ã } | , Å æ ç Å ^ • • æ ^ Å æ æ ~ | | È



**STOP MOWING IF PASSERSBY ARE WITHIN 300 Feet UNLESS:**

È [ ] o æ ä Å ^ æ Å ^ - Å ç | • È @ æ Å ^ æ ä • È | Å ç ä ä • Å æ ^ Å • æ | ^ ä Å æ ä Å Å [ [ ä È [ | æ ã | & ] ä ä } L

È [ , ^ | • Å æ ^ Å ~ } ã \* Å | • ^ Å Å æ ä Å ç æ æ | Å Å @ Å | [ ~ } ä Å æ ç ~ o Å ç [ • ^ ä Å | æ æ • L

È Ü æ • • | • à ^ æ ^ Å ~ o æ ^ Å @ Å ç æ ç \* Å @ [ , } È à b & o Å [ ] ^ Å

È | Å æ æ Å @ æ ^ Å ^ } Å ç | [ ~ \* @ Å • } ^ & o ä Å æ ä Å Å | Å ç } Å æ ã æ Å ~ & @ Å | & | È æ æ • È \* | æ • È æ ä Å ^ } | æ Å à | ä Å @ Å ^ } Å { [ ç ä È

**NOTE:** Where there are grass and weeds high enough to hide debris that could be struck by the blades, the area should be: inspected and large debris removed, mowed at an intermediate height, inspected, closely with any remaining debris being removed, and mowed again at desired final height. (This will also reduce power required to mow, reduce wear and tear on the Mower drivetrain, spread cut material better, reduce streaking, and make the final cut more uniform). Å Ö T Ü È F Ö



Ö | Å [ ç ^ Å @ Å | æ æ • Å ~ } Å @ } Å @ Å [ , ^ | Å ^ & Å Å æ æ ä Å | Å æ ^ | ^ æ [ ] È æ æ | ä ä \* Å | ^ æ æ æ & Å | Å | Å ç | } ã \* È Ü æ æ ã \* Å @ Å [ , ^ | Å ^ & Å ^ ç [ • • Å @ Å ^ ç æ \* Å | æ æ • Å @ Å | Å ^ Å | ç } æ æ ^ Å ^ | ä ~ • Å ç æ æ • Å ^ | ä ~ • Å b | ^ Å | Å ç ^ } Å ^ æ æ Å [ { Å à b & o Å @ [ , } Å [ { ç @ Å | æ æ • È Ö T Ü È D



O | Å [ ç ^ o æ æ ä • Å | Å ^ ç } à | Å [ , ^ | Å ^ & Å Å | æ æ Å O [ ] æ æ & æ Å ^ ~ | ç ã Å ^ | ä ~ • Å b | ^ Å | Å ç ^ } Å ^ æ æ ã ã • Å ç æ ä } ç Å | Å [ ç } Å @ Å ç [ ] ^ ä æ ä Å @ Å ^ & Å æ ^ Å ^ & | ^ | Å [ & Å ä Å } È Ö T Ü È D



VY Ö Å Ü V Ç È Ÿ

U | ^ æ æ } Å ^ & ç } Å È ç

















# OPERATION

Šas\*^Ea^}•^Ei:Á^oç^\*^caē}Á sē Á^āÁí Á^  
 { [, ^ā/Á Á [ ÁíÁ [í^Á sē••Áí Ás@ç^ÁÁ}āí: {  
 &^EÁQÁ^&@Áí}āāā}•Eāē^Á@Á&^cā^\*Á@a @Áí  
 FGíÁí [í^Á}Á@Áā•oí sē•EÁOPS-R-0043



Op - 139

V@}Áí, ^íÁ@Á [ , ^íÁí Á@Á^•ā^āÁ@ā @Áā ā  
 { [, Á@Áç^\*^caē}Áē^Áí}āÁā ^EÁQÁ [••āí^E  
 •^í^&oēí [ , ā^\*Á sē^!}Á@ē^ÁēÁÁEÁ^!^Áē^\*í^  
 d Á@Áā•oí sē•Áí Á^ā^&^Á d^ā ā^\*ÁíÁí [í^  
 ^}āí: { Á&^EÁOPS-R-0044



Op - 146

Ucē Áē^!Áē}āÁ sē&@í^!Áí^•Eí [ , Á@ē} \* ā^\*Áā} ā•E  
 [ [ , ^íÁā ^•Eā} āÁ c@í^ç^! @sāÁ} ā•cēí^•Áē} āÁ [ āē  
 \*í^} āÁ āb&o^Á @^Á [ ^Áē^Áí} ^!sē} \*EÁM^Áē^  
 d Áē [ āÁcā} \*Á@•^Áí { •ÁOPS-R-0028\_A



Op - 147

Öí Á [ oí [ , ÁíÁíā^Á@Áí sēd íÁí d í sē^!āÁcē^Áí^!} ā^\*ÁíÁē^āÁcē^Áí^&} d^Áē^!} oÁē} āÁ sēÁí} cāē} Á@ c  
 • [ [ •EÖ^!} ā^\*Áí sē^!āíE] sē^•Áē} āÁí sē^Áí^!āÁ^Ác@ [ , }Áí [ { Á@Á [ , ^íÁí Áē^āēÁ^ç^\*^caē} Á@ē^Á} ā @  
 ā} sē^EÁā^Áē} sē^Áē} Á&&^!Á @} Áíāē} ā^ç^!Á@ oí sē^!āíEÁē} āÁ^āē^Áí} Á@Áí sēd íÁí āÁ [ , ^íÁí^!ā  
 ā} sē^Áē^!} cā} \*Áā Áē^} ā { ^} oÁē^d^&cā} EÖē!^Áē^Áí^cā} \*^ā @íÁí} Á@Áí sēd íÁí sē^ÁíÁē} ^•Áí Á^cā} \*^ā @  
 [ [ ••āí^Áā^Á} &í^} c^!āē

VY @ ÄÜVOCËÿ

U] ^!sē} Áí^&cā} ÁíEíH

OPERATION





# OPERATION

## 9.4 Shutting Down the Implement

1. Turn the tractor to the left and stop.   
 2. Turn the PTO lever to the left.   
 3. Turn the engine stop switch to the left.   
 4. Turn the tractor to the right and stop.   
 5. Turn the PTO lever to the right.   
 6. Turn the engine stop switch to the right.   
 7. Turn the tractor to the left and stop.   
 8. Turn the PTO lever to the left.   
 9. Turn the engine stop switch to the left.   
 10. Turn the tractor to the right and stop.   
 11. Turn the PTO lever to the right.   
 12. Turn the engine stop switch to the right.




Op-37

1. Turn the tractor to the left and stop.   
 2. Turn the PTO lever to the left.   
 3. Turn the engine stop switch to the left.   
 4. Turn the tractor to the right and stop.   
 5. Turn the PTO lever to the right.   
 6. Turn the engine stop switch to the right.   
 7. Turn the tractor to the left and stop.   
 8. Turn the PTO lever to the left.   
 9. Turn the engine stop switch to the left.   
 10. Turn the tractor to the right and stop.   
 11. Turn the PTO lever to the right.   
 12. Turn the engine stop switch to the right.

OPERATION



1. Turn the tractor to the left and stop.   
 2. Turn the PTO lever to the left.   
 3. Turn the engine stop switch to the left.   
 4. Turn the tractor to the right and stop.   
 5. Turn the PTO lever to the right.   
 6. Turn the engine stop switch to the right.   
 7. Turn the tractor to the left and stop.   
 8. Turn the PTO lever to the left.   
 9. Turn the engine stop switch to the left.   
 10. Turn the tractor to the right and stop.   
 11. Turn the PTO lever to the right.   
 12. Turn the engine stop switch to the right.



## 10. DISCONNECTING THE MOWER FROM THE TRACTOR

1. Turn the tractor to the left and stop.   
 2. Turn the PTO lever to the left.   
 3. Turn the engine stop switch to the left.   
 4. Turn the tractor to the right and stop.   
 5. Turn the PTO lever to the right.   
 6. Turn the engine stop switch to the right.   
 7. Turn the tractor to the left and stop.   
 8. Turn the PTO lever to the left.   
 9. Turn the engine stop switch to the left.   
 10. Turn the tractor to the right and stop.   
 11. Turn the PTO lever to the right.   
 12. Turn the engine stop switch to the right.

OPS-R-0030\_A



# OPERATION


Ó-ŧ | ^Áıæş • ] [ | çā \* Á@Áıæşđ | Áşş áÁ [ , ^ | Ēŋ | ^Á@  
dæşđ | Á } \* ā ^ Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Á [ çā \* Á şş  
đ | Áŧ { ^ Áŧ Áşşŧ { } | ^ Áđ [ ] ĒÁ } & ^ ÁşşÁ [ , ^ | Á şş  
şş^ Áŧ { } | ^ Áđ [ ] ĒÁ şş ^ Á@Á [ , ^ | Áŧ  
đşş • ] [ | çā \* @ ĒÁ OPS-R-0033\_A



Op-37



T æ ^ Áŧ | çā \* Á@Áıæşđ | Áşş áÁ [ , ^ | Ēŋ | ^Á@  
dæşđ | Á } \* ā ^ Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Á [ çā \* Á şş  
đ | Áŧ { ^ Áŧ Áşşŧ { } | ^ Áđ [ ] ĒÁ } & ^ ÁşşÁ [ , ^ | Á şş  
şş^ Áŧ { } | ^ Áđ [ ] ĒÁ şş ^ Á@Á [ , ^ | Áŧ  
đşş • ] [ | çā \* @ ĒÁ OPS-R-0033\_A



## 12.1 Transporting Mower

### TRANSPORTING UNDER THE UNIT'S OWN POWER


Y @ } Áıæş • ] [ | çā \* Áŧ ç ^ Áŧ | Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Ēŋ | ^Á@  
dæşđ | Á } \* ā ^ Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Á [ çā \* Á şş  
đ | Áŧ { ^ Áŧ Áşşŧ { } | ^ Áđ [ ] ĒÁ } & ^ ÁşşÁ [ , ^ | Á şş  
şş^ Áŧ { } | ^ Áđ [ ] ĒÁ şş ^ Á@Á [ , ^ | Áŧ  
đşş • ] [ | çā \* @ ĒÁ OPS-R-0033\_A

### TRANSPORTING UNIT BY FLATBED TRAILER

T | • óıæşđ | Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Ēŋ | ^Á@  
dæşđ | Á } \* ā ^ Áşş áÁ şşÁŧ | ÁşşÁ [ , ^ | Á [ çā \* Á şş  
đ | Áŧ { ^ Áŧ Áşşŧ { } | ^ Áđ [ ] ĒÁ } & ^ ÁşşÁ [ , ^ | Á şş  
şş^ Áŧ { } | ^ Áđ [ ] ĒÁ şş ^ Á@Á [ , ^ | Áŧ  
đşş • ] [ | çā \* @ ĒÁ OPS-R-0033\_A

# OPERATION

OPERATION



U]•ĒĜĜ

OPEN THE BALL VALVES ON THE HYDRAULIC RESERVOIR BEFORE STARTING TRACTOR AGAIN!


12.2 Transporting on Public Roadways

OPS-R-217

# OPERATION

## WARNING

T æ ^ A & ^ i c æ A c æ A @ A U J | , A T [ ç a \* A ^ @ B / + A U T X D A ä } A e A e • c æ | ^ a A e ~ & @ æ ä æ A e A t A ^ A e | æ | A ç ä æ | ^ A e ä A ^ \* æ | ^ E Y @ } A t æ • [ | i ç \* A c Ö ~ ä { ^ } O ^ A ^ @ A / i æ d | A e æ @ \* A æ } ä \* A ä @ A e ä A e | | , A e | A | & e d æ - æ A ^ \* | æ | } • E Y ö ä ,



V @ A U T X A U J | , E T [ ç a \* A ^ @ B / + A U T X D A ä } à ^ { A e ~ } æ | ^ • c æ | ^ a A e ~ { à | | A ^ a A t A e | i O a | æ | ^ • A ^ A c @ | i ^ • ^ } & A ^ A ~ ä { ^ } O a e | ä \* A } A | æ æ , æ • A e A e • [ | , A ^ a E A U T X A ä } • A e ^ A e d æ ~ | æ A e | ä @ [ i æ \* ^ A æ @ A ^ + & ç A ^ a A t ä A t | A | c @ A e ^ A e æ æ ä A ä @ A e ä æ æ E A T æ A ^ | ^ A c @ A U T X A ä } A e & | æ ä A e ä A e æ | A t | { A c @ A ^ æ A ^ A c @ A } æ A e t | ^ d æ • [ | i ç \* A c A i æ d | A e ä A e | | ^ { ^ } O a } A e ä | æ | | æ æ , æ E Y U ^ | æ A c @ A U T X A { à | ^ { A e A e a ^ E ä æ æ ^ a E | A | A | } \* ^ i A ^ + & ç A ^ E OPS-U- 0020



Op-43

OPERATION

T æ A ^ | ^ A c æ A e | A e d | A e æ @ \* A æ } ä \* A ä @ E @ æ | ä @ E e ä A e | æ ^ E æ A ä @ A e ^ A ^ } & ç } ä \* [ | | A | ^ A e t | ^ A | | & A a ä \* A } d A ~ à æ A | æ • E Y @ ^ } ^ , ^ i A | ^ a | A e d | • A c æ A | ^ } c A ^ A e @ ä \* A t | | ç æ ^ A e } ä \* A ä } æ A e ä A | ^ æ æ \* A ä @ ä \* E [ • c [ | a ^ A | a ^ • A e A ^ } | ^ A ~ ä | ^ a A æ O a | ^ i æ æ \* A ä @ E Ö | } • | o a e c | i a ^ a A e d | A e æ | A t | A ä @ ä \* A æ æ ä A | a ä æ æ } • A e æ æ | A t | A } \* i æ A c @ A ä @ ä \* A } [ | a ^ A e d | A | a ^ • E OPS-U- 0021



Op-595

Y @ } A | ^ i æ æ \* A | } A | ~ à | æ A | æ • E A c æ ^ & | } • æ | ^ æ æ } A t | A c @ A | æ A • ^ • E Y ~ | A t A c A æ A [ A c @ A | æ A e & æ æ ä } æ | A t A e | | , A e | A | | | , ä \* A e æ - æ d A e • E Y Ö | A | O a e A ^ a A c @ A ^ \* æ A | ^ a A ä æ A ^ O a ^ { ^ | A e | } d ^ A t | A e | æ | c | æ A e d | • E Y e , æ • A e æ æ | O a } A t æ • [ | i ç \* A c A i æ d | A e ä A e | | ^ { ^ } c [ ] A ~ à | æ A | æ • E A ^ A e æ ç } A e ä A ^ a ^ & A | ^ a A e [ c @ A ^ @ B / + A | A ^ a ^ • d æ • A e A e A c @ A e ^ E OPS-U- 0022



Op-596

VY @ A U V O E Y

U | ^ i æ æ } A ^ & ç } A e U


# OPERATION



Do not operate the tractor with the PTO engaged when the tractor is in reverse or when the tractor is being driven on a slope.



Do not operate the tractor with the PTO engaged when the tractor is in reverse or when the tractor is being driven on a slope. Do not operate the tractor with the PTO engaged when the tractor is being driven on a slope.



OPERATION

Do not operate the tractor with the PTO engaged when the tractor is in reverse or when the tractor is being driven on a slope. Do not operate the tractor with the PTO engaged when the tractor is being driven on a slope.



Op-25

### 12.3 Hauling the Tractor and Implement

Do not operate the tractor with the PTO engaged when the tractor is in reverse or when the tractor is being driven on a slope. Do not operate the tractor with the PTO engaged when the tractor is being driven on a slope.



Op - 46

# OPERATION

OPERATION

W ^ Aaa ^ ~ æ | ^ A a ^ a Aæ a Aæ ^ a Aæ æ | • Aæ a  
 ^ ~ a { ^ } O A Aæ } [ | O A Aæ d | Aæ a Aæ ] | ^ { ^ } d E  
 Ô [ ] • ~ | O Aæ æ O | a ^ a Aæ aæ | Aæ Aæ c | { a ^ Aæ Aæ [ ] | ^ |  
 ^ ~ a { ^ } O A ^ a ^ a Aæ aæ \* Aæ a ^ ~ æ | ^ A a ^ a Aæ aæ • E  
 @ æ ^ Aæ c Aæ aæ • Eæ aæ | • Aæ aæ | Aæ aæ | • E Aæ & | ^ | Aæ  
 a [ , ] Aæ [ O Aæ Aæ [ ] O Aæ a Aæ aæ Aæ Aæ Aæ d | Aæ aæ aæ \* Aæ  
 ] | [ | ^ | Aæ Aæ [ , ] Aæ aæ aæ } • Aæ Aæ ^ aæ aæ Aæ Aæ Aæ d |  
 { æ ^ æ c | ^ | EOPS-U- 0025



O E | aæ \* ^ Aæ Aæ aæ • Aæ [ Aæ aæ Aæ @ } Aæ @ } ^ a Eæ O  
 & aæ aæ • Aæ ^ Aæ ~ | | aæ \* Aæ [ , ] , æ aæ aæ aæ aæ • c  
 O { • ^ | ç ^ • Eæ O aæ ~ | | Aæ @ } Aæ Aæ & | aæ \* Aæ aæ • Aæ |  
 [ O | Aæ c } ^ | • Aæ aæ \* Aæ [ [ | ^ | Aæ | Aæ aæ | • Aæ Aæ ] | ^ |  
 { æ aæ ~ { Aæ } • aæ } Eæ Aæ ^ Aæ c d ^ { ^ Aæ aæ Aæ @ }  
 æ aæ @ } \* Aæ aæ Aæ { [ ç aæ \* Aæ Aæ & | aæ \* Aæ ç aæ • Aæ Aæ  
 ^ c d ^ { ^ Aæ } • aæ } Aæ ç [ | ç aæ Aæ @ } Aæ ^ æ ^ aæ Aæ Aæ  
 ] | c } æ aæ Aæ aæ aæ aæ aæ aæ • aæ b | ^ E



Y @ ^ Aæ | aæ \* Aæ Aæ d | Aæ aæ ] | ^ { ^ } d E æ ^  
 [ & aæ aæ ] æ aæ d | • Aæ Aæ & Aæ aæ Aæ Aæ d | Aæ aæ  
 aæ ] | ^ { ^ } O Aæ ^ Aæ [ O | ç aæ Aæ | Aæ aæ aæ aæ aæ aæ  
 • ^ & | aæ \* Aæ aæ • Aæ ^ Aæ aæ aæ ^ aæ } • aæ } Eæ Aæ | aæ \*  
 dæ } [ | O Aæ aæ Aæ aæ aæ \* Eæ aæ | Aæ | aæ \* Eæ | Aæ ^ | ç aæ \*  
 æ aæ ] Aæ aæ Aæ | ^ | { ^ aæ d | Aæ aæ Aæ ^ c aæ aæ Aæ aæ }  
 d | aæ • ^ & aæ Aæ & | aæ Aæ Aæ Aæ aæ EOPS-U- 0026

# OPERATION

OPERATION

## 13. TROUBLESHOOTING GUIDE

**HYDRAULIC CYLINDER NOT WORKING**  
 • Check hydraulic oil level.  
 • Check for leaks in the hydraulic system.  
 • Check for air in the hydraulic lines.  
 • Check the relief valve settings.  
 • Check the cylinder for damage or wear.

NOTE: Refer to repair parts section on valve bank settings on individual relief cartridges.

**HYDRAULIC MOTOR NOT WORKING**  
 • Check hydraulic oil level.  
 • Check for leaks in the hydraulic system.  
 • Check the motor for damage or wear.

**HYDRAULIC VALVE**  
 • Check for leaks.  
 • Check the valve for damage or wear.  
 • Check the valve settings.  
 • Check the hydraulic oil level.

### MOWER

• Check the deck for damage or wear.  
 • Check the blade for damage or wear.  
 • Check the belt for damage or wear.  
 • Check the engine for proper operation.

### STRUCTURAL MEMBERS

• Check for cracks or damage in the structural members.  
 • Check the frame for proper operation.  
 • Check the suspension for proper operation.  
 • Check the steering system for proper operation.



# MAINTENANCE SECTION

T aq c} a} &^Á^&c} Á E

# MAINTENANCE

## GENERAL INSTRUCTIONS

Väriäntä, ... (Technical instructions in Finnish and English regarding maintenance procedures, safety, and handling of the machine parts.)

## MAINTENANCE PRECAUTIONS

- ... (Warning 1) ...
- ... (Warning 2) ...
- ... (Warning 3) ...
- ... (Warning 4) ...

### **WARNING**

ÖUÁPUVÁ ... (Detailed warning text in Finnish and English regarding safety during maintenance, including instructions on handling components and avoiding injury.)

## BREAK IN PERIOD

QÁáááá ... (Instructions regarding the break-in period for the machine, including recommended driving conditions and maintenance checks.)

### **DANGER**

DANGER ... (Safety warning in Finnish and English regarding the removal and reinstallation of wheel lugs, stating they must always be re-torqued.)



VY ÖÜUVÖÿ

T ... (Additional text or code at the bottom of the page.)



# MAINTENANCE

**MAINTENANCE**

ITEM	SERVICE	COMMENTS
Öä \ Á [ \ ] ç * Á [   0 Öä \ Á Á] ä á ^)	Ô @ &	Í ð + Á Á Ë ð + Á [   0 Á   ~ ^ Á Á Ö Á Á   Á   Á     Á ä á Á Á Á • É
T ç Á Á ç ^ Á ä á Ö &	Ô @ & Á	Ü á ç   ~ ^ Á [   0 Á Á   ~ ^ • ] ^ á á á á } • Á Á @ Á ^ & ç }
P ^ á : ä   á   ~ á   Á ç ^	Ô @ &	Ö ä Á Á ~ ^ á á Á Á   + á Á & { { ^ } á á á } •

## WEEKLY OR EVERY 40 HOURS

ITEM	SERVICE	COMMENTS
Ü [ ç ^ Á ] ä á ^	Š á   á á	Ö   ^ ç ^ Á á á • ç ^ & ç á á á ^ ç á á Á ç ç } ç & Á Á ^ & ç }

## WEEKLY OR EVERY 50 HOURS

ITEM	SERVICE	COMMENTS
Ö Á ç \ Á ^ á : ä   á   ~ á ç ç   (10 micron filter)	Ô @ ç * ^	Ô @ ç * ^ á á   Á á • Á Á ç ~   • Á }   ç ç } Á ç ^   ^ Á Á ç ~   • Á   Á ^ á
Ö É ç ^ Á á @ Á   ^ • ~   ^ ç ç   (10 micron filter)	Ô @ ç * ^	Ô @ ç * ^ á á   Á á • Á Á ç ~   • Á }   ç ç } Á ç ^   ^ Á Á ç ~   • Á   Á ^ á

VY Ö Ü U V Ö Ü

T ç ç } ç & Á Á ^ & ç } Á Ë

# MAINTENANCE

## MONTHLY OR EVERY 150 HOURS

ITEM	SERVICE	COMMENTS
P^ á:æ  æÁ  æÁç^ Á	Ô@&	ÇáÁæ Á ^^á^á
P^ á:æ  æÁæ\ Á!^æ@:	Ô^æ Ð@& Ð^]  æ^	Ô^æ Á!Á^]  æ^Á Ô^ { ^ } æ Á^~ á^á
<b>Rear Tire Type</b> /----- \ i Æ ÆUH /----- \ Æ ÆH /----- \ Æ Æi	<b>Max P.S.I.É</b> GJ GÍ GÍ	

## YEARLY OR EVERY 500 HOURS

ITEM	SERVICE	COMMENTS
Ù] æ á^Á!^æ^	Ô@æ *^	
T [ ç   ÁÛ Æ á^ÁÛ]  æ^ Á!^æ^Á	Ô@æ *^	
P^ á:æ  æÁæ\ Á!^æ	Ô@æ *^	
QÁæ\ Á^ á:æ  æÁ  æÁç^!	Ô@æ *^	
QËá ^ÁÚÁç^! <b>(10 micron filter)</b>	Ô@æ *^ /----- \ ;	Ô@æ *^ Á @ } /æ áææ á à Á^ dæç } æ áææ  É
P^ á:æ  æÁæ\ Á!^æ@:	Ô@æ *^	

VY ÖÜUVÖÿ

T æ ç } æ & Á!^æç } Á Æ

MAINTENANCE

# MAINTENANCE

MAINTENANCE

## TROUBLESHOOTING





SYMPTOMS	CAUSE	REMEDY
Xæ ææ}	Š [ • ^ ÁŌ [   o  Ō ō ſ! Áæ • ^ { à   ^	Ō @ & Áæ   Áſ [   o Áæ   à Áæ @ ^ } Áſ ! ^ & { { ^ } à ^ à Áſ ! ~ ^ Á ^ & à Áæ } • Áſ Áæ • ^ & ç }  æŌ @ & Áſ ! Áſ æ ſ ^ à Áſ   æ ^ • É æ à & É ~ } à æ æ & à Áſ ! Áſ ſ! Á æ ç Á  à É Ŭ ^   æ ^ Áſ ^ ^ à à É  & É Ō @ & Áſ ! Áſ à É [ ] ^ É ^ æ É } æ *   ^ à Áſ @ & ſ! Áæ • ^ { à   ^
T [ , ^ ! Á æ   Á [ ó æ ç	P ^ à   æ   æ Á ç   æ Á ſ   , Š ^ æ • Áſ Áſ ^ Ō æ   ç Áſ   æ ^ ç ç ^	Ō @ & Áæ   Áſ ç   Áſ ^ à Áſ ç   æ V à @ ^ } Áſ   Áſ   æ ^ Áſ ç * • Áſ à Áſ ç • ^ • Ō @ & Áſ ! ^ • • ^ Áſ Áſ ^ É ç Á ] ! ^ • • ^ Áſ Áſ Áſ [ ]   Áſ ç ç Áſ • ç     à Áſ Áſ   ^ æ ç ç ç ç ç ç ç
	S å \ ^ à Áſ   Áſ [ & ^ à  Ō æ   ç &   å à ^	Ō   ^ ç   Áſ   Áſ   æ ^ Áſ ^ •  Q • ] ^ & É ^   æ Áſ   Áſ   æ ^ Áſ   å à ^
U á Á ^ { ] ^   æ   Áſ ^ •	Š   , Áſ Áſ ç   Áſ   ç ^ Áſ ç ç ç ç S å \ ^ à Áſ [ & ^ à Áſ ç • ^ • Y [   } Áſ ^ { ] ç [ ç	Ō   ç * Áſ Áſ Áſ [ ] ^   Áſ ç ^ É Q • ] ^ & É Ŭ ^   æ Áſ ^   æ ^ Ō æ æ   Áſ à Áſ ^ æ
T [ , ^ ! Á æ   Á [ ó æ ç   Á ^ }	Ō [   , } Áſ • ^  Ō æ   ç ç ç ^ • Áſ   ^ à Š   , Áſ Áſ ç   Š å ^ Áſ æ  Ō   ^ & ç [ ] æ Á [   ^ ] [ æ Á æ ç   ç	Ō @ & Áſ ^ • ^ Áſ ^ ç ^ ^ } Áſ [ , ^ ! Á , æ & @ ç   Áſ } æ } Áſ ^   æ ^  T æ ^ Áſ ^   ^ ç ç ç ^ Áſ ^   ^ } Ō @ & Áſ ^ à É ç   Áſ à Áſ   Ō @ & Áſ ç   Áſ ç * • Áſ à Áſ ^ • É ! ^ É ç @ ^   Áſ ^   æ ^  æſ æ ç ~ ç @ Áſ ç ç   Áſ } } ç * É ç   } Á @ Á { [ , ^ ! Á , æ & ç   Áſ } É ç [ , Áæ à æ   Áſ ç Áſ } [ ó @ æ à Áſ ç @ Áſ   ^ ] [ æ Áſ ^ } * æ ç * Á @ • [   ^ ] [ æ Áſ ] [   É ç ç ç Áſ   ^   ç æ à É ^ ç ^ • , æ & @ ç Á [ ] } Á [ ] • ç } Á ç à Á , æ @ æ • & ^ , à   ç   Áſ   Áſ @   Áſ ç   Áſ à ç & ç ^ ~ & @ @ • { æ   Áſ ^ ç } Á @ Áſ } à Áſ - @ Áſ   ^ ] [ æ É ç @ { ^ ç   æ   Áſ à ç & ç   Áſ [ ó æ ç æ ç à Áſ Á @ Áſ ^ ç É & @ & Á @ Á ~ ^ Á ç à Á , ç ç * Áſ   Á ç } Á [ ] ^ } & & æ É ç @ Áſ   à ç & Áſ Áæ ç æ ç à Áſ ^ ó [   % ç ç   Áſ Á @ æ à É ^   æ ^ Á @ Á [   ^ ] [ æ É







# MAINTENANCE

MAINTENANCE

## TORQUE SPECIFICATIONS

Torque for Standard Fasteners													
Nominal Dia. (in.)	threads per inch	 Grade 2			 Grade 5			 Grade 8			 Grade 9		
		Tightening Torque			Tightening Torque			Tightening Torque			Tightening Torque		
		Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20
Unified Coarse Thread Series													
1/4	20	49 in-lbs	59 in-lbs	66 in-lbs	76 in-lbs	86 in-lbs	101 in-lbs	107 in-lbs	122 in-lbs	143 in-lbs	126 in-lbs	143 in-lbs	168 in-lbs
5/16	18	101	122	135	157	178	209	221	251	295	259	294	346
3/8	16	15 ft-lbs	18 ft-lbs	20 ft-lbs	23 ft-lbs	26 ft-lbs	31 ft-lbs	33 ft-lbs	37 ft-lbs	44 ft-lbs	38 ft-lbs	43 ft-lbs	51 ft-lbs
7/16	14	24	29	32	37	42	49	52	59	70	61	70	82
1/2	13	37	44	49	57	64	75	80	90	106	94	106	125
9/16	12	53	63	70	82	92	109	115	130	154	135	153	180
5/8	11	73	87	97	113	128	150	159	180	212	186	211	248
3/4	10	129	155	172	200	227	267	282	320	376	331	375	441
7/8	9	125	150	167	322	365	429	455	515	606	533	604	710
1	8	187	225	250	483	547	644	681	772	909	799	905	1065
1 1/8	7	266	319	354	596	675	794	836	955	1128	988	1132	1341
1 1/4	7	375	450	500	840	952	1121	1176	1363	1545	1357	1541	1810
1 1/2	6	652	783	869	1462	1657	1950	2046	2371	2768	2401	2779	3306
Fine Thread Series													
1/4	28	56 in-lbs	68 in-lbs	75 in-lbs	87 in-lbs	99 in-lbs	116 in-lbs	123 in-lbs	139 in-lbs	164 in-lbs	144 in-lbs	163 in-lbs	192 in-lbs
5/16	24	112	135	150	174	197	231	245	278	327	287	325	383
3/8	24	17 ft-lbs	20 ft-lbs	23 ft-lbs	26 ft-lbs	30 ft-lbs	35 ft-lbs	37 ft-lbs	42 ft-lbs	49 ft-lbs	43 ft-lbs	49 ft-lbs	58 ft-lbs
7/16	20	27	32	36	41	47	55	58	66	78	68	78	91
1/2	20	41	49	55	64	72	85	90	102	120	105	120	141
9/16	18	59	71	78	91	103	121	128	146	171	151	171	201
5/8	18	82	99	110	127	144	170	180	204	240	211	239	281
3/4	16	144	173	192	223	253	297	315	357	420	369	418	492
7/8	14	138	165	184	355	403	474	502	568	669	588	666	784
1	14	210	252	280	542	614	722	765	867	1020	896	1016	1195
1 1/8	12	298	357	397	668	757	890	1083	1227	1444	1269	1439	1693
1 1/4	12	415	498	553	930	1055	1241	1509	1710	2012	1768	2004	2358
1 1/2	12	734	880	978	1645	1865	2194	2668	3024	3557	3127	3544	4169

Torque values for 1/4 and 5/16-in series are in inch-pounds. All other torque values are in foot-pounds. K = 0.15 for "lubricated" conditions  
Torque values calculated from formula T=KDF, where K = 0.17 for zinc plated and dry conditions  
D = Nominal Diameter  
F = Clamp Load  
K = 0.20 for plain and dry conditions

Torque-Tension Relationship for Metric Fasteners													
Nominal Dia. (mm)	Pitch	 Class 4.6			 Class 8.8			 Class 10.9			 Class 12.9		
		Tightening Torque			Tightening Torque			Tightening Torque			Tightening Torque		
		Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry Plated K = 0.17	Dry plain K = 0.20	Lubed K = 0.15	Dry plain K = 0.20	
3	0.5	0.28	0.32	0.38	0.73	0.82	0.97	1.0	1.2	1.4	1.2	1.6	
3.5	0.6	0.44	0.50	0.59	1.1	1.3	1.5	1.6	1.9	2.2	1.9	2.5	
4	0.7	0.66	0.74	0.87	1.7	1.9	2.3	2.4	2.7	3.2	2.8	3.8	
5	0.8	1.3	1.5	1.8	3.4	3.9	4.5	4.9	5.5	6.5	5.7	7.6	
6	1	2.3	2.6	3.0	5.8	6.6	7.7	8.3	9.4	11	9.7	13	
6	1.25	2.1	2.3	2.7	5.3	6.0	7.0	7.6	8.6	10	8.8	12	
7	1	3.8	4.3	5.0	9.7	11	13	14	16	19	16	22	
8	1	5.9	6.6	7.8	15	17	20	22	24	29	25	34	
8	1.25	5.5	6.2	7.3	14	16	19	20	23	27	24	31	
10	1.25	11	13	15	29	33	39	42	48	56	49	66	
10	1.5	11	12	14	28	32	37	40	45	53	47	62	
12	1.25	21	23	28	53	60	71	76	86	101	89	119	
12	1.5	20	22	26	51	58	68	73	82	97	85	113	
12	1.75	19	21	25	49	55	65	70	79	93	81	108	
14	1.25	26	29	34	66	75	89	95	108	127	111	148	
14	1.5	28	32	37	72	82	96	103	117	138	121	161	
14	2	30	34	40	78	88	104	111	126	148	130	173	
16	1.5	50	57	67	129	146	171	184	208	245	215	287	
16	2	47	53	62	121	137	161	173	196	230	202	269	
18	1.5	73	82	97	187	212	249	268	303	357	313	417	
18	2.5	65	73	86	167	189	222	239	270	318	279	372	
20	2.5	91	104	122	236	267	314	337	382	449	394	525	

Clamp load calculated as 75% of the proof load for specified bolts. K = 0.15 for "lubricated" conditions  
All torque values are listed in foot-pounds K = 0.17 for zinc plated, dry conditions  
Torque values calculated from formula T=KDF, where K = 0.20 for plain and dry conditions  
D = Nominal Diameter  
F = Clamp Load

VY 0 A U V O E Y

T 3 3 } 3 & A U ^ 8 q } A E



# MAINTENANCE

MAINTENANCE

## LUBRICATION RECOMMENDATIONS

DESCRIPTION	APPLICATION	GENERAL SPECIFICATION	RECOMMENDED MOBIL LUBRICANT
Viædq  Á^ á!æ  æ	Ü^•^!ç[ ä	RÖËËÖ T ØÁ FFHÍ ÈÁ FFI F ØPPT GÖFH ÖÁØP PGEFD	T [ àä} äí Á G
T [ , ^!Á^ á!æ  æ Ó [  áÁ^ { } ^!æ  •Á€»ÜæðM P [   { æÁ^ { } ^!æ  •Á€»ÜæðM	Ü^•^!ç[ ä	ØUÁÍ ÁØ æÝ ^æÈ [ , Á^ { } RÖËËÖ T ØÁ FFHÍ ÈÁ FFI F ØPÁ Á GÖFH ÖÁØP PGEFD	T [ àäÖVÒÁÍ T T [ àä} äí Á G
P [   { æÁ^ { } ^!æ  •ÁÍ »ÜæðM P ä ÖU ^!æä * Á^ { } ÈÖ [ ç^ÁÍ€Ø		ØUÁÍ ÁØ æÝ ^æ ØUÁÍ €€ÁØ æÝ ^æ	T [ àäÖVÒÁÍ T [ àäÖVÒÁÍ T
Ö!ä^ÁÜ@ecÖ [ ~ ]  ^!	Ö!^æ^ÁÖ~ }	Šäc { È [ { }  ^ç Òçd^ { ^Á!••~!^ PŠÖÖGÈÖUÁÍGÈ	T [ àä^!^æ^ÁÖT ÈÜ
Ö!ä^ÁÜ@ecÄ [ \ ^É WÈ ä ç BÄÜc àÄÜ@ec	Ö!^æ^ÁÖ~ }	Šäc { È [ { }  ^ç Òçd^ { ^Á!••~!^ PŠÖÖGÈÖUÁÍGÈ	T [ àä^!^æ^ÁÖT ÈÜ
Ö^ & ÄÜ ä á!^ÁÜ [ æ^D	Ö!^æ^ÁÖ~ }	Vä^!ÁÜæöÜ] ä á!^Á^ á!æ} c Úæö^ { á!ÁÍ     €€€€	T [ àäöÜPÔÁGÈ
T [ ç  ÄÜ]  ä^			T [  ^ Á G

VY ÖÄÜVÖËÿ

T æ ç } æ & ÁÜ^ & ç } Á È




# MAINTENANCE

MAINTENANCE


## RECOMMENDED FILLING INSTRUCTIONS FOR HYDRAULIC RESERVOIRS

Y @ } Ááá \* Á! Á& @ & á \* Á @ Á áÁ ç! É @ Á } áá @ ~ | á  
 à^Á } á\^áÁ } ÁáÁ ç! Á \* ~ | áá É @ c "OFF" É á á  
 á | , Á ~ áá } áá ^ Á Á [ | Á Á á á } á { } ^! á : ^ É  
 W ^ Á & á á } Á , @ } Á ^! [ çá \* Á @ Á ] ^ . . | á ^ á  
 à! á @ É Ö [ Á [ Á ] áá Á á Á ç! Á [ ^ } á \* Á , @ }  
 ^! [ çá \* Á! á @ É

QÁ ^! Á ^ . . ^! ç [ áá @ Á } Á á @ Á \* | á . . . Á Á @  
 ^! . . ^! ç [ áá @ ~ | áá ^ Á á Á Á Á @ Á } Á - Á @ Á [ , ^!  
 . á @ Á | á . . Á } Á @ Á á Á Á - Á @ Á } É Ö [ Á [ ç! É á | É  
 V @ Á ^ . . ^! ç [ áá @ Á ^ } Á ç! É á á Á @ } Á á Á á á á  
 á @ Á ] ^! Á á @ Á | á . . É Á } Á @ Á [ Á ~ & @ á É @ Á  
 ^ ç & . . Á } á á Á ç ] ^! á á @ ~ \* @ Á ] ^! . . | á ^ á  
 à! á @ É



QÁ ^! Á ^ . . ^! ç [ áá @ Á } Á á @ Á | á . . . Á Á @  
 \* á á Á @ Á ^ . . ^! ç [ áá @ ~ | áá ^ Á á Á Á Á @ Á } é!  
 [ - Á @ Á á @ Á | á . . Á } Á @ Á á Á Á - Á @ Á } É Ö [ Á [ ç  
 [ ç! É á | É Á @ Á } Á @ Á } Á [ Á ~ & @ á É @ Á ç & . .  
 { á á Á Á ç ] ^! á á @ ~ \* @ Á ] ^! . . | á ^ á Á! á @ É



## REPLACING IN-TANK HYDRAULIC FILTER

Š [ . ^ } Á @ Á } ^! Á [ | Á } Á @ Á } Á } ç! Á - Á @ Á á  
 @ ~ á \* É Á } } Á } ç! Á } } é! É [ & , á ^ Á } á } ç! Á  
 ^ Á É Á [ ç ^ Á á Á ] áá Á á É Á } áá Á } Á } ç!  
 á á } ç! Á [ | Á } ] [ . á Á! á! Á Á ^! [ ç ^ á É




# MAINTENANCE

## REPLACING HIGH PRESSURE HYDRAULIC FILTER ELEMENT

MAINTENANCE

1. Turn the engine off and wait for the hydraulic system to cool.  
 2. Remove the cap from the filter housing.  
 3. Turn the cap counter-clockwise to remove it.  
 4. Remove the old filter element.  
 5. Insert the new filter element.  
 6. Turn the cap clockwise to secure it.  
 7. Replace the cap.  
 8. Turn the engine on and check for leaks.  
 9. If there are leaks, stop the engine and check the filter housing.  
 10. If there are no leaks, the filter replacement is complete.




**WARNING:** Bowl will be full of oil! Turn the engine off and wait for the hydraulic system to cool. Remove the cap from the filter housing. Turn the cap counter-clockwise to remove it. Remove the old filter element. Insert the new filter element. Turn the cap clockwise to secure it. Replace the cap. Turn the engine on and check for leaks. If there are leaks, stop the engine and check the filter housing. If there are no leaks, the filter replacement is complete.

# MAINTENANCE

MAINTENANCE

## GREASING THE UPPER AND LOWER SHEAVES

Š[ &æ^Á@Á |^æ^Á \i\•Á } Á@Á } á•Á -Á@Á ] ]^ |  
æ] áÁ | , ^!Á • @æ^Á ] æ • Áæ Á @ , } Áà^ | , ÈÁQ &  
Šá@ { È [ { ] |^cÁ Qæd^ { ^Á Úi^••~ |^Á |^æ^  
& } - | : } æ \* Áq Áb ŠÖ QÈUÁHGÉÁ • ] ^ &áæææ } • Áæ d  
^æ@] æ Á } dÁáÁ | | d~ á^ Á | { Ác@Á } á • ÈV@•^  
• @~ | áÁæ [ Á^Á |^æ^ áÁææ Á | Á | Ác^ |^ Á Áq~ | • Á~  
• ^ | çæ^ È



## TIGHTENING BLADE BOLTS AND DISK BOLTS

QÈ | Ác^ |^ Á Áq~ | • Á -Á ] ^ | ææ } Á | Áææ Èc@Á } á  
à [ | • Áæ áÁæ \ Á [ | • Á @~ | áÁ^ Áæ @ } ^ áÁæ Á | | , • K  
S) áÁ Á [ ~ } ç \* ÁÓ [ | • Ác^ ÁæÁ | ~ ^ Áq Á ÈÈÁ æ áÁæ È  
| á • È  
Öá \ Á [ ~ } ç \* ÁÓ [ | • Ác^ ÁæÁ | ~ ^ Áq Á ÈÈÁ Á | Á | Á |  
[ æ áÁæ È • È




# MAINTENANCE



## MAINTENANCE

### GREASING INNER AND OUTER DRAFT BEAM PIVOT POINTS

1. Grease the inner draft beam pivot points with a grease gun. Refer to the maintenance manual for details.




2. Grease the outer draft beam pivot points with a grease gun. Refer to the maintenance manual for details.



### GREASING PUMP DRIVE SHAFT COUPLER


1. Grease the pump drive shaft coupler with a grease gun. Refer to the maintenance manual for details.



# MAINTENANCE

## DRIVE SHAFT YOKE, U-JOINT & STUB SHAFT

Y... (mirrored text)




## ADJUSTING THE CABLE LIFT

Ö... (mirrored text)

**NOTE:** Make sure the cable turnbuckle is loose enough to allow the cylinder to reach full extension before the head reaches the stop.

P... (mirrored text)




# MAINTENANCE

MAINTENANCE


## BALL VALVES

THE BALL VALVES MUST BE OPEN (handle parallel with valve) WHEN TRACTOR IS RE-STARTED OR PUMP IS COUPLED TO MOTOR OR P.T.O.




## GREASING SPINDLE

Greasing the spindle is a critical maintenance task. The spindle is the central shaft of the PTO or motor. It should be greased regularly to ensure smooth operation and prevent wear. The grease should be applied to the spindle until it is completely covered.



## TIGHTENING SPINDLE BOLTS

The spindle bolts must be tightened to the correct torque. The bolts are located on the spindle housing. They should be tightened in a crisscross pattern to ensure even pressure.






# MAINTENANCE

## GREASING MOTOR SPLINE TO SPINDLE SPLINE

Š [ &æ^Á [ q !Á ] |á^Á } áÁ ] á á^Á ] |á^Á } Á@Á [ , ^!Á^& ÉÖ!^æ^Á ] |á^Á } á@Á [ àáÁ [ |^Á GÁ^Á^áá [ ^ Á [ ^ } &^Á^Á!^æ^ÉÖ@á \*^Á!^æ^Á^áá |^Á!Áç!^Á €€@^!•É



Mnt-R-0346

MAINTENANCE





# MAINTENANCE

## HEAVY DUTY SPINDLE ASSEMBLY INSTALLATION AND BEARING ADJUSTMENT




**WARNING** Read and understand the instructions before attempting to assemble or adjust the spindle assembly. Failure to follow the instructions may result in injury or damage to the equipment.

**NOTE:** The grease zerk and gussets are located on the top side of the spindle housing. Be sure the spindle is assembled correctly.

Be sure to wear eye protection and other protective equipment as needed when working on spindle assembly.

### THE SPINDLE ASSEMBLY

The spindle assembly consists of the following components:



© 2012 Alamo Group Inc.

For more information, visit our website at [www.alamogroup.com](http://www.alamogroup.com)

# MAINTENANCE

MAINTENANCE

## BEARING INSTALLATION

FÈ Ú!^••Á~]]^!Áà^æå \* Á&] Áå ç Ác@Á•] å à!@ ~•å \* Á


GÈ V'!} Ác@Á] å à!^ÁQ~•å \* Á ç^!Áæ å Á!^••Áå Ác@ [ , ^!Á^æå \* Á&] È

HÈ Ú!æ^Ác@Á[ , ^!Áà^æå \* Á&] ^!Áå Ác@Áà^æå \* &] È^ÁçcÁ!^••Ác@Á•æåÁ ç Ác@Á•] å à!@ ~•å \* ÈV@Áå } ^!Á]å Á[ Ác@Á•^æÁ{ ~•Áà^ ÖUY ß Èç, æå•Ác@Áà^æå \* È^ Á[ Á à!æå çå •^æåáå •æ^Ác@ÁQ~•å \* È

I È Q•æ!Ác@Á] å à!^Áå Ác@ÁQ~•å \* Èçå ç! Áæå Ác@^} á! Ác@Á] å à!^Á çcÁ[ çæåáÁç { ^!Á ç •^æåc@Á] å à!^Áæ åå •c@Á^æå \* Á } ^!Áæ È

Í È V'!} Ác@Á] å à!^ÁQ~•å \* Á ç^!Áç Á[ •æå } Dæ åÁ]å çcÁ^!Á] å à!^Áç à!æå çç çç { à!ÁÈ Í! ççççç c@Á] Á^•^Á Ác@Á]] ^!Á^æå \* Á&] È

Î È Ú]] [!c@Á ç { Á Ác@Á] å à!^Áå á! Á!^••Ác@Á]] ^!Á^æå \* Á&] ^!Áå á!Áæå \* Áæå•ç ^} ç!^ç^Á] ç c@Á] å à!^È



**NOTE:** The spindle housing must turn freely when seating the bearing cone and sleeve.

Ï È Ú!^••Ác@Áç [ Á] ^!Á^æå ç ç Ác@Á] å à!^ÁQ~•å \* ÈV@Áå } ^!Áå Á Ác@Á^æÁ ~•ç^Á^ÁÚÈæ æ Á[ { Ác@ á^æå \* È [ Á ç&^•Á à!æå ççæ Á•ææ^È

ì È Q•æ!Ác@Á^æå \* Áæå•ç ^} ç! ççç Á ~ ç! Ác@Á^ÁÈÈÈÈ^Á^æå & Á^ç ^} Ác@Á ~ çæ åÁc@Á]^ç^È Q•æ!Ác@Áæ Á æ ç!È] æå \* Ác@ÁæåÁ ç Ác@Á^È È æÈQ•æ!Ác@Á^æå \* Á[ & Á ~ ççç Á ~ ç! åÁç å ç ç! Áæ åå •çæ Á æ ç!Áæ åÁæå•ç ^} ç! ç!^Ác@Áç [ ] , å \* Á^ç] Á! Á^æå \* Áæå•ç ^} ç

## BEARING ADJUSTMENT


FÈ Ô]æ ] Ác@Á[ ç { Á} á! Ác@Á] å à!^Á^&^!^ Á ç æåå^Á [ Ác@Á] å à!^ÁQ~•å \* Áç } •Á^!È

GÈ Ú[ •æå } Áçæ æ } ^!Áæ^Áæ^ÁæåÁ åææ! Á] Ác@ [ ~ç!Áææ ^ç!Á[ Ác@Á] å à!^ÁQ~•å \* ÈS[ çæ c@Á] á! Ác@ÁæåÁ åææ! Áæ æå •c@Á]æÁ} á [ Ác@Á] å à!^Á çççV@Áåå åææ! Á] å!Á [ , { ^æ^!Áæ& çæ^! Á^æå \* Á} á!æÈ

HÈ Vå ç } Ác@Á^æå \* Áæå•ç ^} ç! ç! ç! Ác@Á^Á ççççç & ç! [ ç! ^} ç! c@Á] å à!^ÁQ~•å \* å Á] åáÁ] , æåÁæ æ Á[ { Ác@Á^Áæ •È

I È Y ç } Ác@Á^Á ççççç & ç!^Á] æ Á^ç ^} Ác@ •] å à!^Áå áQ~•å \* Èç •æ!Ác@Á^æå \* Á[ & Á ~ ç ççç Á ~ ç! ç! ] åÁc@Áæå•ç \* Á ~ ç!^&^!^ Áæ å ç ç! Ác@Á[ & Á ~ ç! Áççççç È Á] ~^È

Í È Çç!Ác@Á[ & Á ~ ç! Áç ç } ^!Áç ^!Á ~ ç!ÁÈÈÈÈ & ç! ÁÈÈÈÈ & ç! Á^Á] æ Á ç } Á ç ç! Á] å c@Á] å à!^ÁQ~•å \* È



QÁc@Á] á! ] æ Á& ]!^&ÈÈÈÈÈ & ç! ÁÈÈÈÈ & ç!^} áÁæ •Á] Á] Áæ Á æ ç!Á] Á^ç^} çc@Á[ & Á ~ ç! [ { [ [ •^} å \* ÈÁc@Á] á! ] æ Áç UVÁ& ]!^&È [ [ •^} Ác@Á[ & Á ~ ç! åÁç } Ác@Áæå•ç ^} ç! ç! Á ~ á^Áæ åÁÈ ç ç! Ác@Á[ & Á ~ ç!^} ^!Á^æå•ç ççç Áç] Á È

VY Q ÁUVÖÿ T æ ç } æ & Á^ç } Á Èç



**JD6X30 TWIN ROTARY**

**PARTS SECTION**

# PART NAME INDEX

RCTVUQTFGT&I 'I W&F C	5
VTCEVQT'O QWP V'MKV	6
VTCEVQT'O QWP V'MKV.VO '"/J [ FTCWNEU	8
VTCEVQT'O QWP V'MKV.VUT'"/J [ FTCWNEU	:
VTCEVQT'O QWP V'MKV.'NQCF GT	32
VTCEVQT'O QWP V'MKV.'NQCF GT'/'HTQP V'J [ FTCWNEU	34
4"URQQN'ECDNG'EQP VTQN'O QWP V	36
ECDNG'*O CP WCN+'N&H'XCNXG'/'4"URQQN'ECDNG'N&H	38
ECDNG'*O CP WCN+'N&H'XCNXG'/'4"URQQN'E QO DQ'N&H	3:
5"URQQN'ECDNG'EQP VTQN'O QWP V	42
ECDNG'*O CP WCN+'N&H'XCNXG'/'5"URQQN'ECDNG'N&H	44
ECDNG'*O CP WCN+'N&H'XCNXG'/'5"URQQN'E QO DQ'N&H	46
VTCEVQT'J [ FTCWNE'RQTVU*UVCP F CTF	48
VTCEVQT'J [ FTCWNE'RQTVU*RTGO KVO	49
ECDNG'*O CP WCN+'N&H'XCNXG'DTGCMF QY P '"/28724263	4:
5R'Z': R'VKG/TQF'E[ N&F GT'/'526: 3	52
RWO R'F T&GUJ CHV'CUUGO DN[	54
RQN[ ECTDQP K/G'UCHGV[ 'Y R'F QY '*UVCP F CTF	55
RQN[ ECTDQP K/G'UCHGV[ 'Y R'F QY '*RCP QTCO R	56
UCHGV[ 'UETGGP .'Y QE	58
HTQP V'72'I CNNQP 'VCP M'O QWP V	5:
UCHGV[ 'N& J V'QRVQP	62
UVGGN'ECP QR[	64



## PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must indicate the **Name and Address** of the person or organization ordering the parts, **who should be charged**, and if possible, the **serial number of the machine** for which the parts are being ordered.
3. The purchase order must clearly list the **quantity of each part**, the complete and correct **part number**, and the basic **name of the part**.
4. The manufacturer reserves the right to substitute parts where applicable.
5. Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:

**Tiger Corporation**  
3301 N. Louise Ave.  
Sioux Falls, SD 57107  
1-800-843-6849  
1-605-336-7900

# TRACTOR MOUNT KIT




## TRACTOR MOUNT KIT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
3	2852227;	3	O C R ' H T C O G . I F 8222
4	28522282	3	O P V . J [ F T Q ' V C P M I F 8222
5	285: 2234	3	V C P M T G U . I F 8222 . 56 I C N
6	43947	8	J G Z ' P W W . 3 1 4 \$ . P E
7	28727289	3	U K J V I C W I G . I F 8222 . V C P M . 56 I C N
8	4423:	4	H N C V Y C U I G T . 3 1 4 \$ . Y R F G
9	28727299	3	E C R . R T G U U W T G . 5 0 R U K
:	V H 6 : : :	3	U V T G G V ' G N D Q Y . 3 1 \$ Z ' ; 2 F G I
;	8 V 286;	3	H K N V G T ' I C W I G
32	28632574	3	E J C P P G N . O P V . V C P M V K G / D Q N V
33	55986	4	H N C V Y C U I G T . 7 1 \$ I T ' ; . U C G
34	43849	6	P [ N Q E M P W W . 5 1 \$ . P E
35	285: 2236	4	V K G ' D Q N V . U R F G ' V C P M J [ F T Q
36	28727266	3	H N V T ' C U U [ . R / V C P M E R N V . U C G 32 O R
37	53953	32	E C R U E T G Y . 42 O O ' Z ' 72 O O . 40 ' R K W E J
38	55: : 2	44	H N C V Y C U I G T . 5 1 6 \$ I T ' ; . U C G
39	53944	:	J G Z ' P W W . 42 O O . 40 ' R K W E J
3:	43: 47	6	J G Z ' P W W . 5 1 6 \$ . P E
3:	43: 55	6	E C R U E T G Y . 5 1 6 \$ Z ' 4 / 3 1 6 \$ . P E
42	56; ; :	3	U R C E G T . F T K & G U J C H V . I F 94 / 9732 42
43	548; 3	6	N Q E M Y C U I G T . 32 O O
44	45335	6	E C R U E T G Y . 32 O O ' Z ' 52 O O . 30 ' R K W E J
45	43; ; :	6	N Q E M Y C U I G T . 9 B 8 \$
46	438: 2	6	E C R U E T G Y . 9 B 8 \$ Z ' 3 / 3 1 6 \$ . P E . I T 7
47	56; ; :	3	F T K & G U J C H V . W I Q R V . I F 84 / 9732 44
48	4387:	3	E C R U E T G Y . 9 B 8 \$ Z ' 4 \$ . P H I T :
49	43954	6	E C R U E T G Y . 3 1 4 \$ Z ' 3 / 5 1 6 \$ . P E
4:	56: 6:	3	J G Z ' P W W . 9 B 8 \$ . P H I T : ' % U V Q X G T +
4:	56; ; 5	3	R W O R ' O P V . I F . W F T K & G
52	46: 82	6	E C R U E T G Y . 42 O O ' Z ' 62 O O . 40 ' R K W E J
53	43; ; 2	6	N Q E M Y C U I G T . 3 1 4 \$
54	28726224	3	R W O R . V C P F G O

# TRACTOR MOUNT KIT, TM - HYDRAULICS




ITEM	PART NO.	QTY.	DESCRIPTION
3	56286	3	CF CRVGT"3/316\$Z"3\$
4	562: 4	3	J QUG.3\$Z": ; \$
5	/////	/	VCP M', TGHGT"VQ"VTCEVQT"O QWP V'MK'RCI G
6	5652;	3	DCNN'XCNXG.3/34HQ T
7	56877	3	GNDQY . '3/34O R'Z"3/34O QT
8	28722527	3	J QUG.3/316\$Z"332\$
9	/////	/	O CRP 'H'ICO G', TGHGT"VQ"VTCEVQT"O QWP V'MK'RCI G
:	28722528	3	J QUG.3/34\$Z"92\$
;	545: 4	4	DTCEMGV.J QUG
32	55: : 2	4	HNCVY CUJ GT.516.1 T : .UCG
33	46: 82	4	ECRUETGY .42O O 'Z"62O O
34	VH6: 76	4	MKV.HNCPI G.%46

## TRACTOR MOUNT KIT, TM - HYDRAULICS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
35	/////	/	RWO R", TGHGT"VQ"VTCEVQT"O QWP V"MK"RCI G
36	VH6: 74	8	MKV.HNCPI G.%2
37	56848	4	DTCEMGV.VWDGIENCOR
38	46: 6;	4	URCEGT
39	/////	/	RWO R"O QWP V", TGHGT"VQ"VTCEVQT"O QWP V"MK"RCI G
3:	4578:	6	J QUG'ENCOR
3;	8V5422	4	URNK"J QUG
42	5292:	4	ECRUETGY .42O O "Z"; 2O O
43	56298	4	ENCOR"MK"3\$
44	56866	3	J QUG.3\$Z"37; \$
45	56833	3	J QUGIVWDG.3\$Z"86\$
46	55776	4	GNDQY "3\$O QTD"Z"3\$O L&E;67
47	56339	3	GNDQY "3\$O QTD"Z"3\$O L&E; 2
48	43866	6	ECRUETGY .51 \$Z"7\$
49	287322: 5	4	XCNXG.DTCMG.UQN.5222RUKO GVTK
4:	55777	8	CF CRVGT.3O QTD"Z"3O L&E
4;	44238	6	HNCVY CUI GT.51 \$
52	43847	6	J GZ"P WW.51 \$
53	563: 3	3	WP KQP "DNQEM.VTT.IF
54	4423:	3	HNCVY CUI GT.34\$.Y KFG
55	43947	3	J GZ"P WW.34\$
56	563: 5	3	CF CRVGT.DWNMI GCF .3O LZ"3O L
57	56: 87	3	J QUG.3\$Z"79\$
58	554: 9	3	HKVVP I .DWNMI GCF .3O LZ"3O QT
59	2872524:	4	S W&EME QWRNGT .3\$UCG.O CNG.HNCV
5:	28725249	4	S W&EME QWRNGT .3\$UCG.HGO .HNCV
5;	56383	3	J QUG.RTGUWTG"*82\$VO 'ECDNG'NHV+
///	5685:	3	J QUG.RTGUWTG"*94\$VO 'ECDNG'NHV+
////	56376	3	J QUG.RTGUWTG"*82\$VO 'EQO DQ'NHV+
///	5685:	3	J QUG.RTGUWTG"*94\$VO 'EQO DQ'NHV+
62	/////	/	TQVCTI "O QVQT"/"UGGEQO O QP "RCTVUUGEVIQP
63	56384	3	J QUG.TGVWTP"*82\$VO 'ECDNG'NHV+
///	5685;	3	J QUG.TGVWTP"*94\$VO 'ECDNG'NHV+
////	56377	3	J QUG.TGVWTP"*82\$VO 'EQO DQ'NHV+
///	5685;	3	J QUG.TGVWTP"*94\$VO 'EQO DQ'NHV+
65	28722326	3	J QUG.3\$Z"86\$
66	28725296	3	WP KQP .3QTD"Z"3QTD
67	563: 9	3	J QUG.TGVWTP
68	563: :	3	J QUG.RTGUWTG
69	28722529	3	J QUG.3\$Z"364\$

# TRACTOR MOUNT KIT, TSR - HYDRAULICS



ITEM	PART NO.	QTY.	DESCRIPTION
3	56286	3	CF CRVGT"3/3 16\$Z"3\$
4	562: 4	3	J QUG.3\$Z": ; \$
5	/////	/	VCPM', TGHGT"VQ"VTCEVQT"O QWP V"MKV"RCI G
6	5652;	3	DCNN'XCNXG.3/3 4HQ T
7	56877	3	GNDQY . '3/3 4O R'Z"3/3 4O QT
8	28722527	3	J QUG.3/3 16\$Z"332\$


## TRACTOR MOUNT KIT,TSR - HYDRAULICS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
9	/////	/	O CRP 'HTCO G', TGHGT"VQ"VTCEVQT"O QWP V'MK/RCI G
:	28722528	3	J QUG.3/34\$Z'92\$
;	545: 4	4	DTCEMGV.J QUG
32	55: : 2	4	HNCVY CUJ GT.516.1 T: .UCG
33	46: 82	4	ECRUETGY .42O O 'Z'62O O
34	VH6: 76	4	MK.VHNCPI G.%46
35	/////	/	RWO R', TGHGT"VQ"VTCEVQT"O QWP V'MK/RCI G
36	VH6: 74	8	MK.VHNCPI G.%42
37	56848	4	DTCEMGV.VWDGIENCOR
38	46: 6;	4	URCEGT
39	/////	/	RWO R'O QWP V', TGHGT"VQ"VTCEVQT"O QWP V'MK/RCI G
3:	4578:	6	J QUG'ENCOR
3;	8V5422	4	URNK/J QUG
42	5292:	4	ECRUETGY .42O O 'Z'; 2O O
43	56298	4	ENCOR'MK'3\$
44	56866	3	J QUG.3\$Z'37; \$
45	56833	3	J QUGIVWDG.3\$Z'86\$
46	55776	4	GNDQY '3\$O QTD'Z'3\$O LIE67
47	56339	3	GNDQY '3\$O QTD'Z'3\$O LIE; 2
48	43866	6	ECRUETGY .51 \$Z'7\$
49	287322: 5	4	XCNXG.DTCMG.UQN.5222RUKO GVTK
4:	55777	8	CF CRVGT.3O QTD'Z'3O LIE
4;	44238	6	HNCVY CUJ GT.51 \$
52	43847	6	J GZ'P WW.51 \$
53	563: 3	3	WP IQP 'DNQEM.VTT.IF
54	4423:	3	HNCVY CUJ GT.314\$.Y K G
55	43947	3	J GZ'P WW.314\$
56	563: 5	3	CF CRVGT.DWNMI GCF .3O LZ'3O L
57	56: 87	3	J QUG.3\$Z'79\$
58	554: 9	3	HK/VIP I .DWNMI GCF .3O LZ'3O QT
59	2872524:	4	S WEMEQWRNGT.3\$UCG.O CNG.HNCV
5:	28725249	4	S WEMEQWRNGT.3\$UCG.HGO .HNCV
5;	56383	3	J QUG.RTGUWTG
62	/////	/	TQVCTI 'O QVQT"/"UGGEQO O QP 'RCTVU'UGEVIQP
63	56384	3	J QUG.TGVWTP
65	28722326	3	J QUG.3\$Z'86\$
66	28725296	3	WP IQP .3QTD'Z'3QTD
67	287222: 8	3	J QUG.RTGUWTG
68	287222: 9	3	J QUG.TGVWTP
69	28722529	3	J QUG.3\$Z'364\$

JD6X30 TWIN

# TRACTOR MOUNT KIT, LOADER



ITEM	PART NO.	QTY.	DESCRIPTION
3	28522283	3	OPHTO.NFT.LF 8652
4	2859229:	3	OPV.NFT.DQNV"QP.LF 8652
///	289222; 2	/	VCPMTGUILF 8222.CUU
5	285: 2234	3	VCPMTGUILF 82226Y F *56I CN+
6	28727266	3	HNVTCUU .R/VCPMERNV.UCG32OR
7	43947	4	JGZ'PW.3H\$PE
8	4423:	4	HNCVY CUI GT.3H\$.Y RFG
9	28727289	3	UK J VI CI G.IF 8222.VCPM56I CN




## TRACTOR MOUNT KIT, LOADER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
:	28727299	3	ECR.DTGC.VJ.GT.Q/T&P I
;	VH6::	3	UVTGGV"GNDQY .3I \$
32	8V286;	3	H&NVT" I CWI G
33	28632574	3	EJ CPPGN.O P.V.VCP.MVKG/DQNV
34	55986	4	HNCVY CUI GT.7I \$I T": .UCG
35	285: 2236	4	VKG'DQNV.U&F G"VCP.MJ [ FTQ
36	53953	36	ECRUETGY .42O O "Z"72O O .40"RK&EJ
37	55: : 2	4:	HNCVY CUI GT.5I6\$I T": .UCG
38	53944	37	J GZ "P WW.42O O .40"RK&EJ .ENC UU':
39	43953	4	ECRUETGY .3I4\$Z"3/3I4\$.PE
3:	28592288	3	I W&F.G.J QUG
3:	286226; 9	3	RNCVG.VQR
42	43; ; 2	32	NQEMY CUI GT.3I4\$
43	4394;	4	ECRUETGY .3I4\$Z"3\$.PE
44	43947	8	J GZ "P WW.3I4\$.PE
45	28642276	4	URCEGT.07\$Z"063\$Z"4072\$
46	45: : :	3	DTMV.CEEWO WNCVQT
47	43; : :	4	NQEMY CUI GT.5I \$
48	43862	4	ECRUETGY .5I \$Z"5/3I4\$.PE
49	46522	3	CEEWO WNCVQT
4:	43: 57	4	ECRUETGY .5I6\$Z"4/5I6\$.PE
4:	8V4829	4	HNCVY CUI GT.EN&RRGF .5I6\$
52	43: 47	4	J GZ "P WW.5I6\$.PE
53	44243	4	HNCVY CUI GT.5I6\$
54	43; ; 5	4	NQEMY CUI GT.5I6\$I T":
55	56; : :	3	URCEGT.F T&KGUJ CHV.IF 94/9742
56	548; 3	6	NQEMY CUI GT.32O O
57	45335	6	ECRUETGY .32O O "Z"82O O *40"RK&EJ +
58	43; : :	6	NQEMY CUI GT.9B8\$
59	438: 2	6	ECRUETGY .9B8\$Z"3/3I6\$.PE
5:	2899226:	3	FT&KGUJ CHV.WIQP V.NQCFGT
5:	4387:	3	ECRUETGY .9B8\$Z"4\$.PHI T:
62	56: 6:	3	J GZ "P WW.9B8\$.PHI T: "UVQXGT+
63	5426;	4	URCEGT.5I6\$QF "Z"3I \$Y NZ"3/3I6\$
64	56; ; 4	3	EQXGT.HIQP V.IF 84/8632I42
65	43954	8	ECRUETGY .3I4\$Z"3/5I6\$.PE
66	285: 2242	3	OP V.RWOR.NFT
67	46: 82	6	ECRUETGY .42O O "Z"72O O .40"RK&EJ
68	*****28726224*****	3*****	RWOR.R572"3/5I6\$I GCT
69	*****494: 4*****	7*****	ECRUETGY .42O O "Z"77O O

# TRACTOR MOUNT KIT, LOADER - FRONT HYDRAULICS




## TRACTOR MOUNT KIT, LOADER - FRONT HYDRAULICS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	MAIN FRAME *REFER TO TRACTOR MOUNT KIT PAGE
2	06500444	1	HOSE,RETURN (72"TM COMBO LIFT)
---	06500240	1	HOSE,RETURN (60"TSR COMBO LIFT)
3	06500445	1	HOSE,PRESSURE (72"TM COMBO LIFT)
---	34945	1	HOSE,PRESSURE (60"TSR COMBO LIFT)
4	33554	3	ELBOW,1MOR X 1MJIC,45°
5	21625	2	HEX NUT,3/8",NC
6	21988	2	LOCKWASHER,3/8"
7	06510083	1	SOLENOID BRAKE VALVE
8	06506012	1	PRFRMD,BRKVLV,4" X 1FJX X 1FJX(180°)
9	32703	2	CAPSCREW,20MM X 100MM,2.5PITCH
10	34229	2	SPACER,3/4"ID X 1-1/2"OD X 1-1/4"
11	21644	2	CAPSCREW,3/8" X 5",NC
12	24849	2	SPACER
13	06530522	3	CAPSCREW,20MM X 30MM,1.5 PITCH
14	32382	3	HOSE BRACKET
15	06500048	1	HOSE,1" X 31"
16	TF4852	2	KIT, FLANGE,#20
17	-----	-	PUMP *REFER TO TRACTOR MOUNT KIT PAGE
18	06500314	1	HOSE,1-1/2" X 80"
19	34309	1	BALL VALVE,1-1/2",FOR
20	34710	1	ADAPTER,1-1/2ORB X 1-1/2MJ
21	34865	1	HOSE,1" X 57"
22	34064	1	ADAPTER,1-1/4MOR X 1MJ
23	-----	-	HYDRAULIC TANK *REFER TO TRACTOR MOUNT KIT PAGE

# 2 SPOOL CABLE CONTROL MOUNT



## 2 SPOOL CABLE CONTROL MOUNT


Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06510097	1	SWITCHBOX,TWIN/T3F,GND
2	34496	1	BRKT,SWITCHBOX,UNI
3	32360	2	LOCKWASHER,#8
4	6T3951	2	SCREW,MACHINE,8/32" X 1/2"
5	21525	3	HEX NUT,1/4",NC
6	21986	3	LOCKWASHER,1/4"
7	23865B	1	CBL CTRL MT BRK
8	21627	3	NYLOCK NUT,3/8",NC
9	27082B	3	SPACER
10	21635	3	CAPSCREW,3/8" X 2-1/4",NC
11	34623	2	CABLE CONTROL,122"
12	30750A	1	BRKT,CBL CTRL,JD6000
13	32691	1	LOCKWASHER,10MM
14	33534	1	CAPSCREW,10MM X 20MM,1.5P
15	21542	2	CAPSCREW,1/4" X 4",NC
16	21544	1	CAPSCREW,1/4" X 5",NC
17	6T1251	2	CBL CTRL BOX,180 DEG

# CABLE (MANUAL) LIFT VALVE - 2 SPOOL CABLE LIFT

## HOSE ROUTING

- A - TO INBOARD CYLINDER GLAND
- B - TO OUTBOARD CYLINDER BUTT
- C - FROM 3-PT CYL BUTT TO TRACTOR REMOTE
- D - FROM 3-PT CYL GLAND TO TRACTOR REMOTE
- LS - LOAD SENSE LINE
- RT - RETURN LINE
- PS - PRESSURE LINE




## CABLE (MANUAL) LIFT VALVE - 2 SPOOL CABLE LIFT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34622	1	VALVE MOUNTING PLATE
2	06410430	1	MOUNT,VALVE,LEFT
3	06410429	1	MOUNT,VALVE,RIGHT
4	06502041	1	VALVE,2SPHSC,TM,CABLE,LS
5	34623	2	CABLE CONTROL,122"
6	6T4411	2	CLEVIS,CBL CTRL,3/16"
7	21500	4	HEX NUT,1/4",NF
8	6T3017	2	ROLL PIN
9	06530514	4	CAPSCREW,18MM X 290MM,2.5P,GR10.9
10	34519	4	SPACER,1-1/4" X 13/16" X 1-1/8"
11	32678	1	ADAPTER,5/8MORB X 1/2FORB
12	33382	1	ELBOW,1/2MORB X 1/2MJ X 90
13	33383	1	ELBOW,5/8MORB X 1/2MJ X 90
14	21632	4	CAPSCREW,3/8" X 1-1/2",NC
15	22016	4	FLATWASHER,3/8"
16	21631	4	CAPSCREW,3/8" X 1-1/4",NC
17	21988	8	LOCKWASHER,3/8"
18	21625	8	HEX NUT,3/8",NC
19	32901	1	ADAPTER,3/8MOR X 3/8MJ (STANDARD TRACTOR)
---	06503142	1	ADAPTER,CHECK VALVE (PREMIUM TRACTOR)
20	33271	3	ADAPTER,1/2MOR X 3/8MJ
21	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
22	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
23	34631	1	HOSE,1/4" X 126"
24	34632	1	HOSE,1/4" X 115"
25	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
26	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
27	30181A	1	CLEVIS,UPPER,CYL
28	6T3003	1	PIN,1" X 3-1/2"
29	6T3004	2	R-CLIP
30	30481	1	CYLINDER,3" X 8"
31	31208	1	SPACER,1/2"
32	6T2272	1	SETSCREW,3/8" X 1/2",NC
33	30184C	1	CLEVIS,LOWER,CYL
34	06500029	1	HOSE,1/4" X 31"
35	06500030	1	HOSE,1/4" X 28"
36	-----	-	ITEMS 34 & 35
37	32900	2	QUICK COUPLER,MALE




# CABLE (MANUAL) LIFT VALVE - 2 SPOOL COMBO LIFT




### HOSE ROUTING

- A - TO INBOARD CYLINDER GLAND
- B - TO OUTBOARD CYLINDER BUTT
- C - TO OUTBOARD CYLINDER GLAND
- D - FROM 3-PT CYL BUTT TO TRACTOR REMOTE
- E - FROM 3-PT CYL GLAND TO TRACTOR REMOTE
- LS - LOAD SENSE LINE
- RT - RETURN LINE
- PS - PRESSURE LINE

### TRACTOR REAR REMOTES



PREMIUM HYDRAULIC PORTS SHOWN



3 POINT CYLINDER




## CABLE (MANUAL) LIFT VALVE - 2 SPOOL COMBO LIFT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34622	1	VALVE MOUNTING PLATE
2	06410430	1	MOUNT, VALVE, LEFT
3	06410429	1	MOUNT, VALVE, RIGHT
4	06502041	1	VALVE, 2SPHSC, TM, CABLE, LS
5	34623	2	CABLE CONTROL, 122"
6	6T4411	2	CLEVIS, CBL CTRL, 3/16"
7	21500	4	HEX NUT, 1/4", NF
8	6T3017	2	ROLL PIN
9	06530514	4	CAPSCREW, 18MM X 290MM, 2.5P, GR10.9
10	34519	4	SPACER, 1-1/4" X 13/16" X 1-1/8"
11	32678	1	ADAPTER, 5/8MORB X 1/2FORB
12	33382	1	ELBOW, 1/2MORB X 1/2MJ X 90
13	33383	1	ELBOW, 5/8MORB X 1/2MJ X 90
14	21632	4	CAPSCREW, 3/8" X 1-1/2", NC
15	22016	4	FLATWASHER, 3/8"
16	21631	4	CAPSCREW, 3/8" X 1-1/4", NC
17	21988	8	LOCKWASHER, 3/8"
18	21625	8	HEX NUT, 3/8", NC
19	32901	1	ADAPTER, 3/8MOR X 3/8MJ (STANDARD TRACTOR)
---	06503142	1	ADAPTER, CHECK VALVE (PREMIUM TRACTOR)
20	33271	5	ADAPTER, 1/2MOR X 3/8MJ
21	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
22	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
23	34632	2	HOSE, 1/4" X 115"
24	34631	1	HOSE, 1/4" X 126"
25	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
26	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
27	30181A	1	CLEVIS, UPPER, CYL
28	6T3003	1	PIN, 1" X 3-1/2"
29	6T3004	2	R-CLIP
30	30481	1	CYLINDER, 3" X 8"
31	31208	1	SPACER, 1/2"
32	6T2272	1	SETSCREW, 3/8" X 1/2", NC
33	30184C	1	CLEVIS, LOWER, CYL
34	06500029	1	HOSE, 1/4" X 31"
35	06500030	1	HOSE, 1/4" X 28"
36	-----	-	ITEMS 34 & 35
37	32900	2	QUICK COUPLER, MALE

### 3 SPOOL CABLE CONTROL MOUNT




### 3 SPOOL CABLE CONTROL MOUNT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06510097	1	SWITCHBOX,TWIN/T3F,GND
2	34496	1	BRKT,SWITCHBOX,UNI
3	32360	2	LOCKWASHER,#8
4	6T3951	2	SCREW,MACHINE,8/32" X 1/2"
5	21525	3	HEX NUT,1/4",NC
6	21986	3	LOCKWASHER,1/4"
7	23865B	1	CBL CTRL MT BRK
8	21627	3	NYLOCK NUT,3/8",NC
9	27082B	3	SPACER
10	21635	3	CAPSCREW,3/8" X 2-1/4",NC
11	34623	3	CABLE CONTROL,122"
12	30750A	1	BRKT,CBL CTRL,JD6000
13	32691	1	LOCKWASHER,10MM
14	33534	1	CAPSCREW,10MM X 20MM,1.5P
15	22903	2	CAPSCREW,1/4" X 5-1/2",NC
16	21545	1	CAPSCREW,1/4" X 6",NC
17	6T1251	3	CBL CTRL BOX,180 DEG

# CABLE (MANUAL) LIFT VALVE - 3 SPOOL CABLE LIFT




## CABLE (MANUAL) LIFT VALVE - 3 SPOOL CABLE LIFT

Continued...


ITEM	PART NO.	QTY.	DESCRIPTION
1	34622	1	VALVE MOUNTING PLATE
2	06410430	1	MOUNT,VALVE,LEFT
3	06410429	1	MOUNT,VALVE,RIGHT
4	06502043	1	VALVE,3SPHSC,TRR/T3F,LS
5	34623	3	CABLE CONTROL,122"
6	6T4411	3	CLEVIS,CBL CTRL,3/16"
7	21500	6	HEX NUT,1/4",NF
8	6T3017	3	ROLL PIN
9	06530514	4	CAPSCREW,18MM X 290MM,2.5P,GR10.9
10	34519	4	SPACER,1-1/4" X 13/16" X 1-1/8"
11	32678	1	ADAPTER,5/8MORB X 1/2FORB
12	33382	1	ELBOW,1/2MORB X 1/2MJ X 90
13	33383	1	ELBOW,5/8MORB X 1/2MJ X 90
14	21632	4	CAPSCREW,3/8" X 1-1/2",NC
15	22016	4	FLATWASHER,3/8"
16	21631	4	CAPSCREW,3/8" X 1-1/4",NC
17	21988	8	LOCKWASHER,3/8"
18	21625	8	HEX NUT,3/8",NC
19	32901	1	ADAPTER,3/8MOR X 3/8MJ (STANDARD TRACTOR)
---	06503142	1	ADAPTER,CHECK VALVE (PREMIUM TRACTOR)
20	33271	4	ADAPTER,1/2MOR X 3/8MJ
21	-----	-	HOSE *REFER TO TRACTOR HYDRUALIC PORTS PAGE
22	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
23	34631	1	HOSE,1/4" X 126"
24	34632	1	HOSE,1/4" X 115"
25	34633	1	HOSE,1/4" X 66" (90°)
26	34634	1	HOSE,1/4" X 66" (180°)
27	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
28	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
29	30181A	1	CLEVIS,UPPER,CYL
30	6T3003	1	PIN,1" X 3-1/2"
31	6T3004	2	R-CLIP
32	30481	1	CYLINDER,3" X 8"
33	31208	1	SPACER,1/2"
34	6T2272	1	SETSCREW,3/8" X 1/2",NC
35	30184C	1	CLEVIS,LOWER,CYL

# CABLE (MANUAL) LIFT VALVE - 3 SPOOL COMBO LIFT




## HOSE ROUTING

- A - TO INBOARD CYLINDER GLAND
- B - TO OUTBOARD CYLINDER BUTT
- C - TO OUTBOARD CYLINDER GLAND
- D - TO 3-PT CYLINDER BUTT
- E - TO 3-PT CYLINDER GLAND
- LS - LOAD SENSE LINE
- RT - RETURN LINE
- PS - PRESSURE LINE



PREMIUM HYDRAULIC PORTS SHOWN



3 POINT CYLINDER


## CABLE (MANUAL) LIFT VALVE - 3 SPOOL COMBO LIFT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34622	1	VALVE MOUNTING PLATE
2	06410430	1	MOUNT, VALVE, LEFT
3	06410429	1	MOUNT, VALVE, RIGHT
4	06502044	1	VALVE, 3SPHSC, TRR/T3F, LS
5	34623	3	CABLE CONTROL, 122"
6	6T4411	3	CLEVIS, CBL CTRL, 3/16"
7	21500	6	HEX NUT, 1/4", NF
8	6T3017	3	ROLL PIN
9	06530514	4	CAPSCREW, 18MM X 290MM, 2.5P, GR10.9
10	34519	4	SPACER, 1-1/4" X 13/16" X 1-1/8"
11	32678	1	ADAPTER, 5/8MORB X 1/2FORB
12	33382	1	ELBOW, 1/2MORB X 1/2MJ X 90
13	33383	1	ELBOW, 5/8MORB X 1/2MJ X 90
14	21632	4	CAPSCREW, 3/8" X 1-1/2", NC
15	22016	4	FLATWASHER, 3/8"
16	21631	4	CAPSCREW, 3/8" X 1-1/4", NC
17	21988	8	LOCKWASHER, 3/8"
18	21625	8	HEX NUT, 3/8", NC
19	32901	1	ADAPTER, 3/8MOR X 3/8MJ (STANDARD TRACTOR)
---	06503142	1	ADAPTER, CHECK VALVE (PREMIUM TRACTOR)
20	33271	5	ADAPTER, 1/2MOR X 3/8MJ
21	-----	-	HOSE *REFER TO TRACTOR HYDRUALIC PORTS PAGE
22	-----	-	HOSE *REFER TO TRACTOR HYDRAULIC PORTS PAGE
23	34632	2	HOSE, 1/4" X 115"
24	34631	1	HOSE, 1/4" X 126"
25	34633	1	HOSE, 1/4" X 66" (90°)
26	34634	1	HOSE, 1/4" X 66" (180°)
27	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
28	-----	-	ADAPTER *REFER TO TRACTOR HYDRAULIC PORTS PAGE
29	30181A	1	CLEVIS, UPPER, CYL
30	6T3003	1	PIN, 1" X 3-1/2"
31	6T3004	2	R-CLIP
32	30481	1	CYLINDER, 3" X 8"
33	31208	1	SPACER, 1/2"
34	6T2272	1	SETSCREW, 3/8" X 1/2", NC
35	30184C	1	CLEVIS, LOWER, CYL

TRACTOR HYDRAULIC PORTS (STANDARD)

STANDARD SERIES TRACTOR




ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	TRACTOR REMOTES (STANDARD)
2	06503013	1	ELBOW,14MMORB X 5/16MJ
3	06500400	1	HOSE,1/4" X 30" (DAN FOSS VALVE)
---	06500350	1	HOSE,1/4" X 26" (HUSCO VALVE)
4	33463	2	ADAPTER,22MMORB X 1/2MJ
5	34612	2	HOSE,1/2" X 34"




## TRACTOR HYDRAULIC PORTS (PREMIUM)

### PREMIUM SERIES TRACTOR



ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	TRACTOR REMOTES (PREMIUM)
2	06503069	1	ADAPTER,14MMORB X 3/8MJ
3	06500267	1	HOSE,1/4" X 30"
4	06500269	2	HOSE,1/2" X 40"
5	06503012	2	ADAPTER,27MMORB X 3/4MJ

# CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502041




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502041

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31595	1	INLET END COVER
2	31594	1	END COVER, LOAD SENSE
3	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
4	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING) (REMOVE SHUTTLE DISC)
5	06503067	1	#10 O-RING PLUG
6	31861	1	RELIEF VALVE, 360 PSI
7	06503068	1	#6 O-RING PLUG
8	6T4209	-	#10 O-RING PLUG
9	31862	1	RELIEF VALVE, 2175 PSI
10	31862	1	RELIEF VALVE, 2175 PSI
11	31593	2	VALVE SEAL KIT (FOR ONE SECTION)
11A	-----	2	WIPER
11B	-----	2	O-RING SMALL
11C	-----	1	O-RING LARGE
11D	-----	1	SHUTTLE DISC
11E	-----	1	SPRING
12	TB1017L	2	LEVER KIT (FOR ONE SECTION)
12A	-----	1	LEVER KNOB
12B	-----	1	LEVER
12C	-----	2	LEVER WASHER
12D	-----	1	LEVER CLIP
12E	-----	2	LINKAGE
12F	-----	1	LEVER PIN
12G	-----	1	ROLL PIN
12H	-----	1	LEVER BOOT
12J	-----	1	LEVER BOLT
12K	-----	1	LEVER DUST COVER
12L	-----	1	LEVER NUT
13	31603	2	COMPENSATOR
14	TB1017X	1	TIE ROD KIT
15	24214	1	O-RING, LARGE

3IN X 8IN TIE-ROD CYLINDER - 30481




## 3IN X 8IN TIE-ROD CYLINDER - 30481

Continued...


ITEM	PART NO.	QTY.	DESCRIPTION
---	30481	1	CYLINDER 3" X 8"
1	6T0167	1	CYLINDER BUTT
2	6T0170	1	CYLINDER GLAND
3	6T0178	1	CLEVIS END
4	23870	1	CYLINDER TUBE
5	23869	1	PISTON ROD
6	6T0173	1	PISTON
7	6T0179	1	LOCKNUT
8	21749	4	TIE ROD ASY
---	06501579	1	SEAL KIT
9	-----	2	O - RING
10	-----	2	BACK - UP WASHER
11	-----	1	O - RING
12	-----	2	BACK - UP WASHER
13	-----	1	O - RING
14	-----	1	U - CUP
15	-----	1	WIPER

## PUMP DRIVESHAFT ASSEMBLY




ITEM	PART NO.	QTY.	DESCRIPTION
---	34999	1	DRIVESHAFT,U-JOINT
----	06770048	1	DRIVESHAFT,U-JOINT (LOADER MOUNT)
1	06505004	1	YOKE PULLEY
2	06505005	1	SLEEVE
3	06505006	1	SHAFT
---	06770047	1	SHAFT (LOADER MOUNT)
4	06505007	2	CROSS
5	06505008	1	YOKE DRIVE
6	6T3203	1	GREASE ZERK,1/4" X 45°
7	6T3207	3	GREASE ZERK,1/4" X STR

## POLYCARBONITE SAFETY WINDOW (STANDARD)



ITEM	PART NO.	QTY.	DESCRIPTION
1	31965	22	TRIM SEAL,3/8" CLIP X 3/4"OD
2	27508	3	CAPSCREW,8MM X 20MM,1.25P
3	22015	4	FLATWASHER,5/16"
4	21581	1	CAPSCREW,5/16" X 1-1/4",NC
5	06490005	1	POLYCARB,FRMD,DOOR,RH
6	06490027	1	POLYCARB,FRMD,REAR,RH
7	06520040	3	BRKT,JD,POLY,RETAIN
8	6T2619	3	LOCKWASHER,8MM
9	21577	1	NYLOCK NUT,5/16",NC

# POLYCARBONITE SAFETY WINDOW (PANORAMIC)






## POLYCARBONITE SAFETY WINDOW (PANORAMIC)

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31965	20	TRIM SEAL,3/8" CLIP X 3/4"OD
2	27508	4	CAPSCREW,8MM X 20MM(1.25P)
3	22015	5	FLATWASHER,5/16"
4	21581	1	CAPSCREW,5/16" X 1-1/4",NC
5	21575	2	HEX NUT,5/16",NC
6	33478	1	ROD,THREADED,5/16" X 3"
7	06520040	3	BRKT,JD,POLY,RETAIN
8	6T2619	4	LOCKWASHER,8MM
9	21577	1	NYLOCK NUT,5/16",NC
10	06490035	1	POLYCARB,FRMD,PAN,JD6-7030
11	33477	1	VIBRATION ISOLATOR,5/16",NC
12	06530525	1	CAPSCREW,6MM X 40MM(1.0P),GR8.8
13	31034	1	SPACER,5/8"OD X 3/8"ID X 3/4"
14	06410269	1	BRKT,SFTY SCRNBOTTOM
15	06537005	1	ADHESIVE,WTHR STRP,BLK (NOT SHOWN)
16	22645	1	DECAL,POLYCARBONATE WINDOW (NOT SHOWN)

# SAFETY SCREEN, WOC




## SAFETY SCREEN, WOC

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34791	1	SAFETY SCREEN BRACKET,LOWER
2	32654	1	SAFETY SCREEN BRACKET,UPPER
3	32646	1	SAFETY SCREEN ASSEMBLY
4	32637	1	SAFETY SCREEN
5	32638	1	LEXAN WINDOW
6	21581	25	CAPSCREW,5/16" X 1 1/4" NC
7	22015	25	FLATWASHER,5/16"
8	21987	25	LOCKWASHER,5/16"
9	21575	25	HEX NUT,5/16" NC
10	21725	6	HEX NUT,1/2" NC
11	21990	6	LOCKWASHER,1/2"
12	21731	6	CAPSCREW,1/2" X 1 1/2" NC
13	21789	1	CAPSCREW,5/8" X 3 1/2" NC
14	21992	3	LOCKWASHER,5/8"
15	21775	3	HEX NUT,5/8" NC
16	21783	2	CAPSCREW,5/8" X 2"

# FRONT 50 GALLON TANK MOUNT




## FRONT 50 GALLON TANK MOUNT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06370204	1	MNT,TANK,FRNT,50 GALLON
2	06520342	1	TANK,50 GALLON
3	06520343	4	ANCHOR,STRAP
4	06520345	2	STRAP
5	06520344	4	BOLT & NUT,STRAP,TANK
6	21727	6	NYLOCK NUT,1/2",NC
7	06533004	12	FLATWASHER,1/2",SAE
8	21732	6	CAPSCREW,1/2" X 1-3/4",NC
9	06370203	1	MNT,TANK,RH
10	06370202	1	MNT,TANK,LH
11	33880	8	FLATWASHER,3/4",SAE
12	30708	8	CAPSCREW,20MM X 90MM,2.5P

## SAFETY LIGHT OPTION

1. Install marker light assembly onto the mounting bracket, running wires inside bracket tube.
2. Remove and retain panel under right rear fender that protects wiring.
3. Remove and discard back three screws and clips securing the right rear fender to the cab.
4. Install mounting bracket to points in previous step with three 1/4" x 3/4"NC bolts and nylock nuts.
5. Using the mounting bracket as a template to drill two holes (13/64 dia.) and tap(1/4"NC) in the wheel well (Note: Use caution not to drill into the filter housing located behind the cab).
6. Secure bottom of mounting Bracket to wheel well with two 1/4" x 3/4"NC bolts and lockwashers.
7. Next remove the top cover of the tractor cab.
8. Drill two holes 5/8" dia, one in the fender under the air duct at the right rear corner of the cab and the other at the right rear corner of the cab just inside the air duct.
9. Install grommets in the 5/8 " dia holes.
10. Route wire from mounting bracket into the area that will be covered by the panel removed in step 2, then through grommets and up into area above cab, install wires ends into connector shell and close strain relief (Note: Green wire to green wire when mated with adapter harness).
11. Splice the green wire from the adapter harness into the purple wire coming from right rear hazard light using heat shrink butt connector.
12. Splice the black wire from the adapter harness into the black wire coming from right rear hazard light using heat shrink butt connector.
13. Connect the adapter harness to the marker light harness.
14. Test for proper operation, the marker light should flash with hazards & right turn signal but should burn steady when left turn signal is in use.
15. Reinstall top cover of tractor cab and panel in fender to protect wiring.




## SAFETY LIGHT OPTION

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	06200420	-	SAFETY LIGHT KIT (ITEMS 1 THRU 6,8 & 9)
1	34800	1	MOUNT,ASAE 279.11
2	21529	5	CAPSCREW,1/4" X 3/4",NC
3	21527	3	NYLOCK NUT,1/4",NC
4	34859	1	MARKER LIGHT ASSY
5	21986	2	LOCKWASHER,1/4"
6	31592	2	GROMMET,RUBBER,5/16" X 13/16"
7	-----	1	ADAPTER,HARNESS
8	35164	2	CONNECTOR,BUTT,H-SHRINK
9	6T1824	2	ZIP TIE (NOT SHOWN)

# STEEL CANOPY



ITEM	PART NO.	QTY.	DESCRIPTION
1	6T6902A	1	CANOPY,STEEL
2	21725	6	HEX NUT,1/2",NC
3	21990	6	LOCKWASHER,1/2"
4	30085A	2	BRKT,CANOPY,STEEL,JD6000
5	30084B	2	SPACER,CANOPY
6	22018	6	FLATWASHER,1/2",WIDE
7	21732	6	CAPSCREW,1/2" X 1-3/4",NC



# COMMON TWIN ROTARY

## PARTS SECTION

# NOTES



# PART NAME INDEX

PARTS ORDERING GUIDE.....	5
CABLE DRAFT BEAM ASSEMBLY.....	6
COMBO DRAFT BEAM ASSEMBLY.....	8
60IN SIDE CABLE TM ROTARY MOWER.....	10
72IN SIDE CABLE TM ROTARY MOWER.....	12
60IN SIDE COMBO TM ROTARY MOWER.....	14
72IN SIDE COMBO TM ROTARY MOWER.....	16
60IN SIDE TSR ROTARY MOWER.....	18
60IN REAR TM ROTARY MOWER.....	20
60IN REAR TSR ROTARY MOWER.....	22
REAR ROTARY HYDRAULICS.....	24
60IN SIDE TM CHAIN GUARDS.....	26
72IN SIDE TM CHAIN GUARDS.....	28
60IN TSR REAR GUARDS.....	30
TM MOWER SPINDLE ASSEMBLY.....	32
TSR MOWER SPINDLE ASSEMBLY.....	34
ROTARY DISK AND KNIVES.....	36
NOTES.....	37
SIDE ROTARY CASTER WHEEL ASSEMBLY.....	38
60IN TM REAR CASTER WHEEL & 3PT ASSY.....	40
CASTER WHEEL ASSEMBLY.....	42
SAFETY STAND.....	43
3IN X 10IN HYDRAULIC CYLINDER BREAKDOWN.....	44
3IN X 12IN HYDRAULIC CYLINDER BREAKDOWN.....	45
3IN X 18IN HYDRAULIC CYLINDER BREAKDOWN.....	46
RESERVOIR TANK FILTER ASSEMBLY.....	47
ROTARY MOTOR BREAKDOWN.....	48
60IN TSR ROTARY MOTOR BREAKDOWN.....	50
FRONT HYDRAULIC PUMP BREAKDOWN.....	52
COOLER ASSEMBLY.....	54
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31320.....	56
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31321.....	58
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502043.....	60
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502044.....	62
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502087.....	64
CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502088.....	66
BRAKE VALVE ASSEMBLY.....	68
BRAKE VALVE HYDRAULIC SCHEMATIC.....	69
CABLE DRAFT BEAM TRAVEL LOCK.....	70
COMBO DRAFT BEAM TRAVEL LOCK.....	71

COMMON TWIN

# PART NAME INDEX


SWITCH BOX.....	72
SWITCH BOX SCHEMATIC.....	73
NOTES 1.....	74

## PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must indicate the **Name and Address** of the person or organization ordering the parts, **who should be charged**, and if possible, the **serial number of the machine** for which the parts are being ordered.
3. The purchase order must clearly list the **quantity of each part**, the complete and correct **part number**, and the basic **name of the part**.
4. The manufacturer reserves the right to substitute parts where applicable.
5. Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:

**Tiger Corporation**  
3301 N. Louise Ave.  
Sioux Falls, SD 57107  
1-800-843-6849  
1-605-336-7900

# CABLE DRAFT BEAM ASSEMBLY




## CABLE DRAFT BEAM ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	6T0105	-	DRAFT BEAM (STD WITH TRAVEL LOCK)
---	27241	-	DRAFT BEAM (EXTENDED 6")
2	6T0150	1	CYLINDER 3" X 18"
3	6T0151R	1	HYD. CYLINDER 3" X 10"
4	6T0100	1	LOWER SHEAVE BRACKET
5	6T0101	1	UPPER SHEAVE BRACKET
6	33768	2	SHEAVE
7	6T0110	1	LIFT CABLE (STD 1/2" X 87 1/2")
---	6T0110E	-	LIFT CABLE (EXTENDED 6")
8	6T0115	1	TURN BUCKLE
9	6T0112	1	SHACKLE WITH PIN
10	6T2999	1	OUTER DRAFT BEAM PIN 1 1/2" X 14 1/2"
11	6T3001	1	INNER DRAFT BEAM PIN 1 1/2" X 15 3/4"
12	6T3005	1	CYLINDER PIN 1" X 6 5/8"
13	TB1033	2	CLEVIS PIN 1" X 4"
14	6T3004	1	R - CLIP 3/16"
15	6T3010	1	UPPER SHEAVE PIN WITH ZERK 3/4" X 3"
16	6T3009	1	LOWER SHEAVE PIN WITH ZERK 3/4" X 2 1/2"
17	6T3020	2	R - CLIP 5/32"
18	6T2272	1	SET SCREW 3/8" X 1/2"
19	6T3211	1	GREASE ZERK 1/8" STRAIGHT
20	21837	1	CAPSCREW 3/4" X 3 1/4"
21	21688	2	CAPSCREW 7/16" X 3 1/4"
22	21825	2	HEX NUT 3/4"
23	21677	2	NYLOCK NUT 7/16"
24	22023	1	FLAT WASHER 1"
25	6T0104N	2	SHEAVE PIN BUSHING 1" OD X 3/4" ID
26	21833	1	CAPSCREW 3/4" X 2 1/4"
27	22021	1	FLAT WASHER 3/4"
28	21993	1	LOCK WASHER 3/4"
29	06537021	4	ROLL PIN
30	6T0106	1	TRAVEL LOCK BRACKET
31	6T4258	2	BREATHER 1/2"
32	34396	2	RESTRICTOR
33	34244	2	ELBOW FITTING 1/2"
34	-----	-	MAIN FRAME *REFER TO TRACTOR PARTS SECTION

COMMON TWIN

# COMBO DRAFT BEAM ASSEMBLY



## NOTES:

1. ITEM 30 IS USED ON THE GLAND END OF ITEM 2 (AS NEEDED)
2. ORIENTATION OF ITEMS 4,5 & 6 ARE CRITICAL




## COMBO DRAFT BEAM ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06350001	1	COMBO DRAFT BEAM - STD DTY ROTARY
---	31063	-	COMBO DRAFT BEAM - HVY DTY ROTARY
2	6T0151R	1	HYD. CYLINDER 3" X 10"
3	32215	1	HYD. CYLINDER 3" X 12" - STD DTY
---	25343	-	HYD. CYLINDER 3" X 12" - HVY DTY
4	TF4500A	1	PIVOT ARM
5	TF4507B	1	RIGHT LINKAGE ARM
6	TF4506B	1	LEFT LINKAGE ARM
7	30126B	2	PIN, HEAD PIVOT - STD DTY
---	TF4514A	-	PIN, HEAD PIVOT - HVY DTY
8	6T3001	1	PIN, BEAM PIVOT
9	TF4519	2	PIN, LINKAGE
10	TB1033	3	PIN, CLEVIS
11	06537021	6	ROLLPIN
12	6T3005	1	PIN, 1" W/ CAP
13	6T3004	1	R-CLIP HAIRPIN
14	6T2614	1	FLATWASHER 1"
15	TB3010	8	BUSHING 1"
16	22847	2	BOSS, LINKAGE PIN
17	22076	1	SPACER, HYD. CYLINDER 1/4"
18	22077	1	SPACER, HYD. CYLINDER 5/16"
19	6T3207	6	GREASE ZERK 1/4"
20	6T3211	3	GREASE ZERK 1/8"
21	6T4258	1	BREATHER 1/2"
22	34244	3	ELBOW FITTING 1/2"
23	34396	3	SWIVEL RESTRICTOR
24	21688	3	CAPSCREW 7/16" X 3 1/4"
25	21677	3	NYLOCK NUT 7/16"
26	21635	2	CAPSCREW 3/8" X 2 1/4"
27	21625	2	HEX NUT 3/8"
28	21831	1	CAPSCREW 3/4" X 1 3/4"
29	21825	1	HEX NUT 3/4"
30	06700095	1	CYLINDER SPACER W/SET SCREW
31	-----	-	MAIN FRAME *REFER TO TRACTOR MOUNT PAGE

COMMON TWIN

# 60IN SIDE CABLE TM ROTARY MOWER



COMMON TWIN


## 60IN SIDE CABLE TM ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	32099	1	RTRY, 60" DECK, CABLE
2	31773	1	GAURD,CHAIN,FRONT,SR60
3	6T1001	1	BRKT, MOTOR MTG, 60"SIDE RTRY
4	6T0820H	2	SKID SHOE, TM60
5	22592	1	FLAP, DEFLECTOR, TM60
6	6T0823	1	BAR, FLAP, TM60
7	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8" HOLES
8	21223	1	SPROCKET, 1-1/4" BORE
9	6T2277	6	CAPSCREW,3/4" X 2",NF
10	21993	6	LOCKWASHER,3/4",GR 8
11	6T2413	6	HEX NUT,3/4",NF,GR 8
12	6T2270	10	PLOW BOLT,3/8" X 1",NC
13	22016	29	FLATWASHER,3/8"
14	21625	29	HEX NUT,3/8",NC
15	21631	11	CAPSCREW, 3/8" X 1-1/4",NC
16	21783	4	CAPSCREW, 5/8" X 2",NC
17	21992	4	LOCKWASHER, 5/8"
18	21775	4	HEX NUT, 5/8"
19	25270	8	FLATWASHER,5/8",GR 8
20	6T0822	2	SHIM, MOTOR MOUNT, 14GA. (AS NEEDED)
21	6T0822A	2	SHIM, MOTOR MOUNT, 18 GA. (AS NEEDED)
22	6504011	1	MOTOR,(M365-2 1/4" GEAR)
23	6T1029	1	CHAIN, COUPLING
24	6T1033	1	COVER, COUPLING
25	21733	4	CAPSCREW, 1/2" X 2",NC
26	21990	4	LOCKWASHER,1/2"
27	21725	4	HEX NUT, 1/2",NC
28	21632	8	CAPSCREW,3/8" X 1-1/2",NC
29	21988	8	LOCKWASHER,3/8"
30	21727	1	NYLOCK NUT,1/2",NC
31	27005	1	SPRING,PUSHOFF,SIDE RTRY
32	22018	1	FLATWASHER,1/2",WIDE
33	21745	1	CAPSCREW,1/2" X 7",NC
34	6T3211	1	GREASE ZERK

COMMON TWIN

72IN SIDE CABLE TM ROTARY MOWER



COMMON TWIN


## 72IN SIDE CABLE TM ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	21225B	1	RTRY,72" DECK, CABLE
2	31931	1	GUARD,CHAIN,FRONT,SR72
3	6T1001	1	BRKT, MOTOR MTG, 60"SIDE RTRY
4	21248	2	SKID SHOE, TM72
5	21295B	1	FLAP, DEFLECTOR, TM72
6	21242A	1	BAR, FLAP, TM72
7	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8" HOLES
8	21223	1	SPROCKET, 1-1/4" BORE
9	6T2277	6	CAPSCREW,3/4" X 2",NF
10	21993	6	LOCKWASHER,3/4",GR 8
11	6T2413	6	HEX NUT,3/4",NF,GR 8
12	6T2270	10	PLOW BOLT,3/8" X 1",NC
13	22016	29	FLATWASHER,3/8"
14	21625	29	HEX NUT,3/8",NC
15	21631	11	CAPSCREW, 3/8" X 1-1/4",NC
16	21783	4	CAPSCREW, 5/8" X 2",NC
17	21992	4	LOCKWASHER, 5/8"
18	21775	4	HEX NUT, 5/8"
19	25270	8	FLATWASHER,5/8",GR 8
20	6T0822	2	SHIM, MOTOR MOUNT, 14GA. (AS NEEDED)
21	6T0822A	2	SHIM, MOTOR MOUNT, 18 GA. (AS NEEDED)
22	06504011	1	MOTOR,(M365-2 1/4" GEAR)
23	6T1029	1	CHAIN, COUPLING
24	6T1033	1	COVER, COUPLING
25	21733	4	CAPSCREW, 1/2" X 2",NC
26	21990	4	LOCKWASHER,1/2"
27	21725	4	HEX NUT, 1/2",NC
28	21632	8	CAPSCREW,3/8" X 1-1/2",NC
29	21988	8	LOCKWASHER,3/8"
30	21727	1	NYLOCK NUT,1/2",NC
31	27005	1	SPRING,PUSHOFF,SIDE RTRY
32	22018	1	FLATWASHER,1/2",WIDE
33	21745	1	CAPSCREW,1/2" X 7",NC
34	6T3211	1	GREASE ZERK

COMMON TWIN

# 60IN SIDE COMBO TM ROTARY MOWER



COMMON TWIN


## 60IN SIDE COMBO TM ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	30087D	1	RTRY, 60" DECK, COMBO - STD DUTY
---	32617	1	RTRY, 60" DECK, COMBO - HVY DUTY
2	31773	1	GAURD,CHAIN,FRONT,SR60
3	6T1001	1	BRKT, MOTOR MTG, 60"SIDE RTRY
4	6T0820H	2	SKID SHOE, TM60
5	22592	1	FLAP, DEFLECTOR, TM60
6	6T0823	1	BAR, FLAP, TM60
7	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8" HOLES
8	21223	1	SPROCKET, 1-1/4" BORE
9	6T2277	6	CAPSCREW,3/4" X 2",NF
10	21993	6	LOCKWASHER,3/4",GR 8
11	6T2413	6	HEX NUT,3/4",NF,GR 8
12	6T2270	10	PLOW BOLT,3/8" X 1",NC
13	22016	29	FLATWASHER,3/8"
14	21625	29	HEX NUT,3/8",NC
15	21631	11	CAPSCREW, 3/8" X 1-1/4",NC
16	21783	4	CAPSCREW, 5/8" X 2",NC
17	21992	4	LOCKWASHER, 5/8"
18	21775	4	HEX NUT, 5/8"
19	25270	8	FLATWASHER,5/8",GR 8
20	6T0822	2	SHIM, MOTOR MOUNT, 14GA. (AS NEEDED)
21	6T0822A	2	SHIM, MOTOR MOUNT, 18 GA. (AS NEEDED)
22	06504011	1	MOTOR,(M365-2 1/4" GEAR)
23	6T1029	1	CHAIN, COUPLING
24	6T1033	1	COVER, COUPLING
25	21733	4	CAPSCREW, 1/2" X 2",NC
26	21990	4	LOCKWASHER,1/2"
27	21725	4	HEX NUT, 1/2",NC
28	21632	8	CAPSCREW,3/8" X 1-1/2",NC
29	21988	8	LOCKWASHER,3/8"

COMMON TWIN

# 72IN SIDE COMBO TM ROTARY MOWER



COMMON TWIN




## 72IN SIDE COMBO TM ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34260	1	RTRY, 72" DECK, COMBO - STD DUTY
---	31408A	1	RTRY, 72" DECK, COMBO - HEAVY DUTY
2	31931	1	GUARD,CHAIN,FRONT,SR72
3	6T1001	1	BRKT, MOTOR MTG, 60"SIDE RTRY
4	21248	2	SKID SHOE, TM72
5	21295B	1	FLAP, DEFLECTOR, TM72
6	21242A	1	BAR, FLAP, TM72
7	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8" HOLES
8	21223	1	SPROCKET, 1-1/4" BORE
9	6T2277	6	CAPSCREW,3/4" X 2",NF
10	21993	6	LOCKWASHER,3/4",GR 8
11	6T2413	6	HEX NUT,3/4",NF,GR 8
12	6T2270	10	PLOW BOLT,3/8" X 1",NC
13	22016	29	FLATWASHER,3/8"
14	21625	29	HEX NUT,3/8",NC
15	21631	11	CAPSCREW, 3/8" X 1-1/4",NC
16	21783	4	CAPSCREW, 5/8" X 2",NC
17	21992	4	LOCKWASHER, 5/8"
18	21775	4	HEX NUT, 5/8"
19	25270	8	FLATWASHER,5/8",GR 8
20	6T0822	2	SHIM, MOTOR MOUNT, 14GA. (AS NEEDED)
21	6T0822A	2	SHIM, MOTOR MOUNT, 18 GA. (AS NEEDED)
22	06504011	1	MOTOR,(M365-2 1/4" GEAR)
23	6T1029	1	CHAIN, COUPLING
24	6T1033	1	COVER, COUPLING
25	21733	4	CAPSCREW, 1/2" X 2",NC
26	21990	4	LOCKWASHER,1/2"
27	21725	4	HEX NUT, 1/2",NC
28	21632	8	CAPSCREW,3/8" X 1-1/2",NC
29	21988	8	LOCKWASHER,3/8"

COMMON TWIN

# 60IN SIDE TSR ROTARY MOWER



COMMON TWIN


## 60IN SIDE TSR ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34975	1	HEAVY DUTY GRASSKAT COMBO
---	06320005	1	STD DUTY GRASSKAT COMBO
----	06320008	1	HEAVY DUTY GRASSKAT CABLE
2	34980	1	SPINDLE ASSY,TM 60"
3	06504016	1	CURRENT MOTOR,(M365-1 1/4" 14-SPLINE)
4	06410254	2	SKID,OUTBOARD,TM60
5	22992	156	CHAIN,10 LINK
6	6T2270	14	PLOW BOLT,3/8" X 1" NC
7	22016	26	FLATWASHER,3/8"
8	21625	30	HEX NUT,3/8",NC
9	06320011	2	SPACER,TSF,SPINDLE
10	6T1025	4	CAPSCREW, 1/2 X 2,GR 8,NC
11	06533006	4	FLATWASHER,1/2,SAE,GR 8
12	06370029	1	TIRE GUARD, LEFT
13	21725	8	HEX NUT, 1/2",NC
14	21990	8	LOCKWASHER, 1/2"
15	22018	8	FLATWASHER, 1/2",WIDE
16	21731	4	CAPSCREW, 1/2" X 1-1/2" NC
17	21732	4	CAPSCREW, 1/2" X 1-3/4" NC
18	21745	1	NYLOCK NUT, 1/2
19	21727	1	SPRING, PUSHOFF, SIDE RTRY
20	27005	1	CAPSCREW, 1/2 X 7,NC
21	22018	1	FLATWASHER,1/2",WIDE
22	34972	4	PLATE,CAP,CHAIN
23	21631	16	CAPSCREW, 3/8 X 1-1/4,NC
24	21988	16	LOCKWASHER, 3/8"
25	34974	2	ROD,CHAIN,INNER,TM60
26	34973	2	ROD,CHAIN,OUTER,TM60

COMMON TWIN

# 60IN REAR TM ROTARY MOWER




## 60IN REAR TM ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	23003	-	REAR RTRY, 60" W/REAR CHAINS
1	32616	1	RTRY, 60" DECK, TRR
2	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8 HOLES
3	6T2277	6	CAPSCREW, 3/4" X 2" NF
4	21993	6	LOCKWASHER,3/4",GR 8
5	6T2413	6	HEX NUT,3/4",NF,GR 8
6	-----	-	DISK *REFER TO DISK & KNIVES PAGE
7	6T1001	1	BRKT, MOTOR MTG, 60"
8	21223	1	SPROKET, 1-1/4" BORE
9	6T1033	1	COVER, COUPLING
10	6T0822	2	SHIM, MOTOR MOUNT, 14GA. (AS NEEDED)
11	6T0822A	2	SHIM, MOTOR MOUNT, 18 GA. (AS NEEDED)
12	6T1029	1	CHAIN, COUPLING
13	21783	4	CAPSCREW, 5/8" X 2",NC
14	25270	8	FLATWASHER,5/8", GR 8
15	21992	10	LOCKWASHER, 5/8"
16	21775	4	HEX NUT, 5/8"
17	23160A	2	SKID SHOE
18	6T2270	12	PLOW BOLT,3/8" X 1" NC
19	22016	21	FLATWASHER,3/8"
20	21625	21	HEX NUT,3/8",NC
21	22993	71	CHAIN, 5/16" GR30, 9 LINK
22	22054	2	ROD, CHAIN HOLDER
23	6T3028	2	COTTER PIN, 1/8" X 1"
24	06504011	1	MOTOR, (M365 - 2" GEAR)
25	21733	4	CAPSCREW, 1/2" X 2",NC
26	21990	16	LOCKWASHER, 1/2"
27	21725	16	HEX NUT, 1/2" NC
28	33656	2	PLATE,GUARD,SAFETY,REAR,RTRY
29	6T2267	12	CARRIAGE BOLT, 1/2" X 2" NF, GR8
30	33655	2	PLATE,GAURD,SAFETY,FRONT, RTRY
31	6T2290	6	CAPSCREW,5/8" X 2",NF GR 8
32	24347	1	REAR DEFLECTOR FLAP
33	24349	1	FLAP MOUNTING BAR
34	21631	9	CAPSCREW, 3/8" X 1-1/4" NC
35	22992	71	CHAIN, 5/16" GR30, 10 LINK
36	22054	2	ROD, CHAIN HOLDER
37	6T3028	2	COTTER PIN, 1/8" X 1"
38	22016	2	FLATWASHER,3/8"

COMMON TWIN

# 60IN REAR TSR ROTARY MOWER



ITEM	PART NO.	QTY.	DESCRIPTION
---	06741023	-	60IN TSR REAR MOWER ASSY
1	06320002	1	TRAILKAT®,60,WLDMNT
2	6T0112	2	SHACKLE,W/PIN,CPLT
3	22051	1	CABLE,LIFT,TRR,60

COMMON TWIN


## 60IN REAR TSR ROTARY MOWER

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
4	06520425	2	PIN
5	06537021	4	ROLLPIN,5MM X 50MM,SS
6	21474A	1	HITCH,3PT,TRR
7	28511	1	STAND,SAFETY SUPPORT W/PAD
8	23329	1	CASTER WHL,SOLID TIRE W/SPIND
9	22057	1	SPINDLE,CASTER AXLE,ASSY
10	22018	2	FLATWASHER,1/2,WIDE
11	21725	2	HEX NUT,1/2,NC
12	6T3211	1	GREASE ZERK,1/8
13	06370003	1	CASTER ADJ,TRAILKAT
14	06504016	1	MOTOR,M365-1 1/4",SPLINE,SEALED
15	6T1025	4	CAPSCREW,1/2 X 2,NC,GR8
16	06533004	12	FLATWASHER,1/2,SAE,GR8
17	21738	2	CAPSCREW,1/2 X 3-1/4,NC
18	06370004	1	CASTER MNT,TRAILKAT
19	21700	4	HEX NUT,1/2,NF
20	21990	4	LOCKWASHER,1/2
21	06420003	2	U-BOLT,.50 X 3.25 X 5.00
22	21625	20	HEX NUT,3/8,NC
23	21988	6	LOCKWASHER,3/8
24	21631	2	CAPSCREW,3/8 X 1-1/4,NC,GR8
25	34972	2	PLATE,CAP,CHAIN
26	34974	1	ROD,CHAIN,INNER,TM60
27	06420005	2	U-BOLT,.38 X 5.63 X 6.31
28	34973	1	ROD,CHAIN,OUTER,TM60
29	06410254	2	SKID SHOE,TSR
30	22992	78	CHAIN,10 LINK
31	33698	2	PIN,1.13 X 9.00
32	33699	2	PIN,1 X 8.88
33	TF1143	4	LYNCH PIN
34	34980	1	SPINDLE ASSY,TM60
35	06320011	2	SPACER,TSR,SPINDLE
36	06530221	8	CAPSCREW,1/2 X 2-1/4,NF,GR8
37	-----	-	DISK *REFER TO DISK & KNIVES PAGE
38	25270	6	FLATWASHER,5/8",USS,GR8
39	6T2290	6	CAPSCREW,5/8" X 2",NF,GR8
40	6T2270	14	PLOW BOLT,3/8" X 1",NC
41	22016	14	FLATWASHER,3/8",GR8

COMMON TWIN

# REAR ROTARY HYDRAULICS





## REAR ROTARY HYDRAULICS


Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	REAR ROTARY MOWER
2	06510083	1	VALVE,BRAKE,SOL,3000PSI,METRI
3	33555	4	ADAPTER,1MORB X 1MJIC (3 FOR TSR)
---	33554	1	ELBOW,1MORB X 1MJIC,45 (TSR PRESSURE TO MOTOR)
4	TF4852	2	KIT, FLANGE, #20
5	34198	1	HOSE, 1" X 40" (TM MOWER RETURN)
---	06500087	-	HOSE, 1" X 42" (TSR MOWER RETURN)
6	34197	1	HOSE, 1" X 33" (TM MOWER PRESSURE)
---	06500086	-	HOSE, 1" X 24" (TSR MOWER PRESSURE)
7	21644	2	CAPSCREW,3/8" X 5" NC
8	21625	2	HEX NUT,3/8",NC
9	22016	2	FLATWASHER,3/8"
10	21988	1	LOCKWASHER, 3/8"
11	6T2665	1	STAR LOCKWASHER, 3/8"
12	-----	1	HOSE (RETURN)
13	-----	1	HOSE (PRESSURE)
14	33930	1	HOSE SLEEVE, TRR
15	6T1823	2	ZIP TIE, 14" STRAPS


COMMON TWIN

60IN SIDE TM CHAIN GUARDS

STANDARD FRONT CHAIN GUARD



OPTIONAL REAR CHAIN GUARD



## 60IN SIDE TM CHAIN GUARDS


Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	31773	-	GUARD,CHAIN,TM60,FRONT,ASSY
1	31762	1	GUARD,CHAIN,TM60,FRONT
2	28407	12	CABLE,5/16",BULK (QTY IN FEET)
3	22993	77	CHAIN,5/16",GR30,9 LINK
4	28408	4	U-BOLT,CABLE,5/16" (NOT SHOWN)
---	31774	-	GUARD,CHAIN,TM60,REAR,ASSY
5	31763	1	GUARD,CHAIN,TM60,REAR
6	31879	1	ROD,SHORT,TM60
7	31878	1	ROD,LONG,TM60
8	22016	2	FLATWASHER,3/8",GR8
9	6T3028	2	COTTER PIN,1/8" X 1"
10	22992	69	CHAIN,5/16",GR30,10 LINK


COMMON TWIN

# 72IN SIDE TM CHAIN GUARDS

STANDARD FRONT CHAIN GUARD



OPTIONAL REAR CHAIN GUARD



## 72IN SIDE TM CHAIN GUARDS


Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	31931	-	GUARD,CHAIN,TM72,FRONT,ASSY
1	31863	1	GUARD,CHAIN,TM72,FRONT
2	28407	14	CABLE,5/16",BULK (QTY IN FEET)
3	22993	91	CHAIN,5/16",GR30,9 LINK
4	28408	4	U-BOLT,CABLE,5/16" (NOT SHOWN)
---	31932	-	GUARD,CHAIN,TM60,REAR,ASSY
5	31864	1	GUARD,CHAIN,TM60,REAR
6	31934	1	ROD,LONG,TM72
7	31933	1	ROD,SHORT,TM72
8	22016	2	FLATWASHER,3/8",GR8
9	6T3028	2	COTTER PIN,1/8" X 1"
10	22992	83	CHAIN,5/16",GR30,10 LINK


COMMON TWIN

# 60IN TSR REAR GUARDS

OPTIONAL REAR CHAIN GUARD



STANDARD SQUARE REAR FLAP GUARD




## 60IN TSR REAR GUARDS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	34973	2	ROD,CHAIN,OUTER,TM60
2	34974	2	ROD,CHAIN,INNER,TM60
3	21631	16	CAPSCREW, 3/8 X 1-1/4,NC
4	34972	4	PLATE,CAP,CHAIN
5	21625	30	HEX NUT,3/8",NC
6	21988	16	LOCKWASHER, 3/8"
7	22992	156	CHAIN,10 LINK
20	06410947	1	MNT,FLAP,RH,EXT,TSR
21	06401184	2	STRAP,FLAP,EXT,TSR
22	06410948	1	COVER,FLAP,EXT,TSR
23	21632	10	CAPSCREW,3/8" X 1-1/2" NC
24	22016	20	FLATWASHER,3/8",GR8
25	06410946	1	MNT,FLAP,LH,EXT,TSR
26	21580	6	CAPSCREW,5/16 X 1 NC
27	22015	12	FLATWASHER,5/16
28	21577	6	NYLOCK NUT, 5/16,NC
29	21625	10	HEX NUT,3/8",NC
30	06520331	2	FLAP,EXT,TSR

COMMON TWIN

# TM MOWER SPINDLE ASSEMBLY



## NOTES:

1. FREEPLAY: .001" - .003"
2. GREASE: FILL WITH MOBILITH SHC 220.
3. APPLY LOCTITE "271" TO O-RING PLUG THRDS.




## TM MOWER SPINDLE ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	6T1024H5	-	SPINDLE ASSEMBLY COMPLETE
1	6T1031	1	SPROCKET
2	6T1016	1	BEARING LOCK NUT - THICK
3	22596	1	JAM WASHER
4	6T1015	1	BEARING ADJUSTMENT NUT - THIN
5	6T1014	1	BEARING ADJUSTMENT SLEEVE
6	6T1011	1	UPPER SEAL - SET OF 2
7	6T1012	1	BEARING CONE
8	6T1013	1	BEARING CUP
9	6T1010H	1	SPINDLE HOUSING
10	30570	1	FITTING STREET ELBOW
11	33990	1	GREASE ZERK
12	6T1013H	1	BEARING CUP
13	6T1012H	1	BEARING CONE
14	6T1011H	1	LOWER SEAL
15	6T1019	1	SPINDLE KEY
16	PT1018H-5	1	SPINDLE
17	06503064	1	O-RING PLUG, 1/8"
---	31771	-	SPINDLE REBUILD KIT (INCLUDES ITEMS 2 - 8 AND 12 - 15)

COMMON TWIN

# TSR MOWER SPINDLE ASSEMBLY



**NOTES:**

1. FREEPLAY: .001" - .003"
2. GREASE: FILL WITH MOBILITH SHC 220.
3. APPLY LOCTITE "271" TO O-RING PLUG THRDS.


## TSR MOWER SPINDLE ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	34980	-	SPINDLE ASSEMBLY COMPLETE
1	34978	1	SPINDLE MOUNT
2	34979	1	SPINDLE,TM60
3	6T1013	1	BEARING CUP
4	6T1012	1	BEARING CONE
5	6T1011	1	UPPER SEAL - SET OF 2
6	6T1014	1	BEARING ADJUSTMENT SLEEVE
7	6T1013H	1	BEARING,CUP,HD
8	6T1012H	1	BEARING CONE,HD
9	6T1011H	1	SEAL,LOWER,HD
10	34985	1	NUT W/SETSCREW
11	6T2275	1	SETSCREW,5/16" X 1/2",NC
12	34988	1	RELIEF,1PSI,1/8" NPT
13	6T3207	1	ZERK,1/4" X STR
14	06503064	1	O-RING PLUG, 1/8"

COMMON TWIN

## ROTARY DISK AND KNIVES




ITEM	PART NO.	QTY.	DESCRIPTION
1	34876	1	BLADE MOUNTING DISK
2	6T1023R	2	NYLOCK NUT,1-1/8"
3	34878	2	SPACER
4	34497	2	KNIFE MOUNTING BOLT
5	34685	2	KNIFE,60" HIGH SUCTION - STANDARD
5A	34684	2	KNIFE,60" - OPTIONAL
6	34682	2	KNIFE 72" (MOUNT ON 72" MOWER ONLY)
7	25270	6	FLATWASHER,5/8",USS,GR8
8	6T2259	6	CAPSCREW,5/8" X 1-3/4",NF
----	6T1825	-	LOCTITE - USED ON ALL DISK MOUNTING BOLTS
---	27167	-	BOLT KIT (INCLUDE ITEMS 7 & 8)
----	06700002	-	KIT,60/72,DISK,KNF MTG (INCLUDE ITEM 1, 3,7 & 8)

COMMON TWIN

**NOTES**

**NOTES**

# SIDE ROTARY CASTER WHEEL ASSEMBLY




## SIDE ROTARY CASTER WHEEL ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	25214C	1	FRAME,CASTER,WHL (TM60)
---	28297A	-	FRAME,CASTER WHL (TM72)
2	22057	1	SPINDLE,CASTER AXLE,ASSY
3	6T2617	2	BUSHING,MACH,1-1/2IDX 2-1/4OD
4	28548	1	CASTER WHEEL,SOLID TIRE
---	22065	1	HUB,ASSY,CASTER
----	22066	1	HUB,CASTER
---	22070	1	DUST CAP
----	22071	5	HUB STUD
---	22073	1	HEX NUT,1",NF (SLOTTED)
----	22533	1	COTTER PIN,3/16" X 2"
---	6T0830	2	BEARING,CONE,CASTER WHEEL
----	6T0838	1	SEAL
---	23329	1	WHEEL,CPLT,SOLID TIRE
----	21416	1	TIRE,SOLID
---	22697	1	RIM,OUTER
----	22696	1	RIM,CASTER
5	6T3014	1	ROLL PIN,1/4" X 2"
6	21925	4	HEX NUT,1",NC
7	22023	5	FLATWASHER,1"
8	22753	1	TUBE,PROTECTOR
9	22058	1	SPRING,REAR RTRY
10	22059B	1	ADJ ROD,TRR
11	21775	2	HEX NUT,5/8"
12	21992	2	LOCKWASHER,5/8"
13	21782	2	CAPSCREW,5/8" X 1-3/4",NC
14	22060	2	CASTER FRAME PIN
15	TF1143	2	PIN,LYNCH,7/16" X 2"
16	TB3010	2	BUSHING,1"
17	-----	1	RTRY,CPLT,TM
18	6T3207	2	GREASE ZERK,1/4" X STR
19	6T3211	1	GREASE ZERK,1/8" X STR
20	21441	2	CASTER FRAME ANCHOR (TM60)
---	42527	2	CASTER FRAME ANCHOR (TM72)
21	21442	2	CASTER FRAME ANCHOR (TM60)
---	42527	2	CASTER FRAME ANCHOR (TM72)

COMMON TWIN

# 60IN TM REAR CASTER WHEEL & 3PT ASSY






**60IN TM REAR CASTER WHEEL & 3PT ASSY**

**Continued...**

<b>ITEM</b>	<b>PART NO.</b>	<b>QTY.</b>	<b>DESCRIPTION</b>
1	-----	-	MOWER,REAR,60IN,TM
2	21474A	1	HITCH, 3PT, TRR
3	22059B	1	ADJ ROD, TRR
4	25095A	1	FRAME, CASTER WHEEL, TRR 60"
5	22057	1	SPINDLE, CASTER AXLE, ASSY
6	21925	4	HEX NUT,1" NC
7	22023	5	FLATWASHER,1"
8	22058	1	SPRING, REAR RTRY
9	22753	1	TUBE, PROTECTOR
10	6T3014	1	ROLL PIN, 1/4" X 2"
11	22060	2	CASTER FRAME PIN
12	TB3010	2	BUSHING,1"
13	TF1143	6	PIN, LYNCH, 7/16" X 2"
14	28548	1	CASTER WHEEL, SOLID TIRE
15	6T0112	2	SHACKLE, W/PIN, CPLT
16	22051	1	CABLE, LIFT, TRR, 60"
17	6T3207	2	GREASE ZERK,1/4" X STR
18	6T3211	1	GREASE ZERK,1/8" X STR
19	33698	2	PIN, CAPPED, 1-1/8" X 9"
20	33699	2	PIN, CAPPED, 1" X 9"
21	6T2617	6	BUSHING,MACH,1-1/2IDX 2-1/4OD
22	21782	2	CAPSCREW, 5/8 X 1 3/4,NC
23	21992	2	LOCKWASHER, 5/8
24	21775	2	HEX NUT, 5/8

COMMON TWIN


## CASTER WHEEL ASSEMBLY



ITEM	PART NO.	QTY.	DESCRIPTION
1	22057	1	SPINDLE,CASTER AXLE,ASSY
2	21987	5	LOCKWASHER,5/16"
3	21575	5	HEX NUT,5/16"
4	28548	5	CAPSCREW,5/16" X 3/4",NC
5	22697	1	RIM,OUTER,CASTER ASSY
6	21416	1	TIRE,SOLID
7	22696	1	RIM,CASTER WHEEL
8	22070	1	DUST CAP
9	22533	1	COTTER PIN,3/16" X 2"
10	6T0836	2	CUP,CASTER WHEEL
11	22073	1	HEX NUT,1",NF (SLOTTED JAM NUT)
12	22071	5	HUB STUD
13	22066	1	HUB,CASTER WHEEL

COMMON TWIN


# SAFETY STAND



ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	REAR RTRY - REFER TO REAR RTRY DECK ASSY
2	28511	1	REAR RTRY STAND
3	06520425	2	PIN
4	6T3014	3	ROLL PIN, 1/4" X 2"
5	6T3004	1	R-CLIP (HAIRPIN COTTER, 3/16")

COMMON TWIN


## 3IN X 10IN HYDRAULIC CYLINDER BREAKDOWN



ITEM	PART NO.	QTY.	DESCRIPTION
---	6T0151R	-	HYD. CYLINDER 3" X 10"
1	6T0167	1	CYLINDER BUTT
2	6T0170	1	CYLINDER GLAND
3	6T0178	1	CLEVIS END
4	6T0164	1	CYLINDER TUBE
5	6T0161	1	PISTON ROD
6	6T0173	1	PISTON
7	6T0179	1	LOCKNUT
8	6T0176	4	TIE ROD ASY
---	6T0187	-	SEAL KIT
9	-----	2	O - RING
10	-----	2	BACK - UP WASHER
11	-----	1	O - RING
12	-----	2	BACK - UP WASHER
13	-----	1	O - RING
14	-----	1	U - CUP
15	-----	1	WIPER

COMMON TWIN


## 3IN X 12IN HYDRAULIC CYLINDER BREAKDOWN



ITEM	PART NO.	QTY.	DESCRIPTION
----	32215	-	HYD. CYLINDER 3" X 12" (STD DUTY)
---	25343	-	HYD. CYLINDER 3" X 12" (HVY DUTY)
1	6T0167	1	CYLINDER BUTT
2	6T0170	1	CYLINDER GLAND
3	6T0178	1	CLEVIS END
4	6T0204	1	CYLINDER TUBE
5	6T0203	1	PISTON ROD
6	6T0173	1	PISTON
7	6T0179	1	LOCKNUT
8	6T0205	4	TIE ROD ASY
---	6T0187	-	SEAL KIT
9	-----	2	O - RING
10	-----	2	BACK - UP WASHER
11	-----	1	O - RING
12	-----	2	BACK - UP WASHER
13	-----	1	O - RING
14	-----	1	U - CUP
15	-----	1	WIPER

COMMON TWIN


## 3IN X 18IN HYDRAULIC CYLINDER BREAKDOWN



ITEM	PART NO.	QTY.	DESCRIPTION
---	6T0150	-	CYLINDER 3" X 18"
1	6T0167	1	CYLINDER BUTT
2	6T0170	1	CYLINDER GLAND
3	6T0178	1	CLEVIS END
4	6T0165	1	CYLINDER TUBE
5	6T0162	1	PISTON ROD
6	6T0173	1	PISTON
7	6T0179	1	LOCKNUT
8	6T0177	4	TIE ROD ASY
---	6T0187	-	SEAL KIT
9	-----	2	O - RING
10	-----	2	BACK - UP WASHER
11	-----	1	O - RING
12	-----	2	BACK - UP WASHER
13	-----	1	O - RING
14	-----	1	U - CUP
15	-----	1	WIPER
16	6T0206	1	SPACER

COMMON TWIN


## RESERVOIR TANK FILTER ASSEMBLY



ITEM	PART NO.	QTY.	DESCRIPTION
---	06505044	-	FILTER ASSY SAE 10 MICRON
1	28583	4	CAPSCREW, 8MM X 25MM(1.25 PITCH)
2	06505045	1	COVER
3	06505046	1	SEAL KIT
4	06505047	1	SPRING
5	06505048	1	BYPASS
6	35259	1	FILTER, 10 MIC, RETURN LINE
7	06505049	1	CAN/BODY

COMMON TWIN

# ROTARY MOTOR BREAKDOWN



COMMON TWIN




## ROTARY MOTOR BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
	06504011	-	MOTOR ASSEMBLY
1	22790	1	END,COVER
2	06504088	1	HOUSING, PEC
3	06504111	1	HOUSING, GEAR
4	06504026	1	SET, GEAR SHAFT
5	06504104	4	CAPSCREW
6	06504078	2	SCREW, DRIVE
7	06504092	1	KEY
8	06504093	4	PIN, DOWEL
9	06504094	1	NAME PLATE
10	06504095	2	THRPL
11	2961940	1	PLUG, ODT
12	2962200	1	RING, SNAP
13	06504096	1	O RING
14	6T5101	1	SEAL, LIP
15	06504097	1	SEAL, LIP
16	22797	2	SEAL, SQ-R
17	06504098	4	SEAL, SIDE CHAN
18	06504099	4	SEAL, END CHAN
19	06504100	2	SEAL, BK-UP
20	06504101	1	RTNR, SEAL
21	6T5809	2	CHECK ASS'Y
22	06504102	4	WASHER
---	06504103	-	SEAL KIT

COMMON TWIN

# 60IN TSR ROTARY MOTOR BREAKDOWN



COMMON TWIN


## 60IN TSR ROTARY MOTOR BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
	06504016	-	MOTOR(M365-1 1/4SPLINE),SEALED
1	22790	1	COVER,END
2	06504088	1	HOUSING,PEC
3	06504111	1	HOUSING,GEAR
4	06504110	1	SET,GEAR SHAFT
5	06504104	4	CAP SCREW
6	06504078	2	SCREW,DRIVE
7	06504093	4	PIN,DOWEL
8	06504094	1	NAME PLATE
9	06504095	2	THRPL
10	02961940	1	PLUG,ODT (0.25)
11	6T5200	1	RING,SNAP
12	06504097	1	SEAL,LIP
13	22797	2	SEAL,SQ-R
14	06504098	4	SEAL,SIDE CHAN
15	06504099	4	SEAL,END CHAN
16	06504100	2	SEAL,BK-UP
17	06504112	1	SPACER
18	06504113	1	RTNR,SEAL
19	6T5809	2	CHECK ASS'Y
20	06504102	4	WASHER
---	06504022	1	SEAL KIT

COMMON TWIN

# FRONT HYDRAULIC PUMP BREAKDOWN




## FRONT HYDRAULIC PUMP BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
---	06504002	1	PUMP,ASSY
1	22766	1	HOUSING,SEC
2	06504068	1	HOUSING,PEC
3	02965092	2	HOUSING,GEAR
4	06504069	1	HOUSING,BEARING CARRIER
10	06504070	1	SET,GEARSHAFT
12	06504071	1	GEAR,SET
15	02961917	4	WASHER
16	06504072	4	STUD
17	06504073	4	NUT,HEX
21	22765	1	SEAL,LIP
22	6T5121	1	PLUG
23	02979970	1	SPACER
24	02979971	1	RING,SNAP
26	02965611	4	THRPL
27	06504074	4	SEAL,CHAN
28	06504075	4	SEAL,BK-UP
29	06504076	4	SEAL,SQ-R
30	02961924	8	PIN,DOWEL
31	06504077	1	NAMEPLATE
32	06504078	2	SCREW,DRIVE
36	06504079	1	SFT,CONN
---	22764	1	SEAL KIT (ITEMS 21, 27, 28 & 29)

COMMON TWIN

# COOLER ASSEMBLY




## COOLER ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	21530	10	CAPSCREW,1/4 X1 NC
2	21986	10	LOCKWASHER,1/4
3	22014	10	FLATWASHER,1/4
4	35176	10	1/4 U-NUT
5	06370015	1	SCREEN,COOLER,FRNT
6	06380006	1	MNT,COOLER,BUMPER TANK,RH
7	06380007	1	MNT,COOLER,BUMPER TANK,LH
8	06510026	1	COOLER,FRONT MNT
---	06510029	1	FAN ASSY ONLY
9	21629	4	CAPSCREW,3/8 X 3/4 NC
10	21988	4	LOCKWASHER,3/8
11	22016	4	FLATWASHER,3/8
12	34117	2	ELBOW,1MOR X 1MJ90,FORGED

COMMON TWIN

# CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31320



COMMON TWIN




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31320

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31595	1	INLET END COVER
2	31594	1	END COVER, LOAD SENSE
3	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
4	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
5	06503067	1	RELIEF PLUG
6	06503067	1	RELIEF PLUG
7	N/A	-	N/A
8	6T4209	1	RELIEF PLUG
9	31862	1	RELIEF VALVE, 2175 PSI
10	31862	1	RELIEF VALVE, 2175 PSI
11	31593	2	VALVE SEAL KIT (FOR ONE SECTION)
11A	-----	2	WIPER
11B	-----	2	O-RING SMALL
11C	-----	1	O-RING LARGE
11D	-----	1	SHUTTLE DISC
11E	-----	1	SPRING
12	TB1017L	2	LEVER KIT (FOR ONE SECTION)
12A	-----	1	LEVER KNOB
12B	-----	1	LEVER
12C	-----	2	LEVER WASHER
12D	-----	1	LEVER CLIP
12E	-----	2	LINKAGE
12F	-----	1	LEVER PIN
12G	-----	1	ROLL PIN
12H	-----	1	LEVER BOOT
12J	-----	1	LEVER BOLT
12K	-----	1	LEVER DUST COVER
12L	-----	1	LEVER NUT
13	31603	2	COMPENSATOR
14	TB1017X	1	TIE ROD KIT
15	24214	1	O-RING, LARGE

COMMON TWIN

CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31321




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 31321

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31595	1	INLET END COVER
2	31594	1	END COVER, LOAD SENSE
3	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
4	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
5	06503067	1	RELIEF PLUG
6	31861	1	RELIEF VALVE, 360 PSI
7	N/A	-	N/A
8	6T4209	1	RELIEF PLUG
9	31862	1	RELIEF VALVE, 2175 PSI
10	31862	1	RELIEF VALVE, 2175 PSI
11	31593	2	VALVE SEAL KIT (FOR ONE SECTION)
11A	-----	2	WIPER
11B	-----	2	O-RING SMALL
11C	-----	1	O-RING LARGE
11D	-----	1	SHUTTLE DISC
11E	-----	1	SPRING
12	TB1017L	2	LEVER KIT (FOR ONE SECTION)
12A	-----	1	LEVER KNOB
12B	-----	1	LEVER
12C	-----	2	LEVER WASHER
12D	-----	1	LEVER CLIP
12E	-----	2	LINKAGE
12F	-----	1	LEVER PIN
12G	-----	1	ROLL PIN
12H	-----	1	LEVER BOOT
12J	-----	1	LEVER BOLT
12K	-----	1	LEVER DUST COVER
12L	-----	1	LEVER NUT
13	31603	2	COMPENSATOR
14	TB1017X	1	TIE ROD KIT
15	24214	1	O-RING, LARGE

COMMON TWIN

CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502043




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502043

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31595	1	INLET END COVER
2	31594	1	END COVER, LOAD SENSE
3	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
4	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
5	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING) (REMOVE SHUTTLE DISC)
6	06503067	1	RELIEF PLUG
7	06503067	1	RELIEF PLUG
8	28816	1	RELIEF VALVE, 1812 PSI
9	06503068	1	RELIEF PLUG
10	6T4209	1	RELIEF PLUG
11	31862	1	RELIEF VALVE, 2175 PSI
12	31862	1	RELIEF VALVE, 2175 PSI
13	28816	1	RELIEF VALVE, 1812 PSI
14	31593	3	VALVE SEAL KIT (FOR ONE SECTION)
14A	-----	2	WIPER
14B	-----	2	O-RING SMALL
14C	-----	1	O-RING LARGE
14D	-----	1	SHUTTLE DISC
14E	-----	1	SPRING
15	TB1017L	3	LEVER KIT (FOR ONE SECTION)
15A	-----	1	LEVER KNOB
15B	-----	1	LEVER
15C	-----	2	LEVER WASHER
15D	-----	1	LEVER CLIP
15E	-----	2	LINKAGE
15F	-----	1	LEVER PIN
15G	-----	1	ROLL PIN
15H	-----	1	LEVER BOOT
15J	-----	1	LEVER BOLT
15K	-----	1	LEVER DUST COVER
15L	-----	1	LEVER NUT
16	31603	3	COMPENSATOR
17	23397	1	TIE ROD KIT
18	24214	1	O-RING, LARGE

COMMON TWIN

CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502044



COMMON TWIN


## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502044

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	31595	1	INLET END COVER
2	31594	1	END COVER, LOAD SENSE
3	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
4	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
5	31597	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING) (REMOVE SHUTTLE DISC)
6	06503067	1	RELIEF PLUG
7	31861	1	RELIEF VALVE, 360 PSI
8	28816	1	RELIEF VALVE, 1812 PSI
9	06503068	1	RELIEF PLUG
10	6T4209	1	RELIEF PLUG
11	31862	1	RELIEF VALVE, 2175 PSI
12	31862	1	RELIEF VALVE, 2175 PSI
13	28816	1	RELIEF VALVE, 1812 PSI
14	31593	3	VALVE SEAL KIT (FOR ONE SECTION)
14A	-----	2	WIPER
14B	-----	2	O-RING SMALL
14C	-----	1	O-RING LARGE
14D	-----	1	SHUTTLE DISC
14E	-----	1	SPRING
15	TB1017L	3	LEVER KIT (FOR ONE SECTION)
15A	-----	1	LEVER KNOB
15B	-----	1	LEVER
15C	-----	2	LEVER WASHER
15D	-----	1	LEVER CLIP
15E	-----	2	LINKAGE
15F	-----	1	LEVER PIN
15G	-----	1	ROLL PIN
15H	-----	1	LEVER BOOT
15J	-----	1	LEVER BOLT
15K	-----	1	LEVER DUST COVER
15L	-----	1	LEVER NUT
16	31603	3	COMPENSATOR
17	23397	1	TIE ROD KIT
18	24214	1	O-RING, LARGE

COMMON TWIN

CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502087



COMMON TWIN




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502087

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	TB1017S	1	INLET END COVER
2	TB1702	1	END COVER, POWER BEYOND
3	TB1017P	1	VALVE SECTION (SINGLE ACTING, SPRING DETENT)
4	TB1017P	1	VALVE SECTION (SINGLE ACTING, SPRING DETENT)
5	TB1017N	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
6	-----	-	N/A
7	-----	-	N/A
8	28816	1	RELIEF VALVE, 1812 PSI
9	TB1017M	1	SHUT-OFF PLUG
10	06502085	1	RELIEF VALVE, 3000 PSI
11	31862	1	RELIEF VALVE, 2175 PSI
12	31862	1	RELIEF VALVE, 2175 PSI
13	28816	1	RELIEF VALVE, 1812 PSI
14	TB1017A	4	VALVE SEAL KIT (FOR ONE SECTION)
14A	-----	2	WIPER
14B	-----	2	O-RING SMALL
14C	-----	1	O-RING LARGE
14D	-----	1	SPRING
14E	-----	1	PUCKET
15	TB1017L	4	LEVER KIT (FOR ONE SECTION)
15A	-----	1	LEVER KNOB
15B	-----	1	LEVER
15C	-----	2	LEVER WASHER
15D	-----	1	LEVER CLIP
15E	-----	2	LINKAGE
15F	-----	1	LEVER PIN
15G	-----	1	ROLL PIN
15H	-----	1	LEVER BOOT
15J	-----	1	LEVER BOLT
15K	-----	1	LEVER DUST COVER
15L	-----	1	LEVER NUT
16	23397	1	TIE ROD KIT
17	24214	1	O-RING, LARGE

COMMON TWIN

CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502088




## CABLE (MANUAL) LIFT VALVE BREAKDOWN - 06502088

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	TB1017S	1	INLET END COVER
2	TB1702	1	END COVER, POWER BEYOND
3	TB1017P	1	VALVE SECTION (SINGLE ACTING, SPRING DETENT)
4	TB1017N	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
5	TB1017N	1	VALVE SECTION (DOUBLE ACTING, CENTER SPRING)
6	-----	-	N/A
7	31861	1	RELIEF VALVE, 360 PSI
8	28816	1	RELIEF VALVE, 1812 PSI
9	TB1017M	1	SHUT-OFF PLUG
10	06502085	1	RELIEF VALVE, 3000 PSI
11	31862	1	RELIEF VALVE, 2175 PSI
12	31862	1	RELIEF VALVE, 2175 PSI
13	28816	1	RELIEF VALVE, 1812 PSI
14	TB1017A	4	VALVE SEAL KIT (FOR ONE SECTION)
14A	-----	2	WIPER
14B	-----	2	O-RING SMALL
14C	-----	1	O-RING LARGE
14D	-----	1	SPRING
14E	-----	1	PUCKET
15	TB1017L	4	LEVER KIT (FOR ONE SECTION)
15A	-----	1	LEVER KNOB
15B	-----	1	LEVER
15C	-----	2	LEVER WASHER
15D	-----	1	LEVER CLIP
15E	-----	2	LINKAGE
15F	-----	1	LEVER PIN
15G	-----	1	ROLL PIN
15H	-----	1	LEVER BOOT
15J	-----	1	LEVER BOLT
15K	-----	1	LEVER DUST COVER
15L	-----	1	LEVER NUT
16	23397	1	TIE ROD KIT
17	24214	1	O-RING, LARGE

COMMON TWIN


## BRAKE VALVE ASSEMBLY



ITEM	PART NO.	QTY.	DESCRIPTION
---	06510083	1	BRAKE VALVE, ASSY
1	34092	1	BRAKE VALVE, BLANK
2	34094	2	LOGIC ELEMENT
3	34095	1	RELIEF VALVE, 3000 PSI
4	06510095	1	METRI PAK COIL
5	34093	1	CARTRIDGE, 2 POSITION, 3 WAY (WITH NUT & WASHER)
6	34091	1	RELIEF VALVE, 2600 PSI
---	34096	2	RELIEF SEAL KIT
----	34097	1	SOLENOID SEAL KIT
---	34098	2	ELEMENT SEAL KIT

COMMON TWIN

## BRAKE VALVE HYDRAULIC SCHEMATIC



### BRAKE VALVE TROUBLESHOOTING

#### FAILURE MODE:

- MOWER WILL NOT START - system pressure is low (engine not lugging).
- MOWER WILL NOT START - system pressure is high (engine lugging). "MR" port will be high pressure.
- MOWER WILL NOT ROTATE AT FULL SPEED - limited power.
- MOWER BLADE WILL NOT STOP - blade will not stop in proper time.


#### CHECK STEPS

- 1 thru 6
- 7
- 3 thru 5
- 7 thru 9

#### CORRECTIVE STEPS:

1. Check for voltage at solenoid (item 6), voltage must be between 10.2 volts and 13.8 volts.
2. Remove, inspect solenoid and cartridge (items 4, 6) for wear or contamination.
3. Remove, inspect logic elements near "P" port (item 3) for wear or contamination.
4. Remove, inspect 3000 psi relief valve (item 2) for wear or contamination.
5. Remove and inspect orifices near "P" port for contamination.
6. Remove "P" port hose and fitting, visually inspect for contamination, check ball for movement.
7. Remove and inspect orifices near "MR" port for contamination.
8. Remove, inspect 2600 psi relief valve (item 5) for wear of contamination.
9. Remove, inspect logic element near "MR" port (item 3) for wear or contamination.


## CABLE DRAFT BEAM TRAVEL LOCK



ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	CABLE DRAFT BEAM
2	6T0106	1	TRAVEL LOCK BRACKET
3	6T0107	2	TRAVEL LOCK PINS 3/4" X 3 1/4"
4	6T3020	2	R - CLIP 5/32"
5	21833	1	CAPSCREW 3/4" X 2 1/4"
6	21825	1	HEX NUT 3/4"
7	21993	1	LOCK WASHER 3/4"
8	22021	1	FLAT WASHER 3/4"
9	22600	1	TRAVEL LOCK EAR
10	22604	2	PIN HOLDER
11	22601C	1	TRAVEL LOCK ASY
12	-----	-	MAIN FRAME *REFER TO PARTS SECTION

COMMON TWIN


## COMBO DRAFT BEAM TRAVEL LOCK



ITEM	PART NO.	QTY.	DESCRIPTION
1	-----	-	COMBO DRAFT BEAM
2	6T0106	1	TRAVEL LOCK BRACKET
3	21833	1	CAPSCREW 3/4" X 2 1/4"
4	-----	-	MAIN FRAME *REFER TO PARTS SECTION
5	33856	1	BRKT,PIN HOLDER
6	21988	2	LOCK WASHER 3/8"
7	21629	2	CAPSCREW 3/8" X 3/4"
8	6T3020	2	R - CLIP 5/32"
9	6T0107	2	TRAVEL LOCK PINS 3/4" X 3 1/4"
10	22021	1	FLAT WASHER 3/4"
11	21993	1	LOCK WASHER 3/4"
12	21825	1	HEX NUT 3/4"

COMMON TWIN

## SWITCH BOX




ITEM	PART NO.	QTY.	DESCRIPTION
1	06514011	1	SWBX,ALUM,BLK,06510097
2	35226	1	SWITCH,MOWER,COLEHERSEE
3	06510028	1	SWITCH,FORWARD/BRAKE/REV
4	33811	2	SWITCH,MASTER/DECK FLOAT
5	6T3923	2	INDICTATOR LIGHT,ON,RED
6	34540	2	STRAIN RELIEF,3/4,BLACK,NYLON
7	06514006	1	BREAKER,15A,SWBX
8	06514015	1	ALARM,SWBX,REVERSER
9	06550002	1	DECAL,SWTCHBX,TWIN/T3F,REV FAN
10	35227	1	RELAY,DP,DT,12V,LY2F,35226

COMMON TWIN



# SWITCH BOX SCHEMATIC



# NOTES

# **WARRANTY SECTION**



## WARRANTY INFORMATION

Tiger Corporation, 3301 N. Louise, Sioux Falls, South Dakota, warrants to the original Retail Customer, the new Tiger equipment is free of defects in material and workmanship. Any part of equipment that in Tiger's judgement, show evidence of such defects will be repaired or replaced without charge, provided that the failure of part(s) shall have occurred within twelve (12) months from the date of delivery of said equipment to the Retail Customer. Expendable components such as knives, oil, chain sprockets, skid shoes, knife mounting disks and the like are excluded but not limited to this warranty.

The Retail Customer must pay the transportation cost to and from the Tiger Dealer's service shop for warranty service. Warranty service will be performed by the Tiger Dealer from whom the equipment was purchased, during service shop regularly scheduled days and hours of operation.

All Tiger obligation under this warranty shall be terminated if the equipment is modified or altered in ways not approved in writing by Tiger, if repair parts other than genuine Tiger repair parts have been used, or if the equipment has been subject to misuse, neglect, accident, improper maintenance or improper operation.

Tiger Corporation reserves the right to make improvements in design or changes in specification at any time without incurring any obligation to owners of equipment previously sold.

No agent or person has authority to alter, add to or waive the above warranties which are agreed to be in the only warranties, representations or promises, expressed or implied, as to the quality or performance of the products covered and which do not include any implied warranty of merchantability or fitness. In no event will Tiger be liable for incidental or consequential damages or injuries, including, but not limited to, loss of profits, rental or substitute equipment or other commercial loss.

### **THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THOSE EXPRESSED HEREIN.**

It is the Purchasers obligation to sign the warranty registration form **AFTER** he / she has Read and Understands the Operation and Safety Instructions stated within this manual.

## **ONE LAST WORD**

This manual cannot possibly cover all of the potentially hazardous situations you will encounter. By being familiar with the safety rules, operating and maintenance instructions in this manual you can help prevent accidents. The objective of this manual is to help make you a better operator. Remember, **SAFETY IS YOU!**



1012

Your safety and the safety of those around you depends on **YOU**. Common sense should play a large role in the operation of this machine.

Since we at Tiger Corporation are constantly striving to improve our products, we reserve the right to change specifications or design at any time.

## TO THE OWNER / OPERATOR / DEALER



To keep your implement running efficiently and safely, read your manual thoroughly and follow these directions and the Safety Messages in this manual and on the machine. The table of contents clearly identifies each section where you can easily find the information you need.

The Occupational Safety and Health Act (OSHA 1928.51 subpart C) makes the following minimum requirements for tractor operators.

### **OWNER REQUIREMENTS:**

1. Provide a Roll-Over-Protective Structure that meets the requirements of this Standard; and
2. Provide Seatbelts that meet the requirements of this Standard and SAE J3C; and
3. Ensure that each employee uses such Seatbelt while the tractor is moving; and
4. Ensure that each employee tightens the Seatbelt sufficiently to confine the employee to the protected area provided by the ROPS.

### **OPERATOR REQUIREMENTS:**

1. Securely fasten seatbelt if the tractor has a ROPS.
2. Where possible, avoid operating the tractor near steep ditches, embankments, and holes.
3. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.
4. Stay off slopes too steep for safe operation.
5. Watch where you are going – especially at row ends, on roads, and around trees.
6. Do Not permit others to ride.
7. Operate the tractor smoothly – no jerky turns, starts, or stops.
8. Hitch only to the draw-bar and hitch points recommended by the tractor manufacturer.
9. When the tractor is stopped, set brakes securely and use park lock, if available



Printed in USA  
© Tiger Corporation