

REAR STOW SIDE ASSEMBLIES

RÖÍ €Ì Í É FFÍ T ÁVI Ø

Ô` | | ^ } œ Á Ð ĐÎ

ÚŒÜVÙÆÕÙVŒÕÁY QYP TUWÞVŒÕÆÐÖÁJÚÒÜŒVŒÕ ŒÙVÜWÔVQJÞÙ

Tiger Corporation

H-€FÁÞ ÉŠ[~ã^Á0€^È
Ùã ~¢ÁØæ|• ÉÜÜÖÁÄ Ï F€Ï

1-800-843-6849

1-605-336-7900

www.tiger-mowers.com

TO THE OWNER / OPERATOR / DEALER

 $O\#/\bar{a}_{1} | ^{ } ^{ } \hat{a}_{2} / \hat{a}_{3} / \hat{a}_{4} | ^{ } \hat{a}_{3} / \hat{a}_{4} | ^{ } \hat{a}_{4} \hat{a}_{4}$ ægææ\$@åÁg Á ā ā ā ^Áo@Á&@æ} &^Á Áæ\$&ãå^} o•È

BEFORE YOU START!! Ü^æåÁs@Áaæ^ĉÁ; ^••æ*^•Á;}Ás@Áa[]|^{ ^}oÁæ;åÁa@;}ÁAjÁs@áÁ;æ)*æ\È Uà•^¦ç^Ás@Á`|^•Á;Æ^ĉÁæ}åÁ•^Á&[{ { [}Á^}•^Â

READ AND UNDERSTAND THIS MANUAL! Non-English speaking operators will need to GET THE MANUAL TRANSLATED as needed!



FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTIONS CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.



2. NO RIDERS, NO CHILDREN OPERATORS.



3. USE SAFETY SHOES. HARD HAT, SAFETY GLASSES, SEAT BELTS, **ROPS & OPS**

4. BLOCK UP SECURELY **BEFORE WORKING** UNDER



- Study and understand Operator's Manuals, Safety Decals, and Instructional Decals for tractor and implement to prevent misuse, abuse, and accidents. Practice before operating in a confined area or near passersby.
 Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children
- 2. Allow no children on or near folding mower or tractor. Allow no riders on tractor or implement. Falling off may cause serious injury or death from being run over by tractor or mower or contact with rotating blades.
- 3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seat belt securely fastened to prevent injury and possible death from falling off or tractor overturn.
 Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, & Ear Plugs are recommended.
- 4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain area is clear before lowering or folding
- 5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding mowers. Put Booms securely in Transport Rest.
- Folding and Boom Mowers have raised center of gravity. Slow down when turning and on hillsides.
- 6. Make certain that SMV sign, warning lights, and reflectors are clearly visible. Follow local traffic codes.
- 7. Never operate with Cutting Head or Folding Section raised if passersby, bystanders, or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Guards or mower structure.
- 8. Before dismounting, secure implement in transport position or lower to ground.
 Put tractor in park or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent crushing by entanglement in rotating parts which could cause injury or death.
 Never mount or dismount a moving vehicle. Crushing from runover may cause serious injury or death.



6. USE SMV. LIGHTS. & REFLECTORS.



7. DO NOT OPERATE WITH CUTTER OR WING RAISED.



8. DO NOT MOUNT OR **DISMOUNT WHILE** MOVING

Warranty Information: Read and understand the complete Warranty Statement found in this manual. Fill out the Warranty Registration form in full and return it within 90 days. Make certain the Serial Number of the machine is recorded on the Warranty Card, and form that you retain.

FORWARD

This manual contains information about many features of the Tiger mowing and roadside maintenance equipment. Some of these include: Safety precautions, Assembly instructions, Operations, Maintenance and Parts. This manual will also assist you in the proper break-in, daily care, and troubleshooting of your new mower.

We recommend that you read carefully the entire manual before operating the unit. Also, time spent in becoming fully acquainted with its performance features, adjustments, and maintenance schedules will be repaid in a long and satisfactory life of the equipment.

Troubleshooting - Please, before you call, help us to help you!

Please look at the equipment to observe what is happening, then:

- Classify the problem
 - Hydraulic, electrical or mechanical Read the trouble shooting section
 - Tractor or Truck chassis Contact vehicle dealer

•	 If unable to correct the problem yourself, 	contact your lo	cal Tiger D	ealer at	fter
	gathering:				
	 Machine model 				

• Machine model	
Serial number _	
Dealer name	

• Detailed information about the problem including results of troubleshooting

Attention Owner / Operator / Dealer: It is your obligation to read, and understand, the warranty information section located at the back of this manual denoting that the purchaser understands the safety issues relating to this machine and has received and will read a copy of this manual.

If at any time, you have a service problem with your Tiger mower, Contact your local dealer for service and parts needed.

MANUFACTURED BY:	DISTRIBUTED BY:		
Tiger Corporation			
3301 N. Louise Ave.			
Sioux Falls, SD 57107	1		
1-800-843-6849	1		
1-605-336-7900			
www.tiger-mowers.com			

TABLE OF CONTENTS

SAFETY SECTION	1
ASSEMBLY / MOUNTING SECTION	2
OPERATION SECTION	3
MAINTENANCE SECTION	4
PARTS SECTION	5
COMMON PARTS SECTION	6
WARRANTY INFORMATION	7




This symbol means: CAUTION – YOUR SAFETY IS AT RISK!

When you see this symbol, read and follow the associated instructions carefully or personal injury or damage may result.

Tiger is a registered trademark.





GENERAL SAFETY INSTRUCTIONS AND PRACTICES

A careful operator is the best operator. Safety is of primary importance to the manufacturer and should be to the owner/operator. Most accidents can be avoided by being aware of your equipment, your surroundings, and observing certain precautions. The first section of this manual includes a list of Safety Messages that, if followed, will help protect the operator and bystanders from injury or death. Read and understand these Safety Messages before assembling, operating or servicing this Implement. This equipment should only be operated by those persons who have read the manual, who are responsible and trained, and who know how to do so responsibly.



The Safety Alert Symbol combined with a Signal Word, as seen below, is used throughout this manual and on decals which are attached to the equipment. The Safety Alert Symbol means: "ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!" The Symbol and Signal Word are intended to warn the owner/operator of impending hazards and the degree of possible injury faced when operating this equipment.

Practice all usual and customary safe working precautions and above all---remember safety is up to <u>YOU</u>. Only <u>YOU</u> can prevent serious injury or death from unsafe practices.

A DANGER

Indicates an imminently hazardous situation that, if not avoided, WILL result in DEATH OR VERY SERIOUS INJURY.

AWARNING

Indicates an imminently hazardous situation that, if not avoided, COULD result in DEATH OR SERIOUS INJURY.

A CAUTION

Indicates an imminently hazardous situation that, if not avoided, MAY result in MINOR INJURY.

Important

Identifies special instructions or procedures that, if not strictly observed, could result in damage to, or destruction of the machine, attachments or the environment.

NOTE: Identifies points of particular interest for more efficient and convenient operation or repair.

READ, UNDERSTAND, and FOLLOW the following Safety Messages. Serious injury or death may occur unless care is taken to follow the warnings and instructions stated in this Manual and in the Safety Messages on the implement. Always follow the instruction in this manual and use good common sense to avoid hazards.



NOTE: If you want a translation of this safety section in one of the following Languages, please contact: Translations at 1502 E. Walnut Street Seguin, TX 78155; Fax: (830) 372-9529; Safety Section Translations are available in Spanish, Portuguese, French, German, Russian. PN GS01

Operator Safety



AWARNING

TO AVOID SERIOUS INJURY OR DEATH DO THE FOLLOWING:

- READ, UNDERSTAND and FOLLOW Operator's Manual instructions, Warnings and Safety Messages.
- · WEAR SAFETY GLASSES, safety shoes, hard hat, hearing protection and gloves when operating or repairing equipment
- WEAR appropriate breathing respirator when operating in dusty conditions to avoid respiratory diseases.
- DO NOT WEAR loose clothing or jewelry to avoid rotating parts entanglement injury.
- DO NOT USE DRUGS or ALCOHOL before or while operating equipment.
- **DO NOT ALLOW** anyone to operate equipment under the influence of drug or alcohol.
- CONSULT medical professional for medication impairment side effects.
- STAY CLEAR of hot surfaces such as Mufflers, hydraulic pumps, valves and tanks.
- STAY ALERT, prolonged operation can cause fatigue, STOP and REST.

GENERAL OPERATING SAFETY

VISIBILITY CONDITIONS WHEN MOWING:

- OPERATE IN DAYLIGHT or with lights that gives at least 100 yards clear visibility.
- BE ABLE TO SEE and identify passersby, steep slopes, ditches, drop-offs, overhead obstructions, power lines, debris and foreign
 objects.
- Avoid backing up while mowing, vision may be limited, severe damage or injury can occur.
- DO NOT run tractor in enclosed building without adequate exhaust ventilation.

GROUND SPEED WHEN MOWING:

- NORMAL SPEED range is between 1 to 2 mph(1-3 kph).
- ADJUST MOWING SPEED for terrain conditions and grass type, density and cut height.
- REDUCE MOWING SPEED when near steep slopes, ditches, drop-offs, overhead obstructions, power lines and to avoid debris
 and foreign objects.

TRACTOR and MOWER

- DO NOT operate the tractor or mower unless the equipment is maintained and operating properly.
- DISCONTINUE OPERATION if tractor or mower electrical and hydraulic controls do no function properly.
- DISCONTINUE OPERATION of the tractor if the braking or steering systems do not function properly.
- DO NOT operate the tractor or mower if there are any hydraulic leaks.

INSECT INFESTATION

 DO NOT operate in areas where bees or insects may attack unless you WEAR PROTECTIVE CLOTHING or use enclosed tractor cab.

PTO SPEED:


- DO NOT EXCEED IMPLEMENT RATED PTO SPEED
- AVOID exceeding rated PTO speeds that may result in broken drivelines or blade failures.


SAFETY SIGNS:

REPLACE missing, damaged or unreadable safety signs immediately. PN OSBM-01

CRUSHING HAZARDS







Use Cab Tractor With Boom Mowers



Always wear seatbelt



Pinch Point Hazard Keep Hands and body parts clear of pinch points



Crushing injury from boom or mower head falling



TO AVOID SERIOUS INJURY OR DEATH FROM FALLING OFF TRACTOR, EQUIPMENT RUN OVER, ROLLOVER AND CRUSHING BY FALLING WING OR IMPLEMENT:

- USE ROPS and SEAT BELT equipped tractors for mowing operations.
- KEEP ROPS lock in up position.
- ALWAYS BUCKLE UP seat belt when operating tractor and equipment.
- ONLY OPERATE tractor and equipment while seated in tractor seat.

WHEN RAISING BOOM MOWER:

- Raise or lower ONLY WHILE SEATED in tractor seat with seat belt buckled.
- KEEP BYSTANDERS CLEAR of area TO AVOID crushing.
- KEEP sufficient clearance around implement and wings TO AVOID contacting buildings or overhead power lines.

LIFTED Equipment can fall from mechanical or hydraulic failure or inadvertent Control Lever movement.



TO AVOID EQUIPMENT FALLING while working near or under lifted boom, components and Mower Head:

- SECURELY SUPPORT or block up raised equipment, wings and components.
- BLOCK UP and securely support equipment before putting hands, feet or body under raised equipment or lifted components.
- KEEP BYSTANDERS CLEAR of raised boom or mower head until securely blocked up.

WHEN PARKING Implement and Tractor:

- LOWER Mower Head to the ground or BLOCK lifted parts before leaving equipment.
- NEVER leave implement unattended in a raised position.

AWARNING

TO AVOID CHILDREN FALLING OFF OR BEING CRUSHED BY EQUIPMENT:

- NEVER ALLOW children to play on or around Tractor or Implement.
- DO NOT operate without operator CAB or OVERHEAD protection. Falling limbs and debris can cause injuries. PN CHBM-01

CONNECTING OR DISCONNECTING IMPLEMENT SAFETY





Stop Tractor Remove Key Read Manual



Crushing Hazard Do Not get under boom when connecting mower head to boom



Stability Hazard Ensure 20% of tractor weight is on front wheels



Stability Hazard
Ensure 1500lbs down
force on left tire with
boom extended



TO AVOID SERIOUS INJURY OR DEATH FROM BEING CRUSHED BY TRACTOR OR IMPLEMENT:

WHEN connecting mower head to the boom:

- KEEP BYSTANDERS AWAY from tractor and mower.
- Ensure there is enough room to lift and swing the boom with out hitting objects

BEFORE connecting and disconnecting the mower head or boom:

STOP TRACTOR ENGINE, place transmission into park, engage parking brake and remove key.

WHEN connecting and disconnecting the mower head or boom:

DO NOT crawl or walk under raised mower head or boom. (Refer to Instructions in Operation Section)

WHEN CONNECTING IMPLEMENT DRIVELINE: (If equipped)

TO AVOID implement driveline coming loose during operation:

- LUBRICATE yoke spring locking collar to ensure it freely slides on PTO shaft.
- **SECURELY** seat yoke locking balls in PTO shaft groove.
- PUSH and PULL DRIVELINE on both the tractor and implement PTO SHAFTS to ensure it is SECURELY ATTACHED.


TO AVOID broken driveline during operations:

- CHECK driveline for proper length between PTO shaft and implement gearbox shaft. (Refer to Instructions in Operation Section)
- Drivelines too short can pull apart or disengage.
- Drivelines too long can bottom out.
- Bottoming driveline telescoping assembly will stop sliding and become solid.
- Driveline bottoming can push through support bearings and break off PTO shaft.

CONTACT DEALER if implement driveline does not match Tractor PTO shaft:

- DO NOT USE PTO ADAPTER.
 - Using a PTO adapter can cause:
- Excessive vibration, thrown objects, blade and implement failures by doubling operating speed.
- Increased working length exposing unshielded driveline areas and entanglement hazards. PN CDBM-01

THROWN OBJECTS HAZARDS





ROTARY MOWERS CAN THROW OBJECTS 300 FEET OR MORE UNDER ADVERSE CONDITIONS.

TO AVOID SERIOUS INJURY OR DEATH TO OPERATOR OR BYSTANDERS FROM THROWN OBJECTS:

KEEP bystanders 300 feet away

STOP MOWING IF PASSERSBY ARE WITHIN 300 FEET UNLESS:

- All THROWN OBJECT SHIELDING including, Front and Rear Deflectors, Chains Guards, Steel Guards, Bands, Side Skirts and Skid Shoes in place and in good condition when mowing.
- Mower is close and parallel to ground without exposing blades.
- MOWING AREA has been inspected and foreign materials and debris have been removed.
- DO NOT shred or mow loose or previously cut material if BYSTANDERS are within 300 feet.
- PASSERSBY are inside enclosed vehicle.

INSPECT AREA FOR POTENTIAL THROWN OBJECTS BEFORE MOWING:

- **REMOVE** debris, rocks, wire, cable, metal objects and other foreign material from area.
 - Wire, cable, rope, chains and metal objects can be thrown or swing outside deck with great velocity:
 - 1. MARK objects that cannot removed.
 - 2. AVOID these objects when mowing.

HIGH GRASS and WEED AREA INSPECTION:

- INSPECT for and REMOVE any hidden large debris.
- MOW at Intermediate height
- **INSPECT** and remove remaining debris
- MOW at final height.


MOWER THROWN OBJECT SHIELDING:

- **KEEP** all thrown object shielding including, Front and Rear Deflectors, Chains Guards, Steel Guards, Bands, Side Skirts and Skid Shoes in place and in good condition when mowing.
- DO NOT OPERATE with any thrown object shielding missing, damaged or removed.

RIGHT OF WAY (Highway) MOWING

- Stop mowing if any bystander comes within 300 feet of the mower.
- No shielding is 100% effective in preventing thrown objects. To Reduce Possibility of Injury:
 - 1. MAINTAIN MOWER SHIELDING, side skirts, skid shoes, and blades in good operational condition,
 - 2. RAISE CUTTING HEIGHT to 6 INCHES minimum,
 - 3. INSPECT AREA thoroughly before mowing to REMOVE potential THROWN OBJECT HAZARDS,
 - 4. **NEVER ALLOW BLADES to CONTACT SOLID OBJECTS** like wire, rocks, post, curbs, guardrails, or ground while mowing. *PN TOBM-01*

THROWN OBJECTS HAZARDS (Continued)



MOWER OPERATION:

- **DO NOT** exceed mower's rated Cutting Capacity or cut non-vegetative material.
- USE ENCLOSED TRACTOR CABS when two or more mowers are operating in mowing area.
- Do Not mow in areas where bees or insects may attack unless you WEAR PROTECTIVE CLOTHING or use enclosed tractor cab.
- ADJUST mower head close and parallel to ground without exposing blades.
- ADJUST cutting HEIGHT to AVOID BLADE CONTACT with solid objects like wire, rocks, posts, curbs, guard rails and fixed obstructions.
- CLOSE Mower door and stop operating if bystanders come within 300 feet of the mower.
- Keep mower door closed when cutting close to the ground.
- Open door only to cut large brush or tree limbs. Close door immediately after cutting limb.
- **DO NOT** push mower head down onto material to cut it, use the front tips of the mower blades to cut into the material.
- **DO NOT** operate mower when mower is in transport position.
- **STOP MOWING** immediately if blades strike heavy objects, fixed structures, metal guard rails and concrete structures:
 - 1. BLADES CAN FAIL from impact and objects can be thrown with great velocity.
 - 2. **INSPECT** and **REPLACE** any damaged blades.
 - 3. CHECK blade carrier and REPLACE if damaged.
- DO NOT mow in standing water TO AVOID possible BLADE FAILURE.
- AVOID MOWING in reverse:
 - 1. **STOP PTO** and back up mower.
 - 2. LOWER mower, engage PTO and mow forward.
- **DISENGAGE** mower head and wait until **BLADES** stop rotating before raising mower to transport position.
- DO NOT ENGAGE PTO with mower in transport position.
- STOP mowing when EXCESSIVE VIBRATION occurs:
 - 1. STOP PTO and tractor ENGINE.
 - 2. **INSPECT** mower for vibration source.
 - 3. REPLACE any damage parts and bent or damaged BLADES. PN TOBM-02

RUN OVER HAZARDS






TO AVOID SERIOUS INJURY OR DEATH FROM FALLING OFF TRACTOR OR EQUIPMENT RUN OVER:

- USE ROPS and SEAT BELT equipped tractors for mowing operations.
- **KEEP ROPS** locked in **UP** position.
- ONLY start tractor while seated in tractor seat.
- ALWAYS BUCKLE UP seat belt when operating tractor and equipment.
- ONLY OPERATE tractor and equipment while seated in tractor seat.
- NEVER ALLOW RIDERS on tractor or implement.
- When not mowing stow Boom and Mower head in transport location before moving.

WHEN MOUNTING AND DISMOUNTING TRACTOR:

- ONLY mount or dismount when tractor and moving parts are stopped.
- **STOP ENGINE AND PTO**, engage parking brake, lower implement, allow all moving parts to stop and remove key before dismounting from tractor. **PN ROBM-01**

PTO ENTANGLEMENT HAZARDS





KEEP AWAY FROM ROTATING DRIVELINES AND ELEMENTS TO AVOID SERIOUS INJURY OR DEATH:

STAY AWAY and **KEEP** hands, feet and body AWAY from rotating blades, drivelines and parts until all moving elements have stopped.

- STOP, LOOK and LISTEN before approaching the mower to make sure all rotating motion has stopped.
- ROTATING COMPONENTS CONTINUE to ROTATE after the PTO is shut off.

PTO SHIELDING:

TO AVOID SERIOUS INJURY OR DEATH FROM ENTANGLEMENT WHEN OPERATING IMPLEMENT:

- KEEP PTO shields, integral driveline shields and input shields installed
- DO NOT OPERATE mower without shields and guards in place or missing
- REPAIR OR REPLACE if damage, broken or missing
- ALWAYS REPLACE GUARDS that have been removed for service or maintenance.
- Do Not use PTO or PTO guard as a step.

TO AVOID broken driveline during operations:


- CHECK driveline for proper length between PTO shaft and implement gearbox shaft. (Refer to Instructions in Operation Section)
- Drivelines too short can pull apart or disengage.
- Drivelines too long can bottom out.
 - Bottoming driveline telescoping assembly will stop sliding and become solid.
- Driveline bottoming can push through support bearings and break off PTO shaft
- AVOID sharp turns or lift mower to heights to cause driveline "knocking".
- Lubricate driveshaft-telescoping components weekly.

CONTACT DEALER if implement driveline does not match Tractor PTO shaft:

• DO NOT USE PTO ADAPTER.

Using a PTO adapter can cause excessive vibration, thrown objects, blade and implement failures by doubling operating speed. Increased working length exposing unshielded driveline areas. PN PEO1

MOWER BLADE CONTACT HAZARDS





KEEP AWAY FROM ROTATING BLADES TO AVOID SERIOUS INJURY OR DEATH FROM BLADE CONTACT:

- STAY AWAY and KEEP HANDS, FEET and BODY AWAY from rotating blades, drivelines and parts until all moving elements have stopped.
- DO NOT put hands or feet under mower decks
- STOP rotating BLADES disengage mower switch and PTO and wait for blade to stop rotating before raising mower head.
- DO NOT approach Sickle Bar head until Tractor Engine has been shut off.
- STOP LOOK and LISTEN before approaching the mower to make sure all rotating motion has stopped. PN MBBM-01

HIGH PRESSURE OIL LEAK HAZARD



High pressure oil penetrating skin



High pressure oil eroding skin



Using cardboard to check for oil leaks



Tank contents under pressure. Allow oil to cool before slowly removing cap



TO AVOID SERIOUS INJURY OR DEATH FROM HIGH PRESSURE HYDRAULIC OIL LEAKS PENERATING SKIN:

- DO NOT OPERATE equipment with oil or fuel leaks.
- KEEP all hydraulic hoses, lines and connections in GOOD CONDITION and TIGHT before applying system
 pressure.
- RELIEVE HYDRAULIC PRESSURE before disconnecting lines or working on the system.
- REMOVE and replace hose if you suspect it leaks. Have dealer test it for leaks.

HIGH PRESSURE FLUID LEAKS CAN BE INVISIBLE.


WHEN CHECKING FOR HYDRAULIC LEAKS AND WORKING AROUND HYDRAULIC SYSTEMS:

- ALWAYS WEAR safety glasses and impenetrable gloves.
- **USE** paper or cardboard to search for leaks.
- DO NOT USE hands or body parts to search for leak.
- **KEEP** hands and body **AWAY** from pin holes and nozzles ejecting hydraulic fluid.
- · Hydraulic fluid may cause gangrene if not surgically removed immediately by a doctor familiar with this form of injury.

Use caution when removing Hydraulic Tank cap.

- Tank contents maybe under pressure
- Allow oil to cool before removing cap.
- Relieve oil pressure before removing cap slowly.
- Stay away from hot oil that may spray from tank. PN HPBM-01

ELECTRICAL & FIRE HAZARDS



Mower head or Boom contacting overhead electrical lines



Strike and explosion Hazard Blades Contacting Utility or Gas Lines



Fire Hazard Do Not operate near fires. Keep debris away from hydraulic pumps and valves




TO AVOID SERIOUS INJURY OR DEATH FROM ELECTRICAL CONTACT WHEN WORKING AROUND ELECTRICAL POWER LINES, GAS LINES AND UTILITY LINES:

- **INSPECT** mowing area for overhead or underground electrical power lines, obstructions, gas lines, cables and Utility, Municipal, or other type structure.
- **KEEP** all raised wings at a 10 feet or greater distance from all power lines and overhead obstructions.
- **DO NOT** allow mower to contact with any Utility, Municipal, or type of structures and obstructions.
- CALL 811 and 1-800-258-0808 for identify buried utility lines.

FIRE PREVENTION GUIDELINES while Operating, Servicing, and Repairing Mower and Tractor to reduce equipment and grass fire Risk:

- EQUIP Tractor with a FIRE EXTINGUISHER
- DO NOT OPERATE mower on a tractor equipped with under frame exhaust
- DO NOT SMOKE or have open flame near Mower or Tractor
- DO NOT DRIVE into burning debris or freshly burnt area
- AVOID FIRE IGNITION by not allowing mower blade to contact solid objects like metal or rock.
- DO NOT operate if oil is leaking. Repair oil leak and remove all accumulated oil before operating.
- CLEAR any grass clippings or debris buildup around mower hydraulic pumps, valves or tanks.
- SHUT OFF ENGINE while refueling. PN EFBM-01

TRANSPORTING HAZARDS



AWARNING

TO AVOID SERIOUS INJURY AND DEATH WHEN TOWING OR TRANSPORTING EQUIPMENT:

- KEEP transport speed BELOW 20 mph to maintain control of equipment.
- REDUCE SPEED on inclines, on turns and in poor towing conditions.
- DO NOT TOW with trucks or other vehicles.
- **USE** only properly sized and equipped tractor for towing equipment.
- FOLLOW all local traffic regulations.

TRACTOR REQUIREMENTS FOR TOWING OR TRANSPORTING IMPLEMENTS:

- ONLY TRANSPORT with tractor with ROPS in the raised position.
- USE properly sized and equipped tractor that exceeds implement weight by at least 20%.
- KEEP 20% of tractor weight on front wheels to maintain safe steering.

BEFORE TRANSPORTING OR TOWING IMPLEMENT:

TRACTOR INSPECTION:

- CHECK steering and braking for proper operation and in good condition.
- CHECK SMV sign, reflectors and warning lights for proper operation and visibility behind unit.
- CHECK that your driving vision is not impaired by tractor, cab, or implement while seated in tractor seat.
- ADJUST your operating position, mirrors, and implement transport for clear vision for traveling and traffic conditions.

PREPARE IMPLEMENT FOR TRANSPORTING OR TOWING:

Store Boom and Mower in transport positions and engage transport locks if equipped.

DETERMINE STOPPING CHARACTERISTICS OF TRACTOR AND IMPLEMENT FOR TRANSPORTING OR TOWING:

BRAKING TESTS:

- Stopping distance with implement attached may increase
- Observe STOPPING distances increases with increased speeds.
- DETERMINE the maximum safe transport speed that does not exceed 20 mph.
- Reduce travel speed in wet or icy roads, stopping distances increase.

DETERMINE MAXIMUM TURING SPEED BEFORE OPERATING ON ROADS OR UNEVEN GROUND:


- TEST equipment in slowly increasing speed in turns to determine it can be operated at higher speeds.
- USE REDUCED turning speeds in sharp turns to avoid equipment turning over.

WHEN TOWING OR TRANSPORTING EQUIPMENT:

- Always WEAR SEAT BELT when operating or transporting mower.
- USE low speeds to avoid overturn with raised wings.
- USE low speeds and gradual steering on curves, hills, rough or uneven surfaces and on wet roads.
- TURN ON tractor FLASHING WARNING LIGHTS.
- ALLOW clearance for implement swing while turning.

KEEP raised boom mower 10 feet or greater distance from all power lines and overhead obstructions. PN THBM-01

HAZARDS WITH MAINTENANCE OF IMPLEMENT



≜WARNING

AVOID SERIOUS INJURY OR DEATH FROM COMPONENT FAILURE BY KEEPING IMPLEMENT IN GOOD OPERATING CONDITION IN PERFORMING PROPER SERVICE, REPAIRS AND MAINTENANCE.

BEFORE PERFORMING SERVICE. REPAIRS AND MAINTENANCE ON THE IMPLEMENT:

- STOP ENGINE AND PTO, engage parking brake, lower implement, allow all moving parts to stop and remove key before
 dismounting from tractor.
- PLACE implement on ground or securely block up raised equipment. Use large blocks on soft or wet soil.
- PUSH and PULL Remote Hydraulic Cylinder lever to relieve hydraulic pressure.
- DISCONNECT Pump solenoid valve or PTO driveline connection before servicing mower head.
- WEAR SAFETY GLASSES, PROTECTIVE GLOVES and follow SAFETY PROCEDURES when performing service, repairs
 and maintenance on the implement:
- Always WEAR protective GLOVES when handling blades, knives, cutting edges or worn component with sharp edges.
- Always WEAR GLOVES and SAFETY GLASSES when servicing hot components
- AVOID CONTACT with hot hydraulic oil tanks, pumps, motors, valves and hose connection surfaces.
- SECURELY support or BLOCK UP raised implement, framework and lifted components before working underneath equipment.
- FOLLOW INSTRUCTIONS in maintenance section when replacing hydraulic cylinders to prevent component falling.
- STOP any implement movements and SHUT-OFF TRACTOR engine before doing any work procedures.
- USE ladder or raised stands to reach high equipment areas inaccessible from ground.
- ENSURE good footing by standing on solid flat surfaces when getting on implement to perform work.
- FOLLOW manufacturer's instructions in handling oils, solvents, cleansers, and other chemical agents.
- DO NOT change any factory-set hydraulic calibrations to avoid component or equipment failures.
- DO NOT modify or alter implement, functions or components.
- DO NOT WELD or repair rotating mower components. These may cause vibrations and component failures being thrown from mower.

PERFORM SERVICE, REPAIRS, LUBRICATION AND MAINTENANCE OUTLINED IN IMPLEMENT MAINTENANCE SECTION:

- **INSPECT** for loose fasteners, worn or broken parts, leaky or loose fittings, missing or broken cotter keys and washers on pins, and all moving parts for wear.
- REPLACE any worn or broken parts with authorized service parts.
- Inspect mower blade spindle to ensure bearing preload. If loose repair before operating.
- LUBRICATE unit as specified by lubrication schedule
- **NEVER** lubricate, adjust or remove material while it is running or in motion.
- TORQUE all bolts and nuts as specified.

BLADE INSPECTION:

- · Inspect blade carrier and blades daily.
- Check blade and blade carrier BOLT TORQUE daily. Loose bolts can cause blade or blade bolt failures.
- REPLACE, bent, damage, cracked and broken blades immediately with new blades.
- AVOID blade failures and thrown broken blades. DO NOT straighten, weld, or weld hard-facing blades.

SAFETY SHIELDS, GUARDS AND SAFETY DEVICES INSPECTION:

- **KEEP** all Deflectors, Chain Guards, Steel Guards, Gearbox Shields, and PTO integral shields, Bands, Side Skirts and Skid Shoes in place and in good condition.
- REPLACE any missing, broken or worn safety shields, guards and safety devices.
- Engine Exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the state of California
 to cause cancer, birth defects or other reproductive harm.
- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer, birth defects or other reproductive harm. *PN HMBM-01*

PARTS INFORMATION

PARTS INFORMATION

Tiger mowers use balanced and matched system components for blade carriers, blades, cuttershafts, knives, knife hangers, rollers, drivetrain components, and bearings. These parts are made and tested to Tiger specifications. Non-genuine "will fit" parts do not consistently meet these specifications. The use of "will fit" parts may reduce mower performance, void mower warranties, and present a safety hazard. Use genuine Tiger mower parts for economy and safety. (SPTM-1)

SEE YOUR TIGER DEALER

Operator's & Parts Manuals




www.algqr.com/tpm

Decal Location

NOTE: Tiger supplies safety decals on this product to promote safe operation. Damage to the decals may occur while in shipping, use, or reconditioning. Tiger cares about the safety of its customers, operators, and bystanders, and will replace the safety decals on this product in the field, free of charge (Some shipping and handling charges may apply). Contact your Tiger dealer to order replacement decals.


Boom Arm




ITEM	PART NO.	QTY.	TYPE	DESCRIPTION
1.	02962764	5	WARNING	Pinch Points
2.	02965262	1	WARNING	Hydraulic Oil Hazard
3.	02962765	1	DANGER	Crushing Hazard
4.		1	LOGO	Name

BOOM

Safety Section 1-16





	ITEM	PART NO.	QTY.	TYPE	DESCRIPTION	
	1.	24028	1	DANGER	Thrown Object Hazard, Deflectors	
	2.	32709	1	WARNING	Use Genuine Tiger Parts	
	3.	33224	1	DANGER	Blades, Thrown Object	
	4.	D637	1	WARNING	Disconnect Hydraulic Solenoid	
	5.		1	LOGO	Tiger Logo	
	6.	00758194	1	WARNING	Pinch Point Hazard	
	7.		1	LOGO	50" Logo	
			1	LOGO	63" Logo	
	8.	D646	1	DANGER	Guard Missing, Do Not Operate	
	9.	D655	1	INSTRUCT	Lube Chart	
	10.	TB1011	1	DANGER	Thrown Object Hazard, Shield	
	11.	6T3236	1	LOGO	Made in the USA	
	12.	42399	2	REFLECT	Red Reflector	
	13.	4240006	1	REFLECT	Amber Reflector	
	14.	nfs	1	SERIAL PLATE	Serial Number Plate	
	воом		Sa	afety Section 1-18		
				•		





TO AVOID SERIOUS INJURY OR DEATH FROM HIGH PRESSURE HYDRAULIC OIL LEAKS PENETRATING SKIN:

- . DO NOT OPERATE equipment with oil or fuel leaks.
- KEEP all hydraulic hoses, lines and connections in good condition and tight before applying system pressure.
- · Relieve hydraulic pressure before disconnecting lines or working on the system.
- REMOVE and replace hose if you suspect it leaks. Have dealer test it for leaks.

HIGH PRESSURE FLUID LEAKS CAN BE INVISIBLE. WHEN CHECKING FOR HYDRAULIC LEAKS AND WORKING AROUND HYDRAULIC SYSTEMS:


- DO NOT use hands to check for leaks.
- ALWAYS WEAR safety glasses and impenetrable gloves.
- USE paper or cardboard to search for leaks.
- · KEEP hands and body AWAY from pin holes and nozzles ejecting hydraulic fluid.
- Hydraulic fluid may cause gangrene if not surgically removed immediately by a doctor familiar with this form of injury.











Safety Section 1-20



THROWN OBJECTS HAZARD

Mower can throw objects up to 300 feet. TO AVOID SERIOUS INJURY OR DEATH to operator or bystanders:

- CLOSE MOWER DOOR and STOP operating if bystanders or traffic come within 300 feet.
- · KEEP door fully closed when cutting grass and weeds.
- OPEN door ONLY to cut large brush. Close door immediately after.
- DO NOT operate with door removed.
- KEEP door in place and in good condition during operation.
- Deflectors are SUBJECT TO WEAR. Replace if worn or damaged.
- ALWAYS transport with door closed.

33224

ENTANGLEMENT HAZARD




- STAY AWAY and KEEP hands, feet and body AWAY from rotating blades, drivelines and parts that continue to move after power shut-off. WAIT until all moving elements have stopped.
- STOP, LOOK and LISTEN for rotating motion before approaching implement.

A WARNING

Non-genuine parts can fail catastrophically. TO AVOID SERIOUS INJURY OR DEATH:

- ONLY use genuine TIGER replacement parts.
- Non-genuine parts can fail creating hazardous conditions for operator and bystanders.

Contact local dealer or TIGER about repair parts at:



www.algqr.com/tpm

Customer Service: 800-843-6849. Email: feedback@tiger-mowers.com

32709



BE AWARE BE ALERT BE ALIVE

BE TRAINED
Before Operating this Mower

To prevent serious injury to yourself and/or bystanders, be trained in Safe Mowing Practices. Alamo Group Companies as well as AEM and FEMA provide training material that is critical for your Safety and the Safety of others when operating this equipment. www.algqr.com/tbv Make these Safety Procedures an important part of every workday. Read and understand the Operator's Manual. Do not let untrained individuals operate this equipment. Contact your Dealer, AEM (www.aem.org), FEMA (314-878-2304, www.FarmEquip.org), or Alamo Group (www.Alamo-Group.com) for information on training material or courses that provide training in Safer Operating Practices for Mowers. 32709 2

removed.

PINCH POINT HAZARD TO AVOID SERIOUS INJURY: DO NOT OPERATE with Belt Shield

00758194





Federal Laws and Regulations

This section is intended to explain in broad terms the concept and effect of federal laws and regulations concerning employer and employee equipment operators. This section is not intended as a legal interpretation of the law and should not be considered as such.

Employer-Employee Operator Regulations

U.S. Public Law 91-596 (The Williams-Steiger Occupational and Health Act of 1970) OSHA

This Act Seeks:

"...to assure so far as possible every working man and woman in the nation safe and healthful working conditions and to preserve our human resources..."

DUTIES

Sec. 5 (a) Each employer-

- (1) shall furnish to each of his employees employment and a place of employment which are free from recognized hazards that are causing or are likely to cause death or serious physical harm to his employees;
- (2) shall comply with occupational safety and health standards promulgated under this Act.
- (b) Each employee shall comply with occupational safety and health standards and all rules, regulations and orders issued pursuant to this Act which are applicable to his own actions and conduct.

OSHA Training Requirements

Title 29, Code of Federal Regulations Part 1928.57(a)(6). www.osha.gov

Operator instructions. At the time of initial assignment and at least annually thereafter, the employer shall instruct every employee who operates an agricultural tractor and implements in the safe operating practices and servicing of equipment with which they are or will be involved, and of any other practices dictated by the work environment.

Keep all guards in place when the machine is in operation;

Permit no riders on equipment

Stop engine, disconnect the power source, and wait for all machine movement to stop before servicing, adjusting, cleaning or unclogging the equipment, except where the machine must be running to be properly serviced or maintained, in which case the employer shall instruct employees as to all steps and procedures which are necessary to safely service or maintain the equipment.

Make sure everyone is clear of machinery before starting the engine, engaging power, or operating the machine.


Employer Responsibilities:

To ensure employee safety during Tractor and Implement operation, it is the employer's responsibility to:

- 1. Train the employee in the proper and safe operation of the Tractor and Implement.
- 2. Require that the employee read and fully understand the Tractor and Implement Operator's manual.
- 3. Permit only qualified and properly trained employees to operate the Tractor and Implement.
- 4. Maintain the Tractor and Implement in a safe operational condition and maintain all shields and guards on the equipment.
- 5. Ensure the Tractor is equipped with a functional ROPS and seat belt and require that the employee operator securely fasten the safety belt and operate with the ROPS in the raised position at all times.
- 6. Forbid the employee operator to carry additional riders on the Tractor or Implement.
- 7. Provide the required tools to maintain the Tractor and Implement in a good safe working condition and provide the necessary support devices to secure the equipment safely while performing repairs and service.
- 8. Require that the employee operator stop operation if bystanders or passersby come within 300 feet.

Child Labor Under 16 Years of Age

Some regulations specify that no one under the age of 16 may operate power machinery. It is your responsibility to know what these regulations are in your own area or situation. (Refer to U.S. Dept. of Labor, Employment Standard Administration, Wage & Home Division, Child Labor Bulletin #102.)



Before attempting to mount your Tiger mower, it is important to read and understand all of the safety messages in the Safety Section of this manual.

≜WARNING

 $\ddot{\Delta} = \dot{\Delta} + \dot{\Delta} +$

TRACTOR PREPARATION

- OEÈ Ü^{ [ç^Áðî @Áse) åÁv-AÁ@e) åÁvc^]•È
- ÓÈ Öã $8[\}$ ^ 80Áà ægc^\|^ Á8æà|^• Á\[{ Áà[c@Áàægc^\|ã\• È
- ÔÈ Ü^{[ç^Án}}*ã,^Ánãa^Án,aa}^|•ÉA,¦Áaaã*^ÁQ,[åÁq,Áa&&^••Á;[}ơÁ,*||^^È
- $\ddot{O} \dot{E} \ddot{U}^{(+)} = \dot{A}_{1}^{(+)} * \bullet \dot{A}_{1}^{(+)} = \dot{A}_{2}^{(+)} = \dot{A}_{3}^{(+)} = \dot{A}_{4}^{(+)} = \dot{A}_{4}^{(+)$
- ÒÈ Ü^{ [ç^Ása) ^Á\[} oÁ, ^ãt @ Ása) åÁ, ^ãt @Á*]][lơ È

ADJUSTING REAR WHEELS



DRIVESHAFT AND FRONT PUMP MOUNTING

Q • cæ|Áå¦ãç^ • @æóÁş q Ás@ Á&; æ; \ • @æóÁsæåæ} c^¦È


\(\text{U}\)\(\frac{\alpha}{\alpha}\)\(\frac{\


CAUTION: DO NOT START THE TRACTOR UNTIL ALL HOSES ARE ATTACHED, TANK IS FILLED WITH PROPER OIL AND BALL VALVES ARE OPEN! STARTING AT THIS TIME WILL CAUSE SERIOUS DAMAGE TO THE PUMP. (ASM-C-0091)

MAINFRAME INSTALLATION

AXLE BRACE MOUNTING

Ú[•ãā]}ÁĠœÁā œÁæ¢|^Áā|æ&^Á}å^¦ÁœÁtæ&Ç|Áā æÁæ¢| Áã æÁæ; ÁÃã æÁæ; ÁÁæ Áæ&^Á]á[Áæ&Á]á[ÁæAÁ]á[ÁæAÁ]á[ÁæAÁ]á[ÁæAÁ]á[ÁæAÁ]á[æ&AÁ]æ&AÁ]ææAÁ]á[





POLYCARBONATE SAFETY WINDOW

NOTE: Installing a boom mower requires that all of the right side windows be replaced or protected with a polycarbonate window. This should be done before mounting the mainframe.




JOYSTICK AND SWITCHBOX MOUNTING

The switchbox is attached to the cross member on the front of the cab, to the right of the steering console. The joystick is attached to the door frame on the right side of the cab. Cables are routed to the right of the driver's seat and out through the rubber boot in the corner of the rear window frame. See the illustration in the Parts Section for hardware used and additional information. (ASM-JD 0087 silicon)





After installation of switchbox brackets 06411086, apply clear RTV (silicon) seal all around the outside of the bracket to prevent leaks.



SWITCHBOX WIRING

 $V@ \acute{A}_{S} [\mathring{A}\ddot{O}\ddot{U}\dot{O}\dot{O}\dot{D}\dot{A}_{S}] ^{\bullet} \mathring{A}_{S}^{\bullet} \mathring{$

V@ ÁÞ^`dæļÁÜæ^c¸ã^Ás ÁsæÁs¦[¸}Á¸ã^Á[&ææ^åÁ}å^¦Ánc^^¦ā;*Á&[|¸{}ÉÁÑÔ`cÁsæÁ|[cÁs,Ás@·Á ¦ã@Á;ã^Á;Á&[|¸{}ÁsfÁsæ&&^••ÉYOS/ÔPÁUWWÁ;¦Án¢ã;cā;*Á¸ã^•È

MANUAL LIFT VALVE PORTS

Á




(ASM-C-0102)

NOTE ON HUSCO CONTROL VALVES



JOYSTICK CONTROL MOUNTING

 $V@Ai_{1}^{\bullet} \circ ai_{2} Ai_{2}^{\bullet} Ai_{1}^{\bullet} Ai_{2}^{\bullet} Ai_{2}^{\bullet$






ELECTRONIC LIFT VALVE PORTS

(ASM-C-0089)Á

DANFOSS VALVE




WEATHER-PACK / METRI-PACK ASSEMBLY

 $V@ \bullet ^{A} + G * & Ca[] \bullet A * [] | ^{A} + A * [] | ^{$

NOTE: Use the specific tool for the type of connector you are assembling.


(ASM-C-0009)



1. Apply seal to cable, before stripping insulation.



2. Align seal with cable insulation.




3. Put terminal in crimping tool, then position wire and seal in place.



4. Crimp and visually inspect for a good crimp before installing in connector body.

CANBUS BOOM JOYSTICK CONTROL



VALVE MOUNTING


Cfccase@ko@ki/catç^Á([) cā,* kā; aæs\^oki[ko@ki/s å^; ki/ki/kko@ki aski[; kā^k/{[çā,* kko@ki
c, [Á^adki[|o f, ko@ki/o A^) å^; kaæ, ko@ki, [ki/kaæ, ki/kaæ, ki





HOSE AND WIRE ROUTING

V@Á^&[}åÁ@[^Á@[`|åÁ`}Á¸ædæ||^|Ág ÁœÆá[cc[{Á\å*^Á;ÆóœÁ;@^|Å;^||ĒÁTæ\Áo@Á @|^ÁGGÁ;[{Ác@Á;|â†ā,Áæ)åÁHË +Á;[{Ác@Áa[cc[{Á\å*^ÈÁW•^Ác@Ág æ*^•Áa^|[¸Á[;Á ;^~|^}&^È

NOTE: DO NOT CUT INTO TUBES / HOSES / WIRES WHEN DRILLING THROUGH METAL OR PLASTIC! DO NOTE: DO NOTE:








REAR STOW SIDE SLIDE ASSEMBLY

TIGER RECOMMENDS USING LOCTITE 271™ ON ALL FASTENERS BEFORE INSTALLING.

- A. THE INNER AND OUTER TUBES ARE SUPPLIED AS AN ASSEMBLY. REMOVE THE INNER FROM THE OUTER TO ASSEMBLE TO MOWER HEAD.
- C. ONCE ITEM 3 IS IN PLACE, SECURE INBOARD END CAP (ITEM 5) WITH ITEMS 9 (QTY 8), 14 (QTY 8) & 8 (QTY 4). LEAVE FASTENERS LOOSE TO ALLOW FOR NEXT STEP
- B. SLIDE THE INNER TUBE OF ITEM 3 INTO ITEM 1
 FROM OUTBOARD SIDE (OPPOSITE ROLLER
 ASSEMBLY) AS SHOWN. SLIDE THE INNER TUBE
 THROUGH THE OUTER TUBE. ONCE YOU HAVE
 TUBE THROUGH THE OUTBOARD SIDE, THEN
 SLIDE UP TO INROARD SIDE
- D. SLIDE OUTER TUBE ALL THE WAY OUTBOARD.




- E. SLIDE ITEM 7 INTO ITEM 3 (TURN 45° AS NEEDED) PART NUMBER FOR ITEM 7 LOCATED NEAR ONE END OF CYLINDER BARREL MUST GO TOWARD INBOARD END! LINE UP MOUNTING BLOCKS WITH HOLES IN OUTER TUBE. LOOSELY SECURE WITH ITEMS 11 (QTY 2) AND 13 (QTY 2). LOOSELY ASSEMBLE ITEMS TO OUTBOARD END WITH ITEMS 9 (QTY 4) AND 8 (QTY 4).
- F. WITH ALL ITEMS IN PLACE, CENTER ITEM 3 IN OPENINGS IN ITEM 1
 AT BOTH ENDS, THEN TIGHTEN FASTENERS. THEN TIGHTEN
 FASTENERS ON ROD ENDS. FINALLY, TIGHTEN BOLTS ON
 UNDERSIDE OF CYLINDER.

See the Slide Assembly page in the Common Parts Section for parts numbers and additional detail. (ASM-RSS SLIDE ASSEMBLY 2017)




REAR STOW SIDE MOWER HOSE ROUTING




D - MAIN BOOM CYLINDER GLAND
E - DECK ROLL CYLINDER BUTT
F - DECK ROLL CYLINDER BUTT
F - DECK ROLL CYLINDER BUTT
G - DECK SHIFT CYLINDER INBOARD
H - DECK SHIFT CYLINDER OUTBOARD

REAR STOW SIDE FLAIL HOSE ROUTING

WARNING NOTE:ÁV@Á•ˇåå^}Á¦^|^æ•^Á; Á@妿ĕ |æ& Á]¦^••ˇ¦^Á&[ˇ|åÁ&æĕ•^ÁœÁ*ˇ åå^}
{ [ç^{ ^} ơḥ -Áṣ^!^Á@æş^Â;ædœ ĒÁŒ; [}^Áş ÁœÁ; ÁæÁ; Á梕^Á;ædœ Á&[ˇ|åÁs^Á*^ç^!^|^Á@¦ơḥ!Á; Á; Aå|^åÈ
Q;Á[¦å^¦Á; Á; ^ç^} ơÁ@妿ĕ |æÁææ; I^ÉÖU ÁÞUVÁŒŠŠUY Ás@•^Á@妿ĕ |æÁæ; E&Áæ; AÖÜÒŒSÁ; I
ÓWÜÙVÆÁTæÀ^Á*¸ I^ÁœÁæ; -^ÓA; A¸ÆÇ, A¸Æ





 $\ddot{\Box} \ \ \ \ \dot{\Box} \ \ \ \dot{\Box} \ \ \dot{\Box$

WHEEL WELL HYDRAULIC TANK INSTALLATION

 $Q \bullet cad|Aad|Aaca] * \bullet Aad aAc aA \bullet Aad aAca Aad aAca Aac$

 $\dot{U}|_{\partial \mathcal{R}^{\wedge}} \dot{A}_{\partial \mathcal{R}} \dot{A}_{\partial$

FILLING HYDRAULIC RESERVOIR

Ü^~\Á(Ás@ ÁT æā, c^) æ) &^ÁÙ^&cā(} Á(¦Áā||ā, *Á) ^&ã&ææā(} •Áæ, åÁ@ 妿 |æ, áÅ^~ šā^{ ^} æ` |æ, áÅ @ 妿 |æ, áÅ Ø æ È

NOTE: Starting or running your Tiger mower before filling reservoir will cause serious damage to the hydraulic pump.

(ASM-C-0004hydro resrv)

WHEEL SPACERS

INSTALLING O-RING FITTINGS

INSTALLING NATIONAL PIPE FITTINGS

PREFORMED TUBE INSTALLATION

ŠæÂā[[{ •Á;}Á|[|'Ár[Ár@ærÁr@ Á;ãr@Ár@ Á&|æ{]Á;|æær•Áā;Á]ÈÁŠ[&æærÁæ|Ár`à^Á&|æ{] •Áæ;å å;•ææ|Ár@{Á|[•^|^Á;}d;Ár@ Á&|æ{] Á||æær•È

GENERAL HOSE INSTALLATION

 $\ddot{U}^{-} \dot{A}_{c} \dot{A}_{c}$


HOSE COVERING

 $\label{eq:control_c$



(ASM-C-0023)

BOOM HYDRAULIC DIAGRAM



ACCUMULATOR INSTALLATION

SOLENOID BRAKE VALVE



TEMPERATURE GAUGE MOUNTING QUÚVQUE OSO

 $T[`] o \acute{h} @ \acute{h} \land [] \land [ae] \land \acute{h} = * \land \acute{h} @ \land \acute{h} = * \land \acute{h} @ \land \acute{h} = * \acute{h$

WHEEL WEIGHT MOUNTING


\(\alpha\) \(\hat{A} \alpha\) \(\frac{A} \cdot\) \(

Q• cæ|ææā]}ÁsnÁ [• cÁ\æeāîÁs[}^Á¸ãcæÁsé\;|\ÁācĒ\$,•^\cā;*Ásé\;|\Ás,Ás@Ás^\;c\!Á|[cÁ;Ás@Á¸@^|Á ¸^ā@ĒÁ\@Á@æåÁ,Ás@Ásæ;•&\^¸•ÆsnÁqÁs@Ás@ÁUWWÙŒÖÒÁ,Ás@Á¸^ār@ɸão@Áæ;æ•@¦•Á [}Ás[cœÁs@Áā,•ãs^ÁsèàåÁ`œãs^ÁrÁs@Áæ••^{à|^È

\(\tilde{\tilde{\pi}\) \(\frac{\pi}{\pi}\) \(\

SINGLE COLUMN BOOMREST MOUNTING

 $\hat{O}_{ab}^{*} = \hat{A}_{ab}^{*} \hat{A}_{ab}^{$



AXLE BRACE INSTALLATION

 $Y \ \tilde{a} \ \tilde{a} \ \tilde{b} \ \tilde{c} \ \tilde{c} \ \tilde{d} \ \tilde{c} \ \tilde{c} \ \tilde{c} \ \tilde{d} \ \tilde{c} \ \tilde{c$

ÁÝ @}Ác@Á; æðj -læ; ^ÆiÁjÁ;[•ãtā]}ĒÁ^{[ç^Ác@Á&æ]•&l^,•Á;}^ÁærÁæÁð; ^Áæj åÁæ]]|^ÁæÁc@^æåÁ |[&lð;*Áæt^}cĒÁÜ^ðj•^lcÁc@Á&æ]•&l^,•Áæj åÁæð @^}ÁæÁ; l```^Áç Áçæ;*^•Á;[c^åÆjÁc@Áç;'``^Æs@ædcÁ |[&æc^åÆjÁc@ÁTæðjc^}æð;*AÙ^&cði}}ÁrÁc@áÁ;æð;*æð;*æðE¥VASM-MF-0013)

MAIN BOOM INSTALLATION

GREASE HINGE PIN ZERKS ON BOOM AFTER ASSEMBLY, ONCE UNDER LOAD WITH BOOM ELEVATED, AND AGAIN AT REST WITH BOOM SUPPORTED. (#ASM-C-0013)

DECK ATTACHMENT

 $\begin{array}{l} \text{Of cross.} @ \hat{A} \otimes \hat{A} \otimes$

 $\hat{O}[\ \ \ \ \ \ \ \hat{A} \ \$

 $\hat{O}[\ \ \ \ \ \ \hat{O}[\ \ \ \ \ \ \ \ \hat{A}] = \hat{A} + \hat{A$

Before proceeding to the final preparation step, double check the complete assembly from the mainframe to the cutter head against the diagrams in the Parts Section for proper placement and assembly of all components. Á(ASM-C-0060)



FINAL PREPARATION FOR OPERATION

OĦÁà[••^•ÊŊ ȝ•Áæ) åÁj ãç[ơŊ[ȝơÁ, శృÁ, ^^åÁt Áà^Át Aæ-^åÁæ-Áð, •d`&c^åÁð, Ác@ÁT æð, c^}æ) &^
Ù^&æŊ Ár Ác@áÁ, æð æÞEV@Á@妿 ¡æKÁ^•^¦ç[ãÁ&æ) Áæþ•[Áà^Áá]^åÁ, ãc@Áæ\Á'^&[{ { ^} å^åÁj ãå
Ç^^ÁT æð, c^}æ) &^ÁÙ^&æŊ Ďæ) åÁs@Ááj Ďæ; åÁs@Ááj •cæ|^åÆ, Ác@Áæ) ÈÆÄÖ[č à|^Á&@&\Áæ]Áæ; •æ
æ) åÁææ c^}^!•ÁÓÒØUÜÒÁcædæ; *Átæ&c[ÈÉÁÓCÞ•[Ár^&`|^Áæ) ^Á[[•^Á@]•^•Át**
; |æ] Á, ãc@Á] |ãcÁ@•^•Á; @|^Á; &&&; |Á; }Ás@Á@]•^•È

≜WARNING

ÓÒ ØUÜÒ Á cælcēj*Á, lÁ,]^¦ææēj*Ás@ Ádæ&d; lÁ[`Á,`•o Á^æå Áæ)åÁ}å^¦•oæ)åÁs@ Á Ùæ^c Áæ)åÁU]^¦ææēj}ÁÛ^&oēj}•Á, -Áo@ēÁ; æ)`ælÁs[{]|^o/|Ê

 $\begin{aligned} & Q\hat{A}xd\hat{A}^{\alpha}\hat{A}^{\alpha}\hat{A}^{\beta}\hat{A}^{\alpha}\hat{A}^{\beta}\hat{A}^{\alpha}\hat{A}^{\beta}\hat{A}^{\alpha}\hat$


Before operating the mower£x@ xx co^\xin 2 axia xx co\xin 2 axia xx co\xin 4 axia [{ xin 2 \xin 4 xin 4 xin 2 \xin 4 xin 4 xi


MOWER TESTING

 $\label{eq:label_label} $$ \end{align*} $$ \e$

If any parts of this Assembly Section, or any other section of this manual are not clearly understood you must contact your dealer or the address on the front of this manual for assistance! (ASM-C-0010)







TIGER BOOM MOWER OPERATING INSTRUCTIONS

READ AND UNDERSTAND THE ENTIRE OPERATING INSTRUCTIONS AND SAFETY SECTION OF THIS MANUAL AND THE TRACTOR MANUAL BEFORE ATTEMPTING TO USE THE TRACTOR AND IMPLEMENT. $Q\hat{A} = A\hat{A} = A$

\(\tilde{



A PELIGRO

Uãh, [A/^A\$] * |^• Eh, ãã æAsê `åæAsaAse * ã\} A `^A ãN[A/æA] æbæA`^A/^Adæå`: &æAæ {^åãaæ Aå^Á^*`¦ããæå Ēdùŏë□



)] IÒ

 $U] ^{l}$ aæa \overline{a} $A \hat{U} ^{k}$ ac \overline{a} $A \hat{H} \stackrel{\text{EG}}{G}$


1.OPERATOR REQUIREMENTS

 $\begin{array}{l} Q\hat{A} @ \hat{A}_{1}^{1} - |aef_{1}^{1} \hat{A} \otimes A_{2}^{1} | A_{3}^{1} \otimes A_{4}^{1} | A_{4}^{1} | A_{4}^{1} \otimes A_{4}^{1} | A_{$

Ùæ^Á;]^¦ææã;}Á;Á^``ã;{ ^}ơÁ^``ã^•Áo@æÁo@Á;]^¦ææ[¦Á; ^æÁæð;]¦[ç^åÁÚ/\!•[}æþÁÚ|[ơ&oãç^ÁÒ``ã;{ ^}ơÁÇÚÚÒE -{¦Áo@ÁoàÁs[}åããã;}•Á; @}Áœæææ&@;*ÊÃ;]^¦ææã;*ÉÞe^¦çã&ã;*ÉÞeò;åÁ^]æáã;*Áo@Áv``ã;{ ^}œÁÚÚÒÆ;Áå^•ã*}^åÁq[]¦[çãå^Á;]^¦ææ[¦Á;¦[ơ&oá;}Áæò;åÁa;&]åa^•Áo@Áy]|[ã;*Áæò;áÁ;^æå;K

PERSONAL PROTECTIVE EQUIPMENT (PPE)

- " Off, æê•ÁY^æ\ÂÛæ^ĉ ÁÕ|æ•^•
- ″ PælåÆPænc
- " Ùc^^|Á/[^ÁÛæ^c ÁØ[[c, ^æl
- ″ Õ∥ç^•
- " P^æ4ā) * ÁÚ¦[c^&cā[}
- ´Ô|[•^ÁØãcã;*ÁÔ|[c@3;*



A DANGER



Ó[[{

U]^¦æaa[}ÂÛ^&aa[}ÂHËH

2.TRACTOR REQUIREMENTS

QuÁsaååäāā)}ÁqfÁd;a&&qt¦ÁQQ¦•^][_^¦Ása}åÁrã^ÁA^ĭ~ã^åÁqfÁj]^¦ææ^Ác@Ás[[{Ár}ãnZÁc@Ád;a&&qt¦Á;~oóÁsa+ofÁsa^Á;¦[]^¦|^ ^``ā]]^åÁq[Á];[çãā^Á;]^¦æq[¦Á];[ơ\&cā[}ÊAq[Áæq^¦ơÁæq];[æ&@ā]*Áç^@æQ^Ásilãç^¦•Á;-Ás@ Áslæ&q[¦q•Á;!^•^}&\ÊÉæq)åÁq[^}•`'^Áda&d;'ÁncæàðjãĉÁ,@}Á[[ð]*Á,ão@Áo@Áà[[{Á`||^Án¢c^}å^åÈ

Tractor Requirements and Capabilities

- CEÙCEÒÁsa;] ; [ç^åÁÜ [||ËUç^¦ÁÚ | c^&cãç^ÁÛ d`&c` |^ÁÇÜ U Ú ÙDÁ; |ÁÜ U Ú ÙÁ&æàÁsa; åÁ^æÁs^|cÈ
- V¦æ&qˈ¦ÁÛæ^c^ÁÖ^çæk^•ÁÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÙ|[ÁT[çā]*ÁK^@æk|^ÁQÙTXDÁ\{ à|^{É} Œā)*É V¦æ&qˈ¦ÁÓæ||æ•cÁÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÌÒ•Á^~ã^åÁqíÁ;æājææājÁæ¢A\æ•cÁríæējèèÀà•ÈÁ;}Á\^æÁ^æáÁaā^

2.1 ROPS and Seat Belt

V@Ádæ&d;¦Á, ˇ•ơÁà^Áヘˇˇđ̞]^åÁ, ão@ÁæÁÜ[||ËÜç^¦Eܦ[e^&cãç^EÙd*&č;|^ÁQÜUÚÙDÁQdæ&d;¦Á&æàÁ;¦Á[||EàæbDÁæ}åÁ•^æc à^|cÁg Á;| c^8cÁc@Á;]^¦æg¦Á;|{ Áæ|jā *Á;~Ác@Ádæ&g¦ÉA^•]^8ãæ||^Áå ;¦ā *ÁæÁ;||Á;ç^¦Á;@¦^Ác@Áå¦ãç^¦Á8;| `|åÁà^ &\`•@ å Áæ) å Á ā|^ å ÈÁU} | ^ ÁI] ^ | æe^ Áo@ Ád æ&d | Á, ão@Áo@ ÁÜUUÚÙÁ Á óo@Á ææ ^ å Á [• ãæ] À Áæ) å Á ^ ææÁ أ أَلْهُ أَلَيْكُ أَنْهُ اللَّهُ اللَّهُ أَلَاهُ أَنْهُ أَنْهُ أَنْهُ أَنْهُ أَلَاهُ أَنْهُ أَلَالًا أَنْهُ أَلَاهُ أَنْهُ أَلِهُ أَنْهُ أَنْهُ أَنْهُ أَنْهُ أَنْهُ أَنْهُ أَنْهُ لَلْهُ أَنْهُ أَلِكُ أَنْهُ أَ V¦æ&d;¦Á([å^|•Á,[oÁ`čā]]^åÁ,ão@\$æÄÜUÚÚÁæ)åÁ^^ææÁs^|oÁ;@v`|åÁ@æç^Ás@•^Á;ã^Áræçā;*Á^æç;}*Á°Æ;¦^•Ás;•æd|^åÁs^Áæ; æ`c@\¦ã^åÁå^æh\bÉÁOPS-U-0003

AWARNING

 $\label{eq:control_loss} U] ^{1} a e^{A} A coe^{A} A O^{\tilde{}} a^{1} \{ ^{A}) c^{A} [] ^{A} a coe^{A} A coe$ [ç^\H;|c^&caç^Á+^•c^{ AQÜUÚÙDAÁOE, æ•Á, ^æAí^æá à^|o•DÁÚ\^lai`•Áa, b`l^Á[l ^ç^}A\$u^æe@A\$K[`|&A^•`|oÁ|[{ Áæq|āj*Aj~~Ás@^Aslæ&x[¦⊞;ædœ3&`|æd|^A\$u`¦āj*Áæd&c`¦}[ç^¦ . @ }Ás@ Ái]^¦æe[¦Ás[ĭ|åÁs^Ájā;}^åÁ;}å^¦Ás@ ÁÜUÚÙÈÁsjö∄□





2.2 Tractor Lighting and SMV Emblem

QÁc@ Ádæ&d ¦Á ālÁà^Ái]^¦æe^åÁ;^æbÁ;¦Ádæe^|^åÁ;} Áæ] `a|a&Á'[æå,æÂáaÁ `•oÁà^Á^` a]|^åÁ ão@Á];[]^; , æd}āj*Ápāt@zāj*ÁseojåÁseAù∥[, ÁT[çāj*Áx∧@a&|∧ÁpùTXD ^{ à|^{ Á, @ B&@ Áce ^ Á& |^ æ|^ Áçã a ā|^ Á; [{ Ác@ Á ^ æ Á; ~ c@\Á`}ādEÁT[•oÁda&Ad;|q\Á@aq;^Áåã-^\^}oÁ•^caã;*•Á[; []^¦ææā]*Áæa)åÁdæa)•][¦œā]*Ájāt@æā]*ÈÉÁÜ^-^¦Áq[Ác@ dæ&d;|Á[]^|æe[|e|Á(æ)`æ|Á-[|Á`•ā;*Ác@·Ádæ&d;|e|


OPS-B- 0017Á




Ó[[{

U] $^{\text{l}}$ aga \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A}

2.3 Tractor Ballast





3.GETTING ON AND OFF THE TRACTOR

Ó^{¦^Á'^œā)*Á;}qíÁœÁdæ&qí¦Éko@Á;]^¦æqí¦Á; *oÁ^æåÁæ)åÁ&[{]|^e^|^Á'}å^¦•œa)åÁc@Áqí]|^{^}óÁæ)åÁdæ&qí¦ []^¦æqí¦Á;æ)*æ†ÉÁQÁæ)^Á;ædó;Añão@¦Á;æ)*æjÁæjÁ;[oÁ&[{]|^e^|^Á'}å^¦•qí[åÉÆ]}•*|oÁæ)Áæĕc@¦ã^åÁå^æ}\¦Á¡¦ æÁ&[{]|^e^Á'¢]|æ)æqāj}ÉÁOPS-U-0007

AWARNING

 $O[A_{l}[\alpha_{l}^{A}] = A_{l}^{A} + A_{l}^{$



Ó[[{

 $U] ^{l}$ aecā[} $\hat{A}\hat{U}^{k}$ acā[} $\hat{A}\hat{H}\hat{E}$

3.1 Boarding the Tractor

A DANGER

$$\begin{split} & \text{P^c,} | \text{Add} | \text{Add$$



A DANGER



▲WARNING

 $\ddot{O}[A][O^{A}[]^{*}] O^{A}[]^{*} O^{A}[$



3.2 Dismounting the Tractor

Ó^{ | ^ Ásã{ [` } cã * Ás@ Át æ&c[| Ésá | ^ Ás@ Át æ&c[| Án} * ¾ ^ Ás[] } Ésá ñ^} * æ* ^ Ás@ Á@ æå Áæ) å Á^d æ&cÁs@ Ás[[{ Áæ} { Át c@ Ád æ} •] [| cÁ] [• ãtā] } ÈÁÚ æ\ Ác@ Ád æ&c[| ÁI] } ÁæÁN ç^|Án* ' | æ& ^ ÉÚ] | æ& ^ Ác@ Ád æ} • { ã • ã] } Áā Áŋ ^ ` d æþÁæ) å Án ^ ósæ @ | æ\ ¾ * Ásl æð ^ ÈÁÚ @ cÁs[] } Ác@ Át æ&c[| ÁN} * ¾ ^ ÉÁN { [ç^ Ás@ Á ^ ÈÉæ) å Ág æð ÁT | Áæ] Át [Æs[{ ^ Át ÁæÁs[{] | ^ c ^ (] ÁSæ ^ (] ^ | Éæ) å Ág æð ÁT æ&c[| Éð æð ÁN } * ¾ ^ ÉÆæ) å Át [] ^ | Áæ æð { [ç^{ } } cÁt Æsæ & [| Čæ & Át Át ÁæÁs[{] | ^ c ^ Át æð & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ c ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Át Æsæ & [] | ^ C ^ Æsæ & [] | ^ Æsæ & [] |

A DANGER

 $\begin{aligned} &\text{OOQUUOA} \land \text{aga} * \text{As@Ad } \text{assQd} \mid \text{A} \land \text{aga} \text{ase} \bullet \text{A} \land \text{oAs@A}, \text{ash} \mid \text{ash} \land \text{Asa} \mid \text{afp} \mid \text{A} \land \text{c} \\ &\text{c@Ad } \text{assQd} \mid \text{Ad } \text{age} \bullet \text{A} \mid \text{ash} \wedge \text{ash} \wedge \text{ash} \mid \text{ash} \wedge \text{ash} \wedge \text{ash} \wedge \text{ash} \mid \text{ash} \wedge \text{ash} \wedge \text{ash} \mid \text{ash} \wedge \text$



Ó[[{

 $U] ^{l}$ aga \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A} \hat{A}

4.STARTING THE TRACTOR

 $V@\dot{A}[]^{\dot{a}} = (\dot{A}(\dot{a})^{\dot{b}})^{\dot{a}} = (\dot{A}(\dot{a})^{\dot{a}})^{\dot{a}} = (\dot{A}(\dot{a})^{\dot{a}})^{\dot{a}$

- " Š[8 α e?\Ás@\Ást} ãā]} Á\^\Ð\ ãa\$.@Á
- "Š[&æe^Áo@Á\}*āj^Á\@oÁj~Á&[}d[|
- ″ Š[&æe^Ás@-Á@ 妿ĕ|æ&Ás[}d[|ÁA^ç^¦∙Á
- "Š[&æe^Áo@^Áat@Á&[}d[|Á/^ç^|
- ‴Š[&æe^Ás@^Áa¦æ\^Áj^忆Áæ)åÁ&|ĭc&@Á
- "Š[&æe^Ác@AÚVUÁ&[}d[|Á
- "Š[&æe^Ás@^ÁHÁ,[ã,cÁ@ã&@Á&[}d[|Á^ç^|
- ‴Š[&æe^Ás@^Áai[[{Á[]^¦æeā]*Á&[}d[|•ÁQQî^•œã&\Á[¦Áçæqç^Áaæa}\D

Ó^_f \^Árcædca} * Ác@ Ádæ&d \ Ár} • ` \^Ác@ Áf || [. a] * KÁ

- ‴Ô[}å`&oÁse|A∫¦^ËoæboÁ;]^¦æeā[}A॔§•]^&oā[}Áse)åÁq^¦çã&∧Áse&&[¦åā]*Áq Áso@Áslæ&o[¦Áq]^¦æe[¦qqÁ;æ)`æþÉÁ
- Τæλ ^ Á ` ' ^ Áæl Á ` æλ å Æ æλ å · Æ æλ å Á cæ ' Á æλ ĉ Áλ ° çãλ Áæ ^ Á ^ & ' \ ^ [Á§ Á μæλ È
- V@ Ádæ&d(¦Ádæ)•{ã•ã[}Á/\ç^¦•Áæ\^Á§A∫æ\Áj¦A;\Á,\^`dæ\ÉÁ
- " $V@As[[{Ai}]^{\adja}*As[]d[]\bullet Ase^As[As@Ai^*daeAse]aAi~Ai[\bullet aiai]È$
- ″ V@ ÁÚVUÁ&[}d[|ÁΛç^¦ÁánÁåãn^}*æ≛^åÈ
- \sim V@ Á@ ålæ jã&Á^{ [c^ Ásq} d[lÁ^c^!• Ásd^ Ásq Ás@ Á,^ dæÁ, [• ãðā] þÉÁ

 $\ddot{U}^{-\lambda} \dot{A}_{1} \dot{A}_{2} \dot{A}_{3} \dot{A}_{4} \dot{A}_{4} \dot{A}_{5} \dot{A}_{5}$








Ó[[{

5.CONNECTING ATTACHING HEADS TO THE BOOM

FÉÁÁÚcædóÁa^Ásæcæs&@j*Ác@Ájāç[cÁa¦æsk\^cQDÁqÁc@Ás@Ási[[{ QFD *•‡*ÁjţQDÁæjåÁ@ædåjæd^ÉÁÁÞ^¢cÁæææs&@Ác@Ás^[jðå^¦Áæjå]ãç[cÁà¦æsk\^cQDDÁqÁc@Ájãç[cÁà¦æsk\^cQFDÁ*•jð*ÁjjQDÁæjå @ædåjæd^È

GĐÁÁV@}Áæacæ&@Ác@Ád^^ÇÍDÁqÁc@Á+|ãã^Áæ••^{à|^ÇÎDÁヾ•ā;* &|æ{]ÇIDÁa;åÁœæå;æt^È

Í BÁOÐ, æ||^Á(æ), ^Á(`|^Áæ||Áa[|o•ÉÁ,`o•ÉÁæ), åÁ, ð, •Áæ; ^Áæð, Åæð, åÁ[|^&[{ ^}å^åÁg!|``^EÁOPS-RSS-0001



AWARNING

 Ofc[āñ AS[} cæSco4, ār@N@] co4*; -æSco* Aāj &l* aāj * A@ ålæ* | ā8A[āļAæa) \ • EA] * {] • EA([d] - EAc; aæc, o* Aæj å @] • ^ÁS[}} ^ &cāj } • ÈÁÜ | [d] - Aāc | ā8A[i] | o* o* i | Aác | Aác | i | Aác | Aác

AWARNING



Ó[[{

U] ^ | aecāi } ÁÙ^&cāi } ÁHĒ

6.PRE-OPERATION INSPECTION AND SERVICE

 $\begin{array}{l} & \left(-\frac{1}{4} - \frac{1}{4} - \frac{1}{4} \right) - \frac{1}{4} -$

AWARNING


U^|a||åa8aa||^Aa||•]^&cAae|A||[çā||*A|] ædo A-[|A|, ^æd-Aæ)|åA||^]|æ&^A. @}}^&x••æ^A||áa@æ||ča@æ||ča%a||áx||ca&/A||ædo EXS[[\A[|•^Aæ|c*]*|EA||]|•^Aæ||c*||e*||A|||[•^Aæ||c*||a||A|||]||e*||A||||e*||A||||e*||A||||e*||A||||e*||A||||e*||A||||e*||A||||e*||A||||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||a*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||a*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||a*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||a*||A|||e*||A|||a*||A|||e*||A|||e*||A|||e*||A|||e*||A|||e*||A|||a*||A|||e*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A|||a*||A||





 ADANGER
 OĦAUæ^c AJ@A |å• EAO` æå• Aæ) åAUæ^c Aå^çæ\• Æ & å å * AG¸ cA⟩ [c

 |ã ão* åÁť DÁŒœ ÁÖ^↓^&ť ¦• ÉÃÔœ ÃÕ° æå• ÉÃÙơ^\ÁÕ` æå• ÉÃÔ° æå• ÉÃÚVU Á¸ co* læ¸ cæ) åÁÜ^c æ&ææì ÅŐ [¦ÁÛ@A |å• Á @` lå]



Ó[[{

6.1 Tractor Pre-Operation Inspection/Service

- "Vā!^Á&[} åãdā[} EðeālÁ| |^•• ` |^
- ″ Υ @^\Å * Æ [| σ Α΄
- ″ Ùc^^¦ā, * Áā, \æ*^
- ″ÚVUÁ, @a\ĺåÁ
- " ÙT XÁ: ā } Ás Ás As As à Ás ã ãa |^
- " V¦æ&d; ¦q;Áã; @ Áæ;Á&l^æ;Áæ;åÁ;}&dã;}æ
- ″ V¦æ&d;¦ÁÛ^æeÁs^|oÁsiÁsiÁsi[[åÁ&i]}åãaāi}Á
- ŰUÚÙÁ≨nÁŞnÁs@AÁæ≨n^åÁn[•ãc≨i}
- ″Þ[Ádæ&d[¦ÁjájÁ∱æð.•Á
- ″Üæåãæe[¦Á¦^^Áj-Áå^à¦ã•Á
- "Ò} * ā, ^ Á, ā/Á^ ç^ |Áse) å ÁS(} å ãcā) }
- " \dot{O} * \ddot{a} \dot{A} * \ddot{a} (\dot{A}) * \dot{A} *
- ″ Ú[、^¦Áà¦æ\^Á∤ˇããÁ/^ç^|Á
- "Ú[^\Ác^\\a]*Á\`aaA\\c^\|Á
- " $Q^{"} \wedge |AS|$ | ASQ |
- ″Ù`~a&a^}oÁ;à¦a&aeaa[}ÁseeÁse|Á;à^Á;[ā]o•
- " OFAÁARON! ÁSI } å å å å } Á Á Ó PS-Ü-0030



6.2 Boom Unit Pre-Operation Inspection and Service

Q)•]^&oÁæ)åÁ•^¦çã&^Ác@Áà[[{Áæd{Áæ)åÁ@æåÁ]¦ā[¦Á[Á[Á]]^¦ææā]}ÈÁÁÖæ{æ*^åÁæ)åЦÁà;[\^}Á]æd•Á•Q`|åÁà^ ¦^]æā^åÁæ)åЦÁ¦^]|æ&^åÁā[{^åãææ*|^ÈÁÁKV[Á^}•`¦^Ác@Á`}ãÁãÁ:Á'^æå^Á[¦Á[]^¦ææā]}ÊÁ&[}å`&oÁc@Á{||[¸ā]*K OPS-B-0020Á

AWARNING

U^|ā|åaBæd|^Aā|•]^&cAæd|A[[çā]*A]ædoA-[lA]^ædAæ)åAl^]|æ&AA.@}}^&^••æh^Á;āc@deĕc@!ā^åAr^|çāB^A;ædo ÈÁŠ[[\Á[!Á][•^Áæec^}^!•ÉÅ[!}[\Á];\A]ædo ĒÁæ)åÁ|^ædo^Á;\A][[•^Áæca]*•ÈÁTæh^Á•`!^Áæd|Á]ā]•Á@æç^æcææ&@;*Áædå]ædo^ÉÁæ)åÁ|^a]•Á@æç^æcæ&@;*Áædå]ædo^ÉÁæ)åÁ|*[[åA,[!\A]*Á;lå^!EÁ\jöte=cæ





U]^¦æaā[}Áùl^&aā[}Án∐E€

 $\label{eq:conditional_problem} $$V @ A_1 = A_2 & A_3 & A_3$

~ Ò} • ` ¦^Áæ|Áæ^ĉ Áã} • Áæ^Áã, Á¦ |æ&^Áæ; åÁ* ãæ|^ĚÁ\
Ü^] |æ&^Á; ã•ã, Èåæ; æ* ^寿; 寿; 寿]^ åÆ|/^* ãæ|^Á
å^&æ|• ĚÁOPS-U- 0011_A



ØÜŒT ÒÁŒÙÙÒT ÓŠŸ

- ″ Q,•]^&oÁ&[}åãcā[}Á,~ÁÙ,ãç^|ÁO≣•^È
- Ö) ` ¦^Ásch|Ás[|œÁsc) åÁn &¦^¸ Ásc}^Ásj Áj[• ãcā[} Ásc) åÁ
 æb^Á;|[]^!|^Ás[!` `^åÈ
- Ö) ¹ ¹ ^ Áæḥ Á ñ Áæ ^ Áñ Á |ææ ^ Áæ è å Áæ e ^ } ^ å Á ã @Á
 &¹ ^ È



Ó[[{ U]^ $|aea_1|$ ÂV^& $a_1|$ ÁV

AWARNING

Ü^|a^c,^Â@ å|aĕ|a&Á|^^••`|^Á|:á|:Áṭ Áá[ā] * Áæ) ^Á; æā] c^} æð, k^i; lÁ^] æāiÁ; [:\ ¼; Àæ) ÁQ]|^{ ^} dĒ Ú|æ&^Áx@ÁT [, ^|ÁP^æáiÁ; }Áx@Á; [` } åÁ; |ÁA^&` |^|^Á`]][!c^åiÁ; }Áa|[&\•Á; lÁa cæ) å•Ēåãa^} * æð ^ c@ÁÚVUĒæ) åÁč; }Á; ~Áx@Á? * ð, ^ÈÁÚ° • @Áæ) åÁ; "||Áx@Á&[}d[|Æ\$^ç,\•Á; lÁa] ^• cæ& Á^¢,\°A; a‡Áæã ^• qÁ^|a³ç^Á; |^••`|^Á; lá|:Áṭ Ácæda; *Áæ) ^Á; æāi c^} æð, &^Á; lÁA^] æāiÁ; [!\ÈÁqùon#d

AWARNING

Þ^ç^¦ÁŚ^æç^Ác@^Á([, ^¦Áš] *æœ^} å^åÅ, @¾^Ác@ Á@ æåÅæã, Áāg Ác@ Á¦æãa^å][•ãtā[}ÈÁÁ/@^Á([, ^¦Á\$[`|åÁæ|Á\$æĕ•ā]*Ár^¦ā[`•Áā] b`¦^Á([Áæ)^[}^Á, @ॄ {ã@Áā;æåç^¦c^} d^Áà^Á}å^¦Ás@^Á([, ^¦Á¢)o⊤₫□



OUUT ADEJT ADEJUOT OSY

- "Q•]^&oÁs(}åããã}}Á;Aó@Áà[[{Áse}{Á;^|å{^}c


- ″Ô@^&\Á&[}åãαā[}Á;~Áa`•@3;*•ÁaæAa[[{Á;ãç[cÁ][ā]o•Áaa}åÁ@妿ĕ|&&&â[ā]å^¦Áaæ)*•È



AWARNING

PYOUCENSOOASO OAD UUOOVOU Þ

- "Q•]^&oÁc@A&[}åããã[}Á;-Ác@Açæqç^Á;[`}cã;*È
- ´´Ò}•`¦^Áãcā,*•Ásd^Á;¦[]^¦|^Á&[}}^&c^åÈ OPS-RSS-0005



U]^¦æeā[}Áû^&cā[}ÁHËG

Ý[[{

AWARNING



PŸÖÜŒŃŚŒĂŪWT ÚÐJŒŚĂŨŎŮŎÜXUŒĴ

- ´ Ô@ea)*^Á@[°] 妿ë|æ8√Å, ãÁ4ā¢^¦Áea)åÁ@° 妿ĕ|æ8√Á, ãÁ æ8&8[¦åã]*Áq[Á;æaā]¢^}æa)&^Ás&@° å*|^È
- `` \^\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\\\dag{\phi}\dag{\phi}\\dag{\phi}\d
- "Q•]^&oA,ç^¦æ|Á&[}åããã[}Á,-Á@妿ĕ|ã&Á,`{]È
- ‴ Q.•]^&oÁ,`{]Áå¦ãç^Án @eedÈ



Ô@&\Ác@ÁļˇãåÁ¹¸ç^|Áş Ác@ÁP^ 妿ĕ |æÁ¼æ)\Á¡}Ác@ V¦æ&q!Êæ; åÁæååÁ; ⼿Á^~ˇã^åĚŒ Ác@ÁæãÁœe Áà^^}Á; l&°åÁ; ˇớq Ác@ÁÔ^|āj å^!•Áæ; åÁP[•^•ÊÃǽt*[^•Áṣ] q Ác@ P^妿 |æÁæ; \Áæ; åÁ^å*&^•Áæ¸6; ['{^Á; Á; āÞÉT æã; œæð; Ác@Á; āÁ¹¸ç^|Á; ãc@ð; Ác@Á; ã æðt æĕ *^Á; &æçåá;}Ác@Á; ãa^ [-Ác@Á¹^•^!ç[āÞÞ^ç^!Áä;Ác@Áæ; \Áæà[ç^Ác@Á;ã æð4 * æ* *^Á; Áæd[¸Á; lÁc@Á¢; æ)•ā; Á; -Áæðá; āð4 @ð4 æ* *^Á; &ææ¸åá;}Á; Ac@Á; æ; Acæá; Acæ

AWARNING

Offich } cat } káu ajázoaj/h; álóaaj ás ásapp [ás@ áÚ!^••*; |^ÁÜ^|ah-álóaaj È

Ü^{ [ç^Á&æ]Á|[] | Á[Á¦^|ā^ç^Á] |^^••`|^Áà^-[|^Á'^{ [çā]*Á&æ]Á&[{]|^c^|ÊĂÙæêÁ&|^æ;Ác[]|^c^}cÁ;^ā *Á&æ]Á&[{]|^c^|ÊÁÙæêÁ&|^æ;Ác[]|^c^}cÁ;^ā *Á&æ]Á&æ;Ác] | A@æ£æ *Áa|Á; A@æ£æ;Ác[]|^c^êÁæ} åÁæ]å {æÁæě•^Á^|ā[*•Á]; A *Áa;Ác]*Ác[A*^•ÊÁæ&^ÊÁæ]åÁ*¢][•^åÁ\ā]ÈÁops-0001-MISC)

AWARNING

U]^¦æa**ā**}Â**Û**^&a**ā**}ÂÚ*

Ó[[{

d VOEÜŸÁPÒŒÖÁŒ ÙÚÓÔVOJÞ



Q•] ^8x/6x2 Á8[} åããã[} Á; Á8à^8\Á\ããÁ Q2^•Á9; åÁ92±å; æ4^ÈÁOPS-RSS-0003

AWARNING

 $O[A_{i}[\sigma] \circ A@_{i} a \bullet A_{i}|A \land \circ A^{i} a \land A^{i} A_{i}[, \land A^{i} \land A^{i} \land A^{i}] \circ A@_{i} a \bullet A^{i} A^{i} A^{i} A^{i} \circ A@_{i} a \bullet A^{i} A^{i} A^{i} A^{i} \circ A@_{i} a \bullet A^{i} A^{i} A^{i} A^{i} \circ A@_{i} A^{i} A^{i} A^{i} \circ A@_{i} A^{i} A^{i} A^{i} \circ A_{i} A^{i} A^{i$



A DANGER

U]^¦æaā[}ÁÛ^&cā[}Áh[ËT

Ý[[{

ØŠOEŠÁP ÒOEÖÁDÞ ÙÚÒÔVOUÞ

- Q•] ^&c/a|æå^•/aáa|æå^Áa|[o•Á[:|ó•Á[:|á|[[•^}^-^- Áa) åÁ\¢&^••ã[^/, ^æb/Á[:|á|[ææ^/Á[:|Á|[[•^]-^]-^- Áa]:|Á|
 &@ &\ ā] * Áaæ ā\:\BÜ/^]|ææ^Áaæ æ* ^åE¾[:|; EÁæ) åÁ
 { ã•ā] * Áa|æå^•Áæ/Æ[{]|^c^Á-^o•Á[:/, ææ]cææ]Á
 &` co^!•@æo/aæa/æ}&^E
- ¨ Ò}• `¦^Á` àà^¦Ás^-∤^&q[¦•Áse^ÁspÁ,[•ãtā]}Áse)åÁ
 }[oÁsæ{æ*^åÈÁÜ^]|æ&A^Á,[¦}ÆÁse]åÁ
 {ã•ā]*Ár^&aã;}•Ás[{ ^åãææ^|È
- $\begin{tabular}{ll} \raisetimes \raisetimes$
- Q•]^&oós@æcÁæd|Áā[|o•Áæð;åÁn&l^¸•Áæð^Áā;Á][•ãuā[}Á
 æð;åÁæð^Á;![]^!|^Á[!~*^åÈ
- "Q•]^&oÁs@Á&[}åããã[}Á;-Ás@Áå¦ãç^Áà^|o•È
- ``` \^\\(\hat{A}\) (\rightarrow\) (\right
- Ű^{[ç^Áæ}^Át¦æ••Át¦Ápœ°!Ás^à¦ãrÁ, @3&@Á, æ∂Ás^Á¸¦æ}]^åÁæ;[*}åÁs@^Á&`œ^¦•@ææ•Án}å•È
- "Q•]^8xÁx@^Á8[} åããã]}Á; Ás^8xÁx\Á\ããÁx@}^•Áse) åÁœ±å, æb^ÈÁOPS-RSS-0004



 $O[A_{i}[\sigma_{i}^{A}] \circ A^{\otimes a}] \stackrel{a \bullet}{} A_{i}|A^{\wedge} \circ A^{\circ}] \stackrel{a \bullet}{} A^{\circ}|A_{i}[]_{i}^{A} \stackrel{a \bullet}{} A^{\otimes a}] \stackrel{a \bullet}{} A^{\circ}[] \circ A^{\otimes a} \stackrel{a \bullet}{} A^{\circ}[] \circ A^{\otimes a} \stackrel{a \bullet}{} A^{\circ}[] \circ A^{\otimes a}[] \circ A^$




A DANGER

 CΠΑÜæΑ° CÂÜ@Λ|å• ΕÃÖ * æå• Åæ) åÅ[c@\Å•æΑ° CÅå^çæΛ° Åå, &| * åå, * ÅÇā* cÅ}[cÅ|ã æΛå Åq DĀE Ö^+/8c[!• ΕÃÜ¢^|ÁÕ *æå• Áæ) åÁÕ^æà[¢ÁÜ@Λ|å• Á(*• σÁà^Á*• ^åÁæ) åÁ(æã cæã) ^åÁð Á† [å [[å] [\] ð *Ág] } ÄñQ∏ÁæΑ° CÅå^çæΛ° Åα @ * |åÁà^Áş•] ^8¢Λå Åæ&Α° | | Áæ¢Á° æ• σÁæð Á [¼, ã•ð * [| Áæ] / 8¢Λå (] [] } Åæ Áγ æ• σÁæβ Ág Áγ ¼ Åα * 8Λ (] ææΛå Áæβ / 8Λ (] ææΛå Ææβ / ææΛå Ææβ / 8Λ (] ææΛå Ææβ / 8Λ (] ææΛå Ææβ / 8Λ (] ææΛå Ææβ / 2 æÆΛ Ææβ / 8Λ () ææΛå Ææβ / 8Λ () ææΛå Ææβ / 8Λ () ææΛά Ææβ / 8Λ () ææΛå Ææβ / 8Λ () ææΛå Ææβ / 8Λ () ææΛå Ææβ / 8Λ () ææΛά Ææβ / 8Λ () ææΛα Ææβ / 8Λ () ææΛά Ææβ / 8Λ () ææΛα Ææβ / 8Λ () ææΛά Ææβ / 8Λ () ææΛα Æβ / 8Λ () ææΛα Ææβ / 8Λ () ææΛα Æβ /

U]^¦æaā[}Áù\^&aā[}ÁHËÉ

6.3 Cutting Component Inspection


Q•]^&oÁa|æå^Ájæ}åÁa}åÁa|æå^Áæ•^{{ à|^ÁA; | Ás@•Á; ||[¸ã;* kÁ OPS-U-0031



▲ DANGER

Q.•]^&AC@ AO|æ\$^•A&æ\$|^Af|Aæ}}[!{ æ|A, ^æHEUOUSOEOOAOUVPAOSCEOOUA;}Ac@æn&æ|;&| QTTÒÖQQE/ÒŠŸÁSÁNão@¦Ási|æå^Á@æK

- $\dot{O}^{8}[\{ \dot{A}_{a}^{a} \} \dot{A}_{a}^{i}] \{ \dot{A}_{a}^{a} \}_{a}^{i} \} \dot{A}_{a}^{i}] \{ \dot{A}_{a}^{a} \}_{a}^{i}]$
- OE; ^Á&; æ&\•Áæ; ^Áçã; ãa | ^ÉÁ; ¦Á
- Ö^^] Á [* * ^ Á§ Ás@ Ás|æå^q Á * | ~æ&^ Ásd^ Á; | ^ ^ } æÂ; l
- Õ[**^•Á;|Á&@]]^åÁæ;^æ;Áş Ás@ Á&; œā;*Árå*^Áæ;*^lÁs@æ;ÁFEG;AGFCEË;{{ DÉA;¦Á V@ Á; ææ;'{ãæ;Á;}Ás@ Áræå;ā;*Árå*^Á@æ;Ás^^},Á;[;|^Ás@æ;ÁrEG;GEË;{{ De



Original Blade Edge

NOTE: Replace Blades in pairs after no more than 1/2" (12.7mm) wear $$O\ p\mbox{-}23$$

 $U] ^{\pm}$ aæa $[A\hat{U}^{8}a_{1}] A\hat{U}^{8}$ Ó[[{

Tractor PRE-OPERATION Inspection			
Mower ID#	Make		
Date:	Shift		
Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.			
Item	Condition at Start of Shift	Specific Comments if not O.K.	
The flashing lights function properly			
The SMV Sign is clean and visible			
The tires are in good condition with proper pressure			
The wheel lug bolts are tight			
The tractor brakes are in good condition			
The steering linkage is in good condition			
There are no visible oil leaks			
The hydraulic controls function properly			
The ROPS or ROBS Cab is in good condition			
The seatbelt is in place and in good condition			
The 3-point hitch is in good condition			
The drawbar pins are securely in place			
The PTO master shield is in place			
The engine oil level is full			
The brake fluid level is full			
The power steering fluid level is full			
The fuel level is adequate			
The engine coolant fluid level is full			
The radiator is free of debris			
The air filter is in good condition			
Operator's Signature: DO NOT OPERATE an UNSAFE	TRACTOR or M	OWER	
	, , , .		

 $V @ \hat{A} @ \hat{A} @ \hat{A} / \hat{A$

Ó[[{ $\text{U] } \land \text{laga[} \text{ } \text{ } \hat{\text{AU}} \land \text{\&ca[} \text{ } \text{ } \hat{\text{AHEF}} \ddot{\text{I}}$


Boom PRE-OPERATION Inspection			
Mower ID#	Make		
Date:	Shift		
Before conducting the inspection, make stopped and the tractor is in park with mower is resting on the ground or securibeen relieved.	n the parking brake	engaged. Make sure tl	
Table 1:			
Item	Condition at Start of Shift	Specific Comments if not O.K.	
The Operator's Manual is in the tractor			
All safety decals are in place and legible			
The mounting frame bolts are in place and tight			
The boom connection bolts & pins are tight			
There are no cracks in boom			
The hydraulic cylinders pins are tight			
The hydraulic pump hose connections are tight			
The hydraulic valve controls function properly			
There are no leaking or damaged hoses			
The hydraulic oil level is full			
There is no evidence of hydraulic leaks			
The blades are not chipped, cracked or bent			
The blade bolts are tight			
The deflectors are in place and in good condition			
The boom shields are in place and in good condition			
The skid shoes are in good condition and tight			
There are no cracks or holes in boom deck			
The hydraulic motor mounting bolts are tight			
The boom head spindle housing is tight and lubricated			
Operator's Signature:			


DO NOT OPERATE an UNSAFE TRACTOR or MOWER


 $\acute{O}[\ [\ \{\qquad \qquad U\]\ ^{|} aca \hat{a}\ \}\ \acute{A}U^{\wedge} &ca\hat{a}\ \}\ \acute{A}H^{\dot{\underline{H}}}\dot{\underline{C}}\dot{l}$

Cable Controlled Mowers


ODÉN[}d[|Án^ç^¦Án^&ækÁnā[ābækÁn[Án@Án}}^Án@]}Án^[,Án@]`|åÁn^Án^ækÁn@ÁN]}d[|Áṣækç^Án[Án^{ā]åÁn@Án]^¦æm[¦Án~ o@Án^ç^¦Án}}&aā]}•È







6.4 Switchbox




SAFETY SHIELD & DEFLECTOR OPERATION Failure to close Safety Shield and Deflector may allow objects to be thrown outward with great force which can cause property damage, bodily injury, or death. SAFETY SHIELD 1. Keep Safety Shield and Deflector fully closed when cutting grass and weeds to reduce possibility of objects being thrown outward by the Blades if persons are in the area. Before Cutting brush, trimming limbs, or other such operations, raise the Deflector and Safety Shield fully to allow the blades to contact the material if area is clear of passerby. Operator must stop cutting and close shield if passerby enters the thrown objects area or blade contact area. 3. Repair or replace Safety Shield and Deflectors as DEFLECTOR needed. 4. Always transport with Safety Shield and Deflector closed. 02967867


Ó[[{


ŠÒXÒÜÁRFÁT ŒÐ ÁÓUUT

ŠÒXÒÜÂGÁÙØÖÒÁÙPØV











Ó[[{

U]^\aeaa[}ÂÛ^&ca[}ÂHËGF

ŠÒXÒÜÂN ÁÓUUTÁÙY QXÒŠ

ŠÒXÒÜÂÁÍ ÁÓUUT ÁÙP QÒŠÖ





Ó[[{

 $\text{U] } \land \text{| aeea} \text{| } A \hat{\textbf{U}} \land \text{| &ca} \text{| } A \hat{\textbf{HEGG}}$

7. Joystick Controlled Mowers


 $V@\dot{A}_{0}[{\{\dot{A}^{*}\}} & cal_{0}\} \bullet \dot{A}_{0} \bullet \dot{A}_{0}] d[||^{a}\dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0}] \bullet cal_{0} \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet cal_{0} \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet cal_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{A}_{0} \bullet \dot{A}_{0} \bullet \dot{A}_{0}] \bullet \dot{A}_{0} \bullet \dot{$

A CAUTION

QÁc@Át[^•cæk\Ák[}d[|ÁæÁf[oÁ[]^!ææā]*Á]![]^!|^ÊŘč'}Åc@Á(æ•c^!Á•¸ãæ&@[Ác@ÁkJØØ+Á][•ãæā]È
Q•cæd|Ás@Á(æ)*ædýædy;^Á@æ)å|^Át}}d[Ágædy;^Áæd)åÁt]]^!ææ^Ás@Á*}&cāt}•Ás}åäçãa*æd|^Át[Át[,Áæ[]{È
Œe^!Áa[[{ÆæÁ*rt],^åÁ\$,Á^•cÊÁdæ)•][!oÁc@Á;}ãóÁt[Ác@Á;ææ\$,c^}æ)&^Áæ&;āãcÁæ)åÁ&[}ææ&oÁ[*'!Vã^*!Ás^æ4*!Át[!Áæ••ã*ææ}&^È

A CAUTION DO NOTÁREZ^{] $O(A[A])^{=}$ ex^{A_0} A_0 A_0 A


Þ[c^kÁÚˇ• @] * Á; æ) ˇæþÁçæþç^Á@æ) å|^•Á‰ œĤ; lÁ‰æ, æê +Á+[{ Ás@ Ádæ&d; lÁ&æàÁ, āļ/Áàlā; * Ác@ Á; æā; à[[{ Á‰] +ÉÁ ãà^Á; œÃ-Ó¾, ˇœÆÁ[||Áà^&; Á‰; œÃ-Ó¾, ¸ãç^|Áà[[{ Á‰e-cHŽÚˇ||ā; * Á; æ) ˇæþÁ@æ) å|^•Át[¸æðåÁ&æàÁ, āļÁ^c { æā} Áà[[{ Á‰[] } +ÉÁàlā; * Á ãà^Á; œÃ-ÓÁ, œÃ-ÓÁ, æÃ-ÁÁ, æÃ-ÁA, æÃ-ÁA, æÃ-ÓÁ, æÃ-ÁA, æÃ-ÓÁ, æÃ-ÓÁ,



U]^¦æea[}ÂÛ^&ca[}ÁHËGH

7.1 Switch Box and Joystick Control


 $V@\dot{A} = \frac{\dot{A} - \dot{A}}{2} + \dot{A} = \frac{\dot{A}}{2} + \dot{A} = \frac{\dot{A}}{$






Ó[[{

Joystick Control




RUŸÙVÔSÁØY ÖÐÓÐÓSÁT UXÒÙÁT ŒÐÞÁÓUUT




Ó[[{

U] $^{\text{l}}$ axe $^{\text{f}}$ } $^{\text{h}}$ $^{\text{l}}$ $^{\text{h}}$ $^{\text{c}}$ $^{\text{f}}$ } $^{\text{f}}$


RUŸÙVÔSÆÒØVÐŰŐPVÁUPØVÙÁ/PÒÆÖÔSÁÚŐÖ VUÁJŐÖ



ŠÒØVÁRUŸÙVØĴSÁÜUŠŠÒÜÁT UXÒÙÁÖÒÔSÁÜUŠŠ




ÜŐPVÁ RUŸÙVÓDSÁÜUŠŠÒÜÁTUXÒÙ Á ÓUUT ÙY OXÒŠ



Ó[[{

U] $^{\text{l}}$ ascā[} $^{\text{h}}$ $^{\text{h}}$ $^{\text{h}}$ $^{\text{h}}$ $^{\text{h}}$ $^{\text{h}}$



8.DRIVING THE TRACTOR AND IMPLEMENT

 $\begin{array}{l} \text{`U} \text{@w} \land \text{d} \text{ ass}_{\textbf{c}} \mid \land \text{d} \text{ass}_{\textbf{c}} \mid \land \text{d} \mid \land \text{d} \text{ass}_{\textbf{c}} \mid \land \text{d} \text{ass}_{$

 $\ddot{\Delta} = \ddot{\Delta} + \ddot{\Delta} +$

 $S^{^{}}_{A} = \frac{1}{4} A^{^{}}_{A} A^{^{}}_{A} = \frac{1}{4} A^{^{}}_{A} A^{^{}}_$

A DANGER




AWARNING

U]^{acaaa}}ÂÛ^&caaa}}ÁHËGÏ


Ó[[{


A DANGER



AWARNING

V:aa)•][:loÁ[}|^ÁææA•]^^å•Á;@!^Á^[`Á&æa)Á{æājaæājA&[}d[|Á[-Ác@-^``ā]{^}dĚÁV^;ā[`•Áæ&&ãā^}o•Áæa)åÁājb';ā(•Á&æa)Á^•`|oÁ;[{Á;]^;ææā]*Áœã-^``ā]{^}dææA@ā*@Á•]^^å•ÉÁV);å(*)•æa)åÁc@ÁV;æ&d[;Áæa)åÁQ]|/{^}oÁæa)å





V^• oás@ Átæ&qt ¦ÁæÁæÁ; [¸Á]^^åÁæj åÁæj &l^æ•^Ás@Á]^^åÁ|[¸|îÈÁŒ]]|^Ás@ÁÓ¦æà^•Á{ [[c@îqt Áå^o!{ a}^Á@Á; d]]a]*Á&@ædæ&c!ārææf Át, Ác@ÁV¦æ&q¦ÁæjåÁQ]|/{ ^}dÈÁŒ£Á[`Áæj&l^æ•^c@Á•]^^åÁ[-Ác@ÁV!æ&q¦Ác@Á; a¢ā]`{ dæj•][¦óÁ]^^åÁ[-Ác@ÁV!æ&q¦Ác@Á; a¢ā]`{ dæj•][¦óÁ]^^åÁ;[oÁţ Á¢&^^åÁŒ£Á;]@ÁÇHEÁ]@Ø4;¦Ádæ)•][¦oá]*Ás@áÁ°`ā]{ ^}dÈ

U}|^Áda;)•][¦oÁo@^Á/¦æ&d[¦Áæ;)åÁQ]|^{^}oÁææÁo@Á*]^^å•Á;@B&@Áæ;|[¸Á[*Áq[Á;![]^!|^Á&[}d[| o@Á*`*ā]{^}cÈ

Ó^Áṣṇ æh^Á; -Ás@Á;]^¦ææāj*Á&[}åãáāj}•ÈÄÖ[Á;[ơÁ;]^¦ææ^Ás@Á/!æ&d;¦Á¸ão@Á,^æàÁ;¦Áæĕ|ćÁsilæà^• [¦Á;[¦}Ásā^•ÈÁY @}Á;]^¦ææāj*Áå[;}ÁsæÁ@āļÁ;¦Á;}Á,^ơÁ;¦ÁæājÁ|ā&\Á[æå•ÉÁs@Ásilæàāj*Áåārœæj&^ āj&¦^æe^•ká·•^Ár¢d^{ ^Á&æd-ÁṣæjåÁ^å*&^Á[`¦Á;]^^åÈÁÁY @}Á;]^¦ææāj*ÁgÁtæææðÁṣæjæê•Á·•^ œÁ/¦æ&d;¦qiÁjæœ@āj*Á;æb}āj*Áðt@ehæjåÁ^å*&^Á[`¦Á;]^^åÈÁÁÓ^Áṣæ;æb^Á;-ÁsææðÁæs[`}åÁ[` æjåÁ;ææ&@Á;°óÁ;¦Ás@Á;cœ¦Á*^ÈÁÉ



Ó[[{ U]^\aeaa[} \hat{L}\cdot \secate \hat{L}\cdot \hat{L}

8.1 Starting the Tractor



8.2 Brake and Differential Lock Setting


$$\begin{split} &\text{T} \triangleq \wedge \hat{\mathbf{A}}^* \mid \wedge \hat{\mathbf{A}} \otimes \hat{\mathbf{A}} \mid \hat{\mathbf{A}} \otimes \hat{\mathbf{A}} \mid \hat{\mathbf{A}} \mid \hat{\mathbf{A}} \otimes \hat{\mathbf{A}} \wedge \hat{\mathbf{A}}$$

Ot, æ•Áåā^} * æ*^Ác@ Átæ&c[¦Áåā~^\^} cãæþÁ[&\ Á¸ @}
c ;} ā; * ÈÁY @} Ár} * æ*^åÁc@ ^Áåã-^\^} cãæþÁ[&\ Á¸ ā]
] '^ç^} cÁ[¦Á|ā ãrÁc@ Ádæ&c[¦Á+[{ Ác '}} ā; * ÈÁÖ' ¦ā; *
} [;{ æþÁ&* ccā; * Á&[} åãaā; }•ÊÁ|[&\ ā; * Ác@ Áåā-^\^} cãæþ
] ;[çãå^•Á; [Ás^} ^ãrÁs] åÁ; @* |åÁ; có\$^Á•^åÈÁ

OPS-U- 0013



A DANGER



Ó[[{ U]^\aea_{1}} Á\U^\&ca_{1}} Á\HËGJ

8.3 Driving the Tractor and Boom

Ùœdơt, --Áůlāçā, *ÁœdÁœÁ|[, Án] ^^åÁœ}åt: læå æļîÁā, &l^æ•^Á[` lÁn] ^^åÁ, @ðp^Á; æðiæðið, *Á&[{] |^c^Á&[} d[|Á; Áœ dæ&d[lĚÁÞ^ç^lÁ;] ^\åé, kæ^j å\åé, kæ^j å\åé, kæ^j å\åé, kæ^j å\åé, kæ² æðið, å|Á; l^ç æðið, æðið

V[Áææç[ãåÁ[ç^\c'] • ÉÁå lãç^Ác@Ádæ&c[¦Á¸ão@É&æ4^Áæ)å
ææÁ•æ^Án]^^ å•ÉÁ^•]^&ãæ4]^Á¸@}Á[]^\ææā;*Á[ç^\
'[`*@Á*![`}åÉÁ&![••ā;*Áåãæ&@•Á[¦Á•|[]^•ÉÁæ)å
č'}ā;*Á &[¦}^!•ÉÁ W•^Á ^¢d^{ ^Á &æ čā;}Á¸@}
[]^\ææā;*Á;}Á•c^\]Á|[]^•ÉÁS^^]Ás@Ádæ&c[¦ÁşÁæÁ[¸
^æá,@}Á*[ā;*Áå[¸}@A|ÉÁÖUÁÞUVÁ&[æ•cÁ;¦Á;^^Ë
_@^|Áå[¸}@A|É

OPS-B- 0006



U]^¦æaā[}ÁÛ^&aā[}Ál∐€

AWARNING

Þ^ç^¦ÁŠ^æç^Ác@^Á([, ^¦Á`; ææc^}å^åÅ, @Ā/Ác@^Á@æåÅā;Ág,Ác@^Á;æã^^å][•ãāā;}ÈÁÁ/@^Á([, ^¦ÁS[`|åÁæ|ÁSæč•ā;*Ár^¦ā[`•Áā;b`¦^Áq;Áæ;^[;}^Á; @ { ā @Áā;æåç^¦c^}d^Áà^Á;å^¦Ás@^Á;[, ^!.Æpiơt#□



A DANGER



9. OPERATING THE BOOM UNIT AND ATTACHED HEAD

THE OPERATOR MUST COMPLETELY UNDERSTAND HOW TO OPERATE THE TRACTOR AND MOWER AND ALL CONTROLS BEFORE ATTEMPTING TO MOW. $\triangle \oplus A$ $\Rightarrow A$ \Rightarrow

 $\begin{array}{l} U \} | \hat{A}[] \wedge | \operatorname{age} \hat{A} \otimes \hat{A}[] \wedge | \hat{A} \otimes \hat$

AWARNING

AWARNING

)]]Ò

U] ^ | ææāi } ÁÛ ^ &æāi } ÁHËHF

AWARNING

AWARNING

9.1 Foreign Debris Hazards/Overhead Obstructions

AWARNING



AWARNING

)]]Ò

AWARNING

9.2 Operating Speed and Ground Speed

Õ¦[ˇ]åÁ•]^^åÁãÁæ&@ðç^åÁà^Ádæ)•{ã•ã¡}Á*^æÁ•^|^&æqi}Áæ)åÁy[oÁà^Ác@Á*)*ä¸^Á[]^¦ææä;*Á•]^^åÈÁÁ/@ []^¦ææ[¦Á;æíÁà^Á^ˇˇã^åÁq[Ár¢]^¦ā;^}oÁ¸ão@Á^ç^¦æþÁ*^æÁæ)*^Á&[{àājææqi}•Áq[Áå^¢)¦{āj^ÁœóÁà^•oÁ*^æÁæ)å |æj*^Á¸@&@Á;¦[çãå^•Áo@Áq[•oÁa*^æÁj^¦-¦¦{æj&^Ák][{Áo@Áq]]|^{^}óÁæ}åÁ,[•oÁ*~æ&å)oÁ;æ&q;¼¸]^¦ææqi}ÈÁOE c@Á^ç^¦ãcÁ;~Á&`cæj*Á&[}åãqi}•Ág&¦^æ*^ÉAc@Á†¦[ˇ}åÁn]^^åÁ;@ˇ|åÁà^Áà^&k^æ*^åÈOPS-B-0009

AWARNING

9.3 Operating the Attached Mower Heads

 $V@ \acute{A} = [\{ \acute{A}Sa) \acute{A}ECCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}ECCCCAS @ \acute{A}(\acute{A}ECCCCAS @ \acute{A}(\acute{A}CCCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}CCCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}CCCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}CCCCAS @ \acute{A}(\acute{A}CCCCA)$

Ü^^\Áq[Á@ÁQE•^{ à|^ÁÙ^&qā} ¼ ÁœÁ Á; æ} ĕæÁq Ár}•`\^ÁœÁ@æåÁæÁ; I]^\|^Áæææ&@åÁq Ác@Áa[[{ Áœã&æÁæ}å @å\æ`|æ\Áa]^• Áæ\^Á;|]^\|^Áæ; A&@Áa[[{ Áœã&æÁæ}å å @å\æ`|æ&Áæ}^å.

A DANGER



Ó[[{ U]^\\aaaa\}\A\\^&aa\}\A\\\

9.4 Mower Operation

V@Á[œæā,*Á;æto•Áā,Ás@āÁ;æ&@ā,^Á@æç^Áà^^},Áå^•ã;}^åÁç•àåÁç•¢^åÁf;¦Á***^åÁ;•^ÈŘP[_^ç^¦ÉÃc@^Á&[*|åÁæā; ˇ][}Áā[]æ&oÁ,ão@Á@ æç^Á+[|ãåÁ;àb^&o•Ë*&@Áæ•Á+&^|Á**æbåÁæāp•Ék&[}&k^ぐÁæà*d;^}o•Â÷œÉk&ÉÉkæě•ā;*Áo@{ÁdfÁs^ c@[; } ÁæaÁæáç^¦^ Á@ã @Áç^|[8ãc ÈÁÞ^ç^¦Áæ||; Á&č co^¦Á@ æåÁ[Á&[}cæ&cÁ* &@Á; àb^8c• ÈÁQ•]^8cā; * Áo@ Á&č coā; * Áæb^æÁ[¦ • X @ A à b x x 4 å A \ [c a * A x x 4 k

U} &^Á;} Áf &ææð;} ÊÁr; ^¦Ás@Á; [, ^¦Ás,^&\Á|ðð @d^Áæð; ç^Ás@Á; ææ^¦ãæþÁf Ás,^Á&`dÊA; Ás@Á; [, ^¦Ás,^^Á; oÁ@æç^Áf • œekoÁ}å^¦ÁæÁ[æeåÈÁYão@Áo@Ádæ&q;¦ÁæeÁæ)Ásã|^ÊÁ\}*æ*^Á;[¸^¦ÈÁÓ¦ā;*Ádæ&q;¦ÁÜÈÚÈTEÁ]Á[ÁFJ€€Ë⊙G€€ÁÜÈÚÈTÈÁæ)å

OZÁJæáJÁ, [_^¦Áå^&\ Á;Q``|åÁà^Á&榦ð^åÁ;[ÁsœæÁs@Á;ædóf,Æc@Áá^&\Á;^ã œÁááÆæ¦ð°åÁá^Ás@Áá;[[{ ÁæþåÁ;ædóf&æk}ð°å -{||[.•Ás@-Á&[}q[`¦Án-Ás@-Át¦[`}åÁn[¦^Ánæ-āîÁa`¦ā,*Án[.ā,*Án]^¦æeāi}•È

V@Á[œe^Á;[¸^¦Ás^&\Á;@,`|åÁæe;æ°•Ás^Ásæe¦ã°åÁæe@¦Ásœe)Ás¦æ**^åÁ;}Ás@A\ãaÁ;@,^•Á;@}Á;[¸ā;*Á;}Ás@ *¦[ˇ}åŘÖ¦æť*āj*Ác@Á[œá^Á;[¸^¦Áå^&\Áāj&l^æe^•Ác@Á•ãã^Á[æå•Á;}Ác@Áà[[{Êåå^&l^æe^•Ác@Á@¦•^][¸^¦ ægæajææi/^Áf Ás@ Á&` cc^¦Á@ æåiÊæaj åÁ^å` &^• Ás@ Ásæàjããĉ Á; Ás@ Ásæ&&` { ` |æg¦ ¦Ás@ Ásæb¦^Á; æb cÁ; Ás@ Á; ° jæg ¦Ás@ Ásæb¦^Á; æb cÁ; Ás@ Á; ° jæg ¦Ás@ Ásæb¦^Á; æb cÁ; Ás@ Á; ° jæg ¦Ás@ Ásæb; ° Ásæb cÁ; Ás@ Ásæb jr Ásæb jr Ásæb Ásæb jr Ásæb Ásæb jr Ásæb Ásæb jr Ásæb jr Ásæb Ásæb jr Ásæb jr Ásæb Ásæb jr å ˈ{ā̞ * Á̞ [ā̞ * Á̞] ^ ¦æeā[} ● È

AWARNING

Y @ } Á [cæaā] * Á j æðo Áæb Áāj Á [cāī } ÉÁn ^ ¦āī * Áāj bǐ ¦ Á j æ Á j && ¦ ÁājÁ&æ cāī } Áā Á [cÁ • ^ å Á ¦ Áåæ) * ^ ¦Áā }[oÁ\^&[*}ã^åĚ\Þ^ç^¦Áæ||[, Áà^•œa)å^¦•Á, ão@a, Á300 feetÁ[-Ás@-Á(æ&s@a,^Á, @}}Áā,Á[]^¦ææā[}È Ò¢d^{ ^Á&æd^Á•@,`|åÁà^Áæà^}Á;@^}Á;]^¦ææā]*Á;^æáÁ[[•^Á;àb^&œ-Ë-`&@Áæ-Á*¦æç^|ÉÁ[&\•ÉÆæ;å å^à¦ãa ÈÁV@∿•^Á&{}}åããã}}•Á∗@|`|åÁsà^Áæq;[ãå^åÈ

9.5 60" RSS Boom Rotary

V@^ÁÎ €+ÁÜÙÙÁà[[{ Á¦[œd^Áঠ*• @Á{ [, ^¦Á, æ• å^• āt } ^åÁ-{ ¦Á& ccā, * Áà | * @Áæ) åÁ-{ |ãæ* ^Á*] Áq ÁG ā & @ • Áā Áå ãæ (^ c^ \ Á; \ Á; ~ | cā | | ^ Áa | æ) & @ • Ác@æ Á@æ (^ Áa e d cætÁ&¦[••Á•^&cãt} Áæt^æÁ^~ ãçæt^} cÁd Á[}^AGÁð; &@ à¦æ}&@È

Ö`¦ā;*Á;[,^¦Á;]^¦ææā;}ÊÁo@\Á@æd;åÁo@;[od^Á; *•oÁà^ ઁ•^åÁq Áq ænāj œænājÁn}*āj,^Án]^^åÁsænÁFJ€€ËGG€€AÜLÈÚÈTÈ V@ãÁ]¦^ç^}o•Á¦æåå&æþÁ&@æ)*^•ÁājÁ[[^\Á•]ājå|^• •]^^åÊ\'^å &a * Ás@ Á, [••ãà āac Á, -Á& cc\'Áæ•^{ à|^ åæ{æ*^È

 $V@\dot{A}@\dot{a}[\capA][\bullet \tilde{a}\tilde{a}] A * \dot{A} \approx \tilde{a}\tilde{a} A A * \dot{a} \approx \tilde{a}\tilde{a}$ å^•ā*}^åÁq[Áµ[•ãαa[}Áx@ Á&`cca]*Á@ æåÁæ)åÁμ¦[çãå^Áæ |ā āc^åÁj | ^•• ` | ^Á|^|ā ~Á @ } Á ¢ & ^•• āc ^Áj | ^•• ` | ^Áa aa]]|aðåÁ[Ác@Áa[[{ EÁÖ[Á][cÁ[¦&^Ác@Áscca]*Á@æå

ật (Á@) æç^Áa¦æ) &@.•Á;¦Án č {]•ÉÖÖæ(æ*/Ág Áo@ Á }ãoÁ;æ`Á^•`∣dÈ



A CAUTION

Y @ }Á • ā * Ác@ Á j cæ f Ác cca * Á@ æ á Áj ¦Áciā {ā * Ás l * • @ Ás à Á @ `à • ĒÁn cÁc@ Á; [^ lÁcæ Ás d Ác@ {È Ö[Á}[oÁ[¸^¦Ác@^Á([¸^¦Á@^æåÁå[¸}Áåãl^&d^Áðjd[ÁæÁd^^Á[¦Á+č{]EÁV@^Á([¸^¦Áà|æå^+Áæb^ å^• ãt}^åÁt[Á&° cÁ, ãc@Ác@ Ár}åÉÁæ)åÁ(ã° • ^ Á&æ)Á&æ* • ^ Áåæ{ æ* ^ Át[Ác@ Áà|æå ^ Áæ}åÁæÁæe æ*å[° • • ãc ǎæaã[}Á[¦Áo@^Á[]^¦æe[¦È

A CAUTION

Ú[` ^¦ā] * Ác@ Áà[[{ Áå[` } ÉÁ; | &ā] * Á; [` ^¦Áå^&\Á; ð[Á*; [` } åÁ; æ Áåæ; æ * ^Á; [` ^¦Áå^&\Áæ) åÁæ;

V[ÁY}•`¦^ÁœÁ&|^æ}Á&`dÊY}*āj^Á;]^^åÁ;@`|åÁà^Á|æājæāj^åÁæÁæj;]¦[¢ājæe^|ÁFJ€€Ë3G€€ÁÜÉÚÈTÈÉQÁs@ Ádæ&d;¦ •|[¸•ÁqÁ^••Áx@a)Árì €€ÄÜÈÜÈ ÈÉA @aÁqÁx@Á,^¢A[¸^¦Á*^æÈÖUÁ>UVÁaa^Áx@Ák]ˇc&@Éx@aÁ¸ā|Á&æ*•^Á;¦^{æč¦^ & & A The engine should not be operated at any time at more than 2400 R.P.M. on the tractor tachometer.

)]]Ò

 $U] ^{\text{laga}} \hat{A}U^{\text{log}} \hat{A}U^{\text{log}}$

 $\mathcal{Q}[| A\& caj * Aa| * \bullet @ Aa aA * \bullet cAq Aa * \bullet cAq$

A CAUTION

DO NOTÁ •^Ár¢&^•ãç^Á[¦&^Á; @}Á][•ããā]}ā] *Á&` ccā] *Á@`æåÁā, qíÁ@`æç^Áa¦æ) &@•Á[¦Á•č{]•È Öæ{æ*^ÁqíÁœ@Á}ãó(æ6)*idÃoóæíÁa^•óÁqíÁroÁœ/Á&` cc°¦Á@`æåÁ6bæóÁæ;æ°+Á|[, |^ÁæóÆ@æç^Á&` ccā] * bjà•È


A CAUTION

ÁQÁ[|ãæ*^Áæ#|•Á[}Áq]Á[]Áq.Á\([, ^\Aå^&\Á&æ*•ā]*Ádæ&q:\Áq[Áà^&[{ ^Á`}•œæà|^É4([ç^Ác@-Áà[[{ %a[\, a+å+Áæ}, åÁ%]*œÁq[Á\]]ā]*Á[-Ác@^Ádæ&q:\ÉAŠ[, ^\Á([, ^\Aå^&\Áq[Á\]]*BÁ+Âæ}, åÁæ]åÁ*@cå[, }Á\)äŒÁŒe^\ÁæHÁ[[aā]*Áq]•ÉÁ\([ç^Áq]]•ÆÁ^{[aæ*^Á\[, Ak@}A\)È

Ó^* āj ÁæÁj æ• ÁææÁs@ Á[] Árāā^Á; Ás@ Ás^^• Áæ) åÁj [¦\Áå[¸}Áj āc@Áræ&@Á&[}•^&`cāç^Áj æ• ÈÁr @}Á&`ccāj * Ásl^^• Áæ) å • @`à• ÊÁ•^ÁæÁ[¸^¦Ár]^^åÁg Áæ|[¸Ás@ Á;}āç^• Áæāj ^Ág Á&`cÁæ Á; ^||Áæ Á; '|&@Ás@ Á[|āæē^È

≜WARNING

Y @ \}Á&`ccā, *Áà; `•@Éad;]; [æ&@Á;æc^; ãædÁfÁà^Á&`c 、ão@Ác@∿Á@^æåÁ]^¦]^}åã&ヾ|æ4Áq[Á{æe^¦ãæ4ÈÁV@^ & ccaj * Á^a * ^ Á[-Ás@ Ás | zcas^ • Á • Q[` | å Áà ^ Ás@ Á[} | ^ • @[`|åÁ} [oÁ&[} cæ&oÁ [ãc@Á | ææ^\ ãæþÈÁV@•Á{ [_ ^\]^|]^|}å&&`|æe|^Á@i,d[Ác@)Á(æe^\¦ææe\¦ææe@\¦Á[[,^\;a]* c@\Á([\^\Á@\æåÁ() A([] Á(\æc\\ãæ\EÁV@\Áåã @Áā }[oÁ\$jo^}å^åÁq[Á&`oÁ;æe^¦ãæфÁ;¦Áq[Áà^ÁæÁ;^ædÁæ~{ |ã^Ác@Áà|æå^•ÈÖ[ÁÞ[oÁæl|[Ác@Áà|æå^•Á;¦Áåã@ df Á&[} cæ&cÁc@\Á* ¦[` } åÊÁ[&\ • Á [¦Á• [|æåÁ[àb\ &o• È $\hat{O}[\ \ \} \ \text{cæ&oA} \ \ \tilde{a} \ \text{c@Ac} \ \hat{A}' \ \ |\ \ |'\ \ \} \ \text{a} \ \hat{A} \ \text{&e}) \ \hat{A} \$ •[|aãA[àb/8.0•Aà^ā]*Ác@[¸}A[čoÁ;[{Á`}å^;Ac@ { [¸^¦Á@^æåÁ¸@\$&@Á&æ)Á&æě•^Á•^¦ā[ř•Á\$jbˈ¦ā�•Áq[c@^Á[]^¦æ@[¦Áæ)åÁà^•œ)å^¦•ÉÁV@≱Áĉ]^Á[~ $[]^{\text{aea}} \hat{A} \approx \hat{A} \approx \hat{A} \approx \hat{A} \approx \hat{A} = \hat{A} \approx \hat{$ æ) åÁ@ædå, æd^Á, @@&@Á&æ) Áà ^Áåæ) *^¦[`•Ád; Ác@ []^{aq[| Áxe} å Áxa^• cæ) å^{|• È



The cutter deck should be level with the ground to reduce the work required by the cutter and tractor to minimize equipment wear and damage.

Ops-14


(OPS-R-220)

)]]Ò

 $U] ^{\text{laga}} \hat{A}U^{\text{log}} \hat{A}U^{\text{log}}$

9.6 63" & 75" Boom Flail


V@ÂHHÁBÁÍ ÁÁ[[{ Á|æájÁ[], ^!•Á, ^!^Áá^•ât}^åÁ[! & cáà* Á*!æ••ÈÁV@Á& cc^!Á•@æeÁ•]^^åÁ{ *•cÁà^ { æáj cæáj ^åÁ-[!Á]![]^!Á& cæáj *ÈÁV[Ááj•*!^Ác@æeÁc@& cc^!Á•@æeÁáñ Á [cææáj * ÁæbÁ; ææá] * { Á•]^^åEÁ!} dææá[!ÁæeÁ*||Ác@[cd^Áå*!áj *Á[], áj *Á[]^!ææá]}•ÈÁQ & cc^!Á•@æeÁ*|[¸•Áí Ác@Á][āj cÁc@æeÁæÁ)}åip^•Áæh^-[åj *Áàæ& Áæè æáj •c Ác@Á][āj cÁc@æeÁæÁ [ç^Ác@{ [¸^Ác@*É}{ [ç^Ác@*{ [¸^1Á@æáÁæ} æáj •c Ác@Á][áj cÁc@*Á][áj *Áæ)åÁæ][¸Ác@*&* cc^!Á•@æeÁf [ç^Ác@*&* cc^!Á*@æeÁf [ç^Ác@*&* cc^!Á*@æeÁf Áæ)åÁæ][¸Ác@*&* cc^!Á*@æeÁf Áæ)åÁæ][¸Ác@*&* cc^!Á*@æeÁf Áæ)åÁæ][¸Ác@*&* cc^!Á*@æeÁf Áæ;åÁæ][¸Ác@*&* cc^!Aæ;æe££~£æ£*~£æ£**



AWARNING

A DANGER

A DANGER



AWARNING


 $\begin{array}{l} T\text{ as} ^{\hat{A}} \hat{A} = A^{\hat{A}} \hat{A} + A^{\hat{A}} \hat{A} +$

Ý[[{

9.7 Shutting Down the Attached Head- For Standard Equipment

 $\begin{array}{l} V_{1} \not \hat{A} @ o \acute{h} & []_{A} \not \hat{A} & \partial \mathring{A} &$


Úæl\Ác@ Átæ&q ¦Á[}ÁæÁ|^ç^|Á*; -æ&^ÉÃ]|æ&^Ác@ dæ)•{ã••ã|}Áā,Á]æl\Á[¦Á}^`dæ\Áæ)åÁæ}]|^Ác@]æl\ā;*Áà;æb^ÉÞ•@ ÓÁa[,}Ác@ Á^}*ā,^ÉÅ\^{ [ç^Ác@ \^^ÉÆ;åÁ;æmÁ;¦Áæ|Á;[cã]}Á;Á8[{ ^Á;ÁæÁ8[{]|^c^ •q]Ás^{¦^Ár¢ãā;*Ás@Ásæ&q;¦È OPS-B-0011_D





A DANGER

OOQUUOA/ræşā * As@ Aslæsat | Ar^ææææa ; æê • Ar^oAs@ Ajæk ā * Aslæsar Asap å £D | Ar^c c@ Ádæsat | Ádæp • { ã••ā] } Áā Á] æk ā * Á* ~æÆåãr > * æ* ^Ác@ ÁÚVUÊ*•t] Ác@ ^} * ā, ^ÉÄr { [ç^Ác@ Á^^ Éæp å Á, ææÁ! | Áæp|Á; [çā] * Á] æb • Át Át] EÁÚ |æsc Ác@ dæsat | Ár @æó4r ç^ | Áb d Áæp|[, Áæp * ^Á; | Áp æk ā * Á* ^æb Át Át | Áp æk á æsat | ¼[{ Á[|| 3 * ÉÁP ^ ç^ | Áb ã* { [* } ó*æáv | æsat | Ác@æóæ á Á [çā] * Á; | Á @ær Ás@ Ár æsat | Ár ææ Ár }] Èæp ó æb | Æsat | Ác@æóæ á | Ár ææ Ár | Ár ææ Ár }] Èæp ó æb | Æsat | Ár ææ Ár | Æsat | Ár ææ Ár | Æsat | Ár ææ Ár | Æsat | Ár ææ Ár | Æsat | Ár ææ Ár | Ár ææ Ár | Æsat | Ár ææ Ár | Ær ææ Ár | Ár ææ Ár | Ær | Ár ææ Ár | Ár ææ Ár | Ær | Ár ææ Ár | Ár ææ Ár | Ær | Ær | Ár ææ



10.TRACTOR, BOOM, AND ATTACHED HEAD STORAGE

Ú|[]^|^Á,|^]æðaj*ÁæjåÁntq[¦aj*Ás@Á}ãúÁæÁs@ÁA}åÁn,Ás@Á^æe[}Æák&lããææÁqÁq[Á;æaajææajāj*Áæóæág]^ææàj&^ÁæjåÁq[@/]Á^}•`'\Á^æð•Án,Áåc]^}åæà|^Ár^¦çæ&^ÉÁV@Áq[|[¸āj*Áæ4^Ár`**^•c^åÁnq[|æ*å^Á;[&vå`¦^•K

Ý[[{

U] ^ læda } ÂÛ ^ & ca [} ÁH EH i

Š`à\a\a\a\e^\frac{\partial}{\partial}\frac\

"Vat @"\} Áse|Ás[|o•Ás[Ás@Aj;|]]^¦Ás[|``^ÈÁÓ)•`¦^Á æ|Ájā,•Áse)åAjc@!Á@eåå,æb^Áse^Ás[Aj|æs8^È




A DANGER

Þ^ç^!Áse|[, Á&@qå!^}ÁqíA;|æêA;}A;!Áse|[*)åÁ\!æ&q[!A;!ÁQ]|^{{ ^} dŽÔ@qå!^}Á&æa;A;|Ä, A;|Áæ|A;~~c@ÁÒ``ā]{ ^} cÁse;åÁsi^Áa;b'!^åÁq;!Á ā|^åĚÁÔ@qå!^}Á&æa;A&æĕ• ^Ác@AQ]|^{{ ^} cÁqíA;Æa;A;Aæ|&\`•@q*Áæ]*Aæ@{•^|ç^•A;LÁ;c@!•ĚÁq;ōĕi□

A DANGER

OOQUUOA^æçā* As@ Aslæ&d; | A^ædædæ; æê•A^oAs@ Aslæ\ā; * AslæA^æb; åtp\A^cc@ Áclæ&d; | Áclæ;•{ ã•ā;} Áā; Áj æk}ā; * Á*^ædæáa*^} * æ*^Ác@ ÁUVUÊ*•d;] Ác@ ^}*ā,^ÊÄ^{ [ç^Ác@ Á^^ÊÆæ; åÁ; ææó4; | ÁæHÁ; [çā; * Áj æb• Át Á; d;] EÁÚJæ&^Ác@ dæ&d; | Á* @æó4^ç^\Aā; d; ÁæH; , Áæ; * Af Aæ; Af A



AWARNING

11.TRANSPORTING THE TRACTOR AND IMPLEMENT

U]^¦æaā[}Áû^&aā[}ÁHËHÌ

Ý[[{

11.1 Placing Boom Arm on Boom Arm Rest - For Standard Equipment

Ó^{ | ^Átæ} •] [| cāj * Átæ& [| Áth^c ^^ } Å[&ææā] • ÉÉsā|^
c@ Átæ& [| Á^ } * āj ^ ÉÉtà ār^ } * æt ^ Ác@ Áææææ @ å Á@ ææå Ê
æð å Á ææð [| Áæþ Á@ ææå Á; [cāj } Átj Ás[{ ^ Átj ÁæÆ\$ [{] | ^ c^ }
• [] ÉÁ Ú | æ& ^ Ác@ Áà [[{ Áāj Ást• Á• [| æt ^ Á& ææå |^ Á' ^• c
• "]] [| cÁæð å Ác@ } Át | } Ác@ Átj ^ • cæð Á; æ• c^ | Ár ¸ āt& ØÁtj
c@ ÁU ØØÁ [• ātāj } ĚÁ



- ″Ü^dæ&oÁÖ^&\ÁÜ[||Á&^|ājå^\¦Á&[{]|^c^|^È
- ″Ù@aoÁ,[ˌ^¦Áad|Áo@∖Á,æêÁ,ĭdÈ
- ‴Ü^dæ&αÁs@ΑÓ[[{Æ&î|ā̞å^¦Æ&[{]|^৫^|îÈ
- " Ù, ā, * Áa[[{ Áa æ&\Á|[, |^Á} cā/√axÆa Á dæāt @A àæ&\È
- Ö¢c^} åÁs@ÁÖ^&\ÁÜ[||Ásc^|ājå^\Á`} cāļÁs@Á; [¸^\Á ãÁs•oÁsæà[ç^Ás@Á-æåå|^È
- ~ Ù@aók@Á, [, ^ \Áş Á } cāÁ@Á[||^ \Á\} * æ* ^ ÁœÁ
 à [cd { Á, ÁœÁ æåå ^ È
- Š[¸^¦Ás@ÁÓ[[{Á'}cāļÁ,[¸^¦ÁiāenÁspq[Áiæåå|^ÈV@Áa[[{ÁasÁ,[¸ÁspÁs@Áslæð•][¦cÁ,[•ãaā,]È

OPS-RSS-0009



11.2 Transporting on Public Roadways

U]^¦æaā[}ÁÛ^&aā[}ÁHËU

Ý[[{







U]^¦æaa[}Áû^&aa[}Á+HË€

Ó[[{

A DANGER



AWARNING





11.3 Hauling the Tractor and Implement



A DANGER

 $Y @ \} $Act a \} \bullet] [| c a \} * AO [[\{ AT [, ^ | A_i \} Acc Act] * & A_i | Act a a _ Acc Act] * AO [[\{ AT [, ^ | A_i \} Acc Act] * Acc Acc] * Acc] * Acc Acc] * Acc] * Acc Acc] * Acc$



Ý[[{

U]^¦æaa[}ÂÛ^&aa[}ÁHËF

W•^Á æå^˘ œe^|^Á •ã^åÁ æ}åÁ ¦æe^åÁ dæā^¦•Á æ}å ^~~~ āl { ^} o Ád; Ádæ) •] [¦ o Ác@ Ád; æ&d; ¦ Áæ) å Áā;] | ^ { ^ } dÈ Ô[}• | | | ÓÁse) Áse c@| | ã ^ å Áse ^ æ | ^ | Áse ^ æ | { ã ^ Ás@ Á; | [] ^ | ^`` | ā { ^ } oÁ^`` ā ^ å ÞÁÁN • ā * Áœå^`` æe^|^ Á• ā ^ å Á&@æði • Ê @ aec^ Áà c Á dad • É& aà | ^ • Áad å D | Áà ã å ^ | • ÉÁ ^ & ` | ^ | Áað å[] Áà[c@Ác@ Á;[} cÁc) åÁ^æ Áí Ác@ Ác æ&c[¦Á cãã ã * Ác@] | [] ^ | Ácā^ÁÁå[¸ } Á[&æaã[} • Áæ• Á•] ^ &ãað^å Áà^ Ác@ Áclæ&c[| { a} ~a&c | ^| ÈOPS-U- 0025



OE; a) * ^ Ác@ Á&@aa] • Á• [Ác@aaÁ, @} Ácat @^} ^ å ÉÁc@ &@eda•Á adh^Á,*||ā,*Áå[} ælåÁ ælåÁ ætæaal•c c@\{ • ^ | c^ • EÁÔæ | ^ ~ | | ^ Áæ | @^ } Ás@ Á ^ & ' | ā * Á& @æ | • Á | | [c@\|Áæec^}^\•Á*•ā]*Áà[[{ ^\|•Á[\|Áàā] å^\|•Á([Áæ]]] |^ { $aca = (A c^{-1} + A c^{-1}) + (A c^{-1})$ æcæ&@] * Áæ) åÁ^{ [çā] * Ác@ Á·^&` ¦ā] * Áå^çã&^• Áæ• Ác@ ^¢d^{ ^Ác^}•ã} Aã; c[|c^åÁ, @} Á!^|^æ•^åÁ@æ•Ác@][e^}caeda4fa5ja4a8o44^la1*•A5jb'l^È

Y@4^Á@eĕ|ā;*Ác@•Ádæ&d;¦Áæ)åÁã;]|^{^}dÊÁ{æ4^ [&&æ•ā]}ædÁ•d[]•Ád Á&@&\Ác@ædÁc@Adæ&d;¦Áæ}å ā[]|^{ ^} cÁ@æç^Á}[cÁ([ç^åÁ[¦Á+@áe^åÁæ)åÁc@æcÁc@ •^&`¦ā;*Á&@edā;•Á@ec;^Á; ædā; œdā;^åÁc^}•āi}ÈÁÝQÁà`¦ā;* da) •][ˈơチaớ@adåÁàˈað ā * ÉÁ @ad]Ác ˈ}ā * ÉÁ ˈÁ· ^ˈçā * ascal} Á as Á ^ + + { ^ a É f] Áscóc@ Á ^ ¢ có ae ^ Á | & acal} }



QÁdaaāp^¦Ána Á,[cój,^¦-^8d^Áp^ç^|Édo@ Ána[[{ Á, ā|Án^}å Án[Á, ā] * Án[ædå•Án@ Án[^¦Án ána ÀÉPæç^Án co@ ¦ A CAUTION] ^ [} } ^ |Á^ æå^ Áṭ Áṣ[} d[|Á\$æ Á, 4*4* Á; [æ‡ } Á, @ } Ás^ |4 å^ |Á, 4 å Æ Á^ { [c^å È æ ^ Á* |^ Ás@]^!•[}^|Áseb^Á,[cÁs, ÁseÁ,[•ãæā]}Ás[Áso^Á@ãæá,|Áse, *@°åÁsî^ÁseÁ, ā; *ā; *Ás[[{ ÈÁ


Ü^dæ&oÁ, ãç^|Á&`|ã, å^¦Áæ) åÁn^&`¦^Áq Á, æājÁ¦æ; ^ÈÁÚãç[oÁà[[{Á[¦,æ}åÁq Ás@.Á&^}o^¦Áq.-Á∤ææÁa^åÈŠõ[,^¦Áa^&\Áq)d[c@ Át æāt^ l Ás^ å Étæt å Ár @ cÁ; --Ás@ Át æ&d; l ÈÁv @ Át æ&d; l Áæt å Ás@ Á; [_ ^ l Á@ æå Ár @ ` | å Á; [_ Ás^ Á&@æā; ^ å Ás[_] Ár ^&` | ^ | ^ of Áco⊘ Ác¦æán^¦Ásn^åÈ

A CAUTION

`}å^|•d[åÉÁ&I}œ&oÁ^[`|ÁVði^|Áå^æ4^|Á|¦Ác@Áæåå|^••ÁI}Ác@Á&Iç^|ÁIÁœãÁ; æð`æbÁf| æ•ãæ}&^Â

U]^¦ædai}ÂÛ^&dai}ÁHËG

Ý[[{



General Instructions

Tiger Mowers are designed for high performance and rugged durability, yet with simplified maintenance. The purpose of this section of the manual is to help the operator in the regular servicing of the mower. Regular maintenance at the intervals mentioned will result in the maximum efficency and long life of the Tiger Mower.

When you purchase a Tiger Mower you also acquire another valuable asset, Tiger's parts organization. Our rapid and efficient service has guaranteed the customer satisfaction for many years. Tiger parts keep up with the demands for efficiency, safety and endurance expected of the Tiger Mower.

Maintenance Precautions

- Be sure end of grease gun and zerks are clean before using. Debris injected into bearings, etc. with grease will cause immediate damage.
- DO NOT use a power grease gun to lubricate bearings. These require very small and exact amounts of lubrication. Refer to the detailed maintenance section for specific lubrication instructions. DO NOT overgrease bearings.
- Be alert to maintenance indicators such as the in-tank filter pressure gauge, hydraulic reservoir sight gauge, etc. Take the required action to correct any problems immediately.
- Release of energy from pressurized systems may cause inadvertent actuation of cylinders, or sudden release of compressed springs. Before disconnecting any hoses relieve pressure by shutting tractor off, setting cutter on ground and actuating lift valve handles.

≜WARNING

DO NOT use hands to check for suspected leaks in hydraulic hoses! Hydraulic fluid escaping under pressure can have sufficent force to penetrate skin and cause serious injury. If fluid is injected into skin, it must be surgically removed within a few hours or gangrene may result. Use a small piece of wood or cardboard, not hands, to search for pin hose leaks. Be sure all connections are tight and hoses and lines are not damaged before applying pressure.

Break in Period

In addition to following the break in instructions for your particular tractor, the in-tank hydraulic fluid filter should be replaced after the first 50 hours of service. The reafter the filter should be replaced every 500 hours, or yearly, which ever comes first.

Re-torque wheel lugs after first five hours of operation and periodically thereafter. See torque specifications listed in the tractor's service manual for your particular model. Wheel lugs must always be re-torqued whenever a wheel is removed and reinstalled.



Never work under the Implement, the fr amework, or any lif ted component unless the Implement is securely supported or blocked up to prevent sudden or inadvertent falling which could cause serious injury or even death. (SG-14)



AWARNING

Do not modify or alter this Implement. Do not permit anyone to modify or alter this Implement, any of its components or any Implement function. (SG-8)

RSS

Maintenance Section 4-2

AWARNING

Ü^|a^ç^A@ a|aĕ|a&Aj|^••`|^Aj|{ā||A[ā||A[ā||A[ā]|*Asp}^Aj| æā]|c^}a) &^Aj||A^] æā]Aj||\Aj| As@ AQ]|^{ \} ab Ú|æ&^Ás@ÁT[¸^¦ÁP^æåÁ;}Ás@Át¦[ˇ}åÁ;¦Á^&`¦^|^Á*]][¦♂åÁ;}Áà|[&\•Á;¦Á;æ;)å•Éåãã^}*æ*^ c@ÁÚVUÊæajåÁč¦}Á;~ÁœÁA}*ãj^EÁÚČ•@æajåÁjč||Ás@Á&[}d[|ÆŠ^ç^¦•Á;¦Áq[^•æ&\Á^ç^¦æájági^• d Á^ [a^ c^ Á; |^ • • ` | ^ Á; | á | Á f Á cæd cā; * Áæ) ^ Á; æð; c^ } æð; &^ Á; | Á^] æði Á; [| \ Ε΄ Α΄ κρότ ∄ D


A DANGER

OF, æê•Àåãa&[}}^&oAc@A¸ã^A^ æå•À+[{ Ac@A{[¸^¦A]~{]}^{]} A•[|^}[ãå à^{ | ^Á, ^| - { | { a, * Á, ^| c, 28.^ Á; } Á @ Á/| asst | Á; | ÁT [_ ^| ÉÁÁN ^ Ásæ cā; } Á, @ } [¦\āj*Á[}Áo@AV¦æ&q¦Á[¦ÁT[¸^¦ÉÁÁV¦æ&q¦Á^}*āj^Á(`•oÁà^Á•q]]]^å



MAINTENANCE OF CRANKSHAFT ADAPTER ASSEMBLY (RIGID ENGINE MOUNT TRACTORS ONLY)

ÁÁÁÁQÁ^]|æ&^{^}dÁ,Á&[{][}^}o•Á;Áó@Á&¦æ}\•@æóÁæåæ]o^¦Áæ••^{à|^Áá•Á^˘ăl^åÉÄ;||[,Áó@Á æ•^{ à|^Á|;| &^å`;|^•Á; @[, }Áà^|[, ÈÁÛ/^æÁ`àà^;|Á;|[{ { ^oÁs[{]|^c^|^Ás[c]As[`}c^;à[;^£Ás@}}Á •^æmÁc^^|Át;|[{{ ^om&[{]|^c^|^AajcfÁt`àà^!Át;|[{{ ^oÁ; @anÁt`àà^!Át;|[{{ ^omás Át`]][!c^åÈ (ASM-JD-0051 CRANKSHAFT ADAPTER MAINTENANCE)



Regular Maintenance

The intervals at which regular servicing should be done are based on hours of operation. Use the tractors hour meter to determine when regular servicing is required.

Refer to the Det ailed Maintenance section for futher instructions on greasing. Copy and use the Daily Maintenance sheet located at the end of this section.

Daily or Every 8 Hours

ITEM	SERVICE	COMMENTS				
Drive Shaft Yoke, U-Joint & Stub Shaft	Grease	Grease as instructed in detailed maint. section				
Pump Drive Shaft Coupler	Check and Lube	Insure drive shaft end play				
Crankshaft Adapter	Check rubber grommets	Replace grommets if damaged or missing				
Pivot Points	Lubricate	Inject grease until it appears at end				
Hydraulic Fittings	Check for leaks	Tighten when needed. Do Not use hands to check for leaks, see maint. Precautions				
Knives	Check	Inspect for missing or damaged knives, change as needed.				
Spindle mouting bolts spindle to deck)	Check	Torque to 331ft. lbs. lubricated Torque to 357ft. lbs. dry				
Knife mounting bolts (knife to disk or blade bar)	Check	Pre-lubricate threads, then torque to 800 ft. lbs.				
Disk/Blade Bar mounting bolts (disk/blade bar to spindle)	Check	Torque to 184ft. lbs. lubricated Torque to 180ft. lbs. dry				
Belts	Check/Adjust	Check if broken, tighten as required				
Main Frame and Deck	Check	Retorque bolts to torque specifications in this section				
Hydraulic Fluid Level	Check	Add if required per fluid recommendations				
Rear Flail Drive(if applicable) Bear Flange and Shaft Coupler	Lubricate	Grease as instructed in detailed maint. section				
Cutter Shaft and Ground Roller	Lubricate	Grease as instructed in detailed maint. section				
RSS	Maintenance Section	n 4-4				

	WEEKLY O	R EVER	Y 40 HOURS
ITEM	SERVICE		COMMENTS
Rotary Spindle	Lubricate		Every 40 hours or weekly
	WEEKLY O	R EVER	Y 50 HOURS
ITEM	SERVICE		COMMENTS
In Tank Hyd. Fluid Filter 10 micron filter)	Change		Change after first 50 hours only, then every 500 hours or yearly
In-Line High Pressure Filter (10 micron filter)	Change		Change after first 50 hours only, then every 500 hours or yearly
	MONTHLY O	R EVER	Y 150 HOURS
ITEM	SERVICE		COMMENTS
Hydraulic Fluid Level	Check		Add as needed
Hyd. Tank Breather	Clean/Check/Replace		Clean or replace Element as required
Rear Tire Type 480/80R38 18.4-34 18.4-38	Max P.S.I. 29 26 26		
	YEARLY OF	R EVER	7 500 HOURS
ITEM	SERVICE		COMMENTS
Spindle Grease Hyd. Tank Fluid In Tank Hyd. Fluid Filter (10 micron filter)	Change Change Change		
In-Line HP Filter (10 micron filter)	Change	or	Change when indicated by restriction indicator.
Hyd. Tank Breather	Change		
RSS	Maintei	nance Secti	on 4-5

TROUBLESHOOTING							
SYMPTOMS	CAUSE	REMEDY					
Vibration	1. Loose Bolts	Check all bolts and tighten to					
		recommended torque specs.					
	2. Cutter assembly	2a. Check for damage blades, disc					
	Unbalanced	or cutter shaft. Replace if needed.					
		2b. Check for wire, rope, etc.					
		entangled in the cutter assembly					
Mower will not lift	1. Hyd. Fluid Low	Check and refill Hyd Fluid					
	2. Leaks in line ROU	2. Tighten or replace fittings and hoses					
	Faulty relief valve	3. Check pressure in line. Line					
	•	pressure in Control Valve should be					
		at least 2500 P.S.I.					
	Faulty cylinder	5. Inspect, repair or replace cylinder					
Mower will not start	1. Blown fuse	Check fuse between mower switch					
or run		and ignition/replace					
	2. Ball valves closed	Make sure valves are open					
	3. Low oil level	3. Check Hyd. tank and fill					
	4. Line leak	4. Check all fittings and lines,					
	E Electronic	re-tighten or replace					
	5. Electronic	5a. Without the tractor running, turn					
	solenoid faulty	the mower switch to on. A low					
		audible click should be heard if the					
		solenoid is engaging the solenoid					
		spool. If click is not heard, leave					
		switch in on position and with a					
		screwdriver or other steel object,					
		touch the small nut on the end of the					
		solenoid. If the metallic object is not					
		attracted to the nut, check the fuse					
		and wiring for an open circuit. If the					
		object is attracted but no "click" is					
		heard, replace the solenoid.					
		5b. Remove the four bolts holding the					
		small block to the main block. Lift					
		and remove small block being					
		careful not to damage O-rings/filter.					
		Clean filter and re-install.					
		5c. Remove large nut on side of large					
		valve block. Remove spring, and use					
		needle nose vise grip to pull spool from					
		block. Check block and spool					
		for contaminates and scratches.					
		Clean parts or replace if scratched.					

Maintenance Section 4-6

TROUBLESHOOTING (CONTINUED)						
SYMPTOMS	CAUSE	REMEDY				
Motor runs but will not cut.	1. Belts	Inspect belts and pulleys. Replace belts and repair as needed.				
	2. Tensioner	 Adjust tensioner nuts tension should be 106 freq cyl/sec. 				
Mower turns slowly or not at all.	Contaminants restricting spool movement in valve body.	 Remove large nut on side of large valve block. Remove spring, and use needle nose vise grip to pull spool from block. Check block and spool for contaminates and scratches. Clean parts or replace if scratched. 				
	Suction lines obstructed	Check for kinks or obstructions in suction hose.				
	3. Low oil level	Check Hyd. tank level and fill.				
Pump will not work	Excessive wear on internal parts	Disassemble and repair.				
Motor will not work	Excessive wear on internal parts	Disassemble and repair.				

NOTE: If flow meter is available, check pressure and flow volume for all suspected hydraulic problems.

If the solution to your problem cannot be found in this section, call the Technical Service representative at the number shown on the front cover of this manual.

	,	,	,	T	orque	for St	andard	Faste	ners				
	threads	C	\rangle	Grade 2	0	>	Grade 5	(D)		Grade 8	0		Grade 9
Dia.	per	Tig	htening Tor	que	Tio	htening To	rque	Tig	htening Tor	que	Tig	htening Tor	que
	inch	Lubed	Dry Plated		Lubed	Dry Plated	Dry plain	Lubed	Dry Plated	Dry plain	Lubed	Dry Plated	Dry plain
(in.)		K=0.15	K=0.17	K = 0.20	K=0.15	K = 0.17	K = 0.20	K=0.15	K = 0.17	K = 0.20	K = 0.15	K=0.17	K = 0.20
					Unit	fied Coa	rse Threa	ad Series					
1/4	20	49 in-lbs	59 in-lbs	66 in-lbs	76 in-lbs	86 in-lbs	101 in-lbs	107 in-lbs	122 in-lbs	143 in-lbs	126 in-lbs	143 in-lbs	168 in-lbs
5/16	18	101	122	135	157	178	209	221	251	295	259	294	346
3/8	16	15 ft-lbs	18 ft-lbs	20 ft-lbs	23 ft-lbs	26 ft-lbs	31 ft-lbs	33 ft-lbs	37 ft-lbs	44 ft-lbs	38 ft-lbs	43 ft-lbs	51 ft-lbs
7/16	14	24	29	32	37	42	49	52	59	70	61	70	82
1/2	13	37	44	49	57	64	75	80	90	106	94	106	125
9/16	12	53	63	70	82	92	109	115	130	154	135	153	180
5/8	11	73	87	97	113	128	150	159	.180	212	186	211	248
3/4	10	129	155	172	200	227	267	282	320	376	331	375	441
7/8	9	125	150	167	322	365	429	455	515	606	533	604	710
1	8	187	225	250	483	547	644	681	772	909	799	905	1065
1 1/8	7	266	319	354	596	675	794	966	1095	1288	1132	1283	1510
1 1/4	7	375	450	500	840	952	1121	1363	1545	1817	1597	1810	2130
1 1/2	6	652	783	869	1462	1657	1950	2371	2688	3162	2779	3150	3706
						Fine T	hread Se	ries					
1/4	28	56 lin-lbs	68 lin-lbs	75 in-lbs	87 in-lbs	99 in-lbs	116 in-lbs	123 in-lbs	139 in-lbs	164 in-lbs	144 in-lbs	163 in-lbs	192 in-lbs
5/16	24	112	135	150	174	197	231	245	278	327	287	325	383
3/8	24	17 A-lbs	20 ft-lbs	23 ft-lbs	26 ft-lbs	30 ft-lbs	35 ft-lbs	37 ft-lbs	42 ft-lbs	49 ft-lbs	43 ff-lbs	49 ft-lbs	58 ft-lbs
7/16	20	27	32	36	41	47	55	-58	66	78	68	78	91
1/2	20	41	49	55	64	72	85	90	102	120	105	120	141
9/16	18	59	71	78	91	103	121	128	146	171	151	171	201
5/8	18	82	99	110	127	144	170	180	204	240	211	239	281
3/4	16	144	173	192	223	253	297	315	357	420	369	418	492
7/8	14	138	165	184	355	403	474	502	568	669	588	666	784
14.5	14	210	252	280	542	614	722	765	867	1020	896	1016	1195
1 1/8	12	298	357	397	668	757	890	1083	1227	1444	1269	1439	1693
1 1/4	12	415	498	553	930	1055	1241	1509	1710	2012	1768	2004	2358

1 1/2 12 734 880 978 1645 1865 2194 2668 3024 3557 3127 3544 4169

Torque values for 1/4 and 5/16-in series are in inch-pounds. All other torque values are in foot-pounds. Torque values calculated from formula T=kDF, where

K=0.15 for "lubricated" conditions K=0.17 for zinc plated and dry conditions K=0.20 for oldin and dry conditions D = Nominal Diameter F = Clamp Load

-	_		Class 4.6			Class 8.8	tiple to		Class 10.9		Clas	s 12.9
		<	4.6	>		8.8	>	١,	10.9	>	F	12.9
Nominal	Pitch	Tigl	tening To	rque		Tightening Torque			htening To	rque		ng Torque
De la			Drg Plated			Dry Plated	Lubed Dry Plated Dry plai					
Dia.		an entitle subsetting	K = 0.17	K = 0.20		K = 0.17	to all or Williams all Indiana.	a dispersion de deservo	K = 0.17	K = 0.20	K = 0.15	K = 0.20
(mm)		(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)	(ft-lbs)
3	0.5	0.28	0.32	0.38	0.73	0.82	0.97	1.0	1.2	1.4	1.2	1.6
3.5	0.6	0.44	0.50	0.59	1.1	1.3	1.5	1.6	1.9	2.2	1.9	2.5
4	0.7	0.66	0.74	0.87	1.7	1.9	2.3	2.4	2.7	3.2	2.8	3.8
5	0.8	1.3	1.5	1.8	3.4	3.9	4.5	4.9	5.5	6.5	5.7	7.6
6	-1	2.3	2.6	3.0	5.8	6.6	7.7	8.3	9.4	-11	9.7	13
- 6	1,25	2.1	2.3	2.7	5,3	6.0	7.0	7.6	8.6	10	8.8	12
7	1	3.8	4.3	5,0	9.7	11	13	14	16	19	16	22
8	1	5.9	6.6	7.8	15	17	20	22	24	29	25	34
- 8	1.25	5.5	6.2	7.3	14	16	19	20	23	27	24	31
10	1.25	.11	13	15	29	33	39	42	48	56	49	66
10	1.5	11	12	14	28	32	37	40	45	53	47	62
12	1.25	21	23	28	53	60	71	76	86	101	89	119
12	1.5	20	22	26	51	58	68	73	82	97	85	113
12	1.75	19	21	25	49	55	65	70	79	93	81	108
14	1.25	26	29	34	66	75	89	95	108	127	111	148
14	1.5	28	32	37	72	82	96	103	117	138	121	161
14	2	30	34	40	78	88	104	111	126	148	130	173
16	1.5	50	57	67	129	146	171	184	208	245	215	287
16	2	47	53	62	121	137	161	173	196	230	202	269
18	1.5	73	82	97	187	212	249	268	303	357	313	417
18	2.5	85	73	86	167	189	222	239	270	318	279	372
20	1.5	101	115	135	270	306	360	374	424	498	437	583
20	2.5	91	104	122	236	267	314	337	382	449	394	525
					ad for spe	cified bolts	K = 0.151	or "lubric	ated" cond	itions	D = Nomin	nal Diamet
All torqui	e value	es are list	ed in foot-	pounds			K = 0.17 for zinc plated, dry conditions					Load

Maintenance Section 4-8

Description	Application	General Specification	Recomended Mobil Lubricant
Tractor Hydraulics	Reservoir	JD-20C MF M1135,M1141 FNHM2C134D (FNH201)	Mobilfluid 424
Mower Hydraulics Cold Temperatures 0° F Start-Up	Reservoir	ISO 46 Anti-Wear-Low Temp	Mobil DTE 15M
Normal Temperatures 10° F Start-Up		JD-20C MF M1135,M1141 FNH M2C134D(FNH201)	Mobilfluid 424
Normal Temperatures 15° F Start Up		ISO 46 Anti-Wear	Mobil DTE 25
High Operating Temp. Above 90° F		ISO 100 Anti-Wear	Mobil DTE 18M
Flail Rear Gearbox	Grease	PAO Synthetic Extreme Pressure Gear Lube	Mobil SHC 75W-90 Mobil 1 Synthetic Gear
Cutter Shaft & Ground Roller Shaft(Flail)	Grease Gun	Lithium-Complex Extreme Pressure NLGI-ISO 320	Mobilgrease CM-S
Drive Shaft Coupler (Flail and Rotary)	Grease Gun	Lithium-Complex Extreme Pressure NLGI2-ISO 320	Mobilgrease CM-S
Drive Shaft Yoke, U-joint & Stub Shaft	Grease Gun	Lithium-Complex Extreme Pressure NLGI2-ISO 320	Mobilgrease CM-S
Boom Swivel Boom Cylinder Pivots (Rotary & Flail Boom)	Grease Gun	Lithium Complex Extreme pressure NLGI2-ISO 320	Mobilgrease CM-S
Deck Boom Pivot & Deck Stop Adjustment Rotary & Flail)	Grease Gun	Lithium Complex Extreme Pressure NLGI-ISO 320	Mobilgrease CM-S
Deck Spindle(Rotary)	Grease Gun	Tiger Spindle Lubricant part number 06540000	Mobilith SHC 220

RSS Maintenance Section 4-9


GRAFFITI REMOVAL

Butyl cellosolve (for removal of paints, marking pen inks, lipstick, etc.) The use of masking tape, adhesive tape or lint removal tools work well for lifting off old weathered paints.

To remove labels, stickers, etc., the use of kerosene or VM&P naphtha are generally effective. When the solvent will not penetrate sticker material, apply heat (hair dryer) to soften the adhesive and promote removal.

IMPORTANT: If a material i s found to be incompatible in a short-term test, it will usually be found to be incompatible in the field. The conv erse, however, is not always true. Favorable performance is no guarantee that actual end-use conditions have been duplicated. Therefore, these results should be used as a guide only and it isrecommended that the user test the products under actual end-use conditions.

RECOMMENDED FILLING INSTRUCTIONS FOR HYDRAULIC RESERVIORS



The reservior should be filled to the center of the sight glass on the side of the tank. Do not over-fill. If the tank has too much oil, the excess may be expelled through the pressurized breather.

DETAILED MAINTENANCE

REPLACING IN-TANK HYDRAULIC FILTER:

Loosen the four bolts on the top cover of the filter housing. Turn cover counter-clockwise until cover is free. Remove and replace filter. Replace top cover and cover bolts in opposite order as removed.




Maintenance Section 4-10

DETAILED MAINTENANCE

REPLACING HIGH PRESSURE HYDRAULIC FILTER ELEMENT:


Ensure the system has been shut down and depressurized. Locate High Pressure Filter housing. Confirm that the element that is a bout to be installed matches the element p/n on the filter model tag. *Example: V3.0510-06 (world line 100, HD049 model)*. Locate the bottom of the High Pressure Bowl. Using the appropriate spanner wrench or ratchet and turning in a counterclockwise rotation, (looking at the bottom of the bowl) remove the bowl from the head. The first couple rotations will seem tight as the o-ring passes the sealing flats. Once the o-ring has cleared the sealing flats the



bowl should spin freely. Taking care not to drop the bowl, finish removing the bowl from the head. **WARNING:** bowl will be full of oil! Pour the oil from the bowl into a container. This oil should be considered contaminated due to the ou tside-in flow direction through the element. Clean the inside of the bowl if "dirt" is present. Remove the old element from the filter head by pulling with a rotation motion. Dispose of the us ed element properly. Remove the new element from the packaging. Using your finger, dab and lubricate the o-ring in the top of the new element with oil. Install the new element into and on the mounting boss within the head. Ensure that the element is fully seated on the boss. Clean and inspect the o-ring that is affixed in the bowl and lubricate with oil. Using a clockwise rotation, screw the bowl back into the head, ensuring that the bowl has not been cross-threaded into the head. Continue to tighten the bowl into the head, using the spanner wrench or ratchet. The rotation of the bowl will become tighter once the o-ring engages the sealing flats. Once the bowl has bottomed out, back-off the bowl by 1/6 tur n. This ensures that the o-ring is seated properly within the sealing flats. Element change out and re-assembly is now complete. Start the machine and inspect the filter area, checking that there is no oil leaking from the filter assembly. Replace the filter element for the first time at 50 hours of operation, then yearly (500 hours) or when indicated by restriction indicator.


GREASING CUTTER SHAFT-FLAIL MOWERS

Locate grease zerks on each end of cutter shaft(s), these are located on the bearing cover. Normal conditions require one or two pumps in each bearing, using Lithium-Complex Extreme Pressure grease confirming to NLGI2-ISO 320 specifications. This is to be done with a standard grease gun daily or at 8 hour intervals. CAUTION: Over greasing may cause premature seal failure.



GREASING GROUND ROLLER SHAFT-FLAIL

Locate grease zerks on eack end of roller tube at lower end of head. Normal conditions require one or two pumps in each bearing, using Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications. This is to be do ne with a standard grease gun daily or at 8 hour intervals. CAUTION: Over greasing may cause premature seal failure.




TIGHTENING KNIFE BOLTS AND DISK BOLTS:

After every 8 hours of operation or daily, the Knife Bolts and Disk Bolts should be tightened as follows:

Knife mounting bolts torque to 800 oiled ft. lbs.

Disk mounting bolts (6ea.) torque to 204 dry or 180 oiled ft. lbs.



GREASING POINTS ON BOOM AND PIVOT

Locate grease zerks on deck pivot assembly, on the deck end of the boom, and at swivel end of main boom. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications until grease begins to protrude from ends.




GREASING SPINDLE

Locate grease fitting on inside of deck hou sing. Inject Tiger Spindle Lubricant, part number 06540000 into spindle housing. Fill with lubricant until lubricant weeps out of to p spindle seal. Lubricate spindle weekly or every 40 hours of use.



TIGHTENING SPINDLE BOLTS

The spindle mounting bolts should be checked and retorqued daily or every 8 hours of service. Torque the (6) bolts shown below to 357 dry or 315 ft. lbs. lubricated.




GREASING PUMP DRIVE SHAFT COUPLER


With engine stopped, ensure drive shaft alignment by grasping coupler and sliding back and forth. Coupler should slide freely with approximately 1/8" of end play. If coupler does not slide freely, inspect for loose pump mount bolts, or damaged or loose crank shaft adapter. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications into coupler until grease begins to protrude from ends. Grease daily or every 8 hours. Do not over grease.



DRIVE SHAFT YOKE, U-JOINT STUB SHAFT


With engine stopped, inject Lithium-Complex extreme pressure grease confirming to NLGI2-ISO 320 specifications into universal joints and slip yoke until grease appears at the seal. Grease them daily or every 8 hours.





GREASING THE BOOM SWIVEL

Locate the zerks on the main swivel boss (if applicable), main boom pivot boss (if applicable) and on both ends of the boom swivel cyl inder. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specification until grease begins to protrude from ends.



RSS Maintenance Section 4-15


GREASING BOOM CYLINDER(S) PIVOT POINTS

Locate the zerk on the butt end tang of cylinder and on rod end tang. Inject Lithium-Complex Extreme Pressure grease confirming to NLGI2- ISO 320 specifications until grease begins to protrude from ends. This procedure is to be used on the main boom cylinder, secondary boom cylinder, deck pivot, and swivel cylinders daily or at 8 hour intervals.



BALL VALVES


The ball valve at the hydraulic reservoir may need to be closed during certain maintenance or repair procedures. THE BALL VALVES MUST BE OPEN (handle parallel with valve) WHEN TRACTOR IS RE-STARTED OR PUMP IS COUPLED TO MOTOR OR P.T.O.! Failure to do so will result in component failure!



BELT TENSION ADJUSTMENT


Locate the tensioning rod for the flail. Loosen the top tension adjustment nut. To tighten the belt, turn the bottom tension nut to compress the spring. To loosen the belt tension, turn the tension nut up to relax the spring. After adjustment, test the belt tension.

The tension should be 207Lbf or 106 freq cyl/sec. If the tension is as desired, turn the top tension nut down to lock the bottom tension nut into place.



ADJUSTING RSS FLAIL CUT HEIGHT

To adjust the cutting height of the Rear Side Stow flail head the two nuts on the roller shaft brackets must be taken off and moved to the desired location/height. Be sure that both sides of the shaft are adjusted to corresponding holes so the shaft remains level.





Maintenance Section 4-17

REVERSING MOWER ROTATION OF RSS FLAIL MOWERS

To reverse the rotation of the Rear Side Stow flail, you need to switch the pressure and return motor hoses at the brake valve. Make sure the tractor is shut off and the ball valve is closed. Relieve the hydraulic pressure in the system first before removing any hoses. After switching the hoses, make sure you open the ball valve or serious damage can be done to the hydraulic pump.

When operating in standard rotation, the front shield must be removed and the baffle installed. When operating in reverse rotation, remove the baffle and install the front shield. Finally, reposition the wear pads on the hoses and replace the zip ties as needed to prevent the hydraulic hoses from rubbing or chafing.





Blades

Check the Blades for cracks and wear and Blade Bolts for tightness, daily. Blades should be replaced when they are worn excessively, bent, deformed, or out of balance.



Blades should always be replaced in pairs. Blades of different weights can cause serious imbalance and damage to the machine and personnel. When replacing blades, take care to replace the blade bolts, nuts, and washers.

Important


Make sure the mower blades are turning clockwise when looking down from the top of the mower. Follow the color coding on the hydraulic hoses and fittings to make sure the motor and hydaulics hoses are assembled properly. Connect the red hose connection only to red fitting. Connect the blue hose connection only to the blue fitting. The blade rotation on the leading edge of the mower should discharge the cut material away from the tractor and operator.



AWARNING

If the leading edge of the mower blades are rotating backwards they can discharge material toward the operator. If this occurs discontinue mowing immediately and revers the direction of the motor rotation by correctly installing the motor pressure and return hoses. Cont act your dealer or Alamo Industrial for specific information on the hose routing.





Maintenance Section 4-19

ROTARY KNIFE REPLACEMENT

- 1. Be sure you have a complete matching set of new knives for replacement.
- 2. Remove knives and inspect holes for damage. Also watch for cracks in the disk (if applicable) around the holes.
- 3. Lube threads with anti-seize. Install bolts through knife and disk from bottom side of disk/blade bar. Install new self-locking nuts and torque them to 800 ft. lbs.
- The knives should swing freely to absorb shocks from impact when striking objects.

≜WARNING

WHEN CUTTING HEAVY BRUSH, KNIFE BOLTS SHOULD BE INSPECTED HOURLY AND RETORQUED TO 1070 DRY OR 800 OILED FT. LBS.

REPLACEMENT OF ROTARY DISK

A CAUTION

Failure to follow the following warnings and instructions may result in serious injury or damage to the equipment or property!

- 1. The bolts that attach the disk to the spindle must be grade 8. These 5/8 inch bolts are to be torqued to 204 dry or 184 oiled ft. lbs.
- 2. A thread locking agent may be applied to threads of all mounting bolts before they are installed.
- Disks must be inspected daily for hairline cracks between spindle mounting bolts or around the knife mounting bolts. These cracks indicate metal fatigue caused by severe abuse. If cracks are present the disk must be replaced.
- 4. Inspect the disk mounting bolts daily when checking tightness of knife mounting bolts. If a disk mounting bolt is loose, it must be removed, threads cleaned, fresh thread locking agent applied, and tightened to proper torque value.
- 5. If a knife mounting bolt is loose, the self locking nut must be replaced as a safety precaution. Lubricate threads with an ti-seize. Install bolts through knife and disk/blade bar from bottom side. Install self locking nuts and torque them to 800 ft. lbs.

Flail Blades Inspection




Inspect the Blades daily for ab normal wear. REPLACE ALL BLADES on the carrier IMMEDIATELY if any blades have:

- · Become bent or deformed from its original shape, or
- · Wear inside the blade bolt hole, or
- · Any cracks are visible, or
- Deep gouges in the blade's surface are present, or
- Gouges or chipped areas in the cutting edge are larger than 1/4"(8mm), or
- The material on the leading edge has been worn away by more than 1/4"(8mm)

DO NOT straighten, sharpen, weld or hard-face blades

Failure to replace worn or damaged blades may lead to catastrophic failure of the blades and ejection of the broken part with tremendous force which may cause serious bodily injury or death.



Always replace blades in sets

- Blades that are damaged may indicate severe service or abuse. If one blade is worn or damaged other blades on the same shaft will have been subjected to the same severe service or abuse.
- The Flail rotor turns at sp eeds exceeding 2000 RPM and is dynamically balanced at the factor y.
 Differences in blade weight between used blades with loss of material from gouges or wear as compared
 to new blades can cause severe vibration and damage to the Flail rotor. Always replace blades as
 complete sets.

Important

Use only genuine Alamo Industrial replacement blades and fasteners. Other blades and fasteners may not meet the Alamo Industrial requirements and could fail during operation. resulting in part being thrown out from under the mower.



Never attempt to sharpen blades. *ops-u-0044*

Maintenance Section 4-21

Blade Pins and D-Ring Inspection

Inspect Blade Pins and D-Rings daily for wear or damage as follows:




Inspect the Blade pins and D-Rings daily for abnormal wear. Make sure the cotter pins are in place and properly spread. REPLACE BLADE Pins and D-Rings IMMEDIATELY if they have:

- Visible cracks or
- · If a Pin or D-Ring has visible worn areas, or
- If a Pin or D-Ring has gouges or chipped areas

Failure to replace abnormally worn pins or D-Rings may lead to catastrophic failure and ejection of the broken part, which may cause serious bodily injury or death.

Always replace the pins and D-Rings whenever excessive wear is noticed.



Important

If the cotter pins are broken by contact with other flail blades, remove the pin and reverse the direction the pin is inserted through the D-Ring so that the cotter pin is on the opposite side of the D-Ring. This will prevent the next set of blades from swinging back and hitting the cotter pin. *ops-u-0045*

Maintenance Section 4-22

BOOM FLAIL KNIFE REPLACEMENT

- 1. If knives are damaged or badly worn, they will need to be replaced as a set. Replacing a single knife can cause severe vibration and possible damage to the mower.
- 2. Assemble knives, clevis, bolts and nuts as shown in part section of manual.
- 3. Install locking hex nut so that the flat face of nut is towards the knife.
- 4. Apply loctite "271" or equivalent to threads.
- 5. Torque nut to 35 FT. LBS. Knife must swing freely.

AWARNING


DO NOT re-use the locking hex nuts for mounting the knives. If hex nut become loose, or require removal for knife replacement or any other reason, they must be discarded and replaced with new nuts.

AWARNING

Knives should not be welded on for any reason.

THE SPINDLE ASSEMBLY

See the diagram below for identification of spindle parts, while servicing.



MntP-B-0024


Dial indicator


set to read end play

MAINTENANCE

BEARING INSTALLATION

- Press upper bearing cup in to the spindle housing.
- 2. Turn the spindle housing over and press in the lower bearing cup.
- 3. Place the lower bearing cone in the bearing cup. Next press t he seal into the s pindle housing. The inner lip of the seal must be DOWN, towards the bearing, so lubricant is sealed inside the housing.
- 4. Install the spindle in the housing. Lightly press the spindle to seat the cone onto the spindle.





- 7. Press the two upper seals into the spindle housing. The inner lip of the seals must be UP, away from the bearing, so excess lubricant can escape.
- 8. Install the bearing adjustment nut (thin nut) so there is 1-1/6" clearance between the nut and the sleeve. Install the jam washer, placing the tab into the key-way. Install the bearing lock nut (thin nut) and hand tighten against jam washer and adjustment nut. See the following section for bearing adjustment.
- 9. Position the spindle housing horizontally with the drain hole oriented "up". Grease through the zerk with Tiger Spindle Lubricant (part number 06540000) until the grease purges from the drain hole.

Spindle housing can turn freely


10. Install the plug into the drain hole.

BEARING ADJUSTMENT

- Clamp the bottom end of the spindle securely in a v ise so the spindle housing turns freely.
- Position a magnetic base dial indicator on the outer diameter of the spindle housing. Locate the end of the dial indicator against the flat end of the spindle shaft. The dial indicator will now measure ac curately bearing end play.
- 3. Tighten the bearing adjustment nut until there is .012 inch mov ement when the spindle housing is pried upward away from the vise jaws.
- 4. When there is .012 inch free play between the spindle and housing, install the bearing lock nut (thick nut). Hold the adjusting nut securely and tighten the lock nut to 300 ft. lbs. of torque.
- 5. After the lock nut is tightened, there must be .001 inch to .003 inch of free play when lightly prying up on the spindle housing.

If the end play is correct, .001 inch to .003 inch, bend tabs up on jam washer to prevent the lock nut from loosening.

If the end play is NOT correct, loosen the lock nut and turn the adjustment nut as required and re-tighten the lock nut. Repeat first part of step 5.



UPPER

BEARING CUP

Maintenance Section 4-25

Boom Cylinder Removal and Replacement Instructions

- 1. Clear the area of all personnel before lowering the boom mower head.
- 2. From the tractor seat with your seat belt fastened around you, Lower the boom mower head to the ground. Extend the boom to the furthest reach and lower the mower head flat on the ground. DO NOT attempt to replace the cylinders with the boom in the raised or transport position.
- 3. Shut off the tractor, engage the parking brake, place the tractor transmission in the park position, and remove the key before dismounting.
- 4. Allow the system to cool to room temperature before removing any hydraulic components
- 5. Wear safety glasses and impenetrable gloves when working with hydraulic hoses and fittings.
- 6. Release all oil pressure from the hydraulic circuit by manually stroking each valve section with the tractor engine off. Utilize the Manual Override function if the unit is equipped with an electric over hydraulic valve.
- 7. Utilize blocks, jack stands or a suitable over head hoist to support the weight of the boom section and remove pressure form the cylinder mounting pins.
- 8. Check to see that the cylinder to be replaced is not under pressure by moving the cylinder pins by hand. The pins should be loose and should slide from the pin bore easily. If the pins are tight and cannot be moved, the cylinder may be under pressure. Make sure the boom components are properly supported and that the pressure is relived from the circuit.
- 9. Cylinder assemblies are heavy and can fall when the pins are removed. Support the hydraulic cylinder with a suitable hoist or jack.
- Slowly loosen the hydraulic connections to the cylinder. Carefully unscrew hose fitting and allow any remaining pressure to bleed off. Use Extreme Care. Oil must be cool, and the technician should stand to the side to prevent exposure to any hydraulic oil. Always consult the Material Safety Data Sheet and wear any required Personal Protective Equipment. A catch pan may be required to retain any spilled oil.
- 11. Cap both ends of the fitting with suitably sized metal caps.
- 12. Remove the cylinder pins starting with the ROD end cylinder pin. Make sure the cylinder is properly supported, and remove the base end cylinder pin. The cylinder may be heavy, use proper lifting techniques to lift and handle the cylinder. If needed, get assistance from another person to safely lift the cylinder from the machine.
- 13. Measure the distance between the cylinder pin holes and extend the new cylinder the correct length prior to attempting an installation.
- 14. Install the new cylinder in place and install both cylinder pins and retaining hardware.
- 15. Remove the metal caps, and re-install the hydraulic hoses.
- 16. Check the hydraulic reservoir of the boom mower to ensure there is sufficient oil. Follow the manufactures recommendations for proper oil type and filtering techniques and requirements to add oil to the system.
- 17. Clear the area of all persons prior to starting the tractor.
- 18. Consult the Operator's Manual for instruction in regard to the proper operating procedure.
- 19. From the tractor seat, with the seat belt fastened, operate the boom to ensure proper operation of the boom function.
- 20. From the tractor seat, with the seat belt fastened, operate the boom controls to fully extend and retract the new cylinder several times to purge any trapped air from the system.
- 21. From the tractor seat, with the seat belt fastened, look for signs of and oil leak. If an oil leak is observed, shut the tractor down and follow the steps to remove pressure from the hydraulic circuit. Identify the source of the leak and resolve the issue.
- 22. Upon completion of the required repairs, return to Step # 16 to recheck the cylinder for proper operation.


RSS Maintenance Section 4-26

CUTTERSHAFT BEARING REPLACEMENT


- 1. Remove existing cuttershaft, bearings and string guards.
- 2. Make sure that the end knives on each end of the cuttershaft are oriented as shown.
- 3. Apply anti-seize on cuttershaft as shown on next page.
- 4. Install non-drive side bearing first.
- 5. Install the top of the string guard on the non-drive side first. Use Loctite-271 or equivalent and torque (95 ft-lb or 104ft-lb if you use an extension).
- 6. Install the bearing and top string guard on the drive side.
- 7. Center the cuttershaft between the string guards. Use Loctite-271 or equivalent and torque (95ft-lb or 104ft-lb if you use an extension) the top string guard on the drive side.
- 8. Install, use Loctite-271 or equivalent, and torque (95ft-lb or 104ft-lb if you use an extension) the bottom string guard on both sides.
- 9. Make sure the cuttershaft is centered. On the non-drive side, tighten one set screw in the bearing onto the cuttershaft.
- 10. Remove the other set screw and drill a 5/16" hole into the cuttershaft 3/16" deep through the hole in the bearing. BE CAREFUL NOT TO DAMAGE THE THREADS IN THE BEARING HOLE.
- 11. Replace the set screw in the bearing, use Loctite-271 or equivalent, and tighten onto the cuttershaft through the new hole.
- 12. Remove the other set screw and repeat the drilling procedure (Step 10). Replace the set screw as stated in Step 11.
- 13. Repeat steps 9 through 12 on the drive side.
- 14. Grease both bearings properly.

See illustration on next page

RSS Maintenance Section 4-27



DAILY MAINTENANCE SCHEDULE
The following services should be performed daily or every 8 hours of service, following the detailed maintenance instructions in the operators manual.
Pump Drive Shaft: If required with drive shaft/coupler check for end play and lubricate at zerks.
Crankshaft adapter: If equipped with rubber grommets check condition, replace if missing or damaged.
Pivot points: Inject grease until it appears at ends.
Hydraulic fittings: Check for leaks with paper or cardboard. Tighten fittings or replace hoses immediately.
Knives: Inspect for missing or damaged knives, change (only complete sets) as needed.
Belts: Check/Tighten/Replace belts as needed.
Main Frame/Deck: Unless otherwise specified retorqued bolts according to torque specifications in this section.
Hydraulic Fluid Level: Add, if required, per fluid recommendations.
Rear Flail Drive, Bearing Flange and Shaft Couplers: Grease as instructed in the de tailed Maintenance Section.
Cutter Shaft and Ground Roller: Grease as instructed in the detailed Maintenance Section.
Maintenance Section **This page may be copied and used as part of the daily maintenance routine.
RSS Maintenance Section 4-29
ivalification decition 4-29



JD 5\$,)!) %%) H(: FGG **PARTS SECTION**

PART NAME INDEX

PARTS ORDERING GUIDE	. 3
TRACTOR MOUNT KIT	
TRACTOR MOUNT KIT - HYDRAULICS	
ELECTRONIC PROPORTIONAL LIFT VALVE EFS	
JOYSTICK AND SWITCHBOX MOUNT	10
CANBUS JOYSTICK CONTROL	
CANBUS ELECTRONIC LIFT VALVE SWITCHBOX	13
CANBUS JOYSTICK ELECTRICAL TROUBLESHOOTING	
CANBUS ELECTRONIC SCHEMATIC	15
CANBUS LIFT VALVE BREAKDOWN	
SINGLE COLUMN BOOMREST	
POLYCARBONATE SAFETY WINDOW	
WHEEL SPACER	22
WHEEL WEIGHT	
NOTES	24

PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

- The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
- The Purchase Order must indicate the Name and Address of the person or organization ordering the parts, who should be charged, and if possible, the serial number of the machine for which the parts are being ordered.
- The purchase order must clearly list the quantity of each part, the complete and correct part number, and the basic name of the part.
 - 4. The manufacturer reserves the right to substitute parts where applicable.
- Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
 - 6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:

Tiger Corporation 3301 N. Louise Ave. Sioux Falls, SD 57107 1-800-843-6849 1-605-336-7900

TRACTOR MOUNT KIT




TRACTOR MOUNT KIT

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06300351	1	MAIN FRAME
2	06410267	1	UPRIGHT,LH
4	06300231	1	AXLE BRC,LH
5	06300266	1	AXLE BRC,RH
6	06700213	1	TANK,RES,WHEEL WELL,ASSY
7	23152	1	PUMP
8	06401034	1	MOUNT,PUMP
9	06380031	1	GUARD,PUMP
10	21639	2	CAPSCREW,3/8" X 3-1/4",NC
11	22016	8	FLATWASHER,3/8"
12	21627	6	NYLOCK NUT,3/8",NC
13	33764	12	FLATWASHER,5/8",SAE
14	22421	12	CAPSCREW,16MM X 40MM,2.0P
15	21832	10	CAPSCREW,3/4" X 2",NC
16	33880	32	FLATWASHER,3/4",SAE
17	21825	10	HEX NUT,3/4",NC
18	31731	8	CAPSCREW,20MM X 50MM,2.5P
19	27282	4	CAPSCREW,20MM X 55MM,2.5P
20	24849	4	SPACER,7/8"ID X 1-1/4"OD X 5/8"
21	6T2291	4	PLOW,BOLT,1/2" X 2",NC
22	21725	4	HEX NUT,1/2",NC
23	21631	4	CAPSCREW,3/8" X 1-1/4",NC
24	06533004	4	FLATWASHER,1/2"
25	21680	2	CAPSCREW, 7/16" X 1-1/4" NC
26	22017	2	FLATWASHER, 7/16"
27	21677	2	NYLOCK NUT, 7/16" NC
28		-	JD BELT (EXISTING)
29	SJ23950	1	JD PULLEY KIT
30	06420149	1	DRIVESHAFT
31	06370109	1	COUPLER

TRACTOR MOUNT KIT - HYDRAULICS




TRACTOR MOUNT KIT - HYDRAULICS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1		-	MAIN FRAME *REFER TO TRACTOR MOUNT KIT
2		-	HYDRAULIC TANK *REFER TO TRACTOR MOUNT KIT
4	06503084	1	ELBOW,1-1/2"FOR X 1-1/2"FOR
5	06503083	1	ADAPTER,1-1/2"MOR X 1-1/2"MOR
6	34309	1	BALL VALVE,1-1/2"FOR
7	34710	1	ADAPTER,1-1/2"MOR X 1-1/2"MJ
8	32382	4	BRACKET,HOSE
9	27281	2	CAPSCREW,20MMM X 60MM,2.5P
10	33880	4	FLATWASHER,3/4",SAE
11	30708	4	CAPSCREW,20MM X 90MM,2.5P
12	24849	4	SPACER
13	06500692	1	HOSE,1-1/2" X 110"
14	TF4852	2	KIT,FLANGE
16	23152	1	PUMP
17	06500430	1	HOSE,1" X 82"
18	06505017	2	CLAMP KIT,1"
19	34626	2	BRACKET,CLAMP
20	06510084	1	BRAKE VALVE
21	33259	1	ELBOW,1"MJ X 1"FJX90
22	32869	1	NIPPLE,LONG,1"MOR X 1"MJ
23	33555	2	ADAPTER,1"MOR X 1"MJ
24	33456	1	HOSE,1" X 70" (PRESSURE)
25	06500702	1	HOSE,1" X 73" (RETURN)
26	34117	1	ELBOW,1"MOR X 1"MJ
27	06500693	1	HOSE,1" X 174"
28	34064	1	ADAPTER,1-1/4"MOR X 1"MJ

ELECTRONIC PROPORTIONAL LIFT VALVE EFS




ELECTRONIC PROPORTIONAL LIFT VALVE EFS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06700230	1	ELECTRONIC VALVE, DF,CNBS, EFS
2	21630	4	CAPSCREW,3/8" X 1",NC
3	34622	1	PLATE, VALVE, REAR MNT
4	21987	4	LOCKWASHER,5/16"
5	21579	4	CAPSCREW,5/16" X 3/4",NC
8	32807	10	ADAPTER,5/8"MB X 3/8"MJ
9	06500687	6	HOSE,1/4" X 268"
10	06500697	2	HOSE,1/4" X 210"
11	06500921	2	HOSE,3/8" X 288"
13	06500825	2	HOSE,3/4" X 40"
14	06503023	2	ADAPTER, 3/4" MB X 3/4"MJ
18	21627	9	NYLOCK NUT,3/8",NC
19	21632	5	CAPSCREW, 3/8" X 1-1/2" NC
22	21631	4	CAPSCREW, 3/8" X 1-1/4" NC
23	06502167	1	ADAPTER, PB, JD5M/E
24	06500072	1	BRACKET
25		-	TRACTOR PREFORMED TUBE
26	RE37651	1	PLUG
27	6T2615	4	WASHER,FENDER,3/8"
28	06340033	1	VALVE MOUNT
31	06503193	1	TEE, RUN, 27MM X 3/4"MF X 3/4"MF
32	06500922	2	HOSE, 3/8" X 23"
33	34128	2	TEE, BRANCH 3/8" X 3/8" X 3/8"

JOYSTICK AND SWITCHBOX MOUNT




JOYSTICK AND SWITCHBOX MOUNT

Continued...


ITEM	PART NO.	QTY.	DESCRIPTION
1	06340031	1	MT,BRKT,JYSTK
2	06510285	1	JOYSTICK, CNBS
3	06770022	1	CAN,JOYSTICK
4	06520019	2	MOUNT,RAM BALL,1-1/2",FLANGE
5	06520290	1	MOUNT,RAM,BALL,DBL,1-1/2"
6	06520020	2	MOUNT,RAM,ARM,1-1/2" X 4-5/8",STD
7	06400882	1	RING,BOLT,MNT,JYSTK
8	23113	2	CAPSCREW,10MM X 30MM,1.5P
9	32990	6	SCREW,MACHINE,10-32 X 1/2",RD HD
10	32829	4	SCREW,MACHINE,10-32 X 3/4",FLT HD
12	06510286	1	SWITCH BOX, RSS, CNBS
13	06411086	4	BRKT,MNT
14	21529	8	CAPSCREW,1/4" X 3/4",NC
15	06411087	2	BRKT,STABILIZING
16	22014	8	FLATWASHER,1/4"
17	21527	14	NYLOCK NUT,1/4",NC
18	21528	4	CAPSCREW,1/4" X 1/2",NC
19	06411116	1	BRKT,MNT,SWITCH BOX
20	21986	4	LOCKWASHER,1/4"
21	06411378	1	BRKT, STABILIZING, RT
23	06510287	1	CONTROLLER, SWBX CNBS
24	06411524	1	MNT, CNTRLLER, CNBS
25	21534	2	CAPSCREW, 1/4" X 2" NC
l			

CANBUS JOYSTICK CONTROL




ITEM	PART NO.	QTY.	DESCRIPTION
1	06510286	1	SWITCHBOX, DF, RSS, CNBS
2	06510285	1	JOYSTICK, RH, DF, CNBS
3	06510083	1	VALVE, BRAKE, SOL, 3000PSI
4	06510287	1	CONTROLLER, SWBX, CNBS
5	06700225	1	VALVE, 5SPL, DF, RSS, CNBS

CANBUS ELECTRONIC LIFT VALVE SWITCHBOX




I I ⊏IVI	PART NO.	QII.	DESCRIPTION
1	06502168	1	SWITCHBOX ASSY
2	06502171	2	SWITCH, MASTER, TRAVEL LOCK
3	06502172	1	INDICATOR LIGHT, FLOAT, GREEN
4	06502170	1	SWITCH, SHIELD
5	34540	1	STRAIN RELIEF, 3/4" BLACK
6	06502174	1	INDICATOR LIGHT, ON, RED
7	06502169	1	CIRCUIT BREAKER, 15A
8	06550044	1	LABEL, SWBX
9	35226	1	SWITCH, MOWER, COLEHERSEE
10	02964063	1	KNOB, RED


CANBUS JOYSTICK ELECTRICAL TROUBLESHOOTING



CANBUS ELECTRONIC SCHEMATIC



CANBUS LIFT VALVE BREAKDOWN




ITEM	PART NO.	QTY.	DESCRIPTION	
1	06502074	1	END PLATE	
1S	06505013	1	END PLATE SEAL KIT	
2	*	5	BONNET	
2S	06505042	1	BONNET SEAL KIT	
2A	33459	1	MAIN BOOM BONNET	
2B	42197	1	SECONDARY BOOM BONNET	
	42197	1	DECK ROLL BONNET	
	42197	1	BOOM SWIVEL BONNET	
	42197	1	DECK SHIELD BONNET	
3	06502075	1	INLET SECTION	
3S	06505013	1	INLET SECTION SEAL KIT	
JD5M RSS T4F				

CANBUS LIFT VALVE BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
4	*	5	ELECTRONIC ACCUATOR
4S	34030	1	ELECTRONIC ACCUATOR SEAL KIT
4A	06502067	1	MAIN BOOM ELECTRONIC ACCUATOR
	06502067	1	SECONDARY BOOM ELECTRONIC ACCUATOR
	06502067	1	DECK ROLL ELECTRONIC ACCUATOR
	06502067	1	BOOM SWIVEL ELECTRONIC ACCUATOR
4B	06502072	1	DECK SHIELD ELECTRONIC ACCUATOR
5	42002	1	TIE BOLT KIT
6	*	5	SECTION
6S	06505013	1	SECTION SEAL KIT
6A	42698	1	MAIN BOOM SECTION
6B	42698	1	SECONDARY BOOM SECTION
6C	42698	1	DECK ROLL SECTION
6D	42698	1	BOOM SWIVEL SECTION
6E	42698	1	SHIELD SECTION
7	*	5	SPOOL
7A	42697	1	MAIN BOOM SPOOL
7B	42697	1	SECONDARY BOOM SPOOL
7C	4229806	1	DECK ROOM BOOM SPOOL
7D	06502073	1	BOOM SWIVEL SPOOL
7E	42201	1	BECK SHIELD SPOOL
8	*	10	ANTI CAV/SHOCK RELIEF
8A1	06502071	1	MAIN BOOM A PORT RELIEF
8A2	06502069	1	MAIN BOOM B PORT RELIEF
8B1	42650	1	SECONDARY BOOM A PORT RELIEF
8B2	06502070	1	SECONDARY BOOM B PORT RELIEF
8C1	42296	1	DECK ROLL A PORT RELIEF
8C2	42295	1	DECK ROLL B PORT RELIEF
8D1	42650	1	BOOM SWIVEL A PORT RELIEF
8D2	42650	1	BOOM SWIVEL B PORT RELIEF
8E1	06502072	1	DECK SHIELD A PORT RELIEF
8E2	06502072	1	DECK SHIELD B PORT RELIEF
9	33459	1	HANDLE

SINGLE COLUMN BOOMREST




SINGLE COLUMN BOOMREST

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1		-	MAINFRAME *REFER TO TRACTOR MOUNT KIT PAGE
2		-	AXLE BRACE,RH *REFER TO TRACTOR MOUNT KIT
3	06310074	1	BOOMREST, SINGLE COLUMN
4	06310116	1	BOOMREST ADAPTER
5	21725	4	HEX NUT,1/2",NC
6	22018	8	FLATWASHER,1/2",WIDE
7	21733	4	CAPSCREW,1/2" X 2",NC
8	21825	8	HEX NUT,3/4",NC
9	22021	16	FLATWASHER,3/4"
10	21843	2	CAPSCREW,3/4" X 6",NC
11	21797	12	CAPSCREW,5/8" X 9",NC
12	33764	4	FLATWASHER,5/8",GR8,SAE
13	06401399	1	BAR, AXLE, RH, JD5XXXM

POLYCARBONATE SAFETY WINDOW




POLYCARBONATE SAFETY WINDOW

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06490014	1	POLYCARB, FRMD, REAR
2	06490013	1	POLYCARB, FRMD, DOOR
3	31965	25	TRIM SEAL (IN FEET)
4	21584	2	CAPSCREW, 5/16" X 2",NC
5	21575	6	HEX NUT, 5/16" NC
6	33477	2	VIBRATION ISOLATOR
7	06410268	1	TOP BRACKET
8	06410269	1	BOTTOM BRACKET
9	21529	2	CAPSCREW,1/4" X 3/4",NC
10	21986	2	LOCKWASHER,1/4"
11	21525	2	HEX NUT,1/4",NC
12	27508	2	CAPSCREW,8MM X 20MM,1.25P
13	6T2619	2	LOCKWASHER,8MM
14	34948	2	WASHER,8MM
15		-	HEX NUT (EXISTING HARDWARE)
	06537005	1	3M ADHESIVE

JD5M RSS T4F


WHEEL SPACER



ITEM	PART NO.	QTY.	DESCRIPTION
1	06770025	1	KIT,SPCR,WHL,JD
2	06400919	1	RING,SPACER,WHEEL,JD

JD5M RSS T4F

WHEEL WEIGHT



ITEM	PART NO.	QTY.	DESCRIPTION
1	31455	4	CAPSCREW,3/4" X 17",NC
2	33880	4	FLATWASHER,3/4",SAE
3	06770057	1	WHEEL WEIGHT,500LBS
4	06430143	4	SPACER,5.5"
5	21825	4	HEX NUT,3/4",NC

JD5M RSS T4F

NOT	ES	



PART NAME INDEX

PARTS ORDERING GUIDE	4
BOOM MOUNT KIT	5
NOTES 2	7
BOOM ASSEMBLY - FLAIL	8
BOOM ASSEMBLY - ROTARY	10
60IN ROTARY MOWER	12
60IN ROTARY DISK AND KNIVES	14
60IN BLADE BAR AND KNIVES	16
NOTES	17
ROTARY MOWER SPINDLE ASSEMBLY	18
75IN FLAIL - STANDARD ROTATION	20
75IN FLAIL - REVERSE ROTATION	22
FLAIL DRIVE ASSEMBLY	24
BOOM PIVOT ASSEMBLY	26
SLIDE ASSEMBLY	28
HOSE RING ASSEMBLY	30
2-1/2IN X 30IN CYLINDER BREAKDOWN	31
3IN X 15IN CYLINDER BREAKDOWN	32
4IN X 14IN CYLINDER BREAKDOWN	33
4IN X 15IN CYLINDER BREAKDOWN	34
NOTES 1	35
FRONT PUMP BREAKDOWN	36
ROTARY MOTOR BREAKDOWN	38
FLAIL MOTOR BREAKDOWN	40
COOLER ASSEMBLY - OPTION	42
RESERVOIR TANK FILTER ASSEMBLY	44
PUMP AND GRILL GUARD OPTIONS	45
MANUAL LIFT VALVE SWITCH BOX	46
MANUAL LIFT VALVE SWITCH BOX SCHEMATIC	47
ELECTRONIC LIFT VALVE SWITCH BOX	48
ELECTRONIC LIFT VALVE SCHEMATIC	49
SOLENOID SWITCH BOX AND WIRING	50
BRAKE VALVE ASSEMBLY	51
BRAKE VALVE HYDRAULIC SCHEMATIC	52
ELECTRICAL TROUBLESHOOTING GUIDE	53
HYDRAULIC TROUBLESHOOTING GUIDE	54
TROUBLESHOOTING	55
TROUBLESHOOTING - CONTINUED	56
FIRE SUPPRESSION SYSTEM	57
FIRE SUPPRESSION 3-POINT MOUNT	58
COMMON RSS	
O DIVINION NOO	

PART NAME INDEX

FIRE SUPPRESSION FRONT MOUNT	60
FIRE SUPPRESSION SYSTEM ELECTRICAL SCHEMATIC	62
WETCUT	63
WETCUT 50 GALLON TANK - 3PNT MOUNT	64
WETCUT 100 OR 150 GALLON TANK - 3PNT MOUNT	65
WETCUT 3PNT PLUMBING - 50IN MOWERS	66
WETCUT 3PNT PLUMBING - LARGE MOWERS	68
WETCUT FRONT PLUMBING - 50IN MOWERS	70
WETCUT FRONT PLUMBING - LARGE MOWERS	72
WETCUT 50IN SPRAYER HEAD ASSEMBLY	74
WETCUT 60IN SPRAYER HEAD ASSEMBLY	76
WETCUT CABLES	78

PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

- The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
- The Purchase Order must indicate the Name and Address of the person or organization ordering the parts, who should be charged, and if possible, the serial number of the machine for which the parts are being ordered.
- The purchase order must clearly list the quantity of each part, the complete and correct part number, and the basic name of the part.
 - 4. The manufacturer reserves the right to substitute parts where applicable.
- Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
 - 6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:

Tiger Corporation 3301 N. Louise Ave. Sioux Falls, SD 57107 1-800-843-6849 1-605-336-7900

BOOM MOUNT KIT




BOOM MOUNT KIT

ITEM	PART NO.	QTY.	DESCRIPTION	
1		-	MAINFRAME *REFER TO TRACTOR MOUNT KIT	
2	21782	1	CAPSCREW,5/8" X 1-3/4",NC	
3	21777	1	NYLOCK NUT,5/8",NC	
4	32381	1	PIN,CAPPED	
5	32322	2	BUSHING	
6	06505185	1	CLAMP KIT	
7	6T3211	2	GREASE ZERK,1/8"NPT	
8	21677	3	NYLOCK NUT,7/16",NC	
9	32380	2	PIN,1"	
10	21683	2	CAPSCREW,7/16" X 2",NC	
11	TB1023	2	ROLL PIN	
12	06420100	1	PIN,1-1/4"	
13		-	SPHERICAL BEARING *NOT FOR SALE	
14	06700221	1	SWIVEL ASSEMBLY	
15	06520250	1	BEARING, WASHER	
16	32810	2	ADAPTER,ELBOW	
17	06501029	1	CYLINDER,3" X 13.88"	
18	06420022	1	PIN, 1/5" X 12"	
19	21688	1	CAPSCREW, 7/16" X 3-1/4"	

NOTES 2

	NOTES
COMMON RSS	

BOOM ASSEMBLY - FLAIL




- RETURN AND PRESSURE HOSES ON FLAIL ARE REVERSED FOR REVERSE ROTATION BOOM FLAILS
- IMPORTANT: ALIGN GREASE HOLE IN BEARING (ITEM 3) WITH GREASE ZERK IN BOOM. MAINTAIN ALIGNMENT DURING BEARING INSTALLATION
- 3. GREASE (ITEM 4) HINGE PIN ZERKS ON BOOM AFTER ASSEMBLY, ONCE UNDER LOAD WITH BOOM ELEVATED AND AGAIN AT REST WITH BOOM SUPPORTED

BOOM ASSEMBLY - FLAIL

ITEM	PART NO.	QTY.	DESCRIPTION	
1		-	SWIVEL ASSY *REFER TO BOOM MOUNT KIT PAGE	
2	6T3211	7	GREASE ZERK,1/8"	
3	32321	6	BEARING	
4	06500723	2	HOSE,1/4" X 52"	
5	06500724	2	HOSE,1/4" X 70"	
6		1	HOSE *REFER TO TRACTOR SPECIFIC PARTS	
7		1	HOSE *REFER TO TRACTOR SPECIFIC PARTS	
8	06505116	3	HOSE CLAMP	
9	32365	1	CYLINDER,4" X 15",WELDED	
10	21687	1	CAPSCREW,7/16" X 3",NC	
11	32375	1	PIN,1-1/2"OD	
12	21677	1	NYLOCK NUT,7/16"	
13	06700000	1	BOOM ASSEMBLY, COMPLETE	
	35331	1	BOOM WELDMENT	
14	TB1033	1	PIN,CLEVIS	
15	06537021	2	ROLL PIN,5MM	
16	32810	2	ELBOW	
17	06501028	1	CYLINDER,4" X 14",WELDED	
18	TB1023	2	ROLL PIN,7/16"	
19	06420100	1	PIN,1-1/4"OD	
20	TB3010	1	SPLIT BUSHING	


BOOM ASSEMBLY - ROTARY



BOOM ASSEMBLY - ROTARY

ITEM	PART NO.	QTY.	DESCRIPTION	
1		-	SWIVEL ASSY *REFER TO BOOM MOUNT KIT PAGE	
2	6T3211	7	GREASE ZERK,1/8"	
3	32321	6	BEARING	
4	06500723	4	HOSE,1/4" X 52"	
5	06500724	2	HOSE,1/4" X 70"	
6		1	HOSE *REFER TO TRACTOR SPECIFIC PARTS	
7		1	HOSE *REFER TO TRACTOR SPECIFIC PARTS	
8	06505116	3	HOSE CLAMP	
9	32365	1	CYLINDER,4" X 15",WELDED	
10	21687	1	CAPSCREW,7/16" X 3",NC	
11	32375	1	PIN,1-1/2"OD	
12	21677	1	NYLOCK NUT,7/16"	
13	06700000	1	BOOM ASSEMBLY, COMPLETE	
	35331	1	BOOM WELDMENT	
14	TB1033	1	PIN,CLEVIS	
15	06537021	2	ROLL PIN,5MM	
16	32810	2	ELBOW	
17	06501028	1	CYLINDER,4" X 14",WELDED	
18	TB1023	2	ROLL PIN,7/16"	
19	06420100	1	PIN,1-1/4"OD	
20	TB3010	1	SPLIT BUSHING	

60IN ROTARY MOWER




ITEM	PART NO.	QTY.	DESCRIPTION
1	06320183	1	DECK,WLDMNT,60" RTRY,RSS
2	33777	2	SKID SHOE,RTRY
3	06320162	1	SHIELD,60"RTRY
4	33879	6	CAPSCREW,3/4" X 2-1/4",NF,GR 8
5	33880	6	FLATWASHER,3/4",GR 8,SAE
6	21993	6	LOCKWASHER,3/4",GR 8
7	6T2413	6	HEX NUT,3/4",NF,GR 8
8	6T1024H5	1	SPINDLE ASSY,CPLT,HD,5/8 HOLES
9	6T2270	16	PLOW BOLT,3/8" X 1",NC
10	22016	33	FLATWASHER,3/8"
11	21625	20	HEX NUT,3/8",NC
12	21988	11	LOCKWASHER,3/8"

60IN ROTARY MOWER

	ITEM	PART NO.	QTY.	DESCRIPTION
	13	21633	11	CAPSCREW,3/8" X 1-3/4",NC
	14	6T0823	1	FLAP RETAINER,60" RTRY
	15	06520238	2	FLAP,60" RTRY
	16	6T1033	1	COUPLER COVER
	17	6T1029	1	COUPLER CHAIN
	18	21223	1	SPROCKET
	19	21733	4	CAPSCREW,1/2" X 2",NC
	20	33776	1	MOTOR MOUNT,PLATE,RTRY
	21	06500458	1	HOSE,1" X 95" (PRESSURE)
	22	TF4852	2	FLANGE KIT,#20
	23	06504011	1	MOTOR
	24	06500613	1	HOSE,1" X 87" (RETURN)
	25	21727	4	NYLOCK NUT,1/2",NC
	26	06533004	4	FLATWASHER,1/2"
	27	6T2290	4	CAPSCREW,5/8" X 2",NF,GR 8
	28	33764	8	FLATWASHER,5/8",GR 8,SAE
	29	21992	4	LOCKWASHER,5/8"
	30	6T2408	4	HEX NUT,5/8",NF
	31	TF1124	1	SQUARE KEY
	32	33881	4	CAPSCREW,FLG,3/8" X 3/4",NC
	33	33779	1	PLATE,COVER,KNF HOLE
	34	06410439	2	COVER
	35	22014	2	FLATWASHER,1/4"
	36	21530	2	CAPSCREW,1/4" X 1",NC
	37	06500141	1	HOSE,1/4" X 92"
	38	06500443	1	HOSE,1/4" X 83"
	39	RD1032	2	LYNCH PIN
	40	33984	2	PIN,SHIELD
	41	33785	1	CYLINDER,1-1/2" X 8"
	42	6T3017	2	ROLLPIN
	43	06420139	1	HINGE PIN,60" RTRY
	44	33772	1	LINK,SHIELD,RTRY
	45	21634	2	CAPSCREW,3/8" X 2",NC
	46	33773	1	LINK 2,SHIELD,RTRY
	47	06401245	2	SKID SHOE,TRB60
	48	06530226	1	CAPSCREW,3/4" X 8-1/2",NC
	49	35340	1	ROLLER
	50	35339	1	BUSHING
	51	21825	1	HEX NUT,3/4",NC
	52	06503057	2	ADAPTER,1/4"MOR X 3/8"MJ
ĺ				

60IN ROTARY DISK AND KNIVES




60IN ROTARY DISK AND KNIVES

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
	27167	1	BOLT KIT (INCLUDES ITEMS 7, 8 & LOCTITE)
1	34876	1	BLADE MOUNTING DISK
2	6T1023R	2	NYLOCK NUT,1-1/8",NF
3	34878	2	SPACER
4	34684	2	STANDARD GRASS KNIFE
5	34685	2	HIGH SUCTION GRASS KNIFE (OPTIONAL)
6	34497	2	KNIFE MOUNTING BOLT
7	25270	6	FLATWASHER,5/8",GR8,USS
8	6T2259	6	CAPSCREW,5/8" X 1-3/4",NF
	6T1825	1	LOCTITE (USED ON ITEM 8)
	33893	1	KNIFE KIT (ITEMS 2,4 & 6)


60IN BLADE BAR AND KNIVES



ITEM	PART NO.	QTY.	DESCRIPTION
1	PT1018H5	1	SPINDLE
2	06400690	1	BAR,BLADE,RTRY60
3	6T1023R	2	KNIFE MTG NUT,1-1/8,NYLOCK,NF
4	06533002	2	FLATWASHER,1-1/8,GR8
5	06521001	2	KNIFE,TRB50,5/8
6	06538000	2	KNIFE MTG BOLT,5/8 SHOULDER
7	33764	6	FLATWASHER,5/8,GR 8,SAE
8	6T2259	6	CAPSCREW,5/8 X 1-3/4,NF,GR8

	NOTES	
	NOTES	
COMMON RSS		

ROTARY MOWER SPINDLE ASSEMBLY




- 1. FREEPLAY: .001" .003" 2. GREASE: FILL WITH MOBILITH SHC 220. 3. APPLY LOCTITE "271" TO O-RING PLUG THRDS.

ROTARY MOWER SPINDLE ASSEMBLY

ITEM	PART NO.	QTY.	DESCRIPTION
	6T1024H5	-	SPINDLE ASSEMBLY COMPLETE
1	6T1031	1	SPROCKET
2	6T1016	1	BEARING LOCK NUT - THICK
3	22596	1	JAM WASHER
4	6T1015	1	BEARING ADJUSTMENT NUT - THIN
5	6T1014	1	BEARING ADJUSTMENT SLEEVE
6	6T1011	1	UPPER SEAL - SET OF 2
7	6T1012	1	BEARING CONE
8	6T1013	1	BEARING CUP
9	6T1010H	1	SPINDLE HOUSING
10	30570	1	FITTING STREET ELBOW
11	33990	1	GREASE ZERK
12	6T1013H	1	BEARING CUP
13	6T1012H	1	BEARING CONE
14	6T1011H	1	LOWER SEAL
15	6T1019	1	SPINDLE KEY
16	PT1018H-5	1	SPINDLE
17	06503064	1	O-RING PLUG, 1/8"
	31771	-	SPINDLE REBUILD KIT (INCLUDES ITEMS 2 - 8 AND 12 - 15)

75IN FLAIL - STANDARD ROTATION



ITEM PART NO. QTY. DESCRIPTION


1 06320185 1 BONNET,75",STD,RSS 2 28737 1 BAFFLE,75",STD

75IN FLAIL - STANDARD ROTATION

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
3	6T2283	10	CARRIAGE BOLT,3/8" X 1",NC
4	6T2615	10	WASHER,FENDER,3/8"
5	21988	10	LOCKWASHER,3/8"
6	21625	46	HEX NUT,3/8",NC
7	27975A	1	GUARD,CUTTERSHAFT
8	21731	4	CAPSCREW,1/2" X 1-1/2",NC
9	21990	6	LOCKWASHER,1/2"
10	21725	6	HEX NUT,1/2",NC
11	28735	2	GROUND ROLLER ADJ BRKT,STD DTY
12	06520028	2	BEARING,FLANGE,1-3/8,GRNDRLR
13	06520027	2	CAP,BEARING,GRNDRLR
14	06520029	2	O-RING,2-3/4 X 3/32",AS568A-148
15	06530001	12	CAPSCREW,SKT HD,8-32 X 1/2",SS
16	TF1045B	2	STUB SHAFT,GROUND ROLLER
17	28738	1	GROUND ROLLER,75"
18	6T2330	8	CAPSCREW,SKT HD,7/16" X 1-1/2",NC
19	6T2331	8	CAPSCREW,SKT HD,7/16" X 1",NC
20	28086A	2	SKID SHOE,STD DUTY REAR FLAIL
21	30013	10	PLOW BOLT,3/8" X 1-1/4",NC,GR5
	28747	-	CUTTERSHAFT ASSY,STANDARD
22	28643B	1	CUTTERSHAFT,75"
23	33713	80	KNIFE,FLAIL,SHORT
24	TF1020	40	KNIFE MTG CLEVIS,FLAIL
25	34011	40	CAPSCREW,7/16" X 3-7/16",NC,GR8
26	21677	40	NYLOCK NUT,7/16",NC
	06200639	-	STRING GUARD KIT,SD (ITEMS 27,29,30)
27	33863	2	STRING GUARD,STD
28	28683	2	BEARING,FLANGE,1-15/16",STD,TSF
29	06530217	8	CAPSCREW,1/2" X 2",NC,L9
30	06533006	8	FLATWASHER,1/2",SAE,L9
31	21732	2	CAPSCREW,1/2" X 1-3/4",NC
32	TF1029	2	BAR,FLAP,TSF/TBF,75"
33	TF1016	1	FLAP,DEFLECTOR,TSF,75"
34	06520242	1	FLAP,75",FRONT
35	21632	26	CAPSCREW,3/8" X 1-1/2",NC
36	22016	36	FLATWASHER,3/8"
37	21825	1	HEX NUT,3/4",NC
38	35339	1	BUSHING
39	35340	1	ROLLER
40	06530226	1	CAPSCREW,3/4" X 8-1/2",NC


75IN FLAIL - REVERSE ROTATION



75IN FLAIL - REVERSE ROTATION

ITEM	PART NO.	QTY.	DESCRIPTION
3	6T2283	10	CARRIAGE BOLT,3/8" X 1",NC
4	6T2615	10	WASHER,FENDER,3/8"
5	21988	10	LOCKWASHER,3/8"
6	21625	36	HEX NUT,3/8",NC
7	27975A	1	GUARD,CUTTERSHAFT
8	21731	6	CAPSCREW,1/2" X 1-1/2",NC
9	21990	8	LOCKWASHER,1/2"
10	21725	8	HEX NUT,1/2",NC
11	28735	2	GROUND ROLLER ADJ BRKT,STD DTY
12	06520028	2	BEARING,FLANGE,1-3/8",GRNDRLR
13	06520027	2	CAP,BEARING,GRNDRLR
14	06520029	2	O-RING,2-3/4" X 3/32",AS568A-148
15	06530001	12	CAPSCREW,SKT HD,8-32 X 1/2",SS
16	TF1045B	2	STUB SHAFT,GROUND ROLLER
17	28738	1	GROUND ROLLER,75"
18	6T2330	8	CAPSCREW,SKT HD,7/16" X 1-1/2",NC
19	6T2331	8	CAPSCREW,SKT HD,7/16" X 1",NC
20	28086A	2	SKID SHOE,STD DUTY REAR FLAIL
21	30013	9	PLOW BOLT,3/8" X 1-1/4",NC,GR5
	28747	-	CUTTERSHAFT ASSY,STANDARD (22, 23, 24, 25 & 26)
	28748	-	CUTTERSHAFT ASSY,SMOOTH (22, 23, 24, 25 & 37)
22	28643B	1	CUTTERSHAFT,75"
23	33713	80	FLAIL KNIVES (STANDARD CUT)
24	TF1020	40	KNIFE MTG CLEVIS,FLAIL
25	34011	40	CAPSCREW,7/16" X 3-7/16",NC,GR8
26	21677	40	NYLOCK NUT,7/16",NC
	06200639	-	STRING GUARD KIT, SD (ITEMS 27,29,30)
27	33863	2	STRING GUARD,STD
28	28683	2	BEARING,FLANGE,1-15/16",STD,TSF
29	06530217	8	CAPSCREW,1/2" X 2",NC,L9
30	06533006	8	FLATWASHER,1/2",SAE,L9
31	21732	2	CAPSCREW,1/2" X 1-3/4",NC
32	TF1029	1	BAR,FLAP,TSF/TBF,75"
33	TF1016	1	FLAP,DEFLECTOR,TSF,75"
34	21632	22	CAPSCREW,3/8" X 1-1/2",NC
35	22016	49	FLATWASHER,3/8"
36	28184A	40	FLAIL KNIVES (SMOOTH CUT)
37	35339	1	BUSHING
38	35340	1	ROLLER
39	06530226	1	CAPSCREW,3/4" X 8-1/2",NC


FLAIL DRIVE ASSEMBLY



FLAIL DRIVE ASSEMBLY

ITEM	PART NO.	QTY.	DESCRIPTION
1		-	BONNET *REFER TO HEAD PARTS
2	32287	1	MOTOR CHANNEL
3	21700	2	HEX NUT,1/2",NF
4	TF3620A	1	SPRING,TENSIONER
5	27938	1	BUSHING,MACH,1"OD X 1/2"ID X 14GA.
6	40496	1	ROD,THREADED,1/2"NF X 8"
7	PT3611A	1	CLEVIS,6"
8	06504013	1	MOTOR
9	TF3044	1	SHEAVE,8.0"
10	TF3013	1	BUSHING,QD,SK 1-1/4",1/4" KEY
11	TF3040	1	SHEAVE,6.3"
12	28702	2	V-BELT (500)
13	28723	1	BUSHING,QD,SK 1-15/16"
14	32569	1	GUARD,BELT
15	21584	6	CAPSCREW,5/16" X 2",NC
16	21987	6	LOCKWASHER,5/16"
17	06504028	1	KEY (KEY FROM MOTOR)
18	26142A	1	KEY,1/2" X 1/2" X 2"
19	21732	5	CAPSCREW,1/2" X 1-3/4",NC
20	21990	5	LOCKWASHER,1/2"
21	21725	5	HEX NUT,1/2",NC
22	21630	3	CAPSCREW,3/8" X 1",NC
23	22016	2	FLATWASHER,3/8"
24	21988	3	LOCKWASHER,3/8"
25	27580	2	BEARING,DX,1-1/2",GRM
26	28682	1	RETAINING,WASHER,2-1/2" X 5/16"
27	TF4852	2	KIT,FLANGE,#20
28	06500616	1	HOSE,1" X 104" (RETURN FOR STANDARD ROTATION)
30	06500617	1	HOSE,1" X 106" (PRESSURE OF STANDARD ROTATION)
31	6T3204	1	GREASE ZERK,1/4" X 90°
32	6T3211	1	GREASE ZERK,1/8"
33	22085	1	ELBOW,1/8" X 90°
34	TF1032	1	GREASE HOSE

BOOM PIVOT ASSEMBLY




BOOM PIVOT ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1		1	BOOM *REFER TO BOOM ASSEMBLY
2	32316	1	LINKAGE, BOOM TO CYLINDER
3	21677	4	NYLOCK NUT, 7/16",NC
4	32319	2	PIN,LINKAGE
5	21687	3	CAPSCREW, 7/16" X 3" NC
6	21688	1	CAPSCREW, 7/16" X 3-1/4" NC
7	32318	6	BEARING
8	32745	1	LINKAGE,CYLINDER TO TREE
9	6T3207	6	GREASE ZERK, 1/4"
10	32838	6	HEX NUT, 5/8" NC
11	06310181	1	TREE, WILDKAT
12	06770096	1	SLIDE ASSEMBLY
14	32313	2	PIN,TREE
15	06412199	1	CLAMP,TREE, WILDKAT
16	06530208	6	CAPSCREW,5/8" X 1-1/2",NC
17	33764	-	FLATWASHER, 5/8" SAE


SLIDE ASSEMBLY



SLIDE ASSEMBLY


ITEM	PART NO.	QTY.	DESCRIPTION
1		-	MOWER *REFER TO MOWER ASSEMBLY PAGE
2	35336	2	CAP
3	06770096	1	SLIDE ASSEMBLY
4	06501027	1	CYLINDER, 2-1/2" X 30"
5	21632	4	CAPSCREW, 3/8" X 1-1/2" NC
6	21630	4	CAPSCREW, 3/8" X 1" NC
7	21804	2	CAPSCREW, 3/4" X 1-1/4" NF
8	21929	2	CAPSCREW, 1" X 1-1/4" NC
9	21993	2	LOCKWASHER,3/4"
10	21995	2	LOCKWASHER,1"
11	21990	4	LOCKWASHER,1/4"
12	33271	2	ADAPTER,1/2"MOR X 3/8"MJ
13	35109	1	HOSE,1/4" X 126" (ROTARY MOWERS)
	06500449	1	HOSE,1/4" X 53" (FLAIL MOWERS)
14	06497006	1	BUMPER,RSS
15	06500480	1	HOSE,1/4" X 107" (ROTARY MOWERS)
	06500449	1	HOSE,1/4" X 53" (FLAIL MOWERS)
16	21729	4	CAPSCREW,1/2" X 1"

HOSE RING ASSEMBLY




ITEM	PART NO.	QTY.	DESCRIPTION
1		-	TREE *REFER TO BOOM PIVOT ASSY PAGE
2	21631	1	CAPSCREW,3/8" X 1-1/4",NC
3	22016	2	FLATWASHER,3/8"
4	06460043	1	ANGLE,MOUNT
5	21627	1	NYLOCK NUT,3/8",NC
6	6310117	1	RING,HOSE
7	06530003	1	CAPSCREW,SHOULDER,SKT HD
	06505021	1	COVER,HOSES (BOOM TO HOSE GUIDE) *NOT SHOWN
	06505020	1	COVER, HOSES (HOSE GUIDE TO DECK) *NOT SHOWN


2-1/2IN X 30IN CYLINDER BREAKDOWN




ITEM	PART NO.	QTY.	DESCRIPTION
	06501027	-	CYLINDER,WELDED,2-1/2" X 30"
1	06501615	1	PISTON ROD ASSY
2	06501616	1	BUTT & TUBE ASSY
3	06501617	1	PISTON
4	06501618	1	GLAND
5	06501598	1	PORT PLUG
6-15	06501619	1	SEAL KIT

3IN X 15IN CYLINDER BREAKDOWN








BUTT END VIEW

ROD END VIEW

l	ITEM	PART NO.	QTY.	DESCRIPTION
l		06501026	-	CYLINDER,WELDED,3" X 15"
l	1	06501608	1	PISTON ROD ASSY
l	2	06501609	1	BUTT & TUBE ASSY
l	3	06501610	1	PISTON
l	4	06501563	1	GLAND
l	5	6T0179	1	LOCK NUT,1-1/4"-12 UNF (TORQUE TO 315 FT.LB.)
l	6	06501598	2	PORT PLUG (NOT SHOWN)
l	7	06501611	4	BUSHING
l	8	06501612	1	SPACER,ROD END
l	9	06501613	1	SPACER,BUTT END
	10-17	06501614	1	SEAL KIT
١				


4IN X 14IN CYLINDER BREAKDOWN



WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.

	ITEM	PART NO.	QTY.	DESCRIPTION
		06501028	1	HYDRAULIC CYLINDER COMPLETE
	1	06501623	1	ROD
	2	06501624	1	TUBE WELDMENT
	3	06501558	1	PISTON
	4	06501607	1	CYLINDER HEAD
	5	6T0172	1	CLEVIS
		06501560	1	SEAL REPAIR KIT (ITEMS 6 THROUGH 12)
l				


4IN X 15IN CYLINDER BREAKDOWN




WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.

	ITEM	PART NO.	QTY.	DESCRIPTION
l		32365	-	CYLINDER,WELDED,4" X 15"
l	1	06501604	1	PISTON ROD ASSY
l	2	06501605	1	BUTT & TUBE ASSY
l	3	06501606	1	PISTON
l	4	06501607	1	GLAND
l	5	06501753	1	LOCK NUT,1-1/4"-12 UNF (TORQUE TO 510 FT.LB.)
l	9	33757	1	SEAL KIT, PACKING (ITEMS 12 THRU 19)
l	10		2	GREASE ZERK
l	12		1	O - RING
l	13		1	CAST IRON PISTON RING
l	14		1	CROWN SEAL
l	15		1	O - RING
l	16		1	O - RING
l	17		1	BACK - UP WASHER
l	18		1	U - CUP
l	19		1	WIPER
	20	34335	2	SPHERICAL BEARING (NOT SHOWN)
١				

NOTES 1



5 SPOOL ELECTRONIC VALVE




ITEM	PART NO.	QTY.	DESCRIPTION
	06502096	-	VLV,5SP,32PVG,SIDE STOW
1	06502074	1	END PLATE
1S	06505013	1	END PLATE SEAL KIT
2		5	BONNET
2S	06505042	1	BONNET SEAL KIT
2A	42197	1	MAIN BOOM BONNET
2B	42197	1	SECONDARY BOOM BONNET
2C	42197	1	DECK ROLL BONNET
2D	42197	1	BOOM SWIVEL BONNET
2E	42197	1	DECK SHIELD BONNET

5 SPOOL ELECTRONIC VALVE

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
3	34308	1	INLET SECTION
3S	06505013	1	INLET SECTION SEAL KIT
4		5	ELECTRONIC ACCUATOR
4A	06502101	1	MAIN BOOM ELECTRONIC ACCUATOR
4B	06502101	1	SECONDARY BOOM ELECTRONIC ACCUATOR
4C	06502100	1	DECK ROLL ELECTRONIC ACCUATOR
4D	06502101	1	BOOM SWIVEL ELECTRONIC ACCUATOR
4E	06502099	1	DECK SHIELD ELECTRONIC ACCUATOR
5	42202	1	TIE-BOLT KIT
6		5	SECTION
6S	06505013	1	SECTION SEAL KIT
6A	42698	1	MAIN BOOM SECTION
6B	42698	1	SEC BOOM SECTION
6C	06502076	1	DECK ROLL SECTION
6D	42698	1	BOOM SWIVEL SECTION
6E	06502077	1	SHIELD SECTION
7		5	SPOOL
7A	42697	1	MAIN BOOM SPOOL
7B	42697	1	SEC BOOM SPOOL
7C	4242106	1	DECK ROLL SPOOL
7D	06502073	1	BOOM SWIVEL SPOOL
7E	42201	1	DECK SHIELD SPOOL
8		10	ANTI CAV/SHOCK RELIEF
8A1	42650	1	MAIN BOOM A PORT RELIEF
8A2	06502069	1	MAIN BOOM B PORT RELIEF
8B1	42650	1	SEC BOOM A PORT RELIEF
8B2	42295	1	SEC BOOM B PORT RELIEF
8C1	42296	1	DECK ROLL A PORT RELIEF
8C2	42295	1	DECK ROLL B PORT RELIEF
8D1	42295	1	BOOM SWIVEL A PORT RELIEF
8D2	42295	1	BOOM SWIVEL B PORT RELIEF
8E1	06502069	1	DECK SHIELD A PORT RELIEF
8E2	06502069	1	DECK SHIELD B PORT RELIEF
9	33459	1	HANDLE

FRONT PUMP BREAKDOWN




FRONT PUMP BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
	23152	1	PUMP ASSEMBLY,1-3/4",COMPLETE
1	22766	1	SHAFT END COVER
2	22779	1	PORT END COVER
3	22774	1	GEAR HOUSING,1-3/4"
4	22771	1	GEAR SET
5	23824	4	CAPSCREW
6	06504078	2	SCREW,DRIVE
7	22773	4	DOWEL PINS
8	06504077	1	NAMEPLATE
9	22770	2	THRUST PLATE
10	22767	1	PLUG
11	06504075	2	SEAL,BK-UP
12	06504074	2	SEAL,CHAN
13	22765	1	SEAL,LIP
14	06504076	2	SEAL,SQ-R
15	02961917	4	WASHER
	24150	1	SEAL KIT (INCLUDES 11, 12, 13 AND 14)

ROTARY MOTOR BREAKDOWN




ROTARY MOTOR BREAKDOWN

Continued...

06504011 - MOTOR ASSEMBLY,TRB60 1 22790 1 END,COVER 2 06504088 1 HOUSING, PEC 3 06504062 1 HOUSING, GEAR,TRB60 4 06504090 1 SET, GEAR SHAFT 5 06504104 4 CAP SCREW,TRB60 6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER 06504103 1 SEAL KIT	ITEM	PART NO.	QTY.	DESCRIPTION
2 06504088 1 HOUSING, PEC 3 06504062 1 HOUSING, GEAR, TRB60 4 06504090 1 SET, GEAR SHAFT 5 06504104 4 CAP SCREW, TRB60 6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102		06504011	-	MOTOR ASSEMBLY,TRB60
3 06504062 1 HOUSING, GEAR, TRB60 4 06504090 1 SET, GEAR SHAFT 5 06504104 4 CAP SCREW, TRB60 6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	1	22790	1	END,COVER
4 06504090 1 SET, GEAR SHAFT 5 06504104 4 CAP SCREW, TRB60 6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	2	06504088	1	HOUSING, PEC
5 06504104 4 CAP SCREW,TRB60 6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	3	06504062	1	HOUSING, GEAR, TRB60
6 06504078 2 SCREW, DRIVE 7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	4	06504090	1	SET, GEAR SHAFT
7 06504092 1 KEY 8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	5	06504104	4	CAP SCREW,TRB60
8 06504093 4 PIN, DOWEL 9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	6	06504078	2	SCREW, DRIVE
9 06504094 1 NAME PLATE 10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 ORING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	7	06504092	1	KEY
10 06504095 2 THRPL 11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	8	06504093	4	PIN, DOWEL
11 2961940 1 PLUG, ODT 12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	9	06504094	1	NAME PLATE
12 2962200 1 RING, SNAP 13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	10	06504095	2	THRPL
13 06504096 1 O RING 14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	11	2961940	1	PLUG, ODT
14 6T5101 1 SEAL, LIP 15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	12	2962200	1	RING, SNAP
15 06504097 1 SEAL, LIP 16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	13	06504096	1	O RING
16 22797 2 SEAL, SQ-R 17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	14	6T5101	1	SEAL, LIP
17 06504098 4 SEAL, SIDE CHAN 18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	15	06504097	1	SEAL, LIP
18 06504099 4 SEAL, END CHAN 19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	16	22797	2	SEAL, SQ-R
19 06504100 2 SEAL, BK-UP 20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	17	06504098	4	SEAL, SIDE CHAN
20 06504101 1 RTNR, SEAL 21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	18	06504099	4	SEAL, END CHAN
21 6T5809 2 CHECK ASS'Y 22 06504102 4 WASHER	19	06504100	2	SEAL, BK-UP
22 06504102 4 WASHER	20	06504101	1	RTNR, SEAL
	21	6T5809	2	CHECK ASS'Y
06504103 1 SEAL KIT	22	06504102	4	WASHER
		06504103	1	SEAL KIT

FLAIL MOTOR BREAKDOWN




FLAIL MOTOR BREAKDOWN

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
	06504132	1	MOTOR ASSEMBLY 350 - TBF50, TBF63
1	06504141	1	SHAFT END COVER
2	06504040	1	PORT END COVER
3	06504041	1	GEAR HOUSING
4	06504117	1	MATCHED GEAR SET
5	TF4402	1	BALL BEARING
6	06504043	4	CAP SCREW
7	06504044	2	SET SCREW
8	06504028	1	KEY
9	06504045	4	DOWEL PIN
10		1	NAMEPLATE
11	0763759	1	THRUSTPLATE
12	02961940	1	PLUG, ODT (0.25)
13	TF4401	1	SNAP RING
14	06504142	1	LIP SEAL
15	TF4410	2	GASKET SEAL
16	06504046	4	SIDE SEAL
17	06504047	4	END SEAL
18	TF4407	2	BACK-UP SEAL
19	06504122	1	SEAL RETAINER
20	6T5809	2	CHECK ASSEMBLY
21	02961917	4	WASHER
22	06504140	1	SHAFT
23	06504139	1	BREATHER
24	06504121	1	SPACER, BRG
25	06504119	1	SNAP RING
	06504022	1	SEAL KIT

COOLER ASSEMBLY - OPTION




COOLER ASSEMBLY - OPTION

Continued...


ITEM	PART NO.	QTY.	DESCRIPTION
1	21530	10	CAPSCREW,1/4 X1 NC
2	21986	10	LOCKWASHER,1/4
3	22014	10	FLATWASHER,1/4
4	35176	10	1/4 U-NUT
5	06370015	1	SCREEN,COOLER,FRNT
6	06380006	1	MNT,COOLER,BUMPER TANK,RH
7	06380007	1	MNT,COOLER,BUMPER TANK,LH
8	06510026	1	COOLER,FRONT MNT
	06510029	1	FAN ASSY, ONLY
9	21629	4	CAPSCREW,3/8 X 3/4 NC
10	21988	4	LOCKWASHER,3/8
11	22016	4	FLATWASHER,3/8
12	34117	2	ELBOW.1MOR X 1MJ90.FORGED

RESERVOIR TANK FILTER ASSEMBLY




ITEM	PART NO.	QTY.	DESCRIPTION
	06505044	-	FILTER ASSY SAE 10 MICRON
1	28583	4	CAPSCREW,8MM X 25MM(1.25 PITCH)
2	06505045	1	COVER
3	06505046	1	SEAL KIT
4	06505047	1	SPRING
5	06505048	1	BYPASS
6	35259	1	FILTER,10 MIC,RETURN LINE
7	06505049	1	CAN/BODY

PUMP AND GRILL GUARD OPTIONS



ITEM	PART NO.	QTY.	DESCRIPTION
1	32430	1	UNIVERSAL PUMP GUARD
2	32737	1	UNIVERSAL GRILL GUARD
3	21833	4	CAPSCREW,3/4" X 2-1/4",NC
4	22021	2	FLATWASHER,3/4"
5	21993	4	LOCKWASHER,3/4"
6	21825	4	HEX NUT,3/4",NC

MANUAL LIFT VALVE SWITCH BOX




ITEM	PART NO.	QTY.	DESCRIPTION
1	06514013	1	SWBX,ALUM,BLK,06510102
2	35226	1	SWITCH,MOWER,COLEHERSEE
3	33811	1	SWITCH,MASTER/DECK FLOAT
4	6T3923	1	INDICTATOR LIGHT, ON, RED
5	06514014	1	BREAKER,10A,SWBX
6	34540	1	STRAIN RELIEF,3/4,BLACK,NYLON
7	06550018	1	DECAL,SWTCHBX,TM/TSF,CG
8	35227	1	RELAY,DP,DT,12V,LY2F,35226

MANUAL LIFT VALVE SWITCH BOX SCHEMATIC

06510102 SCHEMATIC COMMON GROUND SWITCH BOX SIDE MOWER NOTE: **ADD METRIPAK 150** FEMALE PLUG (MALE PINS) W/JUMPER WIRES SW1 PUSH - PULL R 8" BRAKE VALVE 50" BATTERY GROUND 118 BATT GROUND 60* SW2 MASTER DWN 104 Θ^{\perp} BREAKER IGNITION 12V (RED WRE 14AWG) 9 70 NEUTRAL SWITCH (GREEN WIRE 16AWG) 0 NEUTRAL SWITCH


SEE DRAWING # 06515000 FOR A FULL DESCRIPTION OF ALL CONNECTORS

ELECTRONIC LIFT VALVE SWITCH BOX




ITEM	PART NO.	QTY.	DESCRIPTION
1	06510196	1	SWBX,ASSY
2	33811	2	SWITCH,MASTER/DECK FLOAT
3	33813	1	SWITCH,SFTY SHIELD
4	34532	1	SWITCH,TRVL LCK
5	34540	1	STRAIN RELIEF,3/4",BLACK,NYLON
6	6T3923	1	INDICTATOR LIGHT, ON, RED
7	06514006	1	BREAKER,15A,SWBX
8	06550044	1	DECAL,SWBX,06510047
9	35226	1	SWITCH,MOWER,COLEHERSEE
10	35227	1	RELAY,DP,DT,12V,LY2F,35226

ELECTRONIC LIFT VALVE SCHEMATIC




SOLENOID SWITCH BOX AND WIRING




ITEM	PART NO.	QTY.	DESCRIPTION
1		-	SWITCH BOX
2	RE37651	1	PLUG,AUX PWR
3	24204	1	FUSE HOLDER, IN-LINE (OPTION)
4	6T3965	1	FUSE,3AMP (OPTION)
5	6T3934	1	TEMPERATURE GAUGE (OPTION)
6	6T3931	1	TEMPERATURE SENSOR (OPTION)
COMMON	I RSS		

BRAKE VALVE ASSEMBLY



ITEM	PART NO.	QTY.	DESCRIPTION	
	06510083	1	BRAKE VALVE, ASSY	
1	34092	1	BRAKE VALVE, BLANK	
2	34094	2	LOGIC ELEMENT	
3	34095	1	RELIEF VALVE, 3000 PSI	
4	06510095	1	METRI PAK COIL	
5	34093	1	CARTRIDGE, 2 POSITION, 3 WAY (WITH NUT & WASHER)	
6	34091	1	RELIEF VALVE, 2600 PSI	
	34096	2	RELIEF SEAL KIT	
	34097	1	SOLENOID SEAL KIT	
	34098	2	ELEMENT SEAL KIT	
COMMON RSS				

BRAKE VALVE HYDRAULIC SCHEMATIC




BRAKE VALVE TROUBLESHOOTING

FAILURE MODE:	CHECK STEPS
 MOWER WILL NOT START - system pressure is low (engine not lugging). 	1 thru 6
 MOWER WILL NOT START - system pressure is high (engine lugging). "MR" port will be high pressure. 	7
- MOWER WILL NOT ROTATE AT FULL SPEED - limited power.	3 thru 5
- MOWER BLADE WILL NOT STOP - blade will not stop in proper time.	7 thru 9


CORRECTIVE STEPS:

- 1. Check for voltage at solenoid (item 6), voltage must be between 10.2 volts and 13.8 volts.
- 2. Remove, inspect solenoid and cartridge (items 4, 6) for wear or contamination.
- 3. Remove, inspect logic elements near "P" port (item 3) for wear or contamination.
- 4. Remove, inspect 3000 psi relief valve (item 2) for wear or contamination.
- 5. Remove and inspect orifices near "P" port for contamination.
- 6. Remove "P" port hose and fitting, visually inspect for contamination, check ball for movement.
- 7. Remove and inspect orifices near "MR" port for contamination.
- 8. Remove, inspect 2600 psi relief valve (item 5) for wear of contamination.
- 9. Remove, inspect logic element near "MR" port (item 3) for wear or contamination.

ELECTRICAL TROUBLESHOOTING GUIDE



HYDRAULIC TROUBLESHOOTING GUIDE



TROUBLESHOOTING

JOYSTICK TROUBLESHOOTING

Boom operation not responding to joystick movement.

Isolate hydraulic vs. electronic symptom.

Turn off electronic master switch (preventing electronic actuator on valve from attempting to hold spool in neutral position). With tractor engine running, operate the valve section with the manual handle. If function operates normally, continue with electronic inspection. If function does not operate normally, continue with hydraulic inspection.

Electronic inspection.

Connect a voltmeter to the cable connector of the valve section that is not operating. This will allow you to measure supply and signal voltage when the joystick is operated.

Main, Secondary, and Swivel Valves – signal voltage should be 50% of supply voltage with joystick in Neutral position, up to 75% of supply voltage in B direction, down to 25% of supply voltage in A direction. Signal voltage should change smoothly with lever movement.

Pin #1 – Signal Voltage, Pin #4 – Power Voltage, Pin #3 – Ground

Deck Roll Valve or Float Valve – signal voltage should be 50% of supply voltage with joystick in Neutral position, up to 65% of supply voltage in B direction, down to 35% of supply voltage in A direction. Signal voltage should change smoothly with lever movement. Signal voltage should be approximately 75% of supply voltage when float switch is operated.

Pin #1 – Signal Voltage, Pin #4 – Power Voltage, Pin #3 – Ground

Shield Valve or On/Off Valve – Voltage on pin #1 should be equal to supply voltage when switch is operated in A direction. Voltage on pin #4 should be equal to supply voltage when switch is operated in B direction.

Pin #1 - Signal Voltage (Shield Open), Pin #4 - Signal Voltage (Shield Close), Pin #3 - Ground

If none of the valve will operate with electrical signal, verify that there is oil pressure at the valve inlet. Electrical Valves must have pilot supply oil to move the spools.

Possible electronic problems.

Open circuit (broken wire, bad connection or loose connection in switchbox). Shorted to positive, ground, or other. Incorrect voltage signal from joystick.

Continued on next sheet

TROUBLESHOOTING - CONTINUED

Hydraulic inspection.

Install 3 pressure gauges, on the valve inlet (use M port, or tee into hose supplying oil from the pump to the inlet), on the workport that is not operating, and on the LS port.

With the spools in Neutral

Gear pump – P should be approximately 200 psi, LS = 0, workport – pressure on cylinder or function.

LS pump – P should equal pump standby pressure, LS = 0, workport – pressure on cylinder or function.

Pressure Comp pump – P should equal pump standby pressure, LS = 0, workport – pressure on cylinder or function.

Gear pump – P should be approximately 200 psi higher than LS, LS should equal workport, workport – pressure on cylinder or function.

LS pump – P should be LS + standby, LS should equal workport, workport – pressure on cylinder or function.

Pressure Comp pump – P should equal pump standby pressure, LS should equal workport, workport – pressure on cylinder or function.

Operate one spool, measure pressures with function at end of travel or stop

Gear pump – P should equal valve relief setting or workport shock valve setting. LS should equal workport. Workport should equal relief setting or workport shock valve setting.

LS pump – P should equal valve relief setting, pump max pressure setting, or workport shock valve setting. LS should equal workport. Workport should equal relief setting, pump max pressure setting, or workport shock valve setting.

Pressure Comp pump – P should equal pump standby pressure, LS should equal workport. Workport should equal pump standby pressure or workport shock valve setting.

Operate more than one spool.

Gear pump – P should approximately 200 psi higher than LS. LS should equal highest workport pressure. Workport – pressure on cylinder or function. LS pump – P should be LS + standby pressure. LS should equal highest workport pressure. Workport – pressure on cylinder or function. Pressure Comp pump. P should equal pump standby pressure. LS should equal highest workport pressure. Workport – pressure on cylinder or function.

Possible hydraulic problems.


Cylinder leak.

LS signal leaking to tank before reaching pump LS port.

Hydraulic system or pump not supplying flow to valve.

FIRE SUPPRESSION SYSTEM
FIRE SUPPRESSION SYSTEM SECTION
COMMON RSS

FIRE SUPPRESSION 3-POINT MOUNT




FIRE SUPPRESSION 3-POINT MOUNT

Continued...

	ITEM	PART NO.	QTY.	DESCRIPTION
	1	06370137	1	MOUNT,3PNT,FIRE SYS
	2	06503108	1	FITTING,1/2"BARB X 1/2"MP
	3	35091	6	CLAMP,HOSE,#6
	4	06520469	5	HOSE,1/2",BULK (FEET)
	5	06503168	2	SWIVEL,1/2"STR,POLY
	6	06520359	1	PUMP,LARGE
	7	35176	4	U-NUT,1/4"
	8	06520367	2	ELBOW,1/2"BARB X 1/2"MP,POLY
	9	27329	1	U-BOLT,1/4"
	10	06520361	1	FILTER
		06520351	1	ELEMENT, FILTER
	11	06520349	1	FITTING,BARB,HOSE
	12	06503169	1	REDUCER,BUSHING (100 & 150 GALLON TANKS ONLY)
	13	06520346	1	FITTING,BULKHEAD (50 GALLON TANKS ONLY)
	14	21632	4	CAPSCREW,3/8" X 1-1/2",NC
	15	21988	4	LOCKWASHER,3/8"
	16	06520360	1	HOSE REEL
	17	22016	4	FLATWASHER,3/8"
	18	21627	4	NYLOCK NUT,3/8",NC
	19	21529	2	CAPSCREW,1/4" X 3/4",NC
	20	06510258	1	CLAMP,3/4"
	21	22014	1	FLATWASHER,1/4"
	22	21986	1	LOCKWASHER,1/4"
	23	21525	2	HEX NUT,1/4",NC
	24	06370121	1	HOLSTER
	25	06430090	1	SLEEVE
	26	06520366	1	GUN,FIRE SYS
	27	6T3222	1	DECAL
	28	21527	1	NYLOCK NUT,1/4",NC
	29	06510257	1	CLAMP,3/8"
	30	28055	5	WIRE,BLACK,14GA (FEET)
	31	24200	5	WIRE,RED,14GA (FEET)
	32	22802	5	WIRE WRAP (FEET)
	33	PT3905A	1	SWITCH
	34	06510256	4	CABLE,14GA,4WIRE (FEET)
	35	06510255	1	PLUG,7PIN,TRCTR
1				

FIRE SUPPRESSION FRONT MOUNT




FIRE SUPPRESSION FRONT MOUNT

Continued...


1 06520342 1 TANK,50 GALLON 2 06370204 1 MNT,TANK,FRNT,50 GALLON 3 35176 4 U-NUT,1/4,3/4 TO CENTER 4 35091 6 CLAMP,HOSE,#6 5 06503168 2 SWIVEL,1/2 STR,POLY 6 06520469 8 HOSE,1/2,SPRAYER 7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET) 18
3 35176 4 U-NUT,1/4,3/4 TO CENTER 4 35091 6 CLAMP,HOSE,#6 5 06503168 2 SWIVEL,1/2 STR,POLY 6 06520469 8 HOSE,1/2,SPRAYER 7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
4 35091 6 CLAMP,HOSE,#6 5 06503168 2 SWIVEL,1/2 STR,POLY 6 06520469 8 HOSE,1/2,SPRAYER 7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
5 06503168 2 SWIVEL,1/2 STR,POLY 6 06520469 8 HOSE,1/2,SPRAYER 7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
6 06520469 8 HOSE,1/2,SPRAYER 7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
7 06520359 1 PUMP,FIRE KIT 8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
8 06503108 1 FITTING,1/2"BARB X 1/2"MP 9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
9 06520367 2 ELBOW,1/2MPX1/2BARB,POLY 10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
10 27329 1 U-BOLT,1/4X2X1 11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
11 06520361 1 FILTER,FIRE KIT,RAILKUT 06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
06520351 1 STRAINER,40 MESH 12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
12 06520349 1 FITTING,BARB,HOSE,WETCUT 13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
13 06520346 1 FITTING,BULKHEAD 14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
14 21627 8 NYLOCK NUT,3/8 NC 15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
15 22016 16 FLATWASHER,3/8,GR8 16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
16 06510255 1 PLUG,7PIN,TRCTR 17 06510256 22 WIRE,14GA,4WIRE (FEET)
17 06510256 22 WIRE,14GA,4WIRE (FEET)
18 21631 8 CAPSCREW,3/8X1 1/4, NC,GR8
19 06370207 1 MNT,FIRE SUPPRESSION
20 21527 3 NYLOCK NUT,1/4 NC
21 06510257 2 CLAMP,3/8X1/4,INS
22 21529 2 CAPSCREW,1/4 X 3/4 NC
23 6T3222 1 DECAL,CONTROL,ON-OFF SWITCH
24 PT3905A 1 SWITCH,MOWER
25 06520360 1 HOSE REEL,FIRE KIT,RAILKUT
26 06520366 1 GUN,FIRE KIT,RAILKUT
27 06430090 1 SLEEVE,GUN,FIRE SYS
28 06370121 1 HOLSTER,FIRESYS,RAILKUT






WET	сит
	WETCUT SECTION
COMMON RSS	

WETCUT 50 GALLON TANK - 3PNT MOUNT




ITEM	PART NO.	QTY.	DESCRIPTION
1	06370128	1	MNT,3PNT,UNI
2	06370136	1	MNT,TANK,50GAL,WETCUT
4	06520342	1	TANK,50GA.,WETCUT
7	RD1032	3	PIN,LYNCH,1/4" X 2"
8	TB1036	1	PIN,SEC BOOM SWIV,1" X 4-11/16"
9	06520343	4	ANCHOR,STRAP,WETCUT
10	06520344	4	BOLT,STRAP,TANK,WETCUT
11	06520345	2	STRAP,TANK,WETCUT

WETCUT 100 OR 150 GALLON TANK - 3PNT MOUNT



ITEM	PART NO.	QTY.	DESCRIPTION
1	06370128	1	MNT,3PNT,UNI
2	06370138	1	MNT,TANK,100GAL,WETCUT
	06370139	-	MNT,TANK,150GAL,WETCUT
4	06520372	1	TANK,100GA.,WETCUT
	06520373	-	TANK,150GA.,WETCUT
5	21527	2	HEX NUT,NYLOCK,1/4",NC
6	21530	2	CAPSCREW,1/4" X 1",NC
7	RD1032	3	PIN,LYNCH 1/4" X 2"
8	TB1036	1	PIN,SEC BOOM SWIV,1" X 4-11/16"
9	06520345	2	STRAP,TANK,WETCUT
10	06520344	4	BOLT,STRAP,TANK,WETCUT
11	06520343	4	ANCHOR,STRAP,WETCUT

WETCUT 3PNT PLUMBING - 50IN MOWERS




WETCUT 3PNT PLUMBING - 50IN MOWERS

Continued...

1 06370128 1 MNT,3PNT,UNI 2 06520336 1 CNTRLR,SENSOR,06520333 3 06520341 1 PUMP,WETCUT 4 06520346 1 FITTING,BULKHEAD,WETCUT (50 GALLON TANKS ONLY) 5 06520347 1 FITTING,ELBOW,WETCUT 6 06520348 1 VLV,BALL,WETCUT 7 06520349 4 FITTING,BARB,HOSE,WETCUT
3 06520341 1 PUMP,WETCUT 4 06520346 1 FITTING,BULKHEAD,WETCUT (50 GALLON TANKS ONLY) 5 06520347 1 FITTING,ELBOW,WETCUT 6 06520348 1 VLV,BALL,WETCUT
4 06520346 1 FITTING,BULKHEAD,WETCUT (50 GALLON TANKS ONLY) 5 06520347 1 FITTING,ELBOW,WETCUT 6 06520348 1 VLV,BALL,WETCUT
5 06520347 1 FITTING,ELBOW,WETCUT 6 06520348 1 VLV,BALL,WETCUT
6 06520348 1 VLV,BALL,WETCUT
7 06520349 4 FITTING BARR HOSE WETCHT
7 00320347 4 FITTING,DARD,HOSE,WETCOT
8 06503173 4 FITTING,1/2MP X 3/8"BARB
9 06520353 1 FITTING,TEE,WETCUT
10 06520367 1 ELBOW,1/2" X 1/2"BARB,POLY
11 06520361 1 FILTER,FIRE KIT,RAILKUT
12 06520400 2 QUIK CPLR,MALE,1/2",WETCUT
13 06520401 2 QUIK CPLR,FEM,1/2",WETCUT
14 27329 2 U-BOLT,1/4" X 1" X 2"
15 35176 4 U-NUT,1/4",3/4" TO CENTER
16 35091 13 CLAMP, HOSE #6
17 - 20 06520469 5 1/2" HOSE (FEET)
21 - 23 06520316 - 3/8" HOSE (INCLUDED WITH SPRAYER)
24 06510051 4 SEAL,16-18GA,METPAK
25 06510052 1 CONN.,BODY,MALE,METRIPACK 150
26 06510053 1 CONN.,BODY,FEM,METRIPACK 150
27 06510054 2 TERMINAL,MALE,16/18GA.METPAK
28 06510055 2 TERMINAL,FEM,16/18GA.METPAK
29 06510056 2 TPA
30 06520337 1 INCLUDED WITH CONTROLLER
31 06401133 1 SPACER,Ø.31" X 1.75" X .38"
32 06503165 1 ELBOW,1/2"MP X 3/8"BARB
33 06520354 1 BUSHING,REDUCER,WETCUT
34 06503169 1 BUSHING,1"MP X 1/2"FP (100 & 150 GALLON TANKS ONLY)
35 06503176 2 FITTING,BARB,3/8"MP X 1/2"BARB

WETCUT 3PNT PLUMBING - LARGE MOWERS




WETCUT 3PNT PLUMBING - LARGE MOWERS

Continued...

	ITEM	PART NO.	QTY.	DESCRIPTION
	1	06370128	1	MNT,3PNT,UNI
	2	35176	4	U-NUT,1/4,3/4 TO CENTER
	3	06520336	1	CNTRLR,SENSOR,06520333
	4	06520354	1	BUSHING,REDUCER,WETCUT
	5	27329	2	U-BOLT,1/4" X 1" X 2"
	6	06520353	1	FITTING,TEE,WETCUT
	7	06520349	4	FITTING,BARB,HOSE,WETCUT
	8	35091	13	CLAMP, HOSE #6
	9	06520469	5	1/2" HOSE (FEET)
	10	06503168	2	SWIVEL,1/2" STR
	11	06520359	1	PUMP,LARGE
	12	06520361	1	FILTER,FIRE KIT,RAILKUT
		06520351	1	STRAINER,40MESH
	13	06520367	1	ELBOW,1/2X1/2BARB,POLY
	14	06401133	1	SPACER,Ø.31X1.75X.38
	15	06520348	1	VLV,BALL,WETCUT
	16	06520347	1	FITTING,ELBOW,WETCUT
	17	06503169	1	BUSHING,1MPX1/2FP (100 & 150 GALLON TANKS ONLY)
	18	06520346	1	${\tt FITTING,BULKHEAD,WETCUT}~(50~{\tt GALLON}~{\tt TANKS}~{\tt ONLY})$
	19	06503173	4	FITTING,BARB,1/2X3/8,WETCUT
	20	06520401	2	QUIK CPLR,FEM,1/2,WETCUT
	21	06520400	2	QUIK CPLR,MALE,1/2,WETCUT
	22	06520316	-	3/8" HOSE (INCLUDED WITH SPRAYER)
	23	06503165	1	ELBOW,1/2X3/8BARB,POLY
	24	06510052	1	CONN.,BODY,MALE,METRIPACK 150
	25	06510056	2	TPA
	26	06510054	2	TERMINAL,MALE,16/18GA.METPAK
	27	06510051	4	SEAL,16-18GA,METPAK
	28	06510055	2	TERMINAL,FEM,16/18GA.METPAK
	29	06510053	1	CONN.,BODY,FEM,METRIPACK 150
Ĺ				

WETCUT FRONT PLUMBING - 50IN MOWERS




WETCUT FRONT PLUMBING - 50IN MOWERS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06370204	1	MNT,FRONT,UNI
2	06520336	1	CNTRLR,SENSOR,06520333
3	06520341	1	PUMP,WETCUT
4	06520346	1	FITTING,BULKHEAD,WETCUT
5	06520347	1	FITTING,ELBOW,WETCUT
6	06520348	1	VLV,BALL,WETCUT
7	06520349	4	FITTING,BARB,HOSE,WETCUT
8	06503173	4	FITTING,1/2"MP X 3/8"BARB
9	06520353	1	FITTING,TEE,WETCUT
10	06520367	1	ELBOW,1/2"MP X 1/2"BARB,POLY
11	06520361	1	FILTER,FIRE KIT,RAILKUT
	06520351	1	STRAINER,40MESH
12	06520400	2	QUIK CPLR,MALE,1/2",WETCUT
13	06520401	2	QUIK CPLR,FEM,1/2",WETCUT
14	27329	2	U-BOLT,1/4" X 1" X 2"
15	35176	4	U-NUT,1/4",3/4" TO CENTER
16	35091	13	CLAMP,HOSE #6
17 - 20	06520469	5	1/2" HOSE (FEET)
21 - 23	06520316	-	3/8" HOSE (INCLUDED WITH SPRAYER)
24	06510051	4	SEAL,16-18GA,METPAK
25	06510052	1	CONN.,BODY,MALE,METRIPACK 150
26	06510053	1	CONN.,BODY,FEM,METRIPACK 150
27	06510054	2	TERMINAL,MALE,16/18GA.METPAK
28	06510055	2	TERMINAL,FEM,16/18GA.METPAK
29	06510056	2	TPA
30	06520337	1	INCLUDED WITH CONTROLLER
31	06401133	1	SPACER,Ø.31" X 1.75" X .38"
32	06503165	1	ELBOW,1/2"MP X 3/8"BARB,POLY
33	06520354	1	BUSHING,REDUCER,WETCUT
34	06503176	2	FITTING,3/8"MP X 1/2"BARB

COMMON RSS

WETCUT FRONT PLUMBING - LARGE MOWERS




WETCUT FRONT PLUMBING - LARGE MOWERS

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06370204	1	MNT,FRONT,UNIV
2	35176	4	U-NUT,1/4,3/4 TO CENTER
3	06520336	1	CNTRLR,SENSOR,06520333
4	06520354	1	BUSHING,REDUCER,WETCUT
5	27329	2	U-BOLT,1/4" X 1" X 2"
6	06520353	1	FITTING,TEE,WETCUT
7	06520349	4	FITTING,BARB,HOSE,WETCUT
8	35091	13	CLAMP, HOSE #6
9	06520469	5	1/2" HOSE (FEET)
10	06503168	2	SWIVEL,1/2" STR
11	06520359	1	PUMP,LARGE
12	06520361	1	FILTER,FIRE KIT,RAILKUT
	06520351	1	STRAINER,40MESH
13	06520367	1	ELBOW,1/2X1/2BARB,POLY
14	06401133	1	SPACER,Ø.31X1.75X.38
15	06520348	1	VLV,BALL,WETCUT
16	06520347	1	FITTING,ELBOW,WETCUT
17	06520346	1	FITTING,BULKHEAD,WETCUT
18	06503173	4	FITTING,BARB,1/2X3/8,WETCUT
19	06520401	2	QUIK CPLR,FEM,1/2,WETCUT
20	06520400	2	QUIK CPLR,MALE,1/2,WETCUT
21	06520316	-	3/8" HOSE (INCLUDED WITH SPRAYER)
22	06503165	1	ELBOW,1/2X3/8BARB,POLY
23	06510052	1	CONN.,BODY,MALE,METRIPACK 150
24	06510056	2	TPA
25	06510054	2	TERMINAL,MALE,16/18GA.METPAK
26	06510051	4	SEAL,16-18GA,METPAK
27	06510055	2	TERMINAL,FEM,16/18GA.METPAK
28	06510053	1	CONN.,BODY,FEM,METRIPACK 150

WETCUT 50IN SPRAYER HEAD ASSEMBLY




WETCUT 50IN SPRAYER HEAD ASSEMBLY

Continued...

ITEM	PART NO.	QTY.	DESCRIPTION
1	06370105	1	HOOD,SPRAYER
2	06370106	1	HINGE,LH,SPRAYER
3	06370107	1	HINGE,RH,SPRAYER
4	06370108	1	HINGE,CNTR,SPRAYER
5	06410668	1	GUARD,SPRAYER,WETCUT
6	06410753	1	MNT,RH,WET CUT (FLAIL)
	06410942	1	MNT,RH,WET CUT (ROTARY)
7	06410754	1	MNT,LH,WET CUT (FLAIL)
	06410943	1	MNT,LH,WET CUT (ROTARY)
8	06410796	1	GUARD,HOSE,WETCUT
9	06420069	3	PIN,HINGE,WET CUT
10	06497003	1	TUBE,LG,SPRAYER
11	06499012	1	SKIRT,ANTI SPRAY,50
12	06499013	2	SKIRT,ANTI SPRAY,7
13	06520314	2	TUBE,CAP,SPRAYER
14	06520316	15	HOSE,SPRAYER (FEET)
15	06520317	5	NOZZLE,SPRAYER
16	06520319	4	TIP,NOZZLE,SPRAYER
17	06520320	4	FILTER,NOZZLE,SPRAYER
18	06520321	4	NUT,NOZZLE,SPRAYER
19	06520322	49	CHAIN,.18" X 1.31" X 13LINKS
20	06520381	1	ADAPTER,1/4"NPT,WETCUT
21	06520382	1	ELBOW,BARB,3/8" X 1/4"NPT
22	06520383	8	SPACER,.50"O.D. X .252"I.D. X .38",NYLON
23	32550	4	U-BOLT,1/4" X 1" X 1" X 1-3/4"
24	21527	29	HEX NUT,NYLOCK,1/4",NC
25	21528	12	CAPSCREW,1/4" X 1/2",NC
26	21529	13	CAPSCREW,1/4" X 3/4",NC
27	21625	11	HEX NUT,3/8",NC
28	21630	2	CAPSCREW,3/8" X 1",NC
29	21634	7	CAPSCREW,3/8" X 2",NC
30	21632	2	CAPSCREW,3/8" X 1-1/2",NC
31	21986	4	LOCKWASHER,1/4"
32	22014	15	FLATWASHER,1/4"
33	22016	9	FLATWASHER,3/8",GR8
34	34698	6	ROLL PIN, PLAIN, 3/16" X 7/8"
35	35091	1	CLAMP,HOSE #6
36	35176	4	U-NUT,1/4",3/4" TO CENTER
37	06520376	5	CABLE,3/16"
38	06537022	2	U-BOLT,CABLE,3/16"

COMMON RSS

WETCUT 60IN SPRAYER HEAD ASSEMBLY




WETCUT 60IN SPRAYER HEAD ASSEMBLY


Continued...


ITEM	PART NO.	QTY.	DESCRIPTION
1	06370210	1	HOOD,SPRAYER
2	06370106	1	HINGE,LH,SPRAYER
3	06370107	1	HINGE,RH,SPRAYER
4	06370108	1	HINGE,CNTR,SPRAYER
5	06411234	1	GUARD,SPRAYER,WETCUT
6	06410753	1	MNT,RH,WET CUT (FLAIL)
	06410942	1	MNT,RH,WET CUT (ROTARY)
7	06410754	1	MNT,LH,WET CUT (FLAIL)
	06410943	1	MNT,LH,WET CUT (ROTARY)
8	06410796	1	GUARD,HOSE,WETCUT
9	06420069	3	PIN,HINGE,WET CUT
10	06497009	1	TUBE,LG,SPRAYER
11	06499018	1	SKIRT,ANTI SPRAY,60
12	06499013	2	SKIRT,ANTI SPRAY,7
13	06520314	2	TUBE,CAP,SPRAYER
14	06520316	15	HOSE,SPRAYER (FEET)
15	06520317	6	NOZZLE,SPRAYER
16	06520319	5	TIP,NOZZLE,SPRAYER
17	06520320	5	FILTER,NOZZLE,SPRAYER
18	06520321	5	NUT,NOZZLE,SPRAYER
19	06520322	61	CHAIN,.18" X 1.31" X 13LINKS
20	06520381	1	ADAPTER,1/4"NPT,WETCUT
21	06520382	1	ELBOW,BARB,3/8" X 1/4"NPT
22	06520383	10	SPACER,.50"O.D. X .252"I.D. X .38",NYLON
23	32550	5	U-BOLT,1/4" X 1" X 1" X 1-3/4"
24	21527	33	HEX NUT,NYLOCK,1/4",NC
25	21528	15	CAPSCREW,1/4" X 1/2",NC
26	21529	13	CAPSCREW,1/4" X 3/4",NC
27	21625	13	HEX NUT,3/8",NC
28	21630	2	CAPSCREW,3/8" X 1",NC
29	21634	7	CAPSCREW,3/8" X 2",NC
30	21632	4	CAPSCREW,3/8" X 1-1/2",NC
31	21986	4	LOCKWASHER,1/4"
32	22014	33	FLATWASHER,1/4"
33	22016	11	FLATWASHER,3/8",GR8
34	34698	6	ROLL PIN, PLAIN, 3/16" X 7/8"
35	35091	1	CLAMP,HOSE #6
36	35176	4	U-NUT,1/4",3/4" TO CENTER
37	06520376	6	CABLE,3/16" (FEET)
38	06537022	2	U-BOLT,CABLE,3/16"

COMMON RSS

WETCUT CABLES







WARRANTY INFORMATION

Tiger Corporation, 3301 N. Louise, Sioux Falls, South Dakota, warrants to the original Retail Customer, the new Tiger equipment is free of defects in material and workmanship. Any part of equipment that in Tiger's judgement, show evidence of such defects will be repaired or replaced without charge, provided that the failure of part(s) shall have occurred within twelve (12) months from the date of delivery of said equipment to the Retail Customer. Expendable components such as knives, oil, chain sprockets, skid shoes, knife mounting disks and the like are excluded but not limited to this warranty.

The Retail Customer must pay the transportation cost to and from the Tiger Dealer's service shop for warranty service. Warranty service will be performed by the Tiger Dealer from whom the equipment was purchased, during service shop regularly scheduled days and hours of operation.

All Tiger obligation under this warranty shall be terminated if the equipment is modified or altered in ways not approved in writing by Tiger, if repair parts other than genuine Tiger repair parts have been used, or if the equipment has been subject to misuse, neglect, accident, improper maintenance or improper operation.

Tiger Corporation reserves the right to make improvements in design or changes in specification at any time without incurring any obligation to owners of equipment previously sold.

No agent or person has authority to alter, add to or waive the above warranties which are agreed to be in the only warranties, representations or promises, expressed or implied, as to the quality or performance of the products covered and which do not include any implied warranty of merchantability or fitness. In no event will Tiger be liable for incidental or consequential damages or injuries, including, but not limited to, loss of profits, rental or substitute equipment or other commercial loss.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THOSE EXPRESSED HEREIN.

It is the Purchasers obligation to sign the warranty registration form **AFTER** he / she has Read and Understands the Operation and Safety Instructions stated within this manual.

ONE LAST WORD

This manual cannot possibly cover all of the potentially hazardous situations you will encounter. By being familiar with the safety rules, operating and maintenance instructions in this manual you can help prevent accidents. The objective of this manual is to help make you a better operator. Remember, SAFETY IS YOU!



Your safety and the safety of those around you depends on **YOU**. Common sense should play a large role in the operation of this machine.

Since we at Tiger Corporation are constantly striving to improve out products, we reserve the right to change specifications or design at any time.

TO THE OWNER / OPERATOR / DEALER



To keep your implement running efficiently and safely, read your manual thoroughly and follow these directions and the Safety Messages in this manual and on the machine. The table of contents clearly identifies each section where you can easily find the information you need.

The Occupational Safety and Health Act (OSHA 1928.51 subpart C) makes the following minimum requirements for tractor operators.

OWNER REQUIREMENTS:

- 1. Provide a Roll-Over-Protective Structure that meets the requirements of this Standard; and
- 2. Provide Seatbelts that meet the requirements of this Standard and SAE J3C; and
- 3. Ensure that each employee uses such Seatbelt while the tractor is moving; and
- 4. Ensure that each employee tightens the Seatbelt sufficiently to confine the employee to the protected area provided by the ROPS.

OPERATOR REQUIREMENTS:

- 1. Securely fasten seatbelt it the tractor has a ROPS.
- 2. Where possible, avoid operating the tractor near steep ditches, embankments, and holes.
- 3. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.
- 4. Stay off slopes too steep for safe operation.
- 5. Watch where you are going especially at row ends, on roads, and around trees.
- 6. Do Not permit others to ride.
- 7. Operate the tractor smoothly no jerky turns, starts, or stops.
- 8. Hitch only to the draw-bar and hitch points recommended by the tractor manufacturer.
- 9. When the tractor is stopped, set brakes securely and use park lock, if available

