

06022012

# TO THE OWNER / OPERATOR / DEALER

• **BEFORE YOU START!!** Read and understand the complete Warranty Statement found in this manual. Fill out the Warranty Registration form in full and return it within 90 days. Make certain the Serial Number of the machine is recorded on the Warranty Card, and form that you retain.


• **BEFORE YOU START!!** Read and understand the complete Warranty Statement found in this manual. Fill out the Warranty Registration form in full and return it within 90 days. Make certain the Serial Number of the machine is recorded on the Warranty Card, and form that you retain.

**READ AND UNDERSTAND THIS MANUAL! Non-English speaking operators will need to GET THE MANUAL TRANSLATED as needed!**



# DANGER

**FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTIONS CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.**



1. Study and understand Operator's Manuals, Safety Decals, and Instructional Decals for tractor and implement to prevent misuse, abuse, and accidents. Practice before operating in a confined area or near passersby.  
 • Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children

2. Allow no children on or near folding mower or tractor. Allow no riders on tractor or implement. Falling off may cause serious injury or death from being run over by tractor or mower or contact with rotating blades.

3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seat belt securely fastened to prevent injury and possible death from falling off or tractor overturn.  
 • Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, & Ear Plugs are recommended.


4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain area is clear before lowering or folding

5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding mowers. Put Booms securely in Transport Rest.  
 • Folding and Boom Mowers have raised center of gravity. Slow down when turning and on hillsides.

6. Make certain that SMV sign, warning lights, and reflectors are clearly visible. Follow local traffic codes.

7. Never operate with Cutting Head or Folding Section raised if passersby, bystanders, or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Guards or mower structure.

8. Before dismounting, secure implement in transport position or lower to ground.  
 • Put tractor in park or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent crushing by entanglement in rotating parts which could cause injury or death.  
 • Never mount or dismount a moving vehicle. Crushing from rollover may cause serious injury or death.



Warranty Information: Read and understand the complete Warranty Statement found in this manual. Fill out the Warranty Registration form in full and return it within 90 days. Make certain the Serial Number of the machine is recorded on the Warranty Card, and form that you retain.

# FORWARD

This manual contains information about many features of the Tiger mowing and roadside maintenance equipment. Some of these include: Safety precautions, Assembly instructions, Operations, Maintenance and Parts. This manual will also assist you in the proper break-in, daily care, and troubleshooting of your new mower.

We recommend that you read carefully the entire manual before operating the unit. Also, time spent in becoming fully acquainted with its performance features, adjustments, and maintenance schedules will be repaid in a long and satisfactory life of the equipment.

## **Troubleshooting - Please, before you call, help us to help you!**

Please look at the equipment to observe what is happening, then:

- Classify the problem
  - Hydraulic, electrical or mechanical - Read the trouble shooting section
  - Tractor or Truck chassis - Contact vehicle dealer
- If unable to correct the problem yourself, contact your local Tiger Dealer after gathering:
  - Machine model \_\_\_\_\_
  - Serial number \_\_\_\_\_
  - Dealer name \_\_\_\_\_
  - Detailed information about the problem including results of troubleshooting

**Attention Owner / Operator / Dealer:** It is your obligation to read, and understand, the warranty information section located at the back of this manual denoting that the purchaser understands the safety issues relating to this machine and has received and will read a copy of this manual.

If at any time, you have a service problem with your Tiger mower, Contact your local dealer for service and parts needed.

MANUFACTURED BY:

**Tiger Corporation**

3301 N. Louise Ave.

Sioux Falls, SD 57107

1-800-843-6849

1-605-336-7900

[www.tiger-mowers.com](http://www.tiger-mowers.com)

DISTRIBUTED BY:

\_\_\_\_\_

1-\_\_\_\_\_-\_\_\_\_\_-\_\_\_\_\_

1-\_\_\_\_\_-\_\_\_\_\_-\_\_\_\_\_





# TABLE OF CONTENTS

SAFETY SECTION_____	1
ASSEMBLY / MOUNTING SECTION_____	2
OPERATION SECTION_____	3
MAINTENANCE SECTION_____	4
PARTS SECTION_____	5
COMMON PARTS SECTION_____	6
WARRANTY INFORMATION_____	7



1012

**This symbol means:**

## **CAUTION – YOUR SAFETY IS AT RISK!**

When you see this symbol, read and follow the associated instructions carefully or personal injury or damage may result.

Tiger is a registered trademark.





# **SAFETY**

## **SAFETY SECTION**

# SAFETY

## General Safety Instructions and Practices

A safe and careful operator is the best operator. Safety is of primary importance to the manufacturer and should be to the owner / operator. Most accidents can be avoided by being aware of your equipment, your surroundings, and observing certain precautions. The first section of this manual includes a list of Safety Messages that, if followed, will help protect the operator and bystanders from injury or death. Read and understand these Safety Messages before assembling, operating or servicing this mower. This equipment should only be operated by those persons who have read the Manual, who are responsible and trained, and who know how to do so safely and responsibly.



The Safety Alert Symbol combined with a Signal Word, as seen below, is used throughout this manual and on decals which are attached to the equipment. The Safety Alert Symbol means: **“ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!”** The symbol and signal word are intended to warn the owner / operator of impending hazards and the degree of possible injury when operating this equipment.

**Practice all usual and customary safe working precautions and above all -- remember safety is up to YOU! Only YOU can prevent serious injury or death from unsafe practices.**

DANGER!



Indicates an imminently hazardous situation that, if not avoided, WILL result in DEATH OR VERY SERIOUS INJURY.

WARNING!



Indicates an imminently hazardous situation that, if not avoided, COULD result in DEATH OR SERIOUS INJURY.

CAUTION!



Indicates an imminently hazardous situation that, if not avoided, MAY result in MINOR INJURY.

**IMPORTANT!**

Identifies special instructions or procedures that, if not strictly observed, could result in damage to, or destruction of the machine, attachments or the environment.

**NOTE:** *Identifies points of particular interest for more efficient or convenient operation or repair.* (SG-1)

READ, UNDERSTAND, and FOLLOW the following Safety Messages. Serious injury or death may occur unless care is taken to follow the warnings and instructions stated in the Safety Messages. Always use good common sense to avoid hazards. (SG-2)

 **SAFETY INSTRUCTIONS**



# SAFETY

## PELIGRO!



Si no lee Ingles, pida ayuda a alguien que si lo lea para que le traduzca las medidas de seguridad. (SG-3)




**¡ LEA EL INSTRUCTIVO!**

## DANGER!



Never operate the Tractor or Implement until you have read and completely understand this Manual, the Tractor Operator's Manual, and each of the Safety Messages found in the Manual or on the Tractor and Implement. Learn how to stop the tractor engine suddenly in an emergency. Never allow inexperienced or untrained personnel to operate the Tractor and Implement without supervision. Make sure the operator has fully read and understood the manuals prior to operation. (SG-4)



## WARNING!




Always maintain the safety decals in good readable condition. If the decals are missing, damaged, or unreadable, obtain and install replacement decals immediately. (SG-5)

## WARNING!



Make certain that the "Slow Moving Vehicle" (SMV) sign is installed in such a way as to be clearly visible and legible. When transporting the Equipment use the Tractor flashing warning lights and follow all local traffic regulations. (SG-6)



## WARNING!



Operate this Equipment only with a Tractor equipped with an approved roll-over-protective system (ROPS). Always wear seat belts. Serious injury or even death could result from falling off the tractor--particularly during a turnover when the operator could be pinned under the ROPS. (SG-7)



## WARNING!




Do not modify or alter this Implement. Do not permit anyone to modify or alter this Implement, any of its components or any Implement function. (SG-8)

## DANGER!



BEFORE leaving the tractor seat, always engage the brake and/or set the tractor transmission in parking gear, disengage the PTO, stop the engine, remove the key, and wait for all moving parts to stop. Place the tractor shift lever into a low range or parking gear to prevent the tractor from rolling. Never dismount a Tractor that is moving or while the engine is running. Operate the Tractor controls from the tractor seat only. (SG-9)





# SAFETY

## DANGER!



Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in serious injury or death.

(SG-10)



## DANGER!



Never allow children to operate or ride on the Tractor or Implement.

(SG-11)



## WARNING!



Do not mount the Tractor while the tractor is moving. Mount the Tractor only when the Tractor and all moving parts are completely stopped.

12)

(SG-



## DANGER!



Start tractor only when properly seated in the Tractor seat. Starting a tractor in gear can result in injury or death. Read the Tractor operators manual for proper starting instructions.

(SG-13)



## DANGER!



Never work under the Implement, the framework, or any lifted component unless the Implement is securely supported or blocked up to prevent sudden or inadvertent falling which could cause serious injury or even death.

(SG-14)



## DANGER!



Do not operate this Equipment with hydraulic oil leaking. Oil is expensive and its presence could present a hazard. Do not check for leaks with your hand! Use a piece of heavy paper or cardboard. High-pressure oil streams from breaks in the line could penetrate the skin and cause tissue damage including gangrene. If oil does penetrate the skin, have the injury treated immediately by a physician knowledgeable and skilled in this procedure.

(SG-15)




# SAFETY

## WARNING!



The operator and all support personnel should wear hard hats, safety shoes, safety glasses, and proper hearing protection at all times for protection from injury including injury from items thrown by the equipment. (SG-16)



## CAUTION!



### **PROLONGED EXPOSURE TO LOUD NOISE MAY CAUSE PERMANENT HEARING LOSS!**

Tractors with or without an Implement attached can often be noisy enough to cause permanent hearing loss. We recommend that you always wear hearing protection if the noise in the Operator's position exceeds 80db. Noise over 85db over an extended period of time will cause severe hearing loss. Noise over 90db adjacent to the Operator over an extended period of time will cause permanent or total hearing loss. *Note:* Hearing loss from loud noise [from tractors, chain saws, radios, and other such sources close to the ear] is cumulative over a lifetime without hope of natural recovery. (SG-17)



## WARNING!



Transport only at safe speeds. Serious accidents and injuries can result from operating this equipment at unsafe speeds. Understand the Tractor and Implement and how it handles before transporting on streets and highways. Make sure the Tractor steering and brakes are in good condition and operate properly.

**Before transporting the Tractor and Implement, determine the safe transport speeds for you and the equipment. Make sure you abide by the following rules:**

1. Test the tractor at a slow speed and increase the speed slowly. Apply the Brakes smoothly to determine the stopping characteristics of the Tractor and Implement. As you increase the speed of the Tractor the stopping distance increases. Determine the maximum safe transport speed for you and this Equipment.
2. Test the equipment at a slow speed in turns. Increase the speed through the turn only after you determine that it is safe to operate at a higher speed. Use extreme care and reduce your speed when turning sharply to prevent the tractor and implement from turning over. Determine the maximum safe turning speed for you and this equipment before operating on roads or uneven ground.
3. Only transport the Tractor and Implement at the speeds that you have determined are safe and which allow you to properly control the equipment.



**Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes. When operating down a hill or on wet or rain slick roads, the braking distance increases: use extreme care and reduce your speed. When operating in traffic always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy.** (SG-19)

# SAFETY

## WARNING!



Never attempt to lubricate, adjust, or remove material from the Implement while it is in motion or while tractor engine is running. Make sure the tractor engine is off before working on the Implement.

(SG-20)

## WARNING!



Periodically inspect all moving parts for wear and replace when necessary with authorized service parts. Look for loose fasteners, worn or broken parts, and leaky or loose fittings. Make sure all pins are properly secured. Serious injury may occur from not maintaining this machine in good working order. (SG-21)



## WARNING!



Always read carefully and comply fully with the manufacturers instructions when handling oil, solvents, cleansers, and any other chemical agent. (SG-22)



## DANGER!



Never run the tractor engine in a closed building or without adequate ventilation. The exhaust fumes can be hazardous to your health.

(SG-23)

## DANGER!



KEEP AWAY FROM ROTATING ELEMENTS to prevent entanglement and possible serious injury or death.

(SG-24)



## DANGER!



Never allow children to play on or around Tractor or Implement. Children can slip or fall off the Equipment and be injured or killed. Children can cause the Implement to shift or fall crushing themselves or others. (SG-25)

# SAFETY

## DANGER!



**NEVER use drugs or alcohol** immediately before or while operating the Tractor and Implement. Drugs and alcohol will affect an operator's alertness and coordination and therefore affect the operator's ability to operate the equipment safely. Before operating the Tractor or Implement, an operator on prescription or over-the-counter medication must consult a medical professional regarding any side effects of the medication that would hinder their ability to operate the Equipment safely. **NEVER** knowingly allow anyone to operate this equipment when their alertness or coordination is impaired. Serious injury or death to the operator or others could result if the operator is under the influence of drugs or alcohol. (SG-27)



## DANGER!



Operate the Tractor and/or Implement controls only while properly seated in the Tractor seat with the seat belt securely fastened around you. Inadvertent movement of the Tractor or Implement may cause serious injury or death. (SG-29)

## WARNING!



Mow only in conditions where you have clear visibility in daylight or with adequate artificial lighting. Never mow in darkness or foggy conditions where you cannot clearly see at least 100 yards in front and to the sides of the tractor and mower. Make sure that you can clearly see and identify passersby, steep slopes, ditches, drop-offs, overhead obstructions, power lines, debris and foreign objects. If you are unable to clearly see this type of items discontinue mowing. (SGM-1)

## DANGER!




There are obvious and hidden potential hazards in the operation of this Mower. REMEMBER! This machine is often operated in heavy brush and in heavy weeds. The Blades of this Mower can throw objects if shields are not properly installed and maintained. Serious injury or even death may occur unless care is taken to insure the safety of the operator, bystanders, or passersby in the area. Do not operate this machine with anyone in the immediate area. Stop mowing if anyone is within 100 yards of mower. (SGM-2)



## DANGER!



All Safety Shields, Guards and Safety devices including (but not limited to) - the Deflectors, Chain Guards, Steel Guards, Gearbox Shields, PTO integral shields, and Retractable Door Shields should be used and maintained in good working condition. All safety devices should be inspected carefully at least daily for missing or broken components. Missing, broken, or worn items must be replaced at once to reduce the possibility of injury or death from thrown objects, entanglement, or blade contact. (SGM-3)



# SAFETY

## DANGER!



The rotating parts of this machine have been designed and tested for rugged use. However, the blades could fail upon impact with heavy, solid objects such as metal guard rails and concrete structures. Such impact could cause the broken objects to be thrown outward at very high velocities. To reduce the possibility of property damage, serious injury, or even death, never allow the cutting blades to contact such obstacles. (SGM-4)

## WARNING!



Extreme care should be taken when operating near loose objects such as gravel, rocks, wire, and other debris. Inspect the area before mowing. Foreign objects should be removed from the site to prevent machine damage and/or bodily injury or even death. Any objects that cannot be removed must be clearly marked and carefully avoided by the operator. Stop mowing immediately if blades strike a foreign object. Repair all damage and make certain rotor or blade carrier is balanced before resuming mowing. (SGM-5)



## WARNING!



Many varied objects, such as wire, cable, rope, or chains, can become entangled in the operating parts of the mower head. These items could then swing outside the housing at greater velocities than the blades. Such a situation is extremely hazardous and could result in serious injury or even death. Inspect the cutting area for such objects before mowing. Remove any like object from the site. Never allow the cutting blades to contact such items. (SGM-6)

## WARNING!



Mow at the speed that you can safely operate and control the tractor and mower. Safe mowing speed depends on terrain condition and grass type, density, and height of cut. Normal ground speed range is from 0 to 5 mph. Use slow mowing speeds when operating on or near steep slopes, ditches, drop-offs, overhead obstructions, power lines, or when debris and foreign objects are to be avoided. (SGM-7)

## WARNING!



Avoid mowing in reverse direction when possible. Check to make sure there are no persons behind the mower and use extreme care when mowing in reverse. Mow only at a slow ground speed where you can safely operate and control the tractor and mower. Never mow an area that you have not inspected and removed debris or foreign material. (SGM-8)

## WARNING!



Do not put hands or feet under mower decks. Blade Contact can result serious injury or even death. Stay away until all motion has stopped and the decks are securely blocked up. (SGM-9)



## DANGER!



Replace bent or broken blade with new blades. NEVER ATTEMPT TO STRAIGHTEN OR WELD ON BLADES SINCE THIS WILL LIKELY CRACK OR OTHERWISE DAMAGE THE BLADE WITH SUBSEQUENT FAILURE AND POSSIBLE SERIOUS INJURY FROM THROWN BLADES. (SGM-10)



# SAFETY

## WARNING!



Do not mow with two machines in the same area except with Cab tractors with the windows closed. (SGM-11)

## DANGER!



Rotary and Flail Mowers are capable under adverse conditions of throwing objects for great distances (100 yards or more) and causing serious injury or death. Follow safety messages carefully. **STOP MOWING IF PASSERSBY ARE WITHIN 100 YARDS UNLESS:**

- Front and Rear Deflectors are installed and in good, working condition;
- Mower Head is running close to and parallel to the ground without exposed Blades;
- Passersby are outside the existing thrown-object zone;
- All areas have been thoroughly inspected and all foreign material such as rocks, cans, glass, and general debris has been removed.



NOTE: Where there are grass and weeds high enough to hide debris that could be struck by the blades, the area should be: inspected and large debris removed, mowed at an intermediate height, inspected closely with any remaining debris being removed, and mowed again at desired final height. (SBM-1)



## DANGER!



Use extreme caution when raising the Mower head. Stop the Blades from turning when the Mower Head is raised and passersby are within 100 yards. Raising the Mower head exposes the Cutting Blades which creates a potentially serious hazard and can cause serious injury by objects thrown from the Blades or by contact with the Blades. (SBM-2)

## DANGER!



Be particularly careful in transport. The Mower has raised the center of gravity for the tractor and has increased the possibility of overturn. Turn curves or go up slopes only at low speed and using a gradual turning angle. Slow down on rough or uneven surfaces. (SBM-3)



## WARNING!



Never Leave the mower unattended while the head is in the raised position. The mower could fall causing serious injury to anyone who might inadvertently be under the mower. (SBM-4)



## WARNING!



The rotating parts of this machine continue to rotate even after the Tractor has been turned off. The operator should remain in his seat for 60 seconds after the brake has been set, the PTO disengaged, the tractor turned off, and all evidence of rotation has ceased. (SBM-5)

**“Wait a minute...Save a life!”**

# SAFETY




Relieve hydraulic pressure prior to doing any maintenance or repair work on the Implement. Place the Mower Head on the ground or securely supported on blocks or stands, disengage the PTO, and turn off the engine. Push and pull the control Levers or Joystick several times to relieve pressure prior to starting any maintenance or repair work. (SBM-6)

## DANGER!




Always keep a careful lookout and use extreme care when working around overhead obstructions. Never allow the Mower head or boom within 10 feet of any power line. When working close to overhead power lines consult your electric company for a safe code of operation. (SBM-7)



## DANGER!




When transporting Boom Mower on a truck or trailer, the height or width may exceed legal limits when the boom is in the transport position. Contact with side or overhead structures or power lines can cause property damage or serious injury or death. If necessary lower boom to reduce height and/or remove mowing head to reduce width to the legal limits. (SBM-8)



## DANGER!



Never operate the Tractor and Mower Unit without an OPS (Operators Protective Structure) or Cab to prevent injury from objects thrown from ground or from overhead trimming. Stop mowing if workers or passersby are within 100 yards. (SBM-9)



## DANGER!




Each Rear Wheel must have a minimum of 1500 pound contact with the surface to prevent lateral instability and possible tip-over which could result in serious bodily injury or even death. Widen the wheel tread and add weights if needed. Refer to the mounting instructions or call Customer Service if you need assistance with Counterweight Procedure. (SBM-11)



## DANGER!




Always disconnect the wire leads from the mower pump solenoid before performing service on the Tractor or Mower. Use caution when working on the Tractor or Mower. Tractor engine must be stopped before working on Mower or Tractor. The Mower Blades could inadvertently be turned on without warning and cause immediate dismemberment, injury or death. (SBM-12a)



## DANGER!



The flail cutter shaft is designed for standard rotation (same rotation as the tractor wheels during forward travel). **Never operate the cutter shaft in the reverse rotation.** Operating this mower in reverse rotation may cause objects to be thrown out the front of the mower head.



# SAFETY

## WARNING!



Engine Exhaust, some of its constituents, and certain components contain or emit chemicals known to the state of California to cause cancer and birth or other reproductive harm.

## WARNING!



Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and birth or other reproductive harm. **Wash hands after handling!**

Tiger mowers use balanced and matched system components for blade carriers, blades, cutter-shafts, knives, knife hangers, rollers, drive-train components and bearings. These parts are made and tested to Tiger specifications. Non-genuine “will fit” parts do not consistently meet these specifications. The use of “will fit” parts may reduce mower performance, void mower warranties and present a safety hazard. Use genuine Tiger mower parts for economy and safety.



In addition to the design and configuration of this Implement, including Safety Signs and Safety Equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of the machine. Refer also to Safety Messages and operation instruction in each of the appropriate sections of the Tractor and Equipment Manuals. Pay close attention to the Safety Signs affixed to the Tractor and Equipment. (SG-18)

# SAFETY



**FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTIONS CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.**

<b>1. READ MANUAL</b> 	<b>2. NO RIDERS, NO CHILDREN OPERATORS</b> 	<b>3. USE SAFETY SHOES, HARD HAT, SAFETY GLASSES, SEAT BELTS, &amp; ROPS</b> 	<b>4. BLOCK UP SECURELY BEFORE WORKING UNDER</b> 
--	---	---	--

1. Study and understand Operator's Manuals, Safety Signs, and Instructional Decals for tractor & flail mower to prevent misuse, abuse, & accidents. Practice before operating mower in a confined area or near passersby.

- Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children.

2. Allow no children on or near implement or tractor. Allow no riders on tractor or implement. Falling off can cause serious injury or death from being runover by tractor or mower or contact with Flail Mower Blades.

3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seatbelt fastened securely and snugly to prevent injury and possible death from falling off or tractor overturn. Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, and Ear Plugs are recommended.

4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain that area is clear before lowering or folding.

5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding implements. Slow down when turning and on hillsides.

- Install \*\*Restrictor in folding circuit to slow down lowering and unfolding if action is faster than is desirable.

6. Make certain that SMV sign, Warning Lights, and Reflectors are clearly visible. Follow local traffic codes.

7. Never operate with Flail Mower or Folding Section raised if passersby, bystanders or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Shields or implement structure.

8. Before dismounting, secure flail mower in transport position or lower to ground.

- Put tractor in park or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent entanglement in rotating parts which may cause injury or death.
- Never mount or dismount a moving vehicle. Crushing from runover may cause injury or death.

<b>5. TRANSPORT SAFELY, LOCK UP</b> 	<b>6. USE SMV, LIGHTS, &amp; REFLECTORS.</b> 	<b>7. DO NOT OPERATE WITH MOWER OR WING RAISED</b> 	<b>8. DO NOT MOUNT OR DISMOUNT WHILE MOVING</b> 
--	---	---	---


PART NO.  
LOCATION

002369  
HYDRAULIC TANK

**PELIGRO**

Si No Lee Ingles, Pida Ayuda a Alguien Que Si Lo Lea. Para Que le Traduzca las Medidas de Seguridad.

LEA EL INSTRUCTIVO




00725746


00725746  
INSIDE OF CAB



THROWN OBJECTS



CUTTING BLADES



**KEEP AWAY - ROTATING BLADES**

BEING HIT BY THROWN OBJECTS OR CONTACTING ROTATING BLADES CAN CAUSE INJURY OR DEATH.

- Stop mowing if passersby enter the area of thrown objects (See Operator's Manual).
- Use special care if Mower Head or Wing is raised off the ground. (See Manual).
- Operate only if all Guards-Deflectors are in place and in good condition.

00769737

00769737  
MOWER DECK

# SAFETY



PART NO.  
LOCATION

00758194  
MOWER DECK



02962764  
MAIN BOOM, SECONDARY BOOM, MAIN FRAME



02962765  
MAIN FRAME

02965262  
HYDRAULIC TANK



# SAFETY

## **DANGER**

CUTTING BLADES



THROWN OBJECTS



### **KEEP AWAY - ROTATING BLADES**

BEING HIT BY THROWN OBJECTS OR CONTACTING ROTATING BLADES CAN CAUSE INJURY OR DEATH

- Stop mowing if passersby enter the area of thrown objects. (See Operator's Manual)
- Use special care when Flail or Wing is raised off the ground. (See Oper. Manual)
- Operate only if all Guards-Deflectors are in place and in good condition.

PART NO.  
LOCATION



02967668  
MOWER DECK

02971123  
HYDRAULIC TANK

03200285  
OUTSIDE OF CAB

22645  
INSIDE OF CAB

22839  
MOWER DECK



## SAFETY



PART NO.  
LOCATION

22840  
INSIDE OF CAB



24028  
MOWER DECK

25387  
INSIDE OF CAB



10" x 5.5" 31522  
MOWER DECK, MAIN BOOM  
18.25" x 10" 31523  
HYDRAULIC TANK

# SAFETY



PART NO.  
LOCATION

27001  
INSIDE OF CAB



31935  
INSIDE OF CAB

**! DANGER**

1. EACH REAR WHEEL MUST HAVE A MINIMUM OF 1500 POUNDS CONTACT WITH THE SURFACE TO PREVENT LATERAL INSTABILITY AND POSSIBLE TIP-OVER WITH **BODILY INJURY**. WIDEN WHEEL TREAD AND ADD WEIGHTS IF NEEDED. SEE MANUAL OR CALL TIGER CUSTOMER SERVICE FOR COUNTERWEIGHT PROCEDURE.

2. TRANSPORT **CAREFULLY!** SLOW DOWN EVEN MORE ON SLOPES AND WHEN TURNING; NEVER TURN UP A SLOPE SHARPLY OR AT HIGH SPEED; AND USE EXTRA CARE IN ROUGH OR BUMPY AREAS TO PREVENT OVERTURN AND POSSIBLE CRUSHING **INJURY** OR **DEATH**. IF YOUR VIEW TO THE REAR IS BLOCKED, IT IS YOUR RESPONSIBILITY TO **INSTALL MIRRORS** THAT PROVIDE A REAR VIEW TO PREVENT ACCIDENTS FROM BLIND SPOTS.

3. REAR-MOUNTED BOOM MOWERS MOVE CENTER OF GRAVITY TO THE REAR AND REMOVE WEIGHT FROM FRONT WHEELS. ADD FRONT BALLAST UNTIL AT LEAST 20% OF TRACTOR'S WEIGHT IS ON FRONT WHEELS TO PREVENT REARING UP, LOSS OF STEERING CONTROL, AND POSSIBLE **INJURY**.

4. NEVER OPERATE UNIT WITHOUT AN OPS (OPERATOR PROTECTIVE STRUCTURE) OR CAB TO PREVENT **INJURY** FROM OBJECTS THROWN FROM GROUND AND OVERHEAD TRIMMING. STOP CUTTING IF ANYONE IS WITHIN 100 YARDS.

5. KEEP THE BOOM AND CUTTERHEAD AT LEAST 10 FEET FROM ELECTRIC LINES AND PIPE LINES TO PREVENT ACCIDENTAL CONTACT AND POSSIBLE **SERIOUS INJURY** OR EVEN **DEATH**.

6. WHEN TRANSPORTING BOOM MOWERS ON A TRUCK OR TRAILER, THE HEIGHT OR WIDTH MAY EXCEED LEGAL LIMITS. CONTACT WITH SIDE OR OVERHEAD STRUCTURES OR POWER LINES CAN CAUSE **SERIOUS INJURY** OR **DEATH**. LOWER BOOM TO REDUCE HEIGHT AND/OR REMOVE MOWING HEAD TO REDUCE WIDTH TO THE LEGAL LIMITS, IF NEEDED. 32707

32707  
HYDRAULIC TANK



42350  
MOWER DECK

## SAFETY

### ATTENTION

**SERVICE HYDRAULIC SYSTEM  
WITH UNIVERSAL TRACTOR  
HYDRAULIC OIL.**

32708

PART NO.  
LOCATION

32708  
HYDRAULIC TANK

### CAUTION

For your safety and to guarantee optimum product reliability, always use genuine TIGER replacement parts. The use of inferior "will-fit" parts will void warranty of your TIGER implement and may cause premature or catastrophic failure which can result in serious injury or death. If you have any questions concerning the repair parts you are using, contact TIGER, 3301 N. LOUISE AVE., SIOUX FALLS, SD 57107

32709

32709  
INSIDE OF CAB


33224  
MOWER DECK

# Tiger™

33438  
MAIN BOOM

# SAFETY


PART NO.  
LOCATION



33302  
INSIDE OF CAB

### MOWING SAFETY TIPS

1. Read & understand the Operators Manual.
2. Wear Your Seat Belt.
3. Keep all shields and guards in place.
4. Make sure equipment is in proper working condition.
5. Never attempt to get off or on a moving tractor.
6. Never allow riders on tractor or equipment.
7. Only start the tractor from the seat with the key.
8. Always inspect the area before mowing. Remove all foreign debris.
9. Always keep bystanders and coworkers a minimum of 300 feet away.
10. Never allow the mower blades to contact solid objects or foreign material.
11. Never approach rotating elements.
12. Disengage the PTO, place transmission in "Park", set parking brake, shut off engine, and remove key and wait until all rotating motion has stopped before leaving seat.



33743


33743  
INSIDE OF CAB



# SAFETY



PART NO.  
LOCATION  
RED 42399  
REFLECTIVE TAPE  
MOWER DECK



AMBER 42400  
REFLECTIVE TAPE  
MOWER DECK



6T3217  
MOWER DECK



6T3219  
INSIDE OF CAB


6T3220  
FRONT PUMP MOUNT

# SAFETY



PART NO.  
LOCATION


6T3221  
INSIDE OF CAB



6T3222  
INSIDE OF CAB




6T3224  
MOWER DECK



6T3225  
INSIDE OF CAB

# SAFETY



PART NO.  
LOCATION

6T3230  
INSIDE OF CAB



6T3231  
INSIDE OF CAB



6T3233  
HYDRAULIC TANK



6T3234  
INSIDE OF CAB



6T3236  
MOWER DECK


# SAFETY

## ⚠ WARNING

WHEN CUTTING HEAVY BRUSH,  
BLADE BOLTS SHOULD BE  
INSPECTED HOURLY AND  
RETORQUED TO 600 FT. LBS.

6T-3237


6T3237



6T3241

PART NO.  
LOCATION  
6T3237  
INSIDE OF CAB

6T3241  
INSIDE OF CAB



34206  
INSIDE OF CAB

## ⚠ WARNING

IT IS RECOMMENDED THAT THE BOLT AND LOCK NUT BE REPLACED WHENEVER BLADES ARE REPLACED. REPLACE THESE ANY TIME THEY ARE DAMAGED OR WORN AS FAILURE TO DO SO CAN LEAD TO BLADES COMING OFF CAUSING SERIOUS INJURY OR DEATH.

## IMPORTANT

- WHEN REPLACING BLADES, IT IS RECOMMENDED THAT ALL BLADES BE REPLACED FOR PROPER BALANCE TO AVOID EXCESSIVE VIBRATIONS WHICH CAN DAMAGE SPINDLE ASSEMBLY.
- SEE YOUR OPERATOR'S MANUAL FOR PROPER INSTALLATION INSTRUCTIONS.

6T-3243

6T3243  
INSIDE OF CAB

## GREASING INSTRUCTIONS

### CUTTER SHAFT BEARING

GREASE EVERY 8 HRS. OR DAILY

NOTE: If unusual environmental conditions exist-extreme temperatures, moisture, or contaminants-more frequent lubrication is required.

6T3249A

6T3249A  
MOWER DECK

## GREASING INSTRUCTIONS

### GROUND ROLLER BEARING

GREASE EVERY 8 HRS. OR DAILY

NOTE: If unusual environmental conditions exist-extreme temperatures, moisture, or contaminants-more frequent lubrication is required.

6T3261

6T3261  
MOWER DECK

# SAFETY



TB1011  
MOWER DECK



**Tiger Corporation**

800-843-6849  
www.tiger-mowers.com


Description	Application	General Specification	Recommended Lubricant
Tractor Hydraulics	Reservoir	JD-20C	Mobilfluid® 424
Mower Hydraulics Cold Temperatures 0°F Start-up  Normal Temperatures 10°F Start-up Normal Temperatures 15°F Start-up High Operating Temperatures Above 90°F Ambient	Reservoir	ISO 46 Anti-Wear/ Low Temp JD-20C ISO 46 Anti-Wear ISO 100 Anti-Wear	Mobil DTE® 15M  Mobilfluid® 424 Mobil DTE® 25 Mobil DTE® 18M
Flail Rear Gearbox	Reservoir	PAO Synthetic Extreme Pressure Gear Lube	Mobilube SHC® 75W-90, Mobil 1 Synthetic Gear Lubricant
Cutter Shaft and Ground Roller Shaft (Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Drive Shaft Coupler (Rotary and Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Boom Swivel, Boom Cylinder Pivots (Rotary and Flail Boom Type)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Deck Boom Pivot & Deck Stop Adjustment (Rotary and Flail)	Grease Gun	Lithium Complex, NLGI 2 ISO 320	Mobilgrease® CM-S
Deck Spindle (Rotary)	Grease Gun	Tiger Spindle Lubricant	Mobilith SHC 220

**For Mobil product information, availability, or technical information, call 1-800-662-4525.**

Tiger PN 34852

34852  
HYDRAULIC TANK

# SAFETY



50023 MANUAL CANISTER

ITEM	PART NO.	QTY.	DESCRIPTION
	<b>50023</b>	<b>AVAIL</b>	<b>MANUAL CANISTER COMPLETE</b>
1	00776031	1	ROUND MANUAL CANISTER
	33997	1	DECAL, SHEET, MANUAL CANISTER
2		*	DECAL
3		*	DECAL
4		*	DECAL
5	*	AVAIL	SPECIFIC PRODUCT MANUAL
6	33753	1	E M I SAFETY MANUAL
7	34296	1	FRONT ADHESIVE PAD
8	34297	1	REAR ADHESIVE PAD
9	6T1823	4	ZIP TIE 14" LONG

## NOTE:

The manual canister can be bolted, zip tied or adhered to a variety of surfaces. Locate a protected area within the view of the operator. Then select an installation method and attach the canister. **CAUTION - AVOID DRILLING HOLES INTO UNKNOWN AREAS**, wires and other parts may be located behind these areas. When adhering the canister to a surface, thoroughly clean that surface before installing the canister.

# SAFETY

## FEDERAL LAWS AND REGULATIONS

This section is intended to explain in broad terms the concept and effect of federal laws and regulations concerning employer and employee equipment operators. This section is not intended as a legal interpretation of the law and should not be considered as such.

### **Employer-Employee Operator Regulations**

U.S. Public Law 91-596 (The Williams-Steiger Occupational and Health Act of 1970) OSHA

#### **This Act Seeks:**

“...to assure so far as possible every working man and woman in the nation safe and healthful working conditions and to preserve our human resources...”

#### **DUTIES**

Sec. 5 (a) Each employer-

(1) shall furnish to each of his employees employment and a place of employment which are free from recognized hazards that are causing or are likely to cause death or serious physical harm to his employees;

(2) shall comply with occupational safety and health standards promulgated under this Act.

(b) Each employee shall comply with occupational safety and health standards and all rules, regulations and orders issued pursuant to this Act which are applicable to his own actions and conduct.

#### **OSHA Regulations**

OSHA regulations state in part: “At the time of initial assignment and at least annually thereafter, the employer shall instruct every employee in the safe operation and servicing of all equipment with which the employee is, or will be involved.”

#### **Employer Responsibilities:**

To ensure employee safety during Tractor and Implement operation, it is the employer’s responsibility to:

1. Train the employee in the proper and safe operation of the Tractor and Implement.
2. Require that the employee read and fully understand the Tractor and Implement Operator’s manual.
3. Permit only qualified and properly trained employees to operate the Tractor and Implement.
4. Maintain the Tractor and Implement in a safe operational condition and maintain all shields and guards on the equipment.
5. Ensure the Tractor is equipped with a functional ROPS and seat belt and require that the employee operator securely fasten the safety belt and operate with the ROPS in the raised position at all times.
6. Forbid the employee operator to carry additional riders on the Tractor or Implement.
7. Provide the required tools to maintain the Tractor and Implement in a good safe working condition and provide the necessary support devices to secure the equipment safely while performing repairs and service.

#### **Child Labor Under 16 Years of Age**

Some regulations specify that no one under the age of 16 may operate power machinery. It is your responsibility to know what these regulations are in your own area or situation. (Refer to U.S. Dept. of Labor, Employment Standard Administration, Wage & Home Division, Child Labor Bulletin #102.)



# SAFETY

# ASSEMBLY SECTION

# ASSEMBLY

Before attempting to mount your Tiger mower, it is important to read and understand all of the safety messages in the Safety Section of this manual.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.



• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

## TRACTOR PREPARATION

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

(ASM-C-0024)

## CRANKSHAFT ADAPTER

• Read the safety messages in the Safety Section of this manual before attempting to mount the mower.

(ASM-NH-0050)

## ADJUSTING REAR WHEELS

Follow the instructions in the tractor owner's manual for adjusting tires and rims.





# ASSEMBLY

## POLYCARBONATE SAFETY WINDOW

1. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

2. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

3. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

4. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

5. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

6. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

7. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

8. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.

9. The polycarbonate safety window is a clear, durable plastic material that provides protection for the operator. It is designed to be installed on the front of the tractor. The window is made of a single piece of material and is easy to install. It is a clear plastic material that is designed to be installed on the front of the tractor. It is a clear plastic material that is designed to be installed on the front of the tractor.


(ASM-NH-0101 T5 115)



# ASSEMBLY

## EXHAUST MODIFICATION

Remove the exhaust stack from the tractor. The exhaust stack is located on the right side of the tractor, near the engine. The exhaust stack is made of metal and has a flange at the top. The flange is bolted to the tractor frame. The exhaust stack is removed by loosening the bolts and pulling the stack away from the tractor. The exhaust stack is then discarded. The mainframe is then installed on the tractor. The mainframe is made of metal and has a flange at the top. The flange is bolted to the tractor frame. The mainframe is installed by aligning the flange with the tractor frame and bolting it in place. The mainframe is then tested for proper operation.



# ASSEMBLY

## RIGHT TURN SIGNAL RELOCATION

Q•ca} } Á Á@Á æ ÷æ ^ÁÁ~ á•Á [ áãæ } Á Á@Áá @Á á^Á } Áá } æÁá @Á^ { [ ç^Á @Á } Áá } æÁá áÁ^ç^!•^Á@Áá&á } Á Á@ÁÉ æ ááá á^Á [ Ááá•Á ] ÉÜ^É [ ~ ç^Á@Á á^Á @Á [ ~ \* @Á Á á^Á Á@Áá @Á•^ { à|ÉV@Á [ &@Á Á@Áá @Á•^ { à| Á áÁ^Á Á@Á [ ] \* Á|æ^É •[ Á•^Áá Áá á^Á Áá á^Á ~ Á^Á, Á [ &@Á Á@Á á^Á ] æÁÁ~Á& Áá æ Éá |áá áÁá á^Á Á & ç^ÁÉÁ, Á&^, •Áá Á^ÁÁ í Hé í í Á áÁ^Á Á^ÁáÁ Á@Áá Á@Áá @Á•^ { à| ÉÁ ASM-NH-148 light relocation)



## MAINFRAME INSTALLATION

Y á@Á Á ç^! @æÁQ á Áá ÁÁ! Áá É æ á•Éæ^Á } ^Áá^Á Á@Áá ^Á ] Á Á@Á [ ^Á&ç^Á { æ&@ \* Á [ ~ } ç^Áç^Á^ÉQ•ca|Á&^ •Áá áÁ @|Ááá, æ^Á Á^&^! Á@Áá^Á Á@Á { æ ÷æ ^Á Á@Áá& Áá ç^Á •ÉÁ Á @, } Á } Á@Áá& Á [ ~ } Áá æ^Á Á@Ááá^Á& } ÉÁ ÖUÁUVÁá @ } Áá@Áá ^ÉÜ^ { [ ç^Á@Á&^ •Á^ •Á^ Áááá ^Áá áÁá ] Áá@Áá [ & á^Á æ^Á ] ÉÜ^á •Á@Á&^ •Áá áÁá @ } Áá [ ~ ^Á Áá ^Á Á [ ç^Á Á@Á [ ~ ^Á&ç^Á æ^Á Á @Á æ ç^Á æ & Á^& } Á Á@Á á æ æÉ (ASM-C-0003)





# ASSEMBLY

## SWITCHBOX WIRING


Ú[ , ^!Áq aÁ!{ } aÁe^Á~||^aÁr[{ Á@Á!æd!qÁæ&••[!^Á[ &^Á•q\*Á@Á^!aÁq oÁ a^Á}Á  
o@Á~]]|a aÁ|\*Ár!Á[ , ^!Áq aÁ@Á!æd!Á a^Ár!Á!{ } aÁe^Á•q\*Á@Á!aÁq oÁ a^Á}Á  
!^aÁ!Á!æ\*^Á a^Ár!Á!{ } aÁe^Á•q\*Á@Á!aÁq oÁ a^Á}Á  
V@Á, aÁ@[ cÁÁÁÁ^Á^&!^aÁr!Á!{ } aÁe^Á•q\*Á@Á!aÁq oÁ a^Á}Á  
ÁASM-NH-0121 T5 115)



# ASSEMBLY

## MANUAL LIFT VALVE PORTS


ASM-C-0057)



<b>ASSEMBLY</b>	
-----------------	--

## TRACTOR LOAD SENSE, PRESSURE & RETURN

V@Áõçæç^Á••^Á@Á|Á••~|ÁËÜ^ç|}ÁæáÁ[æáÁ]•^Á}Á@Áæçç|çÁ^æÁ{[çÁæáÁË  
V@Á|çÁ•^áÁ^Áá^æç^Á}á^Á@Áçæç^Á[~}ç\*Á|æËV[Á|çæáÁæáá]æÁ|Á••~|ÁËÁ  
Q•^Á|[Á@Áæçç|çÁ[,^Áç^ç|\*Á^ç|}ÁæáÁ&@&Áçæç^Á^Áæáá^áË  
V@Á|Á••~|ÁQ•^ÁÁ|~çáÁ|[Á@Áæçç|çÁ{[çÁæáÁÁÁ&@&Áçæç^ËQ^Á&]áQ•^Á  
|~}•Á|[Áæç^Á}Á@&@&Áçæç^ÁÁ@Á|Á••~|ÁÁ|ç|}Á@Áçæç^ÁË  
V@ÁÜ^ç|}AQ•^Á~}•Á|[Á@Á^ç|}Á|ç|çÁ@Áçæç^ÁÁ@Áæçç|Á^|[ç•Ë  
V@Á[æáÁ]•^Áç^ÁÁ|~çáÁ|[Á@Á[æáÁ]•^Á|ç|çÁ@Áçæç^ÁÁ@Á[æáÁ]•^Á|ç|ç  
æá@Á^æççÁ@Áæçç|Ë  
QÁæááá]æAQ•^Á~}•Á|[Á@Áæçç|Á[,^Áç^ç|\*Á^ç|}Á^}^æçç@Áç@ÁæççÁ@Á  
çæçç|ÁÁ&@&Áçæç^Á[~}çáÁ^|,Á@Áçæç^Á|æËÜ^ç^ÁQç•Á^|,ËQ|Á|çÁ  
çç|çæ}Á^~|ÁÁ@ÁæççÁ^çç}Á|Áæçç|ççÁ@Áæçç|çæçç^ÁQ|~}ËASM-  
NH-0125)




# ASSEMBLY

## LIFT VALVE HOSE ROUTING

For the lift valve hose routing, the lift valve hose must be routed through the wheel well. The lift valve hose must be routed through the wheel well and the lift valve hose must be routed through the wheel well. The lift valve hose must be routed through the wheel well and the lift valve hose must be routed through the wheel well.


**NOTE: DO NOT CUT INTO TUBES / HOSES / WIRES WHEN DRILLING THROUGH METAL OR PLASTIC!**



Use the lift valve hose routing diagram to route the lift valve hose through the wheel well. The lift valve hose must be routed through the wheel well and the lift valve hose must be routed through the wheel well. The lift valve hose must be routed through the wheel well and the lift valve hose must be routed through the wheel well. The lift valve hose must be routed through the wheel well and the lift valve hose must be routed through the wheel well.




<b>ASSEMBLY</b>	
-----------------	--

[illegible]

# ASSEMBLY

## STOWAGE BRACKET RELOCATION

ÁÁ[ Á\^ç^} óá ç\^ç\^} &^Á ã@Á@Áãçç^Á\æ Êç@Á ç, æ^Áàæ\^óæ{ Á•^áÁ ã@Á@ çæç\çÁ@^ç[ ã óá\æ^Á•ç{ Á á\Á^çáÁ\ Á^Á\| &æ^áÊç•ç\Áã^ç\Áæ\^Áæ\ I €Ç €í Áç •^&^Á@Áæç\çÁç, æ^Áæ{ Áç@Á^, Á[•ã} Ë(ASM-NH-0151 T5 115 top link)Á



# ASSEMBLY

## MANUAL SWITCHBOX MOUNTING

ÁV@Á, ã&@ [ cÁ Á Á^Á^& 'ÁÁÁ Á@Áá @Áá^Á Á@Á ð ~ áÁ [ } d [ |Á|áá ^ÁÁ^Á|Á Á@  
Úáó Á^&á } Á |Áó •^ { à |Áá áÁ [ { ] [ } ^ } • Á ^ÁáÁáÁ (ASM-NH-0122)Á






<b>ASSEMBLY</b>	
-----------------	--

[illegible]

# ASSEMBLY

## \*NOTE ON HUSCO CONTROL VALVES\*

T æ ~ æ Æ æ / ^ Å [ } d [ | / ^ Å P ~ • & Å [ } d [ | Å æ ç ^ Å [ [ { Å [ , ^ i • Å ^ ~ a ^ Å @ & Å æ ç ^ • Å æ ç ç È  
 \* | æ Å ^ • d æ ç \* Å | æ æ ^ Å æ í € € H D æ • æ | ^ a Å Å @ Å [ } d [ | Å æ ç ^ Å [ | \ Å [ | • Å @ æ æ ^ Å [ } ^ & c ^ a Å Å  
 @ Å | æ a Å } a • Å Å @ Å æ æ æ a Å ^ & } a æ ^ Å [ [ { Å & | æ a ^ i • È V @ Å @ & Å æ ç ^ Å [ , • Å æ Å Å ^ Å  
 + [ , Å ç Å @ Å | æ a Å } a Å Å @ Å æ æ æ a Å ^ & } a æ ^ Å [ [ { Å & | æ a ^ i • È a Å ^ • d æ ç Å [ , Å ^ Å Å @ Å  
 & | æ a ^ i • È @ ^ a ^ Å | [ ç æ æ \* Å | [ ] ^ i Å [ [ { Å [ } d [ | È V @ Å @ & Å æ ç ^ Å æ í € € H Å ^ } a [ | Å F J i i Ü È  
 È H D Å Å æ æ Å æ } ^ æ æ & Å Å Å Q • ^ æ æ ç ç i Å H G F Å æ a Å æ ç ç i Å H H i i È æ ç È Å | æ æ È Å  
 V @ • ^ Å [ { ] [ ] ^ } c Å æ Å ^ Å ^ } ç a a Å Å Å [ | , • È æ a Å ^ Å Å ^ Å • æ | ^ a Å ^ i Å æ • Å ^ & ç } Å | Å @ Å  
 | æ Å æ ç ^ Å ASM-HUSCO-0001)




# ASSEMBLY

## ELECTRONIC LIFT VALVE PORTS


(ASM-C-0089)A

### DANFOSS VALVE



## JOYSTICK SWITCHBOX MOUNTING


ASM-NH-0137 T5 115)A



# ASSEMBLY

## BOOM JOYSTICK CONTROL CALIBRATION

SUB-D



V@A0/&d[ } &A&[ } d[ |A&ç^&A^~ q ] ^aA ã@A @^•[ | ç ] ^æç æ[ •A ] A0[ [ { ÈU&^AÜ @-É  
 Ö&AÜ ||È& aA0[ [ { AÜ, æ^|A } &ç ] •ÈV@•^æç æ[ •A@ç^&æç^Aæ |ç [ ] æ[ ] a \* ÈV@A^&  
 Ü@|aA^&ç ] A[ ^•A[ A@ç^&æç^Aæ |ç [ ] æ[ ] a \* ÈV@A^•æ A[ | ç&^•A&æç È ^d&A[ |æ ^  
 •ã } æÈV@A^~ d&A^ã } æA[ |æ ^A&ç^A |A EA A^A&ç |A ] | ^A[ |æ ^ÈV@ZG A A^ã } æA[ |æ ^  
 , æA @o@A&ç^A ] [ |A A^ ||AÜU[ |È& aA | A A^ã } æA[ |æ ^A æA @o@A ] [ |A A^ ||AÜU[ |ç  
 @A0[ [ { ÈU&^AÜ @-È& aA0[ [ { AÜ, æ^|A&ç^A^&ç ] •ÈVU) A@A^&AÜ ||A^ } &ç ] A&A A A^ã } æ  
 ç[ |æ ^A æA @o@A&ç^A ] [ |A A^ ||AÜU[ |ç& aA | A A^ã } æA[ |æ ^A æA @o@A ] [ |A A^ ||AÜU  
 ] [ |ÈV@&æç æ[ A ã@æç^Aæ |ç [ ] æ[ ] a \* A^&æ^•A&æ } æA[ { A@A^•æ A&æ^A^•A@ç  
 FÍ A A^|A^æ^A@ç A A^A^A^ ] | ^A[ |æ ^A@æç æ[ A æA |ç ^ ç& aA @ ç&[ , ] ÈV@È ÈA@^  
 ã&æ A ç | } æAæ | ^A A@æç æ[ A |A A@A ] [ |A [ •æ ] A A^|Aæ^A@ç A@ç^A^&a aA^ A@  
 •ã } æA[ |æ ^A[ { A@A^•æ ÈA@æç æ[ A æAæ |ç ^ ç& aA @ ç&[ , ] ÈV@È È&æ^Aæ |ç  
 &[ ] a&æ ] Aæ •^A@æç æ[ A æA æ^A@A ] [ |A A^~ d&È @ ç&[ , ] È& a&æçæ A&^a SÖÖA }  
 @A[ ] A A@æç æ[ ÈV@A&ç^Aæ |ç& A A&æ &^a&A^A^ ] | ^A &ç \* A@A^æ ç&A, æ&AÜ@  
 æ aA@ } AÜ@È @A^•^A@Aæ |ç [ ] æ[ ] a \* È& a&æ •^A@SÖÖA } A[ ] A A@æç æ[ A^  
 \*|^& } Aæ æ È



V@A^•æ A&[ } d[ |A A^~ q ] ^aA ã@A^ã } æAæç ç ] A[ ç ] ç { ^ç•ÈA

V@•^A[ | ç&^A@A&æ æ&æ A& A& a&æ æ[ A&æ •A@A[ A A[ , A A^æ&A[ [ { A^ } &ç ] ÈV@A  
 a ] [ |ç& A@ç^A[ [ { A^ } &ç ] •A[ A[ ç&æ^A[ [ Aæ ÈV@ç&•^A& [ [ { A^ ^a&æ A^a^ &A@  
 •æ&æ A A@A } a&æ aA&æ^A^ |Aæ |A[ } d[ |È

P[ ç&A^•A&AÜ@q[ •A&^, a[æ^|A& aA^A^ |A A&æ •A@A^&^, •Aæ~ || ^AÜU^UV^ }  
 @A[ ç ] ç { ^ç•A&^ } aA@A^A[ ] a \* A[ a ç ] ç { ^ç•A&^ |A^A&æ^A^ } a \* A@A@  
 [ |A@A[ |ç ] ç { ^ç•A&^ & , a^A&æ^•A@A^A[ , A A&æ^A@A[ [ { A^ } &ç ] A^aÈ  
 æ aA^ } a \* A@{ A[ ] ç& & , a^A&æ^•A@A^A[ , A A&æ^A@A[ [ { A^ } &ç ] A^aÈ  
 Ü^A@A^A[ æ @A ] A@A^ç&A, Aæ^A^A[ A@ ] A A&æ •ç \*È





# ASSEMBLY

## BOOM JOYSTICK CONTROL CALIBRATION (CONTINUED)

**BOOM:** %CEÁU[ :dÖ [ { ÁM K Ì Ê Á^& } a•

(Note: Roll deck to be level with ground, and lower boom until deck is on ground. Now index boom “up” function and determine the time required for boom to rise completely.)

%CEÁU[ :dÖ [ { Ö [ , } K Ì Ê Á^& } a•

(Note: Roll deck to be level with ground, and raise the boom to “full up”. Then index the boom “down” function to determine the amount of time required for the deck to contact the ground. CAUTION: Stop the boom just as the deck contacts the ground.)

### SIDE

**SHIFT** %CEÁU[ :EÜã^Ä@CEÁ~ dK Ì Ê Á^& } a•

(Position deck above ground and shift completely inboard. Then index the side shift “out” function and determine the time required for the deck to shift completely outboard.)

Ä

%CEÁU[ :EÜã^Ä@CEÁ~ dK Ì Ê Á^& } a•

(Position deck above ground and shift completely outboard. Then index the side shift “in” function and determine the time required for the deck to shift completely inboard.)

**DECK ROLL:** %CEÁU[ :dÖ^& Á~ dK Ì Ê Á^& } a•

(Raise boom and shift deck so that deck can be articulated without contacting the boom, and roll deck in until deck cylinder is completely extended. Then index the deck roll “out” function and determine the time required for the deck to roll out.)

%CEÁU[ :dÖ^& Á~ dK Ì Ê Á^& } a• Á~ dÖÜÁ~UVÁ•^Äã ãÜ&^, D

(Raise boom and shift deck so that deck can be articulated without contacting the boom, and roll deck out until deck cylinder is completely retracted. Then index the deck roll “in” function and determine the time required for the deck to roll in.)

### BOOM

**SWIVEL:** %CEÁU[ :dÖ [ { ÁCEdFEGÜ^& } a•

(Position boom, rotate head to be level with ground, lower boom until deck is just above ground, and swivel boom full forward. Then index the boom swivel “aft” function and determine the time required for the boom to swivel full aft. Use caution when doing this, stop boom before boom contacts tire.)

%CEÁU[ :dÖ [ { Á~ d, æãKFEFGÜ^& } a•

Ü [ •ã } Á [ [ { Ê [ æ^Ä@æÄ Á^Á^ç^Á~ dÖ [ ] } aÊ, ^/Á [ [ { Á } ç^Á^& Á^Á^•Ö [ ç^Á^ [ ] } aÊ æ^Á^, æ^/Á [ [ { Á^Á^ } ç^Á^ æ^Á^EÜ@ } Á^Á^ç^Á^ [ [ { Á, æ^/Á^, æ^Á^ } &ç } Á^Á^ç^Á^ [ ] } a^ @Á^ Á^~ æ^Á^ Á^@Á^ [ [ { Á^ Á, æ^/Á^ Á^, æ^Á^ } aÊ


(ASM-DF CALIBRATION RSS-0001)



# ASSEMBLY

## BOOM JOYSTICK DIAGRAM

(ASM-DF CALIBRATION RSS-0001A)





<b>ASSEMBLY</b>	
-----------------	--

## REAR STOW SIDE MOWER HOSE ROUTING (CONT.)

**BEFORE TIGHTENING HOSES IN CLAMP, MAKE SURE HOSES CAN PASS THROUGH CENTER POINT OF BOOM PIN. THIS WILL ENSURE PROPER HOSE LENGTH FOR ALL BOOM POSITIONS.**

OE!æ\*^Á@ÁQ•^•ÁÁ@ÁQæ]Á@ÁQæ@•ÁÁ@Á[[{Á[~}q\*Á!æ^Á@ÁQ,}Áæ[ç^È  
 Ú||Á@ÁQ•^•Á~\*Á![{Á@Á,á!ÁÁ@Á[~}q\*Á!æ^Á@ÁQ]•È@}ÁæÁ[[{ÁÁ@  
 +!,æ!æ!á@Á@}Á@ÁQ•^•ÁÁ@ÁQæ]È  
 Tæ^Á~!^Á@ÁF+! [q!ÁQ•^•Á!Á[Á!Á!Á@Á[[{Áæ{ÁÁÁ[ç^áÁqÁ@Á@q,á\*  
 ][•æ}ÁQ@Á@Á^)\*Á@Á[q!ÁQ•^•Á!Á@Á^Á!Á@ÁQ!c}^Á!Á^æ•^Á@!^ÁÁ[Á~&@  
 Q•^Á^ç^^]Áæ]•È(ASM-RSS HOSE ROUTING-0001B)


## ACCUMULATOR INSTALLATION

[illegible]






## CONTINUOUS DUTY SOLENOID SWITCH



## SWIVEL BRACKET MOUNTING



<b>ASSEMBLY</b>	
-----------------	--

[illegible]


**ELEVATED, AND AGAIN AT REST WITH BOOM SUPPORTED.** (NASM-C-0013)

[illegible]

# ASSEMBLY

## SINGLE COLUMN BOOMREST

Öæ^~||^Ä|, ^|Ä@Ä|[{ |^•Öæ} äÄä} Ä@Ä| |^•Ä äÖÄ| •^Ä Ä@Ä| ^Ä| äÄ^ÄÄ|, Ä| •ÖÄ| Ä| äÄä| •^ÄÄä, ä^Ää Ä|, } Ä Ä@Ä| ä•Ä^&ä} Ä| [ •^| Ä| Ä|, Ä| Ä@Ää} { ^} Ä äÖÄ@Ä| ^ äÄ^ÄÄ| ä @} ÄÄ| |^~^ÄÄ| Ää, ä^Ä| } Ä@Ä| ^Ä| äÄ^Ää äÄ@Ää [{ |^•ÖÄ| ä| Ää äÄ@ Ö| [{ |^•ÖÄ| ä^Ä•ä Ä@Ää, ä^Ä| | çä^äÄ} äÄ} äÄ@Ää, ä^Ää äÖä Ää Ä| ••ä|^È  
(ASM-NH-0135)





# ASSEMBLY





# OPERATION SECTION

UJ ^!æq } Å^&q } ÅF





# OPERATION

## 2.TRACTOR REQUIREMENTS

QÁääää}Á Áæd[Á@!^][, ^!Áä äÁÁÁ~ä!áÁ Á] ^!æÁ@Á[[{ Á}ä!@Áæd[Á ~!^! Á!Á![] ^! ^~] ^!Á Á[[] ç!Á ^!æ[Á[] c&d}ä! Á ^!Á}[] æ@\* Á ^!Á!ä! ^!Á Á@Áæd[Á! ^! ^} &ä! äÁ ^} ^!Áæd[Áääää Á @} Á[ , ä\* Á ä!@Á[[{ Á|| Á!}!} ä!äE

## Tractor Requirements and Capabilities

- [illegible]

## **2.1 ROPS and Seat Belt**

[illegible][illegible]

## 2.2 Operator Thrown Object Protection

V@Ádæq|Á{ ~•óàÁÁ~ ¢] ]háÁ, æQ| | ¢&¢Á  
 ~ ¢] { ^} ¢Á Á @ ]á@Á[ ]^]æq|Á[ [ Áæq|\* Áæ á  
 @Q, } Á àò & ¢Q| ÁæÁdæq| • ¢@ Ádæq| Á ~ ¢  
 àÁÁ~ ¢] ]háÁ æQ| Á ]^]æq| Á æ ¢ Á & ^ ^} Á } Á  
 ¢ @ ¢ Á Á Á Á @ Á Á @ ¢ Á Á ¢ á ], • Á ~ • óàÁÁ ¢ ¢  
 æQ| Á @ ¢ Á Á ~ ¢ ¢ ¢ ¢ æ ¢ Á ¢ á ], ¢Q| Á [ ] ¢  
 æÁÁdæq| • ¢@ Ádæq| Á ~ • óàÁÁ~ ¢] ]háÁ æQ| Á  
 ÜÜÜÜÁæq| áÁ[ ]^]æq| Á[ [ ¢ & ¢Á Á æ ¢ Á æ ¢ Á Á ¢  
 [ ] [ ¢ ¢ Á Á [ ] [ ¢ & ¢] Á ¢ Á @ Á ¢ @ ¢ ¢ á Á Á [ ¢ Á ¢ @  
 [ ] ]^]æq| Á ~ ¢ Á ¢ Á ÜÜÜÜÁ ¢ ÜÜÜÜÁ ^ [ ¢ Á ¢ @ ÁÜÜÜÜÁ [ {  
 [ ] ] ¢ Á Ádæq| • Á Á ~ ¢ Á Á Á æ ¢ Á Á ¢ Á ¢ Á

OPS-B- 0001


$$\dot{O}[\cdot] \{$$

U] ^{|æā } Â^&ā } Á-Ë

# OPERATION



1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. 15. 16. 17. 18. 19. 20. 21. 22. 23. 24. 25. 26. 27. 28. 29. 30. 31. 32. 33. 34. 35. 36. 37. 38. 39. 40. 41. 42. 43. 44. 45. 46. 47. 48. 49. 50. 51. 52. 53. 54. 55. 56. 57. 58. 59. 60. 61. 62. 63. 64. 65. 66. 67. 68. 69. 70. 71. 72. 73. 74. 75. 76. 77. 78. 79. 80. 81. 82. 83. 84. 85. 86. 87. 88. 89. 90. 91. 92. 93. 94. 95. 96. 97. 98. 99. 100.



## 2.3 Tractor Lighting and SMV Emblem

1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. 15. 16. 17. 18. 19. 20. 21. 22. 23. 24. 25. 26. 27. 28. 29. 30. 31. 32. 33. 34. 35. 36. 37. 38. 39. 40. 41. 42. 43. 44. 45. 46. 47. 48. 49. 50. 51. 52. 53. 54. 55. 56. 57. 58. 59. 60. 61. 62. 63. 64. 65. 66. 67. 68. 69. 70. 71. 72. 73. 74. 75. 76. 77. 78. 79. 80. 81. 82. 83. 84. 85. 86. 87. 88. 89. 90. 91. 92. 93. 94. 95. 96. 97. 98. 99. 100.

OPS-B- 0017






OPERATION

U] ^i

U] ^i

# OPERATION

[illegible][illegible]



# OPERATION

OPERATION

## 4.STARTING THE TRACTOR

V@Á] ^!æ |Á ~•Á@æ^Áæ { ] |^Á } á^!•æ áá \*Á -Á@Á |æ { ^ } ðÁ } &æ } ðæ áÁ ] ^!æ } æÁ •^Á -Áæ  
dæd |Áæ ] d[ |•Á^ |^Áæ \*Á@Áæd |Á^Áæ, Á@Áæd |Á ] ^!æ |qÁ æ~ æÁæ áÁæ } •^ |qÁ æ c@ |ã^á  
á^æ^Á |Áæd |Á ] ^!æ } Á •d~ &æ } •Á^ ^á^áÉ

Ö•^} æÁæd |Á ] d[ |•K

- " S[ æÁ@Áæ } æ } Á^ ð, æ&æ
- " S[ æÁ@Áæ } \*á^Á @ q~Á ] d[ |
- " S[ æÁ@Áæ áæ |ææ ] d[ |Á^Á^Á
- " S[ æÁ@Áæ @Áæ } d[ |Á^Á
- " S[ æÁ@Áæ ^á^á^áæ áÁæ } &æ
- " S[ æÁ@Áæ ÁVUÁæ ] d[ |Á
- " S[ æÁ@Áæ [ á^Áæ } d[ |Á^Á
- " S[ æÁ@Áæ [ { Á ] ^!æ } \*Áæ ] d[ |•Á^ •æ Á |Áæ^Áæ \ D

Ö- |^Áæ \*Á@Áæd |Á } •^ |Á@Áæ | | , á \*Á

- " Ö[ ] á~ &æ |Á^Éæ |Áæ } Á •] ^&æ } Á áÁ^Áæ |áá \*Á Á@Áæd |Á ] ^!æ |qÁ æ~ æÁæ
- " T æ^Á^ |Áæ |Á^ æá •É æ |á •É æ áÁ c@ |Áæ^Áæ Á^Áæ •Á^Á^Á^ |Á^ ÁæÉ
- " V@Áæ á \*Áæ^Áæ } É
- " V@Áæd |Áæ •{ á•á } Á^Á^Áæ Áæ Áæ |Á^ dæÉ
- " V@Áæ [ { Á ] ^!æ } \*Áæ ] d[ |•Á^ Á@Áæ dæá áÁ -Á [ •æ } É
- " V@ÁVUÁæ ] d[ |Á^Á^Áæ } \*æ^áÉ
- " V@Áæ áæ |Áæ { [ Áæ ] d[ |Á^Á^Áæ Á@Áæ dæÁ [ •æ } É

Ü^Á |Á Á@Áæd |Á , ^ |qÁ æ~ æÁ |Áæd |Áæd \*Á | &á^ |Á^Á^ |Áæd |Á @Á^Áæ áÁæ á  
á^Áæ Á@Áæd |Á ] ^!æ |qÁ^Áæ |Á^Áæ •Á@Áæ } æ } Á, æ&æ Á @ |Áæ& æ \*Á@Áæd |Á ] ^!æ |  
Ö^Á@Áæd |Á } \*á^Áæ } } á \*Éæ |Áæ&æ } æ } æá Á@Áæd |Áæd •{ á•á } Á |Á^Á^Áæ Á^áá  
æ áÁ^Á^Áæ |Á [ Á^Á^Áæ ] d[ |Á^Á^Áæ OPS-B- 0003



Þ^Á^Á^ Á@Áæd |Á } \*á^Áæ Áæ |Á^Áæ •Á^Áæ áá \*Á |Á æ~ Áæ^Áæ æÁ^Áæ dæ } ÁV @  
Áæ •Á { •Áæ Á^Áæ áá [ •Á Á [ |Áæ áá



ÜæÁæd |Á ] ^!æ |Á^Áæ áá Á@Áæd |Á^Áæ Áæd \*Áæ  
dæd |Á Á^Áæ Á^Áæ •Á^Áæ |Á^Áæ Á^Áæ Á@Áæd |Á ] ^!æ |  
{ æ~ æÁ |Á ] ^!æd \*Á •d~ &æ } •Á




Ö[ {

U] ^!æ } Á^Áæ } Á






# OPERATION

[illegible]

0ffAUæ^c AU@ |ã•EÖ° æå•Aæ åAUæ^c Aä^cæ•A &~ ä ä \*AQ~ O\ [ c  
|ä æ~ãÁÜ DÆ@ ÄÖ~+&q |•EÖ@æ ÄÖ° æå•EÜc^|ÄÖ° æå•EÖ^æà c  
Ü@|ã•EÜVU/A c\*|æÄ @|ã•Eæ åÄÜ^cææ|^Ö |Ä@|ã•Ä @~|ã

[illegible]

Ü-^!Ä Ä@Ääq|Ä|^ä|qÄ ä~äÄ Ä)•|^Äe  
 &[]|^Ä|^E|^ä|Ä•|^8q|ÄäÄ&@ä|^ä  
 •^|cÄÄ äÄ! |{|^ÄÄ ä&q|läÄ\*Ä qÄ@  
 {ä~äc|^|^Ä|^&|{|^}ääq|•|ÄÄV@Ä|^|||,ä\*  
 ä^Ä[|^ÄÄ@Ä|•Ä@Ä~ä^ÄäÄÄ|^|cÄÄ/ä  
 ä•|^8q|K

- [illegible]



Op-13

$$\mathcal{O}[\mathcal{I} \setminus \{$$

U] ^{|æā} Â^&amp;ā} ÁĦ€



# OPERATION

[illegible]


P^c^!AS^æ^A@A[ , ^!A^}æc}â^âA @^A@A@æAâA A@A^æ^â  
 ][•æ]ÄA@A[ , ^!A^|âAæAæ•â \*Ä^!â^•A b i^!A A^[]^A @  
 { ä @Aæc^!c^d^Ä^A}â^!A@A[ , ^!A. ÄÖT E D

[illegible]

P^C^A^Acc^ [ ] A^ Q^ A^ à^ à^ Acc^ Acc^ • C^ I^ A^ ^ [ Ç^ A^ æ^ ã^ A^ [ { Ac@AQ ] | ^ ^ ) O\_ @^ / 5 M  
{ ç } Á Á @^ Á acc^ Á \* a^ / Á } } a \* É

UTF-8

" Ô@&Â|Â@âæ|âââ&•Â|}\*ÂQ•^•Ê  
 &|ââ^•Âââââ\*•È IMPORTANT|OÙâUVÁ  
 ^•^Â|~|Âââ&Â|&@&Â|Âââ&•Êâ^•^â  
 ]â&Â|Â@â:Âââ^|Â|&âââ|âââ&@&Â|Â  
 @âæ|ââââ&•Ê  
 " Q•]^&@Â|]ââ|Â|Â@ââ^Â|^]â\*È  
 " Ô•|^âââ\*•ââÂ|[]^|Â|}]^&âÊ  
 OPS-B- 0023 D



U] ^|æǻ } Â^ &ǻ } ÁHFG

# OPERATION

## WARNING

Öl [ Öl ] 'Ae Aoe AÖ ~ q { ^ } Öl @ @ äe | BÄ qÄ | Ä ~ | Ä ^ ä q \* EÄU q  
 ä q Ä ~ | Ä ~ Ä c | [ • Ä ~ Ä q ä Aoe äÄ | ^ • ^ } & Ä ~ | äÄ | ^ • ^ } Aoe ää EÄÖ  
 } [ Aoe & Ä | Ä ^ ä • Ä ~ | Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 ä | ^ ä • Ä ~ | Ä ~ Ä q ^ Ä | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 q & | ä q \* Ä q \* | ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 UOÄ q äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 • ä c Ä | ä • • Ä q äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 ^ [ ~ Ä ~ ] ^ Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 qÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 ] @ • ä q Ä } [ , | ä ~ ä q Ä q äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }



## OPERATION

### PROCEEDS TO THE NEXT STEP

- " Öl & Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }
- " Öl ~ ^ Ä @ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }
- " Öl ~ ^ Ä @ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }
- " Öl ~ ^ Ä @ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }
- " Öl ~ ^ Ä @ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }
- " Öl ~ ^ Ä @ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }



Öl & Ä @ Ä ~ | Ä ~ Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 Viä q | EÄ q äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 P ~ äe | BÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 [ Ä @ Ä ~ ^ c | äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 { ä q \* Ä q \* | ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 ^ | ^ } Öl | Ä ~ Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }

## WARNING

Öl & Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 U ~ [ cÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 ] | cÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 { ä q \* Ä q \* | ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }

## WARNING

Öl & Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 W ~ Ä | cÄ qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }  
 [ | Ä ~ Ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }

Öl { U | ä qÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ } Aoe äÄ | ^ • ^ }

# OPERATION


## OPERATION

ÜUVÖÿÿÁÐÒÖÖÁÐÜÜÖÖVÖÞ

- " Q•] ^&ö|æ•^æ å|æ^æ[ |ø Å| Å| [ •^} ^•• Å æ åÁç&•• æ^Å ^æÖÜ[ æ^Å Å|ø^Å Å æ^Å | Å|ø& å \* Åæ å|ÖÜ^| æ^Åæ æ^åÖ [ ] Ö æ åÁ å•å \* Å|æ^• Å| { } |ø^Å^ø Å { æ æ Å| æ^Åææ &É
- " Ö)•~| Å [ | Å| |ø Å åÁ ^ø Å^Å @} ^å Å @ Å| } | | | æ^Å | ^É
- " Ö)•~| Å^ àà| Å^+&| • Å^ Å| [ •æ } Å å [ | ø æ æ^åÖÜ^| æ^Å [ ] Ö Å| \^} Ö å { å•å \* Å^& } • Å { ^åæ^É
- " Ö)•~| Å^ å|æ| Å^ Å^ Å| [ ] | Å| } ^&ç åÁ | Å^ Å^ å|æ| Å [ | Ö|ø& Å| Å^ å|æ| Å |æ • Å| } \* Å^• Å^ å|æ| • ÖÜÁ UVÁ • Å^ [ | Å^ å| Å|ø& Å| Å| Å^æ • ÖV^ Å^ å| Å [ Å^æ Å^ å| Å| Å^ å|æ| å| Å|ø& Å| Å @å|æ| Å| Å^æ • É
- " Q•] ^&ö|æ[ ] åæ } Å Å& Å| æ Å Q^• Å^ å|æ, æ^ÖOPS-B- 0025



Ö| Å [ | ] ^ø æ å • Å| Å^Å } å| Å [ , ^| Å& • ÖÜ|æ^Å [ ] æ&æ Å^~| ç å Å|å • Å|ø | Å| Å^ç^ Å^æÖÜæ Å æ Å | Å| Å [ | ] Å^æ Å | ^æ å|ø& Å^ Å^& | Å| Å| [ & Å^Å ] Ö



Ö| Å^æ^c ÅÜ|å • ÖÖ^ æå • Åæ åÁ |ø | Å^æ^c Å^çæ • Å &| åå \* ÅQ^c Å [ | Å|æ æåÁ DÆ Ö^+&| • ÖÜ^| Å^æ æå • Åæ åÁÖ^æ| ç ÅÜ|å • Å| ^•c Å^ Å^åæ åÁ| æ æ^å Å| Å [ | å , [ | ] \* Å| } åæ } Ö| Å^æ^c Å^çæ • Å Q^| å Å^ Å • ^&ç å|æ^~| | Å^æ æ Å| Å| Å| å • Å [ | Å| \^} Å| { } | ^} ø Ö Å • å \* Ö| [ \^} Ö| Å| [ ] Å| { • Å ^•c Å^ Å| æ^å Å| } & Å| Å^å & |ø Å [ • • æ æ Å | Å|ø | Å| Å^æ| { Å| , } Å| å&ö Ö| } \* | Å| Ö| Å|æ^Å| } æ&æ

Ö| {

Ü| ^|æ } Å^& } Å|


# OPERATION

# OPERATION

Q. • ^ & o f a | a a ^ A a a a a | a a ^ A a e • ^ { a | ^ Á Á | Á @ Á | | | , a \* Á OPS-U-0031

**Cause:** Blade Pan contacts an immovable object while mower was in motion.

Original Blade Edge



**Cause:** Blade contacting foreign objects

**Remedy:** Inspect the area to be mowed and remove foreign objects that could cause damage to the blades

**Cause:** Mower height set too low.  
Blade used past intended life.

**Remedy:** Replace blades more often.  
Adjust mower height for mowing  
Conditions to eliminate blade-to-  
ground contact

Op-22




Q. ] ^ & a @ a Q | a a ^ . A a a A | | a a | [ | a A ^ a E U O U S C E O A O U V P A O S C E O O U A | } A a a a | a |  
Q T O O O E O S Y A A a @ | A | a a ^ A a K

```

" 0^8{ ( ^A^ ) 0^ / A^ - { ( ^A^ { ( A^ A^ | a^ a^ a^ @ ^ A^
" 0^ ^ A^ a^ . A^ ^ A^ a^ | ^ A^ | A^
" 0^ ^ ) A^ [ ^ * ^ . A^ A^ @ A^ | a^ a^ q^ A^ | - a^ A^ A^ | . ^ . ) a^ |
" 0^ [ ^ * ^ . A^ | A^ @ ) ^ a^ A^ a^ a^ A^ @ A^ a^ * A^ a^ ^ A^ A^ A^ * ^ | A^ @ A^ A^ B^ C^ F^ G^ { { D^ | A^
" V @ A^ a^ | a^ A^ | A^ @ A^ a^ a^ * A^ a^ ^ A^ @ A^ ^ ) A^ | | A^ a^ a^ A^ | | ^ A^ @ A^ B^ C^ F^ G^ { { D^

```

[illegible]

1/2" MAXIMUM  
(12.7mm)

Original Blade Edge

**NOTE:**  
Replace Blades in pairs after no more than 1/2" (12.7mm) wear



# OPERATION

## Tractor PRE-OPERATION Inspection



Mower ID# \_\_\_\_\_ Make \_\_\_\_\_

Date: \_\_\_\_\_ Shift \_\_\_\_\_

### **WARNING**

Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.

| Item   | Condition at Start of Shift | Specific Comments if not O.K. |
|--|-----------------------------|-------------------------------|
| The flashing lights function properly                |                             |                               |
| The SMV Sign is clean and visible                    |                             |                               |
| The tires are in good condition with proper pressure |                             |                               |
| The wheel lug bolts are tight                        |                             |                               |
| The tractor brakes are in good condition             |                             |                               |
| The steering linkage is in good condition            |                             |                               |
| There are no visible oil leaks                       |                             |                               |
| The hydraulic controls function properly             |                             |                               |
| The ROPS or ROBS Cab is in good condition            |                             |                               |
| The seatbelt is in place and in good condition       |                             |                               |
| The 3-point hitch is in good condition               |                             |                               |
| The drawbar pins are securely in place               |                             |                               |
| The PTO master shield is in place                    |                             |                               |
| The engine oil level is full                         |                             |                               |
| The brake fluid level is full                        |                             |                               |
| The power steering fluid level is full               |                             |                               |
| The fuel level is adequate                           |                             |                               |
| The engine coolant fluid level is full               |                             |                               |
| The radiator is free of debris                       |                             |                               |
| The air filter is in good condition                  |                             |                               |

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or MOWER**

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

OPERATION

# OPERATION

## Boom PRE-OPERATION Inspection



Mower ID# \_\_\_\_\_ Make \_\_\_\_\_

Date: \_\_\_\_\_ Shift \_\_\_\_\_



### WARNING

Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.

Table 1:

| Item  | Condition at Start of Shift | Specific Comments if not O.K. |
|---|-----------------------------|-------------------------------|
| The Operator's Manual is in the tractor               |                             |                               |
| All safety decals are in place and legible            |                             |                               |
| The mounting frame bolts are in place and tight       |                             |                               |
| The boom connection bolts & pins are tight            |                             |                               |
| There are no cracks in boom                           |                             |                               |
| The hydraulic cylinders pins are tight                |                             |                               |
| The hydraulic pump hose connections are tight         |                             |                               |
| The hydraulic valve controls function properly        |                             |                               |
| There are no leaking or damaged hoses                 |                             |                               |
| The hydraulic oil level is full                       |                             |                               |
| There is no evidence of hydraulic leaks               |                             |                               |
| The blades are not chipped, cracked or bent           |                             |                               |
| The blade bolts are tight                             |                             |                               |
| The deflectors are in place and in good condition     |                             |                               |
| The boom shields are in place and in good condition   |                             |                               |
| The skid shoes are in good condition and tight        |                             |                               |
| There are no cracks or holes in boom deck             |                             |                               |
| The hydraulic motor mounting bolts are tight          |                             |                               |
| The boom head spindle housing is tight and lubricated |                             |                               |

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or MOWER**


0111

U] ^!æ } Å^&ç } Å-Ë



# OPERATION

## Cable Controlled Mowers

OPERATION



OPERATION



OPERATION


OPERATION

OPERATION

# OPERATION

## 6.4 Switchbox

V@Äæ^c ÄÜ@|äÄ^ç^iÄ]]^}•Äæ ä&| [•^•Ä@Ä @|ä  
 || &æ^äÄ} Ä@Ä[] } Ä^Ä&^ Ä^Ä@æÄY @} Ä [çä\*  
 æÄ!Ä^æÄ@Ä^![] } äÄæ, æ•Äæç^Ä@Ä @|äÄ Ä@  
 &| [•^äÄ] [•äÄ} ÄY @} Ä [ , ä\*Ää Ä@Ä! ~•Ä!Ää  
 d^•Äæ[ç^Ä![] } äÄ^ç^iÄ@Ä @|äÄ æÄ^Ä]]^}^ä  
 {!Äæ ä!Ä&^æ \*ÄÜ^æÄæ äÄ|| , Ä@Ä} æ} ä\*•Ä}  
 c@Ä^&æÄ @ , } Ä^|| , ÄO[Ä[ Ä^} Ä@Ä&^ Ä^Ä@æ  
 ä d Ä æ^äÄæ^Ä^Ä@Ä Ä^Äæ ^Ä!Ä



OPERATION

**DANGER**

**SAFETY SHIELD & DEFLECTOR OPERATION**

- Failure to close Safety Shield and Deflector may allow objects to be thrown outward with great force which can cause property damage, bodily injury, or death.

- Keep Safety Shield and Deflector fully closed when cutting grass and weeds to reduce possibility of objects being thrown outward by the Blades if persons are in the area.
- Before Cutting brush, trimming limbs, or other such operations, raise the Deflector and Safety Shield fully to allow the blades to contact the material if area is clear of passerby. Operator must stop cutting and close shield if passerby enters the thrown objects area or blade contact area.
- Repair or replace Safety Shield and Deflectors as needed.
- Always transport with Safety Shield and Deflector closed.

02967867

Ö||{

U] ^!æä} Ä^&ä} Ä^Ä

# OPERATION


Ops-957

Ops-958


U] ^!æā } Â^&ā } ÁĦĜ

# OPERATION

ŠÒXÒÜÄÍ ÁÓU UT ÄÛY ÅÒŠ



ŠÒXÒÜÄÍ ÁÓU UT ÄÛP ØŠÖ



Ó[[{

U] ^!æ } Ä^&ä } ÄEG

# OPERATION

## 7. Joystick Controlled Mowers

### ⚠ WARNING

DO NOT allow anyone to operate the mower until you have received proper training and are familiar with the controls and safety features. Always wear your seat belt and use proper operating procedures.

Before operating the mower, read the operator's manual and familiarize yourself with the controls and safety features. Always wear your seat belt and use proper operating procedures. Do not operate the mower if you are under the influence of alcohol or drugs, or if you are tired or distracted.


### ⚠ CAUTION

Do not operate the mower on uneven or slippery surfaces, or in adverse weather conditions. Always use proper operating procedures and maintain a safe distance from other people and obstacles. Do not operate the mower if you are under the influence of alcohol or drugs, or if you are tired or distracted.

### ⚠ CAUTION

DO NOT allow anyone to operate the mower until you have received proper training and are familiar with the controls and safety features.


Before operating the mower, read the operator's manual and familiarize yourself with the controls and safety features. Always wear your seat belt and use proper operating procedures. Do not operate the mower if you are under the influence of alcohol or drugs, or if you are tired or distracted.



# OPERATION

## 7.1 Switch Box and Joystick Control

Before operating the mower, read the operator's manual. The operator must be at least 16 years old and have a valid driver's license. The operator must wear the seat belt and safety harness at all times. The operator must not drink alcohol or use drugs before operating the mower. The operator must not operate the mower if they are tired or distracted. The operator must not operate the mower if they are under the influence of alcohol or drugs. The operator must not operate the mower if they are wearing headphones or other devices that impair their hearing or vision. The operator must not operate the mower if they are wearing loose clothing or jewelry that could get caught in the blades. The operator must not operate the mower if they are standing on a ladder or other unstable surface. The operator must not operate the mower if they are near a building or other structure that could be damaged by the blades. The operator must not operate the mower if they are near a power line or other electrical hazard. The operator must not operate the mower if they are near a body of water or other hazard. The operator must not operate the mower if they are near a road or other traffic hazard. The operator must not operate the mower if they are near a school or other public area. The operator must not operate the mower if they are near a residential area. The operator must not operate the mower if they are near a park or other recreational area. The operator must not operate the mower if they are near a forest or other wooded area. The operator must not operate the mower if they are near a field or other open area. The operator must not operate the mower if they are near a road or other traffic hazard. The operator must not operate the mower if they are near a body of water or other hazard. The operator must not operate the mower if they are near a school or other public area. The operator must not operate the mower if they are near a residential area. The operator must not operate the mower if they are near a park or other recreational area. The operator must not operate the mower if they are near a forest or other wooded area. The operator must not operate the mower if they are near a field or other open area.



Do not run the cutter into material larger than 6" diameter.








# OPERATION

## OPERATION

### Joystick Control



RUÿÜVÔSÁY ÖÖÔSÁ UXÒÚÁ ÇPÁÓUT




Ó[[{

U] ^!æ } Á^&ā } Á-Ē


# OPERATION

## OPERATION


RU'YUVOSASOZVUOPVAT UXOUAUOOUPOOY  
OUUT



SOZVU'YUVOSAUSSOUAT UXOUAOOSAUSS



UOPVA RU'YUVOSAUSSOUAT UXOU A OUUT  
UY OOS




U] ^{


U] ^{

# OPERATION

ÜÖPVARJYÜVÖSÄÜÜŠŠÖ ÜÄY PŠÖÄÜÜÖ ÜÜÖÖ  
ÓWVUPÁŦ UXÖÜÁÜUT ŠPWOŠŠÖÁUPÁÖŠÖÖÖŠ  
ÜÖÜÁÜVUY ÁÜUT



ÜPÖŠÖÄ ÜY ÖÖPŦ } Á•, ŠŠÖÄ äŦ ŦDÁ UÜÖÜÖVÖÜ  
ÜÖÖVYÁUPÖŠÖ



## 8.DRIVING THE TRACTOR AND IMPLEMENT

ÜæÄÄæŦ!Äæ•][Ŧ!Ö^~ ä•Ä@Ä]Ŧ!æŦ!ÄŦÄ[••••ÄÄ@Ŧ!~\*ÖÄ][,Ŧä\*^ÄÄ@Ä[äŦ!Ää\*Ä]Ŧ!æä  
æäÄŦ!^ææŦ}•ÄŦÄæ^ÄŦÄŦ!äŦ\*ÄŦÄŦÄææ@äÄŦ][Ŧ{^}dÄÖ•Ŧ!Ä@ÄdæŦ!ÄæÄ@ÄæææÄŦ  
æääŦ!Ä@ÄŦ^äŦÄŦÄŦ[Ŧ{ÄæäÄ@ÄdæŦ!Ä]Ŧ!æŦ\*ÄŦ}d[Ŧ!Äæ^Ä^ÄŦ!ÄæÄæŦ][Ŧ!dÄÄŦ}•Ŧ!Äææ  
,ŦÄŦ!äŦ\*Ä@ÄdæŦ!ÄŦÄŦ[Ŧ{ÄŦçä,Ä@ÄŦ][,ä\*É


Ü^æÄŦ!ÄææŦÄ•d~&Ŧ}•ÄÖ^&ŦÄŦÄ@ÄÖ[Ŧ{ÄæŦ!ÄŦÄææŦ!æŦäÄŦ~ŦŦ!Äææä•ÄÜ[Ŧ{^Ä^&Ŧ  
æ^Äæææ@äÄŦ[Ŧ!ÄŦÄŦÄŦÄŦÄ@ÄÖ[Ŧ{ÄŦ@Ŧ!Ä@Ŧ!ÄÄŦÄ[••äŦ!ÄææäÄÜ^æŦÄæäÄŦæ^ÄŦ!ÄŦ[~  
~}äŦ!•æääÄ@ÄææŦÄŦ••æ^Ä^Ŧ!ÄŦ[Ŧ!æŦÄ@ÄŦ][Ŧ{^}dÄS^ŦÄŦ!Ä^&ŦÄŦ!æŦäÄŦäÄŦ!Ä  
ÜŦ]ŦæŦ!•Ŧ!Äæææ^Ä^&ŦÄŦ!ÄŦÄææÄ^&Ŧ}ÄŦ!Ä[Ŧ!ÄŦ[Ŧ{æŦ}É

S^Ŧ]ÄŦ!Ŧ[Ŧ]ŦÄŦ!ÄŦ!ÄŦ!ÄŦ[Ŧ,Ŧ!ÄŦ&Ŧ!ææ^ÄæÄ@,Ääb&ÄŦÄŦ!æŦ!Ŧ!æŦ!Ŧ!æŦ!Ŧ!æŦ!Ŧ!æŦ!Ŧ!æŦ!  
äææŦ&Ŧ!SÖÜÜÖSÖÜÜÖOPS-B- 0005


Ö[Ŧ{

U]Ŧ!æŦ}ÄŦ&Ŧ}ÄŦ

# OPERATION

[illegible]



000U0A^æð \*A@Áæð|A^æð, æ\*^A^@Aæð \*Áæ^Aæð|A^c  
 @Áæð|Áæð\*{ æ\*} Áæð \*A^æðæð\*æ^A@ÁU0Aæð|Ác@  
 ^}\*á^æð|{ç^A@Á^æð áá æð|Áæð|çð\*ÁæðÁæð|æðæðA@  
 æð|Áæðç^ÁæðÁæð, Áæð\*Áæð \*A^æðÁæð|ç^|ç@Áæð|  
 +{ Á||æ\*æðç^Áæð|{ }æðÁæð|Áæð|çð\*Áæðç^A@Áæð}\*á^  
 æð}\*æð|æðA@Áæð|Áæð|ç|ç^|Áæð|Áæð|æð|æðæð





# OPERATION

0E. æ•Ää~^} æ^Ä@Ääæ|Ää-^~} cæÄ| & Ä @}  
 c|} ä•ÄY @} Ä} \* æ^äÄ@ ^Ää-^~} cæÄ| & Ä ä|  
 | ^c^} Ä| |Ää äÄ@Ääæ|Ä~| { Äc|} ä•ÄÖ|ä\*  
 } |{ æÄ~ cæ\* Ä&| ää~} •Ä| & ä\* Äc@Ää-^~} cæ|  
 | | cæ^•Ä| Ä^} ^Ää äÄ @~| äÄ| cæ^Ä•^äÄ

[illegible]

U] ^!æcā } ÁÛ^&amp;cā } Á-Ë€

# OPERATION


©2013 Alamo Group Inc.

**⚠ WARNING**

P^c^i^A^S^æ^A^c@A[,^i^A^}æ^}a^aA^@^A^c@A^æ^A^A^c@A^æ^a^  
 ]|^æ^}E^A^@^A[,^i^A^|a^A^æ^}æ^}•q^\*^A^i^q^•^A^b^i^A^A^}^}^A^@  
 {q^@^æ^c^i^c^}q^A^A^}a^i^A^@^A[,^i^A^i^o^t^E^D



**⚠ DANGER**

[illegible]

## **9.OPERATING THE BOOM UNIT AND ATTACHED HEAD**

**THE OPERATOR MUST COMPLETELY UNDERSTAND HOW TO OPERATE THE TRACTOR AND MOWER AND ALL CONTROLS BEFORE ATTEMPTING TO MOW.**

[illegible]

U)|'Á|]'^|æ^Á@^Á|,|^|Á@æ^Á|[{^Á@^Áæ&|Á|]'^|æ|q^Á^æ^Á~@^Á@^Á^æ^|ç^Á&|^|'Áæç|^á|ÉÁ|]'  
 []|^|æ^Áæ^Á[[{^Áæ^Á~^Á|^á@æ^Á|^Áæ^Á^Á^Áæ&|^Á@æ^Á~^Á|^á^Á~@æ^Á|]'^|æ^Á|]'æ^Áæ^ç|É|]'ç&ç^á  
 |æ^Á~^Á^Á^Á|^|'Á|æ^Á|^Áæ^Á^Áæ&|^Á~^Á|^á^Á~@æ^Á|U|U|U|U|^Á|^|æ|^Áæ^ç^Á&^Á|^Á

[illegible]

**⚠ WARNING**

01A[01, A, a@, [A a@ ^•A A@Aa ^AaAa c&] 01 a@OaAa@ !•A a@A A a a[ , • &| • ^a@A OT EFFD

**⚠ WARNING**

[illegible] $\mathcal{O}[\{$ 

U] ^!æā } Â^ &amp;ā } Á-Ë-G





# OPERATION

[illegible][illegible]

V@Àà[[{ Áàà Áààà@À Áà àÁ ] ^!æ^Á ~|ç|Á@àà^Á } ^ÁàÁàà^ ÁÁ | Áàà à^Áà \*^Á ÁÇ^ ^àà } Á& } d|  
à } | Áàà } • ÈÁ/ @ Áààà@ àÁ@ àà^ Áà^ Áà^ à^ ^àÁ | Áà^ ^!^ | àà } | Áàà } • ÈÁ/ @ Á@ ààÁ @ ^|àÁ^ Á^ ^!^ &c àÁàè àà  
[ ] Á@ Á [ , à \* Áà } | Áàà } Áà àÁ@ Á &àà } Á@à@ ÁÁ } àÁ Áà \* Á | ^!æ^àÈ

Ü^Λ!Á! Á@Á•^ { à! Æ^&á } Á Á@Á æ ~ æÁ! Á ) • ! Á@Á@ æÁ! Á [ ] ^ ! Á æ æ@ á! Á Á@ Á [ [ { Á æ@ á! á @ á! æ | á! Á ^ Á Á! [ ] ^ ! Á } } ^ & á! ÜOPS-B- 0010

[illegible]



Q | Á& ǎ \* Á!~ • @ǎǎ Á• ~ ǎ | Á!• ǎǎ Á• ǎ | Á@ Áǎǎ | Áǎ á Á , ǎ | Á@ Á! [ [ Áǎ á Á [ , ^! Áǎ ǎ Á | ǎǎ ^ É/ @  
@ |ǎ [ ] ǎǎ | [ • ǎǎ ] ǎ \* Áǎǎ | Á | Á@ Á! [ [ Áǎ Á!• ǎ ] ^ Áǎ Á | [ • ǎǎ ] Á@ Á& ǎ \* Á@ ǎǎǎ á Á | [ ǎǎ Áǎǎǎ ǎ á  
| ]!•• ^! Á! | ǎ Á @ | Á ǎ•• ǎ ^ Á |!•• ^! Áǎǎ | ǎ á Á Á@ Á! [ [ É

**CAUTION**

DO NOT Á•^Á'ç&••ä~Ä!|&Á @}Ä[•ää}ä \*Á& ää \*Á@ääÄ q Ä@æ Ä!æ &@•Ä!Äč{ ]•È  
Öæ æ^Ä Ä@Ä} ää æÄ• |dQf Ä••Ä Ä•Ä@& ü!Ä@ääÄäææ æ+||, |Ää@æ\*Ä ää \*  
þàÈ

**⚠ CAUTION**

ÁÁÁ |æ^ Áá| Á | Á | Á | Á | , ^!Áá^& Ááæ • ä \* Ááæ | Á | Áá^& { ^ Á } • æ | Á | [ ç^ Áá@ Áá | [ {  
 % | , æá+ Áá áÁ | ~ cÁ | Á | á | ç^ Áá | ä \* Á | Á@ Ááæ | Á | Á | , ^!Áá^& Á | Á | [ ^ áÁá áÁ @ c  
 á | , } Á | áÁÁ | Á | Á | [ ç | Á | Á | • Á | { [ ç^ Á | æ^ Á | { Á | , ^!Áá^& È

V@Á [ , ^!Á á!Á ] ^!æÁ [ ^!Á -æÁ ] d'Á Á \* @!Á ] áá ] .Á áÁ áÁ .Á [ , ^!Á @Á ] Á .Á Á ^Á ] Á @Á É Á @Á [ , ^!Á ^Á \* Á .Á Á áá æÁ Á d' ] Á @Á áá d' É & Á ] Á áÁ ] á ] ^Á Á Á @Á ] á á!Á ] Áá æÁ æ ^Á Á ] Á .É Y @ ] Á ^ ] áá \* Á ] Á .Á ^Á ] áá Á Á ] Á .Á , áÁ , Á ] Á .Á Á ) ^!Á [ ] ^!Ááá & Á [ Á @Á [ , ^!Á á!Á [ c ááá áÁ ^Á ^!Á ááá ] Á á!Á ^Á ] áá Á ] Á .Á áÁ ] ^ ^ áá ^á Á ^Á .Á É

Ó\* ā Āā æ • ÁēÁ@Ā | Áā^Ā Á@Ā^• Áē āĀ [ \ Āā[ , } Á āŌāæŌ} • ^& ā^Ā æ • ÈY @} Áē āē \* Áē^• Áē ā  
• @ • ā • É • ^ Āā [ , ^ Ā ] ^^ āĀ āē [ , Á@Ā ] ā^• Áē ^Ā Áē Ōē Á || Áē ā ~ | & @ Āā | āē ^È

## **⚠ WARNING**

Qá•œâ!•Á]||æ@æ æ@ÁÆÁ^Á @Á [ , ^!Á Á ] ^!æ } Á } [ , ^!Á , æ@Áæææ  
ã { ^!æ ^!ÆÆÁ @c[ , } É ^!^!Áæ ^!Á@Áæ : Á | Á || , Á •œâ!•Á Á ]||æ@æ æ@ \$00  
**FEET** Á Á@Á } á } cÁ Á [ c } Á d } •& { } | ^!É

[illegible]

Ó~\* á Áæ@ æ·Áæ@Á [ Áæ^Á Á@Á^·Áæ áÁ [ \ Á[ , } Á æ@Áæ@ }·^& æ^Á æ·ÉÁ^Áæ[ , Á]^áÁæ æ[ , Á@Á&æ \* Á[æ^·Áæ ÁæÁ Á ~|&Áæ Á ^|Áæ Á& á@Á [ æ^ÉÁ @) Á@Áæ æ·Á@Áæ·Á Áæ^É áæ^)\* æ^Á@Á [ , ^|Áæ áÁ^ç!) Á[[{ Á Áææ^Áæ^Á[·æ] ÉÁ^ç!) Á Áææ\* Á[ áæ áÁ æ^Á^ææ·É ^æÉ

0E'Á@~Áã•óã æ Á[ Á] ^'æ } Ë[Á[ |•Á @ ~|áÁ^Á&@& ^áÁæ áÁã @ ^) ^áÁ^& ^'Á[ ËV@Á @ ~|áÁ^Áã[ ] ^ ^'á áãæ[ Á[ Á] • ^'Á@Á[ |•Á[ Á[ óã&[ { ^'Á[ [•^Áæ áÁæ • ^Áæ æ ^'Á[ Á@Áæ[ |Á[ Á[ , ^'Ë[Á[ ß ^'Á[ Á@ [ ] ^'æ |Ë

$$\mathcal{O}[\{$$

U] ^{|æǣ} Â^&ǣ} ÁĤÎ



©2013 Alamo Group Inc.

# OPERATION

## 9.8 Shutting Down the Attached Head- For Standard Equipment

1. Turn the engine off by pulling the engine stop switch (located on the right side of the operator's seat).

2. Turn the PTO off by pulling the PTO stop switch (located on the right side of the operator's seat).

3. Turn the transmission off by pulling the transmission stop switch (located on the right side of the operator's seat).

4. Turn the parking brake off by pulling the parking brake stop switch (located on the right side of the operator's seat).



On-Off Switch

5. Turn the PTO off by pulling the PTO stop switch (located on the right side of the operator's seat).

6. Turn the transmission off by pulling the transmission stop switch (located on the right side of the operator's seat).

7. Turn the parking brake off by pulling the parking brake stop switch (located on the right side of the operator's seat).




8. Turn the engine off by pulling the engine stop switch (located on the right side of the operator's seat).

9. Turn the PTO off by pulling the PTO stop switch (located on the right side of the operator's seat).

10. Turn the transmission off by pulling the transmission stop switch (located on the right side of the operator's seat).

11. Turn the parking brake off by pulling the parking brake stop switch (located on the right side of the operator's seat).



# OPERATION

- 
- A black and white photograph of a Case IH 8255 tractor. The tractor is shown from a front-three-quarter view, parked on a gravel or dirt surface. Its front loader bucket is raised and tilted to the left. The tractor has large, deep-tread tires on the front and slightly smaller ones on the rear. The Case IH logo is visible on the side of the hood. In the background, there are trees and a clear sky.

**⚠ DANGER**

**⚠ DANGER**

**⚠ WARNING**

[illegible]
$$U] \wedge \{ \text{æ} \} \} \hat{A} \wedge \{ \text{ç} \} \} \hat{A} \hat{E} \in$$



## OPERATION

[illegible][illegible]

# OPERATION

[illegible][illegible][illegible]

# OPERATION


Y @}A []^!æþ\* A []}A~ à|æA []æþÆ @æþ  
 &[]}æþ!æþ}A[]A @!A[]æþA•^!•ÆU~||A[]A @Aæþ  
 [-A @A[]æþA &æþ}æþ}A[]A[] , AæþA[] || , æþ\* Aæþ-æþ  
 d Aæþ•ÆU[] A[]A æþAæþA @A~æþ}A[]^!æþAæþ AæþAæþ  
 ^[]^!AæþA[]A[] }æþæþ A[]Aæþæþ |c |æþAæþd |•È  
 O[] æþAæþAæþA[] @}A[]æþ•[] |c |æþ\* A @A[]æþd |Aæþ à  
 { [ , ^!A[] }A[]~à|æA[]æþ•ÆU~^æþ}A[]A~•AæþAæþ•È  
 @A[] [ { Aæþ } à•A[] Aæþ @Aæþ@!A @}A @A[]æþd |•  
 , æþO[] [ AæþAæþ~|A @!AæþA[] A~•æþ à^!•ÆU[]^!•È  
 |æþ^A[] à•d~&[] }•A[]Aæþ^A~æþA~AæþAæþ æþAæþA  
 ]æþA~A @A[] [ , ^!A @æþA[]A[] [ { ÈA~^!æþd }Aæþ à  
 |A~&A[]^!æþA @!A~æþA~A[]A[]A~Aæþ•AæþAæþ  
 @Aæþæþ OPS-B- 0016



Þ^ç^!Aæþ , AæþA~^}A[]A @!A[]^!•[]•A[]AæþA}A @A[]æþd |A[]A[] |^ ^}È  
 Oæþ}A~Aæþ Aæþ~|æþ Aæþ}•Aæþ |^A[]AæþAæþAæþ



T æþAæþ!æþ AæþA @A[] , AT [ çæþ\* AX^æþA~Aæþ XDAæþ }Aæþ•æþAæþ  
 •~&æþ æþAæþ AæþAæþAæþ^æþ^AæþæþAæþ àA~æþAæþ AæþAæþ•[] |c |æþ\* A @  
 O~æþ { ^}A~•A @A[]æþd |A[]æþ O}A æþ}Aæþ @Aæþ àA[] || , AæþA[] &æþ  
 dæþA~^!æþ }•Aæþ }•ÆU[]




U^!æþ &A[]^!æþA~^!A~^!}æþ\* A[]Aæþ |c |æþ\* A @A[]æþ•È  
 O}•^!A @æþA[] O[] æþA[]Aæþ AæþA[] &Aæþ^!•^ @!  
 , @}A[]^!æþ\* A[]A~à|æA[]æþ•È OPS-U- 0023



# OPERATION

[illegible]

Op - 46

[illegible]

W^A^A a~ a~ a~ | A • a^A A a^A | a~ a^A d a~ | A a^A a^A  
 ~ a { ^ } a^A A a^A • | [ | a^A @ A a^A | A a^A a^A | ^ { ^ } d  
 O | • | a^A a^A a^A | a^A a^A a^A | a^A a^A a^A | [ | a^A  
 ~ a { ^ } a^A ~ a^A a^A a^A a^A • a~ a~ a~ | A a^A a^A a^A a^A • E  
 @ a~ a^A c^A d a^A • E a~ a^A a^A a^A | a^A a^A a^A • E a^A a^A | ^ | A a^A  
 a^A , } a^A a^A a^A a^A | a^A a^A a^A a^A a^A a^A | A a^A a^A a^A a^A  
 | [ | a^A a^A a^A , } | A a^A a^A • a~ a^A a^A a^A a^A a^A a^A a^A a^A  
 { a^A ~ a^A a^A | a^A EOPS-U-0025



Op-47

$$\dot{O}[\cdot] \{$$

U] ^{|æcā} Â^&cā} Á-Ë |

# OPERATION

OE!æ \*^Á@Á&@æ •Á•[ Á@æÁ, @}Áæ @}^áÆ@  
 &@æ •Á æ^Á~||æ \*Á[ }, æáÁ æ áÁ æ æ •c  
 @ { •^|ç^•Æ@æ^~||^ Áæ @} Á@Á^&|æ \*Á&@æ •Á!  
 [ @!Áæ @}^•Á •æ \*Áæ [[ { ^!•Á! Áæ á^•Áæ Áæ ]|^  
 { ææ ~{ Á @} •æ } Æ Á^Á^Áæ^ { ^Á &æ^Á, @}  
 ææ&@æ \*Áæ áÁ^ [ çæ \*Á@Á^&|æ \*Áæçæ •Áæ Á@  
 ^æ^ { ^Á@} •æ } Áæ ç [ ç^áÁ, @} Á^|ææ^áÁæ Á@  
 ] [ @} ææ Áæ æ æ^Áæ ~•Áæ b|^E

Y @Áæ æ|æ \*Á@Áæææ!Áæ áÁæ ]|^ { ^} æ^  
 [ &æ æ } æ^•æ ] •Áæ Á&@æ Á@æ Á@Áæææ!Áæ á  
 æ ]|^ { ^} áæ^Á [ á [ ç^áÁ!Á ææ áÁæ áÁ@æ Á@  
 •^&|æ \*Á&@æ •Áæ^Á æ ææ^áÁ} •æ } Æ Á^Á!æ \*  
 çæ •] [ |æææáÁæ æ æ^Áæ Áæ } æ^Á! ^!çæ \*  
 ææ } Áæ á^| { ^áææ ] Áæ@Á^ææ^Áæ ææ }  
 ç Áæ •] ^&@Á^&|æ Áæ Á@Áæ ææ OPS-U- 0026



## CAUTION

Qææ^Áæ Á [ á^!^æç^Áæ@Á [[ { Á æ^} áÁ Á, æ \*Áæ, æá •Á@Á, ^!Áæ^Æææ^Á @!  
 ]^!•] } ^!Áææ^Áæ } ç [ Áæ Á, æ \*æ \*Á [ æ } Á @} Áæ|æ á^!Áæ Áæ Á^ [ ç^áÆ æ^Á!^Á@  
 ]^!•] } ^!Áæ^Á [ æ Áæ ] •æ } Áæ Áæ^Áæ!Áæ •@áÁæ Áæ, æ \*æ \*Áæ [[ { Æ

Ü^ææÁ, æ^Áæ|æ|æ á^!Áæ áÁ^&|æ^Áæ Áæ Áæ ^Æ|æ|æ Áæ [[ { Á! , æáÁæ Á@Áæ } ç^Á Áææ^áÁæ, ^!Áæ&Á } ç  
 @ Áææ^Áæ^áÁæ áÁ @ á^ Á@ Áæææ|Æ@ Áæææ|æ áÁ@Á [ , ^!Á@æá@ |áÁ [ , Á^Áæ^áÁæ, } Á^&|æ^  
 ç Á@ Áææ^Áæ^áÁæ

## CAUTION

Qææ^Áæ æ^Áæ Á@Á ] ^!ææ \*Á^&æ } Æ! Áæ^Á @!Á^&æ } Áæ Áæ æ æ^Á Á [ áæ { ]|^  
 ~} á^!•ç [ áÆ& } ææ^Á [ ^!Áæ^Áææ^Á! Á@ Áææá!••Á } Á@Áæ ç^Á Áæ Áæ æ æ^Á!  
 æ •æ æ &^Á

OPERATION

OPERATION

Ó[[{

U] ^!æĭ } Á^&ā } ÁĒ î

# **MAINTENANCE SECTION**

Maintenance Section 4-1

# MAINTENANCE

## MAINTENANCE

### General Instructions

Tiger Mowers are designed for high performance and rugged durability, yet with simplified maintenance. The purpose of this section of the manual is to help the operator in the regular servicing of the mower. Regular maintenance at the intervals mentioned will result in the maximum efficiency and long life of the Tiger Mower.

When you purchase a Tiger Mower you also acquire another valuable asset, Tiger's parts organization. Our rapid and efficient service has guaranteed the customer satisfaction for many years. Tiger parts keep up with the demands for efficiency, safety and endurance expected of the Tiger Mower.

### Maintenance Precautions

- Be sure end of grease gun and zerks are clean before using. Debris injected into bearings, etc. with grease will cause immediate damage.
- DO NOT use a power grease gun to lubricate bearings. These require very small and exact amounts of lubrication. Refer to the detailed maintenance section for specific lubrication instructions. DO NOT over-grease bearings.
- Lexan windows should be washed with mild soap or detergent and lukewarm water, using a soft clean sponge or soft cloth. DO NOT use abrasive or alkaline cleaners or metal scrapers on lexan windows!
- Be alert to maintenance indicators such as the in-tank filter pressure gauge, hydraulic reservoir sight gauge, etc. Take the required action to correct any problems immediately.
- Release of energy from pressurized systems may cause inadvertent actuation of cylinders, or sudden release of compressed springs. Before disconnecting any hoses, relieve pressure by shutting tractor off, setting cutter on ground and actuating lift valve handles.

#### **WARNING**

DO NOT use hands to check for suspected leaks in hydraulic hoses! Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin and cause serious injury. If fluid is injected into skin, it must be surgically removed within a few hours or gangrene may result. Use a small piece of wood or cardboard, not hands, to search for pin hose leaks. Be sure all connections are tight and hoses and lines are not damaged before applying pressure.

### Break in Period

In addition to following the break-in instructions for your particular tractor, the in-tank hydraulic fluid filter should be replaced after the first 50 hours of service. Thereafter the filter should be replaced every 500 hours, or yearly, whichever comes first.

Re-torque wheel lugs after first five hours of operation and periodically thereafter. See torque specifications listed in the tractor's service manual for your particular model. **Wheel lugs must always be re-torqued whenever a wheel is removed and reinstalled.**

#### **⚠ DANGER**

Never work under the Implement, the framework, or any lifted component unless the Implement is securely supported or blocked up to prevent sudden or inadvertent falling which could cause serious injury or even death. (SG-14)





# MAINTENANCE




Do not modify or alter this Implement. Do not permit anyone to modify or alter this Implement, any of its components or any Implement function. (SG-8)



Relieve hydraulic pressure prior to doing any maintenance or repair work on the Implement. Place the Mower Head on the ground or securely supported on blocks or stands, disengage the PTO, and turn off the engine. Push and pull the control Levers or Joystick several times to relieve pressure prior to starting any maintenance or repair work. (SBM-6)




Always disconnect the wire leads from the mower pump solenoid before performing service on the Tractor or Mower. Use caution when working on the Tractor or Mower. Tractor engine must be stopped before working on Mower or Tractor. The Mower Blades could inadvertently be turned on without warning and cause immediate dismemberment, injury or death. (SBM-12a)



## MAINTENANCE OF CRANKSHAFT ADAPTER ASSEMBLY (RIGID ENGINE MOUNT TRACTORS ONLY)

If replacement of components of the crankshaft adapter assembly is required, follow the assembly procedures shown below. Seat rubber grommet completely into counterbore, then seat steel grommet completely into rubber grommet while rubber grommet is supported.

(ASM-JD-0051 CRANKSHAFT ADAPTER MAINTENANCE)



# MAINTENANCE

## Regular Maintenance

The intervals at which regular servicing should be done are based on hours of operation. Use the tractors hour meter to determine when regular servicing is required.

Refer to the Detailed Maintenance section for further instructions on greasing. Copy and use the Daily Maintenance sheet located at the end of this section.

### Daily or Every 8 Hours

| ITEM  | SERVICE               | COMMENTS   |
|---|-----------------------|--|
| Drive Shaft Yoke, U-Joint & Stub Shaft                        | Grease                | Grease as instructed in detailed maintenance section                             |
| Pump Drive Shaft Coupler                                      | Check and Lube        | Insure driveshaft end play   |
| Crankshaft Adapter  | Check rubber grommets | Replace grommets if damaged or missing   |
| Pivot Points  | Lubricate             | Inject grease until it appears at end  |
| Hydraulic Fittings  | Check for leaks       | Tighten when needed. Do Not use hands to check for leaks, see maint. precautions |
| Knives  | Check                 | Inspect for missing or damaged knives, change as needed.                         |
| Spindle mouting bolts (spindle to deck)                       | Check                 | Torque to 315 ft. lbs. lubricated<br>Torque to 357 ft. lbs. dry                  |
| Knife mounting bolts (knife to disk or blade bar)             | Check                 | Pre-lubricate threads with anti-seize torque to 800 ft. lbs.                     |
| Disk/Blade Bar mounting bolts (disk/blade bar to spindle)     | Check                 | Torque to 180 ft. lbs. lubricated<br>Torque to 204 ft. lbs. dry                  |
| Belts   | Check/Adjust          | Check if broken, tighten as required   |
| Main Frame and Deck   | Check                 | Retorque bolts to torque specifications in this section                          |
| Hydraulic Fluid Level   | Check                 | Add if required per fluid recommendations  |
| Rear Flail Drive(if applicable) Bear Flange and Shaft Coupler | Lubricate             | Grease as instructed in detailed maintenance section                             |
| Cutter Shaft and Boom   | Lubricate             | Grease as instructed in Maintenance Section 4-4                                  |

# MAINTENANCE

## MAINTENANCE

Ground Roller

detailed maintenance section

### WEEKLY OR EVERY 40 HOURS

| ITEM           | SERVICE   | COMMENTS                 |
|----------------|-----------|--------------------------|
| Rotary Spindle | Lubricate | Every 40 hours or weekly |

### WEEKLY OR EVERY 50 HOURS

| ITEM  | SERVICE | COMMENTS   |
|---|---------|--|
| In Tank Hyd. Fluid Filter<br><b>(10 micron filter)</b>    | Change  | Change after first 50 hours only, then every 500 hours or yearly |
| In-Line High Pressure Filter<br><b>(10 micron filter)</b> | Change  | Change after first 50 hours only, then every 500 hours or yearly |

### MONTHLY OR EVERY 150 HOURS

| ITEM  | SERVICE                      | COMMENTS                             |
|---|------------------------------|--------------------------------------|
| Hydraulic Fluid Level                             | Check                        | Add as needed                        |
| Hyd. Tank Breather                                | Clean/Check/Replace          | Clean or replace element as required |
| Rear Tire Type<br>480/80R38<br>18.4-34<br>18.4-38 | Max P.S.I.<br>29<br>26<br>26 |                                      |

### YEARLY OR EVERY 500 HOURS

| ITEM  | SERVICE                    | COMMENTS  |
|---|----------------------------|---|
| Spindle Grease<br>Hyd. Tank Fluid<br>In Tank Hyd. Fluid Filter<br><b>(10 micron filter)</b> | Change<br>Change<br>Change |   |
| In-Line HP Filter<br><b>(10 micron filter)</b>  | Change or                  | Change when indicated by restriction indicator. |
| Hyd. Tank Breather  | Change                     |   |

Boom

Maintenance Section 4-5

# MAINTENANCE

## TROUBLESHOOTING

| SYMPTOMS                           | CAUSE  | REMEDY  |
|------------------------------------|--|---|
| <b>Vibration</b>                   | 1. Loose bolts                                 | 1. Check all bolts and tighten to recommended torque specs.   |
|                                    | 2. Cutter assembly unbalanced                  | 2a. Check for damaged blades, disc or cuttershaft. Replace if needed.<br>2b. Check for wire, rope, etc. entangled in the cutter assembly  |
| <b>Mower will not lift</b>         | 1. Hyd. Fluid Low                              | 1. Check and refill hyd fluid   |
|                                    | 2. Leaks in line ROU<br>3. Faulty relief valve | 2. Tighten or replace fittings and hoses<br>3. Check pressure in line. Line pressure in control valve should be at least 2500 P.S.I.  |
|                                    | 5. Faulty cylinder                             | 5. Inspect, repair or replace cylinder  |
| <b>Mower will not start or run</b> | 1. Blown fuse                                  | 1. Check fuse between mower switch and ignition/replace   |
|                                    | 2. Ball valves closed                          | 2. Make sure valves are open  |
|                                    | 3. Low oil level                               | 3. Check hyd. tank and fill   |
|                                    | 4. Line leak                                   | 4. Check all fittings and lines, re-tighten or replace  |
|                                    | 5. Electronic solenoid faulty                  | 5a. Without the tractor running, turn the mower switch to on. A low audible click should be heard if the solenoid is engaging the solenoid spool. If click is not heard, leave switch in on position and with a screwdriver or other steel object, touch the small nut on the end of the solenoid. If the metallic object is not attracted to the nut, check the fuse and wiring for an open circuit. If the object is attracted but no "click" is heard, replace the solenoid.<br>5b. Remove the four bolts holding the small block to the main block. Lift and remove small block being careful not to damage O-rings/filter. Clean filter and re-install.<br>5c. Remove large nut on side of large valve block. Remove spring, and use needle nose vise grip to pull spool from block. Check block and spool for contaminants and scratches. |

# MAINTENANCE

Clean parts or replace if scratched.

## TROUBLESHOOTING (CONTINUED)





| SYMPTOMS                                 | CAUSE   | REMEDY  |
|--|---|---|
| <b>Motor runs but will not cut.</b>      | 1. Belts  | 1. Inspect belts and pulleys. Replace belts and repair as needed.   |
|  | 2. Tensioner  | 2. Adjust tensioner nut flatwasher washer is flush with top of guide.   |
| <b>Mower turns slowly or not at all.</b> | 1. Contaminants restricting spool movement in valve body. | 1. Remove large nut on side of large valve block. Remove spring, and use needle nose vise grip to pull spool from block. Check block and spool for contaminants and scratches. Clean parts or replace if scratched. |
|  | 2. Suction lines obstructed                               | 2. Check for kinks or obstruction in suction hose.  |
|  | 3. Low oil level  | 3. Check hyd. tank level and fill.  |
| <b>Pump will not work</b>                | 1. Excessive wear on internal parts                       | 1. Disassemble and repair.  |
| <b>Motor will not work</b>               | 1. Excessive wear on internal parts                       | 1. Disassemble and repair.  |

NOTE: If flow meter is available, check pressure and flow volume for all suspected hydraulic problems.

If the solution to your problem cannot be found in this section, call the Technical Service representative at the number shown on the front cover of this manual.

# MAINTENANCE

## Torque for Standard Fasteners





| Nominal Dia.<br>(in.)               | threads per inch |  Grade 2 |            |           |  Grade 5 |            |            |  Grade 8 |            |            |  Grade 9 |            |            |
|-------------------------------------|------------------|---|------------|-----------|---|------------|------------|---|------------|------------|---|------------|------------|
|                                     |                  | Tightening Torque   |            |           | Tightening Torque   |            |            | Tightening Torque   |            |            | Tightening Torque   |            |            |
|                                     |                  | Lubed   | Dry Plated | Dry plain | Lubed   | Dry Plated | Dry plain  | Lubed   | Dry Plated | Dry plain  | Lubed   | Dry Plated | Dry plain  |
|                                     |                  | K = 0.15  | K = 0.17   | K = 0.20  | K = 0.15  | K = 0.17   | K = 0.20   | K = 0.15  | K = 0.17   | K = 0.20   | K = 0.15  | K = 0.17   | K = 0.20   |
| <b>Unified Coarse Thread Series</b> |                  |   |            |           |   |            |            |   |            |            |   |            |            |
| 1/4                                 | 20               | 49 in-lbs   | 59 in-lbs  | 66 in-lbs | 76 in-lbs   | 86 in-lbs  | 101 in-lbs | 107 in-lbs  | 122 in-lbs | 143 in-lbs | 126 in-lbs  | 143 in-lbs | 168 in-lbs |
| 5/16                                | 18               | 101   | 122        | 135       | 157   | 178        | 209        | 221   | 251        | 295        | 259   | 294        | 346        |
| 3/8                                 | 16               | 15 ft-lbs   | 18 ft-lbs  | 20 ft-lbs | 23 ft-lbs   | 26 ft-lbs  | 31 ft-lbs  | 33 ft-lbs   | 37 ft-lbs  | 44 ft-lbs  | 38 ft-lbs   | 43 ft-lbs  | 51 ft-lbs  |
| 7/16                                | 14               | 24  | 29         | 32        | 37  | 42         | 49         | 52  | 59         | 70         | 61  | 70         | 82         |
| 1/2                                 | 13               | 37  | 44         | 49        | 57  | 64         | 75         | 80  | 90         | 106        | 94  | 106        | 125        |
| 9/16                                | 12               | 53  | 63         | 70        | 82  | 92         | 109        | 115   | 130        | 154        | 135   | 153        | 180        |
| 5/8                                 | 11               | 73  | 87         | 97        | 113   | 128        | 150        | 159   | 180        | 212        | 186   | 211        | 248        |
| 3/4                                 | 10               | 129   | 155        | 172       | 200   | 227        | 267        | 282   | 320        | 376        | 331   | 375        | 441        |
| 7/8                                 | 9                | 125   | 150        | 167       | 322   | 365        | 429        | 455   | 515        | 606        | 533   | 604        | 710        |
| 1                                   | 8                | 187   | 225        | 250       | 483   | 547        | 644        | 681   | 772        | 909        | 799   | 905        | 1065       |
| 1 1/8                               | 7                | 266   | 319        | 354       | 596   | 675        | 794        | 966   | 1095       | 1288       | 1132  | 1283       | 1510       |
| 1 1/4                               | 7                | 375   | 450        | 500       | 840   | 952        | 1121       | 1363  | 1545       | 1817       | 1597  | 1810       | 2130       |
| 1 1/2                               | 6                | 652   | 783        | 869       | 1462  | 1657       | 1950       | 2371  | 2688       | 3162       | 2779  | 3150       | 3706       |

## Fine Thread Series

| Nominal Dia. | Threads per inch | 56 in-lbs | 68 in-lbs | 75 in-lbs | 87 in-lbs | 99 in-lbs | 116 in-lbs | 123 in-lbs | 139 in-lbs | 164 in-lbs | 144 in-lbs | 163 in-lbs | 192 in-lbs |
|--------------|------------------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|------------|------------|------------|------------|
| 1/4          | 28               | 56 in-lbs | 68 in-lbs | 75 in-lbs | 87 in-lbs | 99 in-lbs | 116 in-lbs | 123 in-lbs | 139 in-lbs | 164 in-lbs | 144 in-lbs | 163 in-lbs | 192 in-lbs |
| 5/16         | 24               | 112       | 135       | 150       | 174       | 197       | 231        | 245        | 278        | 327        | 287        | 325        | 383        |
| 3/8          | 24               | 17 ft-lbs | 20 ft-lbs | 23 ft-lbs | 26 ft-lbs | 30 ft-lbs | 35 ft-lbs  | 37 ft-lbs  | 42 ft-lbs  | 49 ft-lbs  | 43 ft-lbs  | 49 ft-lbs  | 58 ft-lbs  |
| 7/16         | 20               | 27        | 32        | 36        | 41        | 47        | 55         | 58         | 66         | 78         | 68         | 78         | 91         |
| 1/2          | 20               | 41        | 49        | 55        | 64        | 72        | 85         | 90         | 102        | 120        | 105        | 120        | 141        |
| 9/16         | 18               | 59        | 71        | 78        | 91        | 103       | 121        | 128        | 146        | 171        | 151        | 171        | 201        |
| 5/8          | 18               | 82        | 99        | 110       | 127       | 144       | 170        | 180        | 204        | 240        | 211        | 239        | 281        |
| 3/4          | 16               | 144       | 173       | 192       | 223       | 253       | 297        | 315        | 357        | 420        | 369        | 418        | 492        |
| 7/8          | 14               | 138       | 165       | 184       | 355       | 403       | 474        | 502        | 568        | 669        | 588        | 666        | 784        |
| 1            | 14               | 210       | 252       | 280       | 542       | 614       | 722        | 765        | 867        | 1020       | 896        | 1016       | 1195       |
| 1 1/8        | 12               | 298       | 357       | 397       | 668       | 757       | 890        | 1083       | 1227       | 1444       | 1269       | 1439       | 1693       |
| 1 1/4        | 12               | 415       | 498       | 553       | 930       | 1055      | 1241       | 1509       | 1710       | 2012       | 1768       | 2004       | 2358       |
| 1 1/2        | 12               | 734       | 880       | 978       | 1645      | 1865      | 2194       | 2668       | 3024       | 3557       | 3127       | 3544       | 4169       |

Torque values for 1/4 and 5/16-in series are in inch-pounds. All other torque values are in foot-pounds. K = 0.15 for "lubricated" conditions  
 Torque values calculated from formula  $T = KDF$ , where K = 0.17 for zinc plated and dry conditions  
 K = 0.20 for plain and dry conditions  
 D = Nominal Diameter  
 F = Clamp Load

## Torque-Tension Relationship for Metric Fasteners

| Nominal Dia.<br>(mm) | Pitch<br>(mm) |  Class 4.6 |            |           |  Class 8.8 |            |           |  Class 10.9 |            |           |  Class 12.9 |           |
|----------------------|---------------|---|------------|-----------|---|------------|-----------|---|------------|-----------|--|-----------|
|                      |               | Tightening Torque   |            |           | Tightening Torque   |            |           | Tightening Torque   |            |           | Tightening Torque  |           |
|                      |               | Lubed   | Dry Plated | Dry plain | Lubed   | Dry Plated | Dry plain | Lubed   | Dry Plated | Dry plain | Lubed  | Dry plain |
|                      |               | K = 0.15  | K = 0.17   | K = 0.20  | K = 0.15  | K = 0.17   | K = 0.20  | K = 0.15  | K = 0.17   | K = 0.20  | K = 0.15   | K = 0.20  |
| 3                    | 0.5           | 0.28  | 0.32       | 0.38      | 0.73  | 0.82       | 0.97      | 1.0   | 1.2        | 1.4       | 1.2  | 1.6       |
| 3.5                  | 0.6           | 0.44  | 0.50       | 0.59      | 1.1   | 1.3        | 1.5       | 1.6   | 1.9        | 2.2       | 1.9  | 2.5       |
| 4                    | 0.7           | 0.66  | 0.74       | 0.87      | 1.7   | 1.9        | 2.3       | 2.4   | 2.7        | 3.2       | 2.8  | 3.8       |
| 5                    | 0.8           | 1.3   | 1.5        | 1.8       | 3.4   | 3.9        | 4.5       | 4.9   | 5.5        | 6.5       | 5.7  | 7.6       |
| 6                    | 1             | 2.3   | 2.6        | 3.0       | 5.8   | 6.6        | 7.7       | 8.3   | 9.4        | 11        | 9.7  | 13        |
| 6                    | 1.25          | 2.1   | 2.3        | 2.7       | 5.3   | 6.0        | 7.0       | 7.6   | 8.6        | 10        | 8.8  | 12        |
| 7                    | 1             | 3.8   | 4.3        | 5.0       | 9.7   | 11         | 13        | 14  | 16         | 19        | 16   | 22        |
| 8                    | 1             | 5.9   | 6.6        | 7.8       | 15  | 17         | 20        | 22  | 24         | 29        | 25   | 34        |
| 8                    | 1.25          | 5.5   | 6.2        | 7.3       | 14  | 16         | 19        | 20  | 23         | 27        | 24   | 31        |
| 10                   | 1.25          | 11  | 13         | 15        | 29  | 33         | 39        | 42  | 48         | 56        | 49   | 66        |
| 10                   | 1.5           | 11  | 12         | 14        | 28  | 32         | 37        | 40  | 45         | 53        | 47   | 62        |
| 12                   | 1.25          | 21  | 23         | 28        | 53  | 60         | 71        | 76  | 86         | 101       | 89   | 119       |
| 12                   | 1.5           | 20  | 22         | 26        | 51  | 58         | 68        | 73  | 82         | 97        | 85   | 113       |
| 12                   | 1.75          | 19  | 21         | 25        | 49  | 55         | 65        | 70  | 79         | 93        | 81   | 108       |
| 14                   | 1.25          | 26  | 29         | 34        | 66  | 75         | 89        | 95  | 108        | 127       | 111  | 148       |
| 14                   | 1.5           | 28  | 32         | 37        | 72  | 82         | 96        | 103   | 117        | 138       | 121  | 161       |
| 14                   | 2             | 30  | 34         | 40        | 78  | 88         | 104       | 111   | 126        | 148       | 130  | 173       |
| 16                   | 1.5           | 50  | 57         | 67        | 129   | 146        | 171       | 184   | 208        | 245       | 215  | 287       |
| 16                   | 2             | 47  | 53         | 62        | 121   | 137        | 161       | 173   | 196        | 230       | 202  | 269       |
| 18                   | 1.5           | 73  | 82         | 97        | 187   | 212        | 249       | 268   | 303        | 357       | 313  | 417       |
| 18                   | 2.5           | 65  | 73         | 86        | 167   | 189        | 222       | 239   | 270        | 318       | 279  | 372       |
| 20                   | 1.5           | 101   | 115        | 135       | 270   | 306        | 360       | 374   | 424        | 498       | 437  | 583       |
| 20                   | 2.5           | 91  | 104        | 122       | 236   | 267        | 314       | 337   | 382        | 449       | 394  | 525       |

Clamp load calculated as 75% of the proof load for specified bolts. K = 0.15 for "lubricated" conditions  
 All torque values are listed in foot-pounds K = 0.17 for zinc plated, dry conditions  
 Torque values calculated from formula  $T = KDF$ , where K = 0.20 for plain and dry conditions  
 D = Nominal Diameter  
 F = Clamp Load

# MAINTENANCE

## LUBRICATION RECOMMENDATIONS

## MAINTENANCE

| Description  | Application   | General Specification                                | Recommended Mobil Lubricant                |
|--|---------------|--|--|
| Tractor Hydraulics   | Reservoir     | JD-20C<br>MF M1135,M1141<br>FNHM2C134D (FNH201)      | Mobilfluid 424                             |
| Mower Hydraulics<br>Cold Temperatures 0° F<br>Start-Up       | Reservoir     | ISO 46 Anti-Wear-Low Temp                            | Mobil DTE 15M                              |
| Normal Temperatures<br>10° F Start-Up                        |               | JD-20C<br>MF M1135,M1141<br>FNH M2C134D(FNH201)      | Mobilfluid 424                             |
| Normal Temperatures<br>15° F Start Up                        |               | ISO 46 Anti-Wear                                     | Mobil DTE 25                               |
| High Operating Temp.<br>Above 90° F                          |               | ISO 100 Anti-Wear                                    | Mobil DTE 18M                              |
| Flail Rear Gearbox   | Grease        | PAO Synthetic Extreme<br>Pressure Gear Lube          | Mobil SHC 75W-90<br>Mobil 1 Synthetic Gear |
| Cutter Shaft & Ground<br>Roller Shaft(Flail)                 | Grease<br>Gun | Lithium-Complex<br>Extreme Pressure<br>NLGI-ISO 320  | Mobilgrease CM-S                           |
| Drive Shaft Coupler<br>(Flail and Rotary)                    | Grease<br>Gun | Lithium-Complex<br>Extreme Pressure<br>NLGI2-ISO 320 | Mobilgrease CM-S                           |
| Drive Shaft Yoke,<br>U-joint & Stub Shaft                    | Grease<br>Gun | Lithium-Complex<br>Extreme Pressure<br>NLGI2-ISO 320 | Mobilgrease CM-S                           |
| Boom Swivel<br>Boom Cylinder Pivots<br>(Rotary & Flail Boom) | Grease<br>Gun | Lithium Complex<br>Extreme pressure<br>NLGI2-ISO 320 | Mobilgrease CM-S                           |
| Deck Boom Pivot &<br>Deck Stop Adjustment<br>Rotary & Flail) | Grease<br>Gun | Lithium Complex<br>Extreme Pressure<br>NLGI-ISO 320  | Mobilgrease CM-S                           |
| Deck Spindle(Rotary)   | Grease<br>Gun | Tiger Spindle Lubricant<br>part number 06540000      | Mobilith SHC 220                           |

Boom

Maintenance Section 4-9

# MAINTENANCE

## MAINTENANCE

### POLYCARBONATE CARE AND MAINTENANCE

The propriety UV and Abrasion Resistant Surface coating on SHIELDS SUPERCOATED polycarbonate significantly improves performance. Periodic cleaning using proper procedures and compatible cleaners are recommended to prolong service life. Tiger Corp. polycarbonate is SUPERCOATED on both sides.

#### CLEANING THE SUPERCOAT HARD-COAT

1. Wash with a mild solution of soap or detergent and lukewarm water.
2. Using a soft cloth or sponge, gently wash the sheet to loosen dirt and grime and rinse well with clean water.
3. To prevent water spotting, thoroughly dry with chamois or cellulose sponge.
4. Avoid the use of abrasive cleaners, squeegees and/or other cleaning implements that may mar or gouge the coating.

#### CLEANING AGENTS WHICH HAVE BEEN FOUND TO BE COMPATIBLE UNDER LABORATORY CONDITIONS:

##### Aqueous Solutions of Soaps and Detergents

|              |                |               |             |
|--------------|----------------|---------------|-------------|
| Windex(1)    | Top Job(2)     | Joy(2)        | Mr Clean(2) |
| Fantastik(3) | Formula 409(4) | Sumalight D12 | Brucodecid  |

##### Organic Solvents

|                  |            |                 |                     |
|------------------|------------|-----------------|---------------------|
| Butyl Cellosolve | Kerosene   | Hexel, F.O. 554 | Naphtha(VM&P grade) |
| Neleco-Placer    | Turco 5042 |                 |                     |

##### Alcohols

|          |           |
|----------|-----------|
| Methanol | Isopropyl |
|----------|-----------|

All residual organic solvents should be removed with a secondary rinse.

### GRAFFITI REMOVAL

Butyl cellosolve (for removal of paints, marking pen inks, lipstick, etc.) The use of masking tape, adhesive tape or lint removal tools work well for lifting off old weathered paints.

To remove labels, stickers, etc., the use of kerosene or VM&P naphtha is generally effective. When the solvent will not penetrate sticker material, apply heat (hair dryer) to soften the adhesive and promote removal.

**IMPORTANT:** If a material is found to be incompatible in a short-term test, it will usually be found to be incompatible in the field. The converse, however, is not always true. Favorable performance is no guarantee that actual end-use conditions have been duplicated. Therefore, these results should be used as a guide only and it is recommended that the user test the products under actual end-use conditions.





# MAINTENANCE

## RECOMMENDED FILLING INSTRUCTIONS FOR HYDRAULIC RESERVOIRS

When filling or checking the oil level, the unit should be parked on a level surface., shut OFF, and allow sufficient time to cool to ambient temperature. Use caution when removing the pressurized breather. Do not place face over opening when removing breather.

If your reservoir has two sight glasses: The reservoir should be filled to the top of the lower sight glass on the side of the tank. Do not overfill. The reservoir has been overfilled when oil is visible in the upper sight glass. If tank has too much oil, the excess may be expelled through the pressurized breather.


If your reservoir has one sight glass/temperature gage: The reservoir should be filled to the center of the sight glass on the side of the tank. Do not over-fill. If the tank has too much oil, the excess may be expelled through the pressurized breather.



## DETAILED MAINTENANCE

### REPLACING IN-TANK HYDRAULIC FILTER:

Loosen the four bolts on the top cover of the filter housing. Turn cover counter-clockwise until cover is free. Remove and replace filter. Replace top cover and cover bolts in opposite order as removed.




# MAINTENANCE

## MAINTENANCE

### GREASING CUTTERSHAFT -- FLAIL MOWERS


Locate grease zerks on each end of cuttershaft(s), these are located on the bearing cover. Normal conditions require one or two pumps in each bearing, using Lithium-Complex Extreme Pressure grease confirming to NLGI2-ISO 320 specifications. This is to be done with a standard grease gun daily or at **8 hour intervals**. **CAUTION: Over greasing may cause premature seal failure.**



# MAINTENANCE


## GREASING GROUND ROLLER SHAFT-- FLAIL

Locate grease zerks on each end of roller tube at lower end of head. Normal conditions require one or two pumps in each bearing, using Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications. This is to be done with a standard grease gun daily or at **8 hour intervals**. **CAUTION: Over greasing may cause premature seal failure.**



## ADJUSTING/CHECKING BELT TENSION

To adjust belt tension or replace belts on flail cutter head, remove four bolts that secure the belt cover and remove cover. The hex nuts shown below can be adjusted to increase/decrease the belt tension as needed. (NOTE: Location of adjustment nuts may vary on flail cutter heads.) **Be sure to replace the belt cover BEFORE operating mower!**




## TIGHTENING KNIFE BOLTS AND DISK BOLTS:

After every 8 hours of operation or daily, the Knife Bolts and disk bolts should be tightened as follows:

Knife mounting bolts torque to 800 lubricated ft. lbs.

Disk mounting bolts (6ea.) torque to 204 dry or 180 lubricated ft. lbs.




# MAINTENANCE

## MAINTENANCE

### GREASING POINTS ON BOOM AND PIVOT

Locate grease zerks on deck pivot assembly, on the deck end of secondary boom, at main/secondary boom joint, and at swivel end of main boom. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications until grease begins to protrude from ends.



### DECK STOP ADJUSTMENT

On boom flail, loosen locking nut. Turn adjustment bolt in, and run deck cylinder out to full extension. Adjust bolt out until the head just touches the boom, and tighten lock nut. **NOTE: Bolt should not hit boom before cylinder reaches full travel.**



### GREASING SPINDLE


Locate grease fitting on inside of deck housing. Inject Tiger Spindle Lubricant, part number 06540000 into spindle housing. Fill with lubricant until lubricant weeps out of top spindle seal. Lubricate spindle weekly or every 40 hours of use.



# MAINTENANCE

## TIGHTENING SPINDLE BOLTS

The spindle mounting bolts should be checked and retorqued daily or every 8 hours of service. Torque the (6) bolts shown below to 357 dry or 315 ft. lbs. lubricated.



## GREASING PUMP DRIVE SHAFT COUPLER

With engine stopped, ensure driveshaft alignment by grasping coupler and sliding back and forth. Coupler should slide freely with approximately 1/8" of end play. If coupler does not slide freely, inspect for loose pump mount bolts, or damaged or loose crankshaft adapter. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications into coupler until grease begins to protrude from ends. Grease daily or every 8 hours. Do not over grease.







# MAINTENANCE

## MAINTENANCE


### DRIVESHAFT YOE, U-JOINT STUB SHAFT

With engine stopped, inject Lithium-Complex extreme pressure grease conforming to NLGI2-ISO 320 specifications into universal joints and slip yoke until grease appears at the seal. Grease them daily or every 8 hours.



### GREASING THE BOOM SWIVEL

Locate the zerks on the main swivel boss (if applicable), main boom pivot boss (if applicable) and on both ends of the boom swivel cylinder. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specification until grease begins to protrude from ends.




# MAINTENANCE

## MAINTENANCE


### GREASING BOOM CYLINDER(S) PIVOT POINTS

Locate the zerk on the butt end tang of cylinder and on rod end tang. Inject Lithium-Complex Extreme Pressure grease conforming to NLGI2-ISO 320 specifications until grease begins to protrude from ends. This procedure is to be used on the main boom cylinder, secondary boom cylinder, deck pivot, and swivel cylinders daily or at 8 hour intervals.



### BALL VALVES

The ball valve at the hydraulic reservoir may need to be closed during certain maintenance or repair procedures. **THE BALL VALVES MUST BE OPEN (handle parallel with valve) WHEN TRACTOR IS RE-STARTED OR PUMP IS COUPLED TO MOTOR OR PTO!** Failure to do so will result in component failure!



# MAINTENANCE

## Blades

Check the Blades for cracks and wear and Blade Bolts for tightness, daily. Blades should be replaced when they are worn excessively, bent, deformed, or out of balance.

### CAUTION


Blades should always be replaced in pairs. Blades of different weights can cause serious imbalance and damage to the machine and personnel. When replacing blades, take care to replace the blade bolts, nuts, and washers.




### Important


Make sure the mower blades are turning clockwise when looking down from the top of the mower. Follow the color coding on the hydraulic hoses and fittings to make sure the motor and hydraulics hoses are assembled properly. Connect the red hose connection only to red fitting. Connect the blue hose connection only to the blue fitting. The blade rotation on the leading edge of the mower should discharge the cut material away from the tractor and operator.

### WARNING

If the leading edge of the mower blades are rotating backwards they can discharge material toward the operator. If this occurs discontinue mowing immediately and reverse the direction of the motor rotation by correctly installing the motor pressure and return hoses. Contact your dealer or Alamo Industrial for specific information on the hose routing.



| <b>⚠ WARNING</b>  | <b>⚠ ADVERTENCIA</b>   |
|---|--|
| <b>TO AVOID SERIOUS INJURY AND DEATH FROM THROWN OBJECTS:</b> <ul style="list-style-type: none"><li>• MAKE CERTAIN blades rotate the correct direction.</li></ul> | <b>PARA EVITAR LESION SERIA O MUERTE POR OBJETOS LANZADOS:</b> <ul style="list-style-type: none"><li>• ASEGURE que las cuchillas giran en la dirección correcta.</li></ul> |
| <b>BLADE ROTATION</b><br>   |  |
| <b>ROTACIÓN DE CUCHILLAS</b>  |  |
| <br>Return<br>Retorno<br><b>BLUE</b>   | <br>Pressure<br>Presión<br><b>RED</b>   |



D619



# MAINTENANCE

## ROTARY KNIFE REPLACEMENT

1. Be sure you have a complete matching set of new knives for replacement.
2. Remove knives and inspect holes for damage. Also watch for cracks in the disk (if applicable) around the holes.
3. Lube threads with anti-seize. Install bolts through knife and disk from bottom side of disk/blade bar. Install new self-locking nuts and torque them to 800 ft. lbs.
4. The knives should swing freely to absorb shocks from impact when striking objects.



**WHEN CUTTING HEAVY BRUSH, KNIFE BOLTS SHOULD BE INSPECTED HOURLY AND RETORQUED TO 800 LUBRICATED FT. LBS.**

## REPLACEMENT OF ROTARY DISK/BLADE BAR



**Failure to follow the following warnings and instructions may result in serious injury or damage to the equipment or property!**

1. The bolts that attach the disk to the spindle must be grade 8. These 5/8 inch bolts are to be torqued to 204 dry or 184 ft. lbs lubricated with Loctite 271.
2. A thread locking agent may be applied to threads of all mounting bolts before they are installed.
3. **Disks must be inspected daily for hairline cracks between spindle mounting bolts or around the knife mounting bolts. These cracks indicate metal fatigue caused by severe abuse. If cracks are present the disk must be replaced.**
4. Inspect the disk mounting bolts daily when checking tightness of knife mounting bolts. If a disk mounting bolt is loose, it must be removed, threads cleaned, fresh thread locking agent applied, and tightened to proper torque value.
5. If a knife mounting bolt is loose, the self locking nut must be replaced as a safety precaution. Lubricate threads with anti-seize. Install bolts through knife and disk/blade bar from bottom side. Install self locking nuts and torque them to 800 ft. lbs.

# MAINTENANCE

## Flail Blades Inspection




Inspect the Blades daily for abnormal wear. REPLACE ALL BLADES on the carrier IMMEDIATELY if any blades have:

- Become bent or deformed from its original shape, or
- Wear inside the blade bolt hole, or
- Any cracks are visible, or
- Deep gouges in the blade's surface are present, or
- Gouges or chipped areas in the cutting edge are larger than 1/4"(8mm), or
- The material on the leading edge has been worn away by more than 1/4"(8mm)

**DO NOT** straighten, sharpen, weld or hard-face blades

Failure to replace worn or damaged blades may lead to catastrophic failure of the blades and ejection of the broken part with tremendous force which may cause serious bodily injury or death.



Always replace blades in sets

- Blades that are damaged may indicate severe service or abuse. If one blade is worn or damaged other blades on the same shaft will have been subjected to the same severe service or abuse.
- The Flail rotor turns at speeds exceeding 2000 RPM and is dynamically balanced at the factory. Differences in blade weight between used blades with loss of material from gouges or wear as compared to new blades can cause severe vibration and damage to the Flail rotor. Always replace blades as complete sets.

# MAINTENANCE

## **Blade Pins and D-Ring Inspection**

Inspect Blade Pins and D-Rings daily for wear or damage as follows:




Inspect the Blade pins and D-Rings daily for abnormal wear. Make sure the cotter pins are in place and properly spread. REPLACE BLADE Pins and D-Rings IMMEDIATELY if they have:

- Visible cracks or
- If a Pin or D-Ring has visible worn areas, or
- If a Pin or D-Ring has gouges or chipped areas

Failure to replace abnormally worn pins or D-Rings may lead to catastrophic failure and ejection of the broken part, which may cause serious bodily injury or death.

Always replace the pins and D-Rings whenever excessive wear is noticed.



### **Important**

If the cotter pins are broken by contact with other flail blades, remove the pin and reverse the direction the pin is inserted through the D-Ring so that the cotter pin is on the opposite side of the D-Ring. This will prevent the next set of blades from swinging back and hitting the cotter pin. OPS-U-0045

# MAINTENANCE

## MAINTENANCE


### Flail Axe Blades Inspection



**DANGER**

Inspect the Blades daily for abnormal wear. REPLACE ALL BLADES on the carrier IMMEDIATELY if any blades have:

- Become bent or deformed from its original shape, or
- Oval shape wear inside the blade bolt hole, or
- Any cracks are visible, or
- Deep gouges in the blade's surface are present, or
- Gouges or chipped areas in the cutting edge are larger than 1/4"(8mm), or
- The material on the leading edge has been worn away by more than 1/4"(8mm)



Failure to replace worn or damaged blades may lead to catastrophic failure of the blades and ejection of the broken part with tremendous force which may cause serious bodily injury or death.

Always replace blades in sets

- Blades that are damaged may indicate severe service or abuse. If one blade is worn or damaged other blades on the same shaft will have been subjected to the same severe service or abuse.
- The Flail Axe rotor turns at speeds exceeding 2000 RPM and is dynamically balanced at the factory. Differences in blade weight between used blades with loss of material from gouges or wear, as compared to new blades, can cause severe vibration and damage to the Flail Axe rotor. Always replace blades as complete sets.

**Important**

Use only genuine Alamo Industrial replacement blades, blade bolts and fasteners. Other blades and bolts may not meet the requirements of Alamo Industrial and may fail during operation, resulting in the part failing and being thrown out from under the mower.



**CAUTION**

Never attempt to sharpen blades. OPS-U-0042

# MAINTENANCE

## Flail Axe Blade Bolt Inspection

Inspect Blade Bolts daily for wear or damage as follows:




Inspect the Blade Bolt daily for abnormal wear. REPLACE ALL BLADE BOLTS on the carrier IMMEDIATELY if any bolts have:

- Visible cracks or
- If the blade bolt is worn or any recessed area is visible on the bolt, or
- If Blade Bolt has gouges or chipped areas. or
- If Bushing fits loose in the Rotor Shaft.

Failure to replace abnormally worn bolts or bushings may lead to catastrophic failure of the blades and ejection of the broken part, which may cause serious bodily injury or death.

Always replace Blade Bolts with new bolts and new bushings whenever replacing the Blades. To tighten bolts and nuts, first apply thread lock to nut. Make sure to tighten bolts and nuts just enough to allow the blades to swing freely and not bend the cuttershaft lugs. If cuttershaft lugs are bent together because of over tightening the blades will not swing freely. OPS-U-0043



# MAINTENANCE

## MAINTENANCE

### 50" FLAIL KNIFE BLADE REPLACEMENT (Light Brush Grass)

1. If knives are damaged or badly worn, they will need to be replaced as a set. Replacing a single knife can cause severe vibration and possible damage to the mower. The knife should not be welded on for any reason.
2. Always replace the knife bolts when replacing the knives. DO NOT REUSE THE KNIFE BOLTS OR NUTS.
3. Assemble knives, bushings, bolts and nuts as shown in Parts Section of the manual.
4. Install the locking hex nut so that the flat face of the nut is towards the knife.
5. Apply Loctite 271 or equivalent to threads.
6. Torque nut to 50 ft. lbs. Knife must swing freely.



DO NOT re-use the locking hex nuts for mounting the knives. If hex nut becomes loose, or required removal for knife replacement or any other reason, they must be discarded and replaced with new nuts.

### 50" FLAIL KNIFE BLADE REPLACEMENT (Medium Brush Grass)

7. If knives are damaged or badly worn, they will need to be replaced as a set. Replacing a single knife can cause severe vibration and possible damage to the mower. The knife should not be welded on for any reason.
8. Always replace the knife bolts when replacing the knives. DO NOT REUSE THE KNIFE BOLTS OR NUTS.
9. Assemble knives, bushings, bolts and nuts as shown in Parts Section of the manual.
10. Install the locking hex nut so that the flat face of the nut is towards the knife.
11. Apply Loctite 271 or equivalent to threads.
12. Torque nut to 120 ft. lbs. Knife must swing freely.



DO NOT re-use the locking hex nuts for mounting the knives. If hex nut becomes loose, or required removal for knife replacement or any other reason, they must be discarded and replaced with new nuts.

### 50" FLAIL KNIFE BLADE REPLACEMENT (Heavy Duty Brush)

13. If knives are damaged or badly worn, they will need to be replaced as a set. Replacing a single knife can cause severe vibration and possible damage to the mower. The knife should not be welded on for any reason.
14. Always replace the knife bolts when replacing the knives. DO NOT REUSE THE KNIFE BOLTS OR NUTS.
15. Assemble knives, bushings, bolts and nuts as shown in Parts Section of the manual.
16. Install the locking hex nut so that the flat face of the nut is towards the knife.
17. Apply Loctite 271 or equivalent to threads.
18. Torque nut to 176 ft. lbs. Knife must swing freely.



DO NOT re-use the locking hex nuts for mounting the knives. If hex nut becomes loose, or required removal for knife replacement or any other reason, they must be discarded and replaced with new nuts.

# MAINTENANCE

## 63" BOOM FLAIL KNIFE REPLACEMENT

1. If knives are damaged or badly worn, they will need to be replaced as a set. Replacing a single knife can cause severe vibration and possible damage to the mower.
2. Assemble knives, clevis, bolts and nuts as shown in part section of manual.
3. Install locking hex nut so that the flat face of nut is towards the knife.
4. Apply Loctite 271 or equivalent to threads.
5. Torque nut to 35 FT. LBS. Knife must swing freely.



**DO NOT re-use the locking hex nuts for mounting the knives. If hex nut become loose, or require removal for knife replacement or any other reason, they must be discarded and replaced with new nuts.**



**Knives should not be welded on for any reason.**

## HEAVY DUTY SPINDLE ASSEMBLY INSTALLATION AND BEARING ADJUSTMENT

**WARNING!** A press **MUST** be used to install bearing cups, bearing cones, and seals. **DO NOT** use a hammer to install races, bearings, or seals. The parts of assembly may be damaged.


**NOTE:** The grease zerk and gussets are located on the top side of the spindle housing. Be sure the spindle is assembled correctly.

Be sure to wear eye protection and other protective equipment as needed when working on spindle assembly.

# MAINTENANCE

## THE SPINDLE ASSEMBLY

See the diagram below for identification of spindle parts, while servicing.




MAINTENANCE



# MAINTENANCE


## BEARING INSTALLATION

1. Press upper bearing cup into the spindle housing.
2. Turn the spindle housing over and press in the lower bearing cup.
3. Place the lower bearing cone in the bearing cup. Next press the seal into the spindle housing. The inner lip of the seal must be DOWN, towards the bearing, so lubricant is sealed inside the housing.
4. Install the spindle in the housing. Lightly press the spindle to seat the cone onto the spindle.
5. Support the bottom of the spindle and press the upper bearing cone and bearing adjustment sleeve onto the spindle.
6. **NOTE: The spindle housing must turn freely when seating the bearing cone and sleeve.**
7. Press the two upper seals into the spindle housing. The inner lip of the seals must be UP, away from the bearing, so excess lubricant can escape.
8. Install the bearing adjustment nut (thin nut) so there is 1-1/6" clearance between the nut and the sleeve. Install the jam washer, placing the tab into the key-way. Install the bearing lock nut (thin nut) and hand tighten against jam washer and adjustment nut. See the following section for bearing adjustment.
9. Position the spindle housing horizontally with the drain hole oriented "up". Grease through the zerk with Tiger Spindle Lubricant (part number 06540000) until the grease purges from the drain hole.
10. Install the plug into the drain hole.



## BEARING ADJUSTMENT

1. Clamp the bottom end of the spindle securely in a vise so the spindle housing turns freely.
2. Position a magnetic base dial indicator on the outer diameter of the spindle housing. Locate the end of the dial indicator against the flat end of the spindle shaft. The dial indicator will now measure accurately bearing end play.
3. Tighten the bearing adjustment nut until there is .012 inch movement when the spindle housing is pried upward away from the vise jaws.
4. When there is .012 inch free play between the spindle and housing, install the bearing lock nut (thick nut). Hold the adjusting nut securely and tighten the lock nut to 300 ft. lbs. of torque.
5. After the lock nut is tightened, there must be .001 inch to .003 inch of free play when lightly prying up on the spindle housing.



If the end play is correct, .001 inch to .003 inch, bend tabs up on jam washer to prevent the lock nut from loosening.

If the end play is NOT correct, loosen the lock nut and turn the adjustment nut as required and re-tighten the lock nut. Repeat first part of step 5.

# MAINTENANCE

## MAINTENANCE

### Boom Cylinder Removal and Replacement Instructions

1. Clear the area of all personnel before lowering the boom mower head.
2. From the tractor seat with your seat belt fastened around you, lower the boom mower head to the ground. Extend the boom to the furthest reach and lower the mower head flat on the ground. DO NOT attempt to replace the cylinders with the boom in the raised or transport position.
3. Shut off the tractor, engage the parking brake, place the tractor transmission in the park position, and remove the key before dismounting.
4. Allow the system to cool to room temperature before removing any hydraulic components
5. Wear safety glasses and impenetrable gloves when working with hydraulic hoses and fittings.
6. Release all oil pressure from the hydraulic circuit by manually stroking each valve section with the tractor engine off. Utilize the manual override function if the unit is equipped with an electric over hydraulic valve.
7. Utilize blocks, jack stands or a suitable over head hoist to support the weight of the boom section and remove pressure from the cylinder mounting pins.
8. Check to see that the cylinder to be replaced is not under pressure by moving the cylinder pins by hand. The pins should be loose and should slide from the pin bore easily. If the pins are tight and cannot be moved, the cylinder may be under pressure. Make sure the boom components are properly supported and that the pressure is relieved from the circuit.
9. Cylinder assemblies are heavy and can fall when the pins are removed. Support the hydraulic cylinder with a suitable hoist or jack.
10. Slowly loosen the hydraulic connections to the cylinder. Carefully unscrew hose fitting and allow any remaining pressure to bleed off. **Use extreme care.** Oil must be cool, and the technician should stand to the side to prevent exposure to any hydraulic oil. Always consult the Material Safety Data Sheet and wear any required Personal Protective Equipment. A catch pan may be required to retain any spilled oil.
11. Cap both ends of the fitting with suitably sized metal caps.
12. Remove the cylinder pins starting with the ROD end cylinder pin. Make sure the cylinder is properly supported, and remove the base end cylinder pin. The cylinder may be heavy-- use proper lifting techniques to lift and handle the cylinder. If needed, get assistance from another person to safely lift the cylinder from the machine.
13. Measure the distance between the cylinder pin holes and extend the new cylinder the correct length prior to attempting an installation.
14. Install the new cylinder in place and install both cylinder pins and retaining hardware.
15. Remove the metal caps and re-install the hydraulic hoses.
16. Check the hydraulic reservoir of the boom mower to ensure there is sufficient oil. Follow the manufacturer's recommendations for proper oil type and filtering techniques and requirements to add oil to the system.
17. Clear the area of all persons prior to starting the tractor.
18. Consult the Operator's Manual for instructions in regard to the proper operating procedure.
19. From the tractor seat, with the seat belt fastened, operate the boom to ensure proper operation of the boom function.
20. From the tractor seat, with the seat belt fastened, operate the boom controls to fully extend and retract the new cylinder several times to purge any trapped air from the system.
21. From the tractor seat, with the seat belt fastened, look for signs of an oil leak. If an oil leak is observed, shut the tractor down and follow the steps to remove pressure from the hydraulic circuit. Identify the source of the leak and resolve the issue.
22. Upon completion of the required repairs return to Step # 16 to recheck the cylinder for proper operation.

# MAINTENANCE

## MAINTENANCE


### CUTTERSHAFT BEARING REPLACEMENT

1. Remove existing cuttershaft, bearings and string guards.
2. Make sure that the end knives on each end of the cuttershaft are oriented as shown.
3. Apply anti-seize on cuttershaft as shown on next page.
4. Before installation the bearings must be fully greased per the following protocol: 1. Add 2 or 3 pumps of grease, 2. Spin the bearing 2 or 3 times. 3. Add 2 or 3 pumps of grease. 4. Spin the bearing 2 or 3 times. 5. Add 2 or three pumps of grease. Continue this procedure until you can visually confirm that grease is purging from the entire circumference of the seal.
5. Install non-drive side bearing first.
6. Install the top of the string guard on the non-drive side first. Use Loctite 271 or equivalent and torque (95 ft-lb or 104ft-lb if you use an extension).
7. Install the bearing and top string guard on the drive side.
8. Center the cuttershaft between the string guards. Use Loctite 271 or equivalent and torque (95ft-lb or 104ft-lb if you use an extension) the top string guard on the drive side.
9. Install, use Loctite 271 or equivalent, and torque (95ft-lb or 104ft-lb if you use an extension) the bottom string guard on both sides.
10. Make sure the cuttershaft is centered. On the non-drive side, tighten one set-screw in the bearing onto the cuttershaft.
11. Remove the other set screw and drill a 5/16" hole into the cuttershaft 3/16" deep through the hole in the bearing. BE CAREFUL NOT TO DAMAGE THE THREADS IN THE BEARING HOLE.
12. Replace the set screw in the bearing, use Loctite 271 or equivalent, and tighten onto the cuttershaft through the new hole.
13. Remove the other set screw and repeat the drilling procedure (Step 10). Replace the set screw as stated in Step 11.
14. Repeat steps 9 through 12 on the drive side.

**See illustration on next page**

# MAINTENANCE

## MAINTENANCE



## MAINTENANCE

### MAINTENANCE

## GROUND ROLLER BEARING REPLACEMENT

1. Remove existing ground roller brackets, bearings, and ground roller.
2. Remove bearings from stub shafts and ground roller brackets.
3. Clean stub shafts thoroughly, and apply anti-seize to O.D. of outer end.
4. Before installation, bearings must be fully greased per the following protocol: 1. Add 2 or 3 pumps of grease, 2. Spin the bearing 2 to 3 times. 3. Add 2 or 3 pumps of grease. 4. Spin the bearing 2 to 3 times. 5. Add 2 or 3 pumps of grease. Continue this procedure until you can visually confirm that grease is purging from the entire circumference of the seal.
5. Install bearing onto ground roller brackets using existing hardware and Loctite 271.
6. Slide bearing-ground roller bracket assemblies onto stub shafts of ground roller.
7. Install ground roller brackets onto flail bonnet using existing hardware.
8. Insure that ground roller brackets are set to the same elevation on both sides.
9. Center ground roller in bearings.
10. Tighten one setscrew in one bearing onto stub shaft of ground roller.
11. At the other end, remove the setscrew collar and drill 5/16" holes in both setscrew locations into the stub shaft 3/16" deep (or align setscrew holes in bearing collar with existing countersinks in stub shaft).
12. Reinstall setscrew collar on drilled-end. Remove both setscrews, apply Loctite 271 or equivalent, and tighten setscrews into stub shaft.
13. Then remove setscrew collar from other end, and repeat the drilling procedure from Step 11. Reinstall setscrew collar and install setscrews per Step 12.

**See illustrations in the Common Parts Section.**

# MAINTENANCE

## DAILY MAINTENANCE SCHEDULE

The following services should be performed daily or every 8 hours of service, following the detailed maintenance instructions in the operator's manual.

\_\_\_\_\_ Pump driveshaft: If required with drive shaft/coupler check for end play and lubricate at zerks.

\_\_\_\_\_ Crankshaft adapter: If equipped with rubber grommets check condition, replace if missing or damaged.

\_\_\_\_\_ Pivot points: Inject grease until it appears at ends.

\_\_\_\_\_ Hydraulic fittings: Check for leaks with paper or cardboard. Tighten fittings or replace hoses immediately.

\_\_\_\_\_ Knives: Inspect for missing or damaged knives, change (only complete sets) as needed.

\_\_\_\_\_ Belts: Check/tighten/replace belts as needed.

\_\_\_\_\_ Mainframe/deck: Unless otherwise specified retorque bolts according to torque specifications in this section.

\_\_\_\_\_ Hydraulic fluid level: Add, if required, per fluid recommendations.

\_\_\_\_\_ Rear flail drive, bearing flange and shaft couplers: Grease as instructed in the detailed maintenance section.

\_\_\_\_\_ Cuttershaft and ground roller: Grease as instructed in the detailed maintenance section.

Service performed by: \_\_\_\_\_ Date: \_\_\_\_/\_\_\_\_/\_\_\_\_ Hour

Meter: \_\_\_\_\_

Maintenance Section

\*\*This page may be copied and used as part of the daily maintenance routine.

# '''D5 F HG'SECTION

## PART NAME INDEX

|   |    |
|---|----|
| PARTS ORDERING GUIDE.....                     | 3  |
| TRACTOR MOUNT KIT.....                        | 4  |
| TRACTOR MOUNT KIT - OPEN STOW.....            | 6  |
| TRACTOR MOUNT KIT-HYDRAULICS.....             | 8  |
| ELECTRONIC PROPORTIONAL LIFT VALVE MOUNT..... | 10 |
| CHECK VALVES.....                             | 12 |
| JOYSTICK AND SWITCHBOX MOUNT.....             | 14 |
| AXLE BRACES TO LIFT VALVE.....                | 16 |
| SINGLE COLUMN BOOMREST.....                   | 18 |
| BOOMREST - OPEN STOW.....                     | 20 |
| NOTES.....                                    | 21 |
| POLYCARBONATE SAFETY WINDOW.....              | 22 |
| WHEEL WEIGHT.....                             | 24 |




## PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must indicate the **Name and Address** of the person or organization ordering the parts, **who should be charged**, and if possible, the **serial number of the machine** for which the parts are being ordered.
3. The purchase order must clearly list the **quantity of each part**, the complete and correct **part number**, and the basic **name of the part**.
4. The manufacturer reserves the right to substitute parts where applicable.
5. Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:

**Tiger Corporation**  
3301 N. Louise Ave.  
Sioux Falls, SD 57107  
1-800-843-6849  
1-605-336-7900

## TRACTOR MOUNT KIT




## TRACTOR MOUNT KIT

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                      |
|------|----------|------|----------------------------------|
| 1    | 23152    | 1    | PUMP,P350-1 3/4" GEAR            |
| 2    | 21733    | 4    | CAPSCREW,1/2" X 2", NC           |
| 3    | 06533004 | 8    | FLATWASHER,1/2",SAE,GR 8         |
| 4    | 31731    | 8    | CAPSCREW,20MM X 50MM,(2.5),10.9  |
| 5    | 33880    | 44   | FLATWASHER,3/4",GR 8,SAE         |
| 6    | 06380076 | 1    | MNT,PUMP,NHT5.115                |
| 7    | 21727    | 4    | NYLOCK NUT,1/2", NC              |
| 8    | 6T0375B  | 1    | COUPLING,14 SPLINE,W/ZERK        |
| 9    | 06420174 | 1    | DRV SHFT,32.63,LH,T5.115         |
| 10   | 6T2508   | 3    | CAPSCREW,12MM X 45MM(1.25 PITCH) |
| 11   | 27724    | 3    | LOCKWASHER,12MM                  |
| 12   | 06700043 | 1    | ADPTR,DRV SHFT,KUB,ASSY          |
| 13   | 32382    | 5    | BRACKET,HOSE                     |
| 14   | 21833    | 10   | CAPSCREW,3/4" X 2-1/4", NC       |
| 15   | 21825    | 10   | HEX NUT,3/4", NC                 |
| 16   | 06412229 | 1    | UPRIGHT,LH,T5.115                |
| 17   | 24860    | 2    | CAPSCREW,20MMX40MM(2.5P)10.9     |
| 18   | 21627    | 8    | NYLOCK NUT,3/8", NC              |
| 19   | 22016    | 16   | FLATWASHER,3/8",GR8              |
| 20   | 06530531 | 8    | CAPSCREW,18MM X 50MM(1.5P)GR10.9 |
| 21   | 06533005 | 8    | FLATWASHER,18MM,GR10.9           |
| 22   | 06300353 | 1    | AXL BRC,LH,NH T5.115             |
| 23   | 21632    | 8    | CAPSCREW,3/8" X 1-1/2", NC       |
| 24   | 06412268 | 1    | MNT,06380077                     |
| 25   | 06700206 | 1    | TANK,RES,ASSY,T5.115             |
| 26   | 06300352 | 1    | AXL BRC,RH,NH T5.115,SC          |
| 27   | 06402514 | 1    | BAR,AXLE BRC                     |
| 28   | 21847    | 2    | CAPSCREW,3/4" X 10", NC          |
| 29   | 06300350 | 1    | MNFRM,NH T5.115                  |
| 30   | 06412287 | 1    | STOP.OSS,RH,T5.115               |
| 31   | 24879    | 2    | CAPSCREW,20MM X 65MM2.5P,GR10.9  |
| 32   | 06420091 | 1    | SPACER,DRV SHFT,NHT4.85          |

NH T5.95-T5.115 BENGAL

TRACTOR MOUNT KIT - OPEN STOW




## TRACTOR MOUNT KIT - OPEN STOW

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                      |
|------|----------|------|----------------------------------|
| 1    | 23152    | 1    | PUMP,P350-1 3/4" GEAR            |
| 2    | 21733    | 4    | CAPSCREW,1/2" X 2", NC           |
| 3    | 06533004 | 8    | FLATWASHER,1/2",SAE,GR 8         |
| 4    | 31731    | 8    | CAPSCREW,20MM X 50MM,(2.5),10.9  |
| 5    | 33880    | 44   | FLATWASHER,3/4",GR 8,SAE         |
| 6    | 06380076 | 1    | MNT,PUMP,NHT5.115                |
| 7    | 21727    | 4    | NYLOCK NUT,1/2", NC              |
| 8    | 6T0375B  | 1    | COUPLING,14 SPLINE,W/ZERK        |
| 9    | 06420174 | 1    | DRV SHFT,32.63,LH,T5.115         |
| 10   | 6T2508   | 3    | CAPSCREW,12MM X 45MM(1.25 PITCH) |
| 11   | 27724    | 3    | LOCKWASHER,12MM                  |
| 12   | 06700043 | 1    | ADPTR,DRV SHFT,KUB,ASSY          |
| 13   | 32382    | 5    | BRACKET,HOSE                     |
| 14   | 21833    | 10   | CAPSCREW,3/4" X 2-1/4", NC       |
| 15   | 21825    | 10   | HEX NUT,3/4", NC                 |
| 16   | 06412229 | 1    | UPRIGHT,LH,T5.115                |
| 17   | 24860    | 2    | CAPSCREW,20MMX40MM(2.5P)10.9     |
| 18   | 21627    | 8    | NYLOCK NUT,3/8", NC              |
| 19   | 22016    | 16   | FLATWASHER,3/8",GR8              |
| 20   | 06530531 | 8    | CAPSCREW,18MM X 50MM(1.5P)GR10.9 |
| 21   | 06533005 | 8    | FLATWASHER,18MM,GR10.9           |
| 22   | 06300465 | 1    | AXL BRC,LH,NH T5.115, OS         |
| 23   | 21632    | 8    | CAPSCREW,3/8" X 1-1/2", NC       |
| 24   | 06412268 | 1    | MNT,06380077                     |
| 25   | 06700206 | 1    | TANK,RES,ASSY,T5.115             |
| 26   | 06300466 | 1    | AXL BRC,RH,NH T5.115,OS          |
| 27   | 06402514 | 1    | BAR,AXLE BRC                     |
| 28   | 21847    | 2    | CAPSCREW,3/4" X 10", NC          |
| 29   | 06300350 | 1    | MNFRM,NH T5.115                  |
| 30   | 06412287 | 1    | STOP.OSS,RH,T5.115               |
| 31   | 24879    | 2    | CAPSCREW,20MM X 65MM2.5P,GR10.9  |
| 32   | 06420091 | 1    | SPACER,DRV SHFT,NHT4.85          |

NH T5.95-T5.115 BENGAL

# TRACTOR MOUNT KIT-HYDRAULICS




## TRACTOR MOUNT KIT-HYDRAULICS

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                                |
|------|----------|------|--|
| 1    | ---      | -    | MAINFRAME*REFER TO TRACTOR MOUNT KIT*      |
| 2    | 06510083 | 1    | VALVE,BRAKE,SOL,3000PSI                    |
| 3    | 22016    | 4    | FLATWASHER,3/8",GR8                        |
| 4    | 21644    | 2    | CAPSCREW,3/8" X 5", NC                     |
| 5    | 06500754 | 1    | HOSE ,1" X 105" (RETURN FROM HEAD)         |
| 6    | 06500753 | 1    | HOSE, 1" X 103" (PRESSURE TO HEAD)         |
| 7    | 33555    | 2    | ADAPTER,1"MB X 1"MJ                        |
| 8    | 32869    | 1    | NIPPLE,MALE LONG,1" MOR X 1"MJ             |
| 9    | 33259    | 1    | ELBOW,1"MJ X 1"FIX 90°                     |
| 10   | 06500700 | 1    | HOSE,1" X 180"                             |
| 11   | 34117    | 1    | ELBOW,1"MB X 1"MJ,FORGED                   |
| 12   | 06500274 | 1    | HOSE,1" X 74"                              |
| 13   | 21627    | 6    | NYLOCK NUT,3/8", NC                        |
| 14   | ---      | -    | BRACKET,HOSE*REFER TO TRACTOR MOUNT KIT*   |
| 15   | TF4852   | 2    | KIT,FLANGE,#20                             |
| 16   | 23152    | 1    | PUMP                                       |
| 17   | 06500802 | 1    | HOSE,1 1/2" X 107"                         |
| 18   | 34710    | 1    | ADAPTER,1 1/2" ORB X 1 1/2" MJ             |
| 19   | 06503084 | 1    | ELBOW,1 1/2" FB X 1 1/2" FB                |
| 20   | 06503083 | 1    | ADAPTER,1 1/2" ORB X 1 1/2" ORB            |
| 21   | 34309    | 1    | BALL VALVE,1 1/2" FOR                      |
| 22   | ----     | -    | HYDRAULIC TANK*REFER TO TRACTOR MOUNT KIT* |
| 23   | 06505127 | 1    | PLUG,SAE 3/4"                              |
| 24   | 06505077 | 1    | CAP,BREATHER,O-RING                        |
| 25   | 34064    | 1    | ADAPTER,1 1/4MOR X 1MJ                     |
| 26   | 6T0649   | 1    | FILTER GAUGE                               |
| 27   | TF4888   | 1    | STREET ELBOW,1/8 X 90                      |
| 28   | 06505044 | 1    | FLTR ASSY,IN-TANK CPLT,SAE10MP             |

## ELECTRONIC PROPORTIONAL LIFT VALVE MOUNT



| ITEM | PART NO. | QTY. | DESCRIPTION                  |
|------|----------|------|------------------------------|
| 1    | 33463    | 1    | ADAPTER, 22MM ORB X 1/2 " MJ |
| 2    | 06500803 | 1    | HOSE, 1/2" X 14"             |
| 3    | 06500339 | 1    | HOSE, 1/2" X 35"             |
| 4    | 06503012 | 1    | ADAPTER, 27MM ORB X 3/4" MJ  |




## ELECTRONIC PROPORTIONAL LIFT VALVE MOUNT

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                           |
|------|----------|------|---------------------------------------|
| 5    | 06503002 | 1    | ADAPTER, 12MM MB X 5/16" MJ           |
| 6    | 06500400 | 1    | HOSE, 1/4" X 34"                      |
| 7    | 06500804 | 1    | HOSE, 3/8" X 62"                      |
| 8    | 06503172 | 1    | ELBOW, 3/8" MJ X 3/8" FJX X 45°       |
| 9    | 33271    | 1    | ADAPTER, 1/2" MOR X 3/8" MJ           |
| 10   | 06503019 | 1    | ADAPTER, 1/2" MB X 1/2" FJX           |
| 11   | 06500122 | 1    | HOSE, 3/8" X 30"                      |
| 12   | 6T3992   | 1    | RUN TEE, 1/2" MJ X 1/2" FJX X 1/2" MJ |
| 13   | 33528    | 2    | ADAPTER, 1/2" MB X 1/2" MJ            |
| 14   | 21534    | 4    | CAPSCREW, 1/4" X 2", NC               |
| 15   | 22014    | 8    | FLATWASHER, 1/4"                      |
| 16   | —        | -    | *SEE HYDRAULIC CHECK VALVE PAGE*      |
| 17   | 06410171 | 1    | PLATE,MNT,VLV,TSA                     |
| 18   | 21525    | 6    | HEX NUT, 1/4", NC                     |
| 19   | 21986    | 4    | LOCKWASHER, 1/4"                      |
| 20   | 27508    | 2    | CAPSCREW, 8MM X 20MM (1.25)           |
| 21   | 6T2619   | 2    | LOCKWASHER, 8MM                       |
| 22   | 34948    | 2    | FLATWASHER, 8MM                       |
| 23   | 06402606 | 1    | ADAPTOR PLATE, MNT, VLV, T5.115       |
| 24   | 21530    | 2    | CAPSCREW, 1/4" X 1", NC               |
| 25   | 21987    | 4    | LOCKWASHER, 5/16"                     |
| 26   | 21579    | 4    | CAPSCREW, 5/16" X 3/4", NC            |
| 27   | -----    | -    | *SEE LIFT VLV MNT TO AXLE BRC PAGE*   |
| 28   | -----    | -    | *SEE LIFT VLV MNT TO AXLE BRC PAGE*   |
| 29   | 06502165 | 1    | VLV,5SP,DF,PVEA,WILDKAT,CNBS          |
| 30   | 33392    | 1    | ADAPTER, 5/16" MB X 3/8" MJ           |
| 31   | 32807    | 10   | ADAPTER, 5/8" MB X 3/8" MJ            |
| 32   | 06500687 | 6    | HOSE, 1/4" X 268"                     |
| 33   | 06500697 | 2    | HOSE, 1/4" X 210"                     |
| 34   | 06500688 | 2    | HOSE, 1/4" X 288"                     |
| 35   | 33294    | 2    | ELBOW, 3/4" MB X 1/2" MJ              |
| 36   | 27082B   | 2    | SPACER                                |
| 37   | 21577    | 4    | NYLOCK NUT, 5/16" NC                  |
| 38   | 06460072 | 1    | BRACKET                               |
| 39   | 21632    | 1    | CAPSCREW, 3/8" X 1-1/2" NC            |
| 40   | 06500400 | 1    | HOSE, 1/4" X 34"                      |
| 41   | 24300    | 1    | ACCUMULATOR                           |
| 42   | 06503029 | 1    | TEE, RUN                              |
| 43   | 23888    | 1    | BRKT, ACCUMULATOR                     |
| 44   | 21631    | 4    | CAPSCREW, 3/8" X 1-1/4" NC            |
| 45   | 21627    | 4    | NYLOCK NUT, 3/8" NC                   |

NH T5.95-T5.115 BENGAL

|                     |
|---------------------|
| <b>CHECK VALVES</b> |
|---------------------|




©2020 Alamo Group Inc.

## CHECK VALVES

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION              |
|------|----------|------|--------------------------|
| 1    | 06500122 | 1    | HOSE, 1/2" X 30"         |
| 2    | 06503172 | 1    | ELBOW, 3/8" MB X 3/8" MJ |
| 3    | 06500803 | 1    | HOSE, 1/2" X 14"         |
| 9    | 33271    | 1    | ADAPTER                  |
| 10   | 06502005 | 2    | VALVE RELIEF BODY        |
| 11   | 06502006 | 2    | CHECK VALVE CARTRIDGE    |
| 12   | 6T3992   | 1    | ADAPTER, TEE             |
| 13   | 06503019 | 1    | ADAPTER                  |
| 14   | 06500804 | 1    | HOSE, 3/8" X 62"         |
| 15   | 33528    | 2    | ADAPTER                  |
| 16   | 21534    | 4    | BOLT                     |
| 17   | 21525    | 4    | NUT                      |
| 18   | 22014    | 4    | FLATWASHER               |
| 19   | 21986    | 4    | LOCKWASHER               |

# JOYSTICK AND SWITCHBOX MOUNT




## JOYSTICK AND SWITCHBOX MOUNT

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                       |
|------|----------|------|-----------------------------------|
| 1    | 33691    | 1    | JOYSTICK                          |
| 2    | 32829    | 4    | SCREW,MACHINE,10-32 X 3/4",FLATHD |
| 3    | 06510196 | 1    | SWITCH BOX,DF,SS,OS               |
| 4    | 21585    | 2    | CAPSCREW,5/16" X 2-1/4",NC        |
| 5    | 21577    | 2    | NYLOCK NUT,5/16",NC               |
| 6    | 06340011 | 1    | MNT,STND,JOYSTICK                 |
| 7    | 21639    | 3    | CAPSCREW,3/8" X 3-1/4",NC         |
| 8    | 21627    | 3    | NYLOCK NUT,3/8",NC                |
| 9    | 41794    | 3    | SPACER                            |
| 10   | 06340015 | 1    | SWITCH BOX MNT                    |
| 11   | 21529    | 4    | CAPSCREW,1/4" X 3/4",NC           |
| 12   | 21986    | 4    | LOCKWASHER,1/4"                   |
| 13   | 22014    | 4    | FLATWASHER,1/4"                   |
| 14   | 06520041 | 2    | MOUNT,RAM,BALL,1-1/2"             |
| 15   | 06520020 | 1    | MOUNT,RAM,ARM                     |
| 16   | 06340010 | 1    | ROD,1/2"NPT X 7"                  |
| 17   | 35033    | 1    | CAN,JOYSTICK,ASSY                 |
| 18   | 35204    | 1    | KNOB,3/8",NC,INSERT               |
| 19   | 35206    | 1    | HEX NUT,JAMB,3/8",NC              |
| 20   | 35205    | 1    | SETSCREW,3/8" X 2",NC,KNURLED     |
| 21   | 33693    | 1    | CBL,EXT,4FT,JOYSTICK              |

## AXLE BRACES TO LIFT VALVE




## AXLE BRACES TO LIFT VALVE

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                       |
|------|----------|------|-----------------------------------|
| 1    | 21681    | 4    | CAPSCREW, 7/16" X 1-1/2", NC      |
| 2    | ---      | -    | *SEE TRACTOR MOUNT PAGE*          |
| 3    | ----     | -    | *SEE TRACTOR MOUNT PAGE*          |
| 4    | 21727    | 4    | NYLOCK NUT, 1/2", NC              |
| 5    | 06340054 | 1    | VLV MNT, RH, T5.115               |
| 6    | 06340053 | 1    | VLV MNT, LH, T5.115               |
| 7    | 21627    | 8    | NYLOCK NUT, 3/8", NC              |
| 8    | 21625    | 4    | HEX NUT, 3/8", NC                 |
| 9    | 21988    | 4    | LOCKWASHER, 3/8"                  |
| 10   | 06340055 | 1    | VLV MNT, T5.115                   |
| 11   | 22016    | 12   | FLATWASHER, 3/8", GR8             |
| 12   | 21631    | 12   | CAPSCREW, 3/8" X 1 1/4" , NC, GR8 |
| 13   | 34622    | 1    | PLATE, VALVE, REAR MNT            |

# SINGLE COLUMN BOOMREST






## SINGLE COLUMN BOOMREST

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                                 |
|------|----------|------|---|
| 1    | ----     | -    | MAINFRAME *REFER TO TRACTOR MOUNT KIT*      |
| 2    | ---      | -    | AXLE BRACE, RH *REFER TO TRACTOR MOUNT KIT* |
| 3    | 06310074 | 1    | BOOMREST,SINGLE COLUMN                      |
| 4    | 06410968 | 1    | SADDLE                                      |
| 5    | 21725    | 4    | HEX NUT,1/2",NC                             |
| 6    | 06533004 | 8    | FLATWASHER,1/2",SAE                         |
| 7    | 21733    | 4    | CAPSCREW, 1/2" X 2", NC                     |
| 8    | 21825    | 8    | HEX NUT,3/4",NC                             |
| 9    | 22021    | 16   | FLATWASHER,3/4"                             |
| 10   | 21843    | 8    | CAPSCREW,3/4" X 6",NC                       |

## BOOMREST - OPEN STOW




| ITEM | PART NO. | QTY. | DESCRIPTION                |
|------|----------|------|----------------------------|
| 1    | 06300465 | 1    | AXLE BRACE, LH             |
| 2    | 06300466 | 1    | AXLE BRACE, RH             |
| 3    | 33880    | 16   | FLATWASHER, 3/4" GR8, SAE  |
| 4    | 21833    | 8    | CAPSCREW, 3/4" X 2-1/4" NC |
| 5    | 21825    | 8    | HEX NUT, 3/4" NC           |
| 6    | 06310157 | 1    | BOOMREST, OS, T4           |
| 7    | 06533004 | 8    | FLATWASHER, 1/2" GR8, SAE  |
| 8    | 21725    | 4    | HEX NUT, 1/2" NC           |
| 9    | 21733    | 4    | CAPSCREW, 1/2" X 2" NC     |
| 10   | 06411166 | 1    | SADDLE, T4, BENGAL         |

## NOTES

## NOTES

POLYCARBONATE SAFETY WINDOW




## POLYCARBONATE SAFETY WINDOW

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                      |
|------|----------|------|----------------------------------|
| 1    | 31965    | 23   | TRIMLOCK (IN FEET)               |
| 2    | 33477    | 1    | ISOLATOR                         |
| 3    | 21575    | 2    | HEXT NUT, 5/16", NC              |
| 4    | 33478    | 1    | ROD, THREADED 5/16" X 3"         |
| 5    | 06410396 | 1    | BRACKET, TOP, SAFETY SCREEN      |
| 6    | 06490051 | 1    | POLYCARBONATE, DOOR, RH          |
| 7    | 23113    | 2    | CAPSCREW, 10MM X 30MM            |
| 8    | 22016    | 2    | FLATWASHER, 3/8"                 |
| 9    | 06490052 | 1    | POLYCARBONATE, REAR, T95-115     |
| 10   | 22645    | 1    | DECAL                            |
| 11   | 06402536 | 1    | BRACKET, LOWER, SFTY SCR N T4.85 |
| 12   | 06330045 | 2    | MOUNT, SFTY SCR N, LWR, T5 115   |

## WHEEL WEIGHT



| ITEM | PART NO. | QTY. | DESCRIPTION            |
|------|----------|------|------------------------|
| 1    | 02970758 | 1    | WHEEL WEIGHT,UNIVERSAL |
| 2    | 31455    | 3    | CAPSCREW,3/4" X 17",NC |
| 3    | 33626    | 9    | FLATWASHER,3/4",USS    |
| 4    | 06430148 | 3    | SPACER,2"              |
| 5    | 21993    | 3    | LOCKWASHER,3/4"        |
| 6    | 21825    | 3    | HEX NUT,3/4",NC        |

PARTS SECTION

# NOTES



## PART NAME INDEX

|   |    |
|---|----|
| PARTS ORDERING GUIDE.....                       | 5  |
| BOOM ASSY - BENGAL 18 T4.....                   | 6  |
| BOOM ASSY BENGAL STANDARD 22 T4.....            | 8  |
| BOOM ASSY HYD BENGAL 22 T4.....                 | 10 |
| BOOM ASSY BENGAL EXT 24 T4.....                 | 12 |
| BOOM ASSY HYD BENGAL 24 T4.....                 | 14 |
| BOOMREST - OPEN STOW.....                       | 16 |
| 50IN ROTARY MOWER ASSEMBLY.....                 | 18 |
| 50IN ROTARY KNIVES AND DISH.....                | 20 |
| 50IN ROTARY BLADE BAR AND KNIVES.....           | 21 |
| 60IN ROTARY MOWER ASSEMBLY.....                 | 22 |
| 60IN ROTARY KNIVES AND DISH.....                | 24 |
| 60IN ROTARY BLADE BAR AND KNIVES.....           | 25 |
| ROTARY MOWER SPINDLE ASSEMBLY.....              | 26 |
| BOOM ROTARY PIVOT ASSEMBLY.....                 | 28 |
| 50IN FLAIL DRIVE ASSEMBLY.....                  | 30 |
| 50IN FLAIL MOWER ASSEMBLY.....                  | 32 |
| 50IN FLAIL MOWER ASSY, PASS-THROUGH KNIVES..... | 34 |
| 63IN FLAIL DRIVE ASSEMBLY.....                  | 36 |
| 63IN FLAIL MOWER ASSEMBLY.....                  | 38 |
| BOOM FLAIL PIVOT ASSEMBLY.....                  | 40 |
| 3IN X 13-7/8 IN WELDED CYLINDER BREAKDOWN.....  | 42 |
| 3IN X 18IN WELDED CYLINDER BREAKDOWN.....       | 43 |
| 3-1/2IN X 20IN WELDED CYLINDER BREAKDOWN.....   | 44 |
| 4IN X 20IN WELDED CYLINDER BREAKDOWN.....       | 45 |
| 5IN X 20IN WELDED CYLINDER BREAKDOWN.....       | 46 |
| NOTES.....                                      | 47 |
| 5 SPOOL ELECTRONIC VALVE - OPEN STOW,3PS.....   | 48 |
| 5 SPOOL ELECTRONIC VALVE - SIDE STOW.....       | 50 |
| FRONT HYDRAULIC PUMP.....                       | 52 |
| 50IN AND 60IN ROTARY MOTOR BREAKDOWN.....       | 54 |
| FLAIL MOTOR BREAKDOWN.....                      | 56 |
| RESERVOIR TANK FILTER ASSEMBLY.....             | 58 |
| PUMP AND GRILL GUARD OPTIONS.....               | 59 |
| BOOM TRAVEL LOCK.....                           | 60 |
| MANUAL LIFT VALVE SWITCH BOX.....               | 61 |
| MANUAL LIFT VALVE SCHEMATIC.....                | 62 |
| ELECTRONIC LIFT VALVE SWITCH BOX.....           | 63 |
| ELECTRONIC LIFT VALVE SCHEMATIC.....            | 64 |
| SOLENOID SWITCH BOX AND WIRING.....             | 65 |

COMMON BENGAL T4

## PART NAME INDEX


|                                       |    |
|---------------------------------------|----|
| BRAKE VALVE ASSEMBLY.....             | 66 |
| BRAKE VALVE HYDRAULIC SCHEMATIC.....  | 67 |
| ELECTRICAL TROUBLESHOOTING GUIDE..... | 68 |
| HYDRAULIC TROUBLESHOOTING GUIDE.....  | 69 |
| TROUBLESHOOTING.....                  | 70 |
| TROUBLESHOOTING - CONTINUED.....      | 71 |
| WHEEL WEIGHT - BENGAL 18.....         | 72 |

## PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this manual.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must indicate the **Name and Address** of the person or organization ordering the parts, **who should be charged**, and if possible, the **serial number of the machine** for which the parts are being ordered.
3. The purchase order must clearly list the **quantity of each part**, the complete and correct **part number**, and the basic **name of the part**.
4. The manufacturer reserves the right to substitute parts where applicable.
5. Some parts may be unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a purchase order.
6. The manufacturer reserves the right to change prices without prior notice.

NOTE: When ordering replacement decals, refer to the part numbers and descriptions listed in the safety section in the front of this manual.




For maximum safety and to guarantee optimum product reliability, always use genuine **Tiger** replacement parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death.

Direct any questions regarding parts to:


**Tiger Corporation**  
3301 N. Louise Ave.  
Sioux Falls, SD 57107  
1-800-843-6849  
1-605-336-7900

## BOOM ASSY - BENGAL 18 T4



### NOTES:

1. IMPORTANT: ALIGN GREASE HOLE OR GAP IN BEARING (ITEMS 5 & 13) WITH GREASE ZERK IN BOOM. MAINTAIN ALIGNMENT DURING BEARING INSTALLATION.
2. GREASE HINGE PIN ZERKS (ITEM 4) ON BOOM AFTER ASSEMBLY, ONCE UNDER LOAD WITH BOOM ELEVATED AND AGAIN AT REST WITH BOOM SUPPORTED.
3. ONLY ONE SET COLLAR (ITEM 15) NEEDED FOR ROTARY MOWERS.



VIEW A-A

### KEY

- A - SECONDARY BUTT
- B - SECONDARY GLAND
- C - DECK ROLL BUTT
- D - DECK ROLL GLAND
- E - SHIELD BUTT
- F - SHIELD GLAND
- R - RETURN
- P - PRESSURE


## BOOM ASSY - BENGAL 18 T4

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                     |
|------|----------|------|---------------------------------|
| 1    | ----     | -    | REAR STOW SWIVEL ASSY           |
| 2    | 06700167 | -    | MAIN BOOM ASSY                  |
| ---  | 06310111 | 1    | MAIN BOOM WELDMENT              |
| 3    | 06700168 | -    | SECONDARY BOOM ASSY             |
| ---- | 06310112 | 1    | SECONDARY BOOM WELDMENT         |
| 4    | 6T3211   | 4    | GREASE ZERK,1/8"                |
| 5    | 32321    | 2    | BEARING, DX, 1-1/2" X 2"        |
| 6    | 06500499 | 2    | HOSE,1/4" X 50"                 |
| 7    | 06500500 | 2    | HOSE,1/4" X 108"                |
| 8    | 06500502 | 2    | HOSE,1/4" X 100"                |
| 9    | 06500713 | 1    | HOSE,1" X 163"                  |
| 10   | 06500714 | 1    | HOSE,1" X 162"                  |
| 11   | 06505116 | 2    | CLAMP KIT                       |
| 12   | 24724    | 2    | SWIVEL,1MJ X 1FJX45             |
| 13   | TB3010   | 3    | BUSHING                         |
| 14   | TB1035   | 1    | BUSHING,SPACER                  |
| 15   | 35312    | 1    | SET COLLAR                      |
| 16   | 06510050 | 1    | TRAVEL LOCK,METRIPACK COIL      |
| 17   | 31329    | 1    | ADAPTER,1/2ORB X 1/2ORB ADJ     |
| 18   | 06501023 | 1    | DECK ROLL CYLINDER,3" X 18"     |
| 19   | 06537021 | 6    | ROLL PIN,5MM                    |
| 20   | TB1033   | 4    | PIN,1"                          |
| 21   | 6T3207   | 4    | GREASE ZERK,1/4"                |
| 22   | TB3033   | 1    | CLEVIS WITH SPHERICAL BEARING   |
| 23   | 21677    | 2    | NYLOCK NUT,7/16",NC             |
| 24   | 21688    | 2    | CAPSCREW,7/16" X 3-1/4",NC      |
| 25   | TB1025   | 1    | PIN,1-1/2"                      |
| 26   | TB1036   | 1    | PIN,1"                          |
| 27   | TF1143   | 1    | PIN,LYNCH                       |
| 28   | 06501024 | 1    | SECONDARY CYLINDER,3-1/2" X 20" |
| 29   | 06501022 | 1    | MAIN CYLINDER,4" X 20"          |
| 30   | 06420100 | 1    | PIN,1-1/4"                      |
| 31   | TB1023   | 2    | ROLL PIN,7/32"                  |
| 32   | TB3013C  | 1    | PIN,1-1/2"                      |

COMMON BENGAL T4

# BOOM ASSY BENGAL STANDARD 22 T4



## NOTES:

1. IMPORTANT: ALIGN GREASE HOLE IN BEARING (ITEMS 4 & 5) WITH GREASE ZERK IN BOOM. MAINTAIN ALIGNMENT DURING BEARING INSTALLATION.
2. GREASE (ITEM 10) HINGE PIN ZERKS ON BOOM AFTER ASSEMBLY, ONCE UNDER LOAD WITH BOOM ELEVATED AND AGAIN AT REST WITH BOOM SUPPORTED.


## BOOM ASSY BENGAL STANDARD 22 T4

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                             |
|------|----------|------|---|
| 1    | -----    | -    | SWIVEL ASSY *REFER TO TRACTOR MOUNT KIT |
| 2    | 06700189 | 1    | MAIN BOOM, T4                           |
| 3    | 24517    | 1    | SECONDARY BOOM ARM ASSY                 |
| 4    | 32321    | 2    | BEARING, DX, 1-1/2" X 2"                |
| 5    | TB1044   | 2    | BUSHING, 1-1/4"ID                       |
| 7    | 06501020 | 1    | CYLINDER, 5" X 20"                      |
| 8    | TB3010   | 3    | BUSHING, 1"ID                           |
| 9    | TB1035   | 1    | BUSHING,SPACER                          |
| 10   | 6T3211   | 4    | GREASE ZERK,1/8"                        |
| 11   | 6T3207   | 3    | GREASE ZERK,1/4"                        |
| 12   | 35312    | 1    | SET COLLAR                              |
| 13   | 06510050 | 1    | TRAVEL LOCK,METRIPACK COIL              |
| 14   | 31329    | 1    | ADAPTER,1/2ORB X 1/2ORB ADJ             |
| 15   | 06501022 | 1    | CYLINDER, 4" X 20"                      |
| 16   | 06501023 | 1    | CYLINDER,3" X 18"                       |
| 17   | 06537021 | 6    | ROLL PIN,5MM                            |
| 18   | TB1033   | 1    | PIN,1" X 4"                             |
| 19   | TB1036   | 1    | PIN,1" X 4-11/16"                       |
| 20   | TF1143   | 1    | PIN,LYNCH                               |
| 21   | 21688    | 2    | CAPSCREW,7/16" X 3-1/4",NC              |
| 22   | 21677    | 2    | NYLOCK NUT,7/16",NC                     |
| 23   | 6T3210   | 1    | GREASE ZERK,1/8" X 90°                  |
| 24   | TB1025   | 1    | PIN,1-1/2" X 12"                        |
| 25   | 30172    | 1    | CLEVIS,SPHERICAL                        |
| 26   | 6T3014   | 2    | ROLL PIN, 1/4" X 2"                     |
| 27   | TB1045B  | 2    | PIN, PRIMARY CYLINDER                   |

COMMON BENGAL T4

# BOOM ASSY HYD BENGAL 22 T4






## BOOM ASSY HYD BENGAL 22 T4

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                            |
|------|----------|------|--|
| 1    | -----    | -    | MAIN BOOM *REFER TO BOOM ARM ASSY      |
| 2    | -----    | -    | SECONDARY BOOM *REFER TO BOOM ARM ASSY |
| 3    | 06500694 | 1    | HOSE, 1/4" X 83"                       |
| 4    | ---      | 1    | HOSE, 1/4" X 83"                       |
| 5    | 06500695 | 1    | HOSE, 1/4" X 138"                      |
| 6    | ----     | 1    | HOSE, 1/4" X 138"                      |
| 7    | 06500696 | 1    | HOSE, 1/4" X 112"                      |
| 8    | ---      | 1    | HOSE, 1/4" X 112"                      |
| 9    | 06500859 | 1    | HOSE, 1" X 182"                        |
| 10   | ---      | 1    | HOSE, 1" X 182"                        |
| 11   | 06505019 | 3    | CLAMP KIT,3 SECTION                    |
| 12   | 34102    | 2    | TUBE,PRFRMD,SEC BOOM                   |
| 13   | 2403306  | 2    | TUBE,PRFRMD,SEC BOOM,HP                |
| 14   | 30111    | 2    | CLAMP KIT,2 SECTION                    |

COMMON BENGAL T4

# BOOM ASSY BENGAL EXT 24 T4




**BOOM ASSY BENGAL EXT 24 T4****Continued...**

| <b>ITEM</b> | <b>PART NO.</b> | <b>QTY.</b> | <b>DESCRIPTION</b>                      |
|-------------|-----------------|-------------|---|
| 1           | -----           | -           | SWIVEL ASSY *REFER TO TRACTOR MOUNT KIT |
| 2           | 06700191        | 1           | MAIN BOOM, EXT, T4                      |
| 3           | 06700094        | 1           | SECONDARY BOOM ARM ASSY, EXT, T4        |
| 4           | 32321           | 2           | BEARING, DX, 1-1/2" X 2"                |
| 5           | TB1044          | 2           | BUSHING, 1-1/4"ID                       |
| 7           | 06501020        | 1           | CYLINDER, 5" X 20"                      |
| 8           | TB3010          | 3           | BUSHING, 1"ID                           |
| 9           | TB1035          | 1           | BUSHING,SPACER                          |
| 10          | 6T3211          | 4           | GREASE ZERK,1/8"                        |
| 11          | 6T3207          | 3           | GREASE ZERK,1/4"                        |
| 12          | 35312           | 1           | SET COLLAR                              |
| 13          | 06510050        | 1           | TRAVEL LOCK,METRIPACK COIL              |
| 14          | 31329           | 1           | ADAPTER,1/2ORB X 1/2ORB ADJ             |
| 15          | 06501022        | 1           | CYLINDER, 4" X 20"                      |
| 16          | 06501023        | 1           | CYLINDER,3" X 18"                       |
| 17          | 06537021        | 6           | ROLL PIN,5MM                            |
| 18          | TB1033          | 1           | PIN,1" X 4"                             |
| 19          | TB1036          | 1           | PIN,1" X 4-11/16"                       |
| 20          | TF1143          | 1           | PIN,LYNCH                               |
| 21          | 21688           | 2           | CAPSCREW,7/16" X 3-1/4",NC              |
| 22          | 21677           | 2           | NYLOCK NUT,7/16",NC                     |
| 23          | 6T3210          | 1           | GREASE ZERK,1/8" X 90°                  |
| 24          | TB1025          | 1           | PIN,1-1/2" X 12"                        |
| 25          | 30172           | 1           | CLEVIS,SPHERICAL                        |
| 26          | 6T3014          | 2           | ROLL PIN, 1/4" X 2"                     |
| 27          | TB1045B         | 2           | PIN, PRIMARY CYLINDER                   |

COMMON BENGAL T4

# BOOM ASSY HYD BENGAL 24 T4




## BOOM ASSY HYD BENGAL 24 T4

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                            |
|------|----------|------|--|
| 1    | -----    | -    | MAIN BOOM *REFER TO BOOM ARM ASSY      |
| 2    | -----    | -    | SECONDARY BOOM *REFER TO BOOM ARM ASSY |
| 3    | 06500716 | 1    | HOSE, 1/4" X 100"                      |
| 4    | ---      | 1    | HOSE, 1/4" X 100 "                     |
| 5    | 06500717 | 1    | HOSE, 1/4" X 170"                      |
| 6    | ----     | 1    | HOSE, 1/4" X 170"                      |
| 7    | 06500718 | 1    | HOSE, 1/4" X 130"                      |
| 8    | ---      | 1    | HOSE, 1/4" X 130"                      |
| 9    | 06500715 | 1    | HOSE, 1" X 198"                        |
| 10   | ---      | 1    | HOSE, 1" X 198"                        |
| 11   | 06505019 | 3    | CLAMP KIT,3 SECTION                    |
| 12   | 34103    | 2    | TUBE,PRFRMD,SEC BOOM                   |
| 13   | 30169    | 2    | TUBE,PRFRMD,SEC BOOM,HP                |
| 14   | 30111    | 2    | CLAMP KIT,2 SECTION                    |

COMMON BENGAL T4

## BOOMREST - OPEN STOW




## BOOMREST - OPEN STOW

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION               |
|------|----------|------|---------------------------|
| 1    | 06310157 | 1    | BOOMREST,OS               |
| 2    | 06410968 | 1    | SADDLE                    |
| 3    | 21732    | 4    | CAPSCREW,1/2" X 1-3/4",NC |
| 4    | 06533004 | 8    | FLATWASHER,1/2",SAE       |
| 5    | 21725    | 4    | HEX NUT,1/2",NC           |
| 6    | 21782    | 8    | CAPSCREW,5/8" X 1-3/4",NC |
| 7    | 33764    | 16   | FLATWASHER,5/8",SAE       |
| 8    | 21775    | 8    | HEX NUT,5/8",NC           |
| 9    | 24881    | 12   | LOCKWASHER,20MM           |
| 10   | 27281    | 12   | CAPSCREW,20MM X 60MM,2.5P |
| 11   | ---      | 1    | AXLE BRACE,RH             |
| 12   | ----     | 1    | AXLE BRACE,LH             |

COMMON BENGAL T4

## 50IN ROTARY MOWER ASSEMBLY



| ITEM | PART NO. | QTY. | DESCRIPTION                    |
|------|----------|------|--------------------------------|
| 1    | 33780    | 1    | DECK,WLDMNT,50" RTRY           |
| 2    | 33777    | 2    | SKID SHOE,50" RTRY             |
| 3    | 33754    | 1    | SHIELD,50"RTRY                 |
| 4    | 33879    | 6    | CAPSCREW, 3/4 X 2 1/4,NF GR 8  |
| 5    | 33880    | 6    | FLATWASHER,3/4",GR 8,SAE       |
| 6    | 21993    | 6    | LOCKWASHER,3/4",GR 8           |
| 7    | 6T2413   | 6    | HEX NUT,3/4,NF,GR 8            |
| 8    | 6T1024H5 | 1    | SPINDLE ASSY,CPLT,HD,5/8 HOLES |




## 50IN ROTARY MOWER ASSEMBLY

### Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                   |
|------|----------|------|-------------------------------|
| 9    | 6T2270   | 16   | PLOW BOLT,3/8" X 1" NC        |
| 10   | 22016    | 33   | FLATWASHER,3/8"               |
| 11   | 21625    | 20   | HEX NUT,3/8",NC               |
| 12   | 21988    | 11   | LOCKWASHER, 3/8"              |
| 13   | 21633    | 11   | CAPSCREW, 3/8 X 1 3/4,NC      |
| 14   | 33774    | 1    | FLAP RETAINER,50" RTRY        |
| 15   | 33775    | 2    | FLAP,50" RTRY                 |
| 16   | 6T1033   | 1    | COUPLER COVER                 |
| 17   | 6T1029   | 1    | COUPLER CHAIN                 |
| 18   | 21223    | 1    | SPROCKET                      |
| 19   | 21733    | 4    | CAPSCREW, 1/2 X 2,NC          |
| 20   | 33776    | 1    | MOTOR MOUNT,PLATE,50" RTRY    |
| 21   | 24490    | 1    | HOSE - PRESSURE               |
| ---  | 06500155 | 1    | HOSE- PRESSURE (LRS ONLY)     |
| 22   | TF4852   | 2    | FLANGE KIT - #20              |
| 23   | 06504012 | 1    | MOTOR                         |
| 24   | 24489    | 1    | HOSE - RETURN                 |
| ---  | 06500154 | 1    | HOSE-RETURN (LRS ONLY)        |
| 25   | 21725    | 4    | HEX NUT, 1/2" NC              |
| 26   | 06533004 | 4    | FLATWASHER, 1/2"              |
| 27   | 6T2290   | 4    | CAPSCREW,5/8X2,NF GR 8        |
| 28   | 33764    | 8    | FLATWASHER,5/8",GR 8,SAE      |
| 29   | 21992    | 4    | LOCKWASHER, 5/8               |
| 30   | 6T2408   | 4    | HEX NUT, 5/8, NF              |
| 31   | TF1124   | 1    | SQUARE KEY                    |
| 32   | 33881    | 2    | CAPSCREW,FLG, 3/8 X 3/4,NC    |
| 33   | 33779    | 1    | PLATE,COVER,KNF HOLE          |
| 34   | 06410439 | 1    | COVER                         |
| 35   | 22014    | 2    | FLATWASHER,1/4                |
| 36   | 21530    | 2    | CAPSCREW,1/4 X 1,NC           |
| 37   | 34187    | 1    | HOSE 1/4" X 75"               |
| 38   | 34186    | 1    | HOSE 1/4" X 66"               |
| 39   | RD1032   | 2    | LYNCH PIN                     |
| 40   | 33984    | 2    | PIN,SHIELD,50"                |
| 41   | 33785    | 1    | 1-1/2" X 8", CYLINDER, WELDED |
| 42   | 6T3017   | 2    | ROLLPIN                       |
| 43   | 33778    | 1    | HINGE PIN,50" RTRY            |
| 44   | 33772    | 1    | LINK, SHIELD 50" RTRY         |
| 45   | 21634    | 2    | CAPSCREW, 3/8" X 2, NC        |
| 46   | 33773    | 1    | LINK 2, SHIELD 50" RTRY       |


COMMON BENGAL T4

## 50IN ROTARY KNIVES AND DISH




| ITEM  | PART NO. | QTY. | DESCRIPTION  |
|-------|----------|------|--|
| ----- | 06700089 | -    | KIT,TRB50,DISK,W/BOLT KIT (INCLUDES ITEMS 1,3 & 7) |
| 1     | 06770003 | 1    | BLADE MOUNTING DISK                                |
| 2     | 6T1023R  | 2    | NYLOCK HEX NUT 1 1/8"                              |
| 3     | 34878    | 2    | SPACER   |
| 4     | 06538000 | 2    | KNIFE MOUNTING BOLT                                |
| 5     | 06521001 | 2    | STANDARD KNIFE                                     |
| 6     | 33764    | 6    | FLATWASHER   |
| 7     | 6T2259   | 6    | CAPSCREW   |
| ----- | 06770012 | -    | BOLT KIT (INCLUDES ITEMS 6, 7 & LOCTITE)           |
| 8     | 06521002 | 2    | GRASS KNIFE (OPTIONAL)                             |
| ----- | 6T1825   | -    | LOCTITE - USED ON ALL DISK MOUNTING BOLTS          |

## 50IN ROTARY BLADE BAR AND KNIVES



| ITEM | PART NO. | QTY. | DESCRIPTION                 |
|------|----------|------|-----------------------------|
| 1    | PT1018H5 | 1    | SPINDLE,5/8HOLES,HD,WO/TABS |
| 2    | 06400388 | 1    | BAR,BLADE,TRB               |
| 3    | 06521001 | 2    | KNIFE,TRB50,5/8             |
| 4    | 06538000 | 2    | KNIFE MTG BOLT,5/8 SHOULDER |
| 5    | 06533002 | 2    | FLATWASHER,1 1/8,GR 8       |
| 6    | 6T1023R  | 2    | KNIFE MTG NUT,1 1/8,NF,GR8  |
| 7    | 6T2259   | 6    | CAPSCREW,5/8X1-3/4,NF,GR8   |
| 8    | 33764    | 6    | FLATWASHER,5/8,GR 8,SAE     |

## 60IN ROTARY MOWER ASSEMBLY



| ITEM | PART NO. | QTY. | DESCRIPTION                    |
|------|----------|------|--------------------------------|
| 1    | 06320159 | 1    | DECK,WLDMNT,60" RTRY           |
| 2    | 33777    | 2    | SKID SHOE,RTRY                 |
| 3    | 06320162 | 1    | SHIELD,60"RTRY                 |
| 4    | 33879    | 6    | CAPSCREW, 3/4 X 2 1/4,NF GR 8  |
| 5    | 33880    | 6    | FLATWASHER,3/4",GR 8,SAE       |
| 6    | 21993    | 6    | LOCKWASHER,3/4",GR 8           |
| 7    | 6T2413   | 6    | HEX NUT,3/4,NF,GR 8            |
| 8    | 6T1024H5 | 1    | SPINDLE ASSY,CPLT,HD,5/8 HOLES |


## 60IN ROTARY MOWER ASSEMBLY

### Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                   |
|------|----------|------|-------------------------------|
| 9    | 6T2270   | 16   | PLOW BOLT, 3/8" X 1" NC       |
| 10   | 22016    | 33   | FLATWASHER, 3/8"              |
| 11   | 21625    | 20   | HEX NUT, 3/8", NC             |
| 12   | 21988    | 11   | LOCKWASHER, 3/8"              |
| 13   | 21633    | 11   | CAPSCREW, 3/8 X 1 3/4, NC     |
| 14   | 6T0823   | 1    | FLAP RETAINER, 60" RTRY       |
| 15   | 06520238 | 2    | FLAP, 60" RTRY                |
| 16   | 6T1033   | 1    | COUPLER COVER                 |
| 17   | 6T1029   | 1    | COUPLER CHAIN                 |
| 18   | 21223    | 1    | SPROCKET                      |
| 19   | 21733    | 4    | CAPSCREW, 1/2 X 2, NC         |
| 20   | 33776    | 1    | MOTOR MOUNT, PLATE, RTRY      |
| 21   | 24490    | 1    | HOSE - PRESSURE               |
| ---  | 06500155 | 1    | HOSE-PRESSURE (LRS ONLY)      |
| 22   | TF4852   | 2    | FLANGE KIT - #20              |
| 23   | 6504011  | 1    | MOTOR                         |
| 24   | 24489    | 1    | HOSE - RETURN                 |
| ---  | 06500154 | 1    | HOSE-RETURN (LRS ONLY)        |
| 25   | 21725    | 4    | HEX NUT, 1/2" NC              |
| 26   | 06533004 | 4    | FLATWASHER, 1/2"              |
| 27   | 6T2290   | 4    | CAPSCREW, 5/8X2, NF GR 8      |
| 28   | 33764    | 8    | FLATWASHER, 5/8", GR 8, SAE   |
| 29   | 21992    | 4    | LOCKWASHER, 5/8               |
| 30   | 6T2408   | 4    | HEX NUT, 5/8, NF              |
| 31   | TF1124   | 1    | SQUARE KEY                    |
| 32   | 33881    | 2    | CAPSCREW, FLG, 3/8 X 3/4, NC  |
| 33   | 33779    | 1    | PLATE, COVER, KNF HOLE        |
| 34   | 06410439 | 1    | COVER                         |
| 35   | 22014    | 2    | FLATWASHER, 1/4               |
| 36   | 21530    | 2    | CAPSCREW, 1/4 X 1, NC         |
| 37   | 34187    | 1    | HOSE 1/4" X 75"               |
| 38   | 34186    | 1    | HOSE 1/4" X 66"               |
| 39   | RD1032   | 2    | LYNCH PIN                     |
| 40   | 33984    | 2    | PIN, SHIELD                   |
| 41   | 33785    | 1    | 1-1/2" X 8", CYLINDER, WELDED |
| 42   | 6T3017   | 2    | ROLLPIN                       |
| 43   | 06420139 | 1    | HINGE PIN, 60" RTRY           |
| 44   | 33772    | 1    | LINK, SHIELD, RTRY            |
| 45   | 21634    | 2    | CAPSCREW, 3/8" X 2, NC        |
| 46   | 33773    | 1    | LINK 2, SHIELD, RTRY          |
| 47   | 06401245 | 2    | SKID SHOE, TRB60              |


COMMON BENGAL T4

## 60IN ROTARY KNIVES AND DISH




| ITEM | PART NO. | QTY. | DESCRIPTION                         |
|------|----------|------|-------------------------------------|
| 1    | 34876    | 1    | BLADE MOUNTING DISH,60"             |
| 2    | 6T1023R  | 2    | NYLOCK NUT,1-1/8",NF                |
| 3    | 34878    | 2    | SPACER                              |
| 4    | 34684    | 2    | STANDARD GRASS KNIFE                |
| 5    | 34685    | 2    | HIGH SUCTION GRASS KNIFE (OPTIONAL) |
| 6    | 34497    | 2    | KNIFE MOUNTING BOLT                 |
| 7    | 25270    | 6    | FLATWASHER,5/8",GR8,USS             |
| 8    | 6T2259   | 6    | CAPSCREW,5/8" X 1-3/4",NF,GR8       |
| ---  | 6T1825   | 1    | LOCTITE (USED ON ITEM 8)            |
| ---- | 27167    | 1    | BOLT KIT (ITEMS 7 & 8)              |
| ---  | 33893    | 1    | KNIFE KIT (ITEMS 2,4 & 6)           |

## 60IN ROTARY BLADE BAR AND KNIVES



| ITEM | PART NO. | QTY. | DESCRIPTION                   |
|------|----------|------|-------------------------------|
| 1    | PT1018H5 | 1    | SPINDLE                       |
| 2    | 06400690 | 1    | BAR,BLADE,RTRY60              |
| 3    | 6T1023R  | 2    | KNIFE MTG NUT,1-1/8,NYLOCK,NF |
| 4    | 06533002 | 2    | FLATWASHER,1-1/8,GR8          |
| 5    | 06521001 | 2    | KNIFE,TRB50,5/8               |
| 6    | 06538000 | 2    | KNIFE MTG BOLT,5/8 SHOULDER   |
| 7    | 33764    | 6    | FLATWASHER,5/8,GR 8,SAE       |
| 8    | 6T2259   | 6    | CAPSCREW,5/8 X 1-3/4,NF,GR8   |

## ROTARY MOWER SPINDLE ASSEMBLY



### NOTES:

1. FREEPLAY: .001" - .003"
2. GREASE: FILL WITH MOBILITH SHC 220.
3. APPLY LOCTITE "271" TO O-RING PLUG THRDS.




## ROTARY MOWER SPINDLE ASSEMBLY

Continued...

| ITEM  | PART NO. | QTY. | DESCRIPTION  |
|-------|----------|------|--|
| ----- | 6T1024H5 | -    | SPINDLE ASSEMBLY COMPLETE                              |
| 1     | 6T1031   | 1    | SPROCKET   |
| 2     | 6T1016   | 1    | BEARING LOCK NUT - THICK                               |
| 3     | 22596    | 1    | JAM WASHER   |
| 4     | 6T1015   | 1    | BEARING ADJUSTMENT NUT - THIN                          |
| 5     | 6T1014   | 1    | BEARING ADJUSTMENT SLEEVE                              |
| 6     | 6T1011   | 1    | UPPER SEAL - SET OF 2                                  |
| 7     | 6T1012   | 1    | BEARING CONE   |
| 8     | 6T1013   | 1    | BEARING CUP  |
| 9     | 6T1010H  | 1    | SPINDLE HOUSING  |
| 10    | 30570    | 1    | FITTING STREET ELBOW                                   |
| 11    | 33990    | 1    | GREASE ZERK  |
| 12    | 6T1013H  | 1    | BEARING CUP  |
| 13    | 6T1012H  | 1    | BEARING CONE   |
| 14    | 6T1011H  | 1    | LOWER SEAL   |
| 15    | 6T1019   | 1    | SPINDLE KEY  |
| 16    | PT1018H5 | 1    | SPINDLE  |
| 17    | 06503064 | 1    | O-RING PLUG, 1/8"                                      |
| ----- | 31771    | -    | SPINDLE REBUILD KIT (INCLUDES ITEMS 2 - 8 AND 12 - 15) |

COMMON BENGAL T4

# BOOM ROTARY PIVOT ASSEMBLY




## BOOM ROTARY PIVOT ASSEMBLY

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                             |
|------|----------|------|---|
| 1    | TB1032   | 1    | ROTARY PIVOT ASSY                       |
| 2    | TB1028   | 1    | PIVOT ARM ASSY                          |
| 3    | TB1033   | 1    | PIN,CLEVIS                              |
| 4    | 06537021 | 2    | ROLL PIN                                |
| 5    | TF3097   | 1    | PIN                                     |
| 6    | TB1030   | 1    | PIN                                     |
| 7    | 33985    | 1    | PIN                                     |
| 8    | 33986    | 1    | PIN                                     |
| 9    | 21688    | 1    | CAPSCREW,7/16 X 3-1/4,NC                |
| 10   | 21677    | 1    | NYLOCK NUT,7/16 NC                      |
| 11   | 21635    | 3    | CAPSCREW,3/8 X 2-1/4                    |
| 12   | 6T3207   | 3    | GREASE ZERK                             |
| 13   | 21627    | 3    | NYLOCK NUT,3/8,NC                       |
| 14   | TB3010   | 3    | BUSHING                                 |
| 15   | -----    | -    | SECONDARY BOOM *REFER TO BOOM ARM ASSY  |
| 16   | -----    | -    | CYLINDER *REFER TO BOOM ARM ASSY        |
| 17   | -----    | -    | ROTARY MOWER HEAD *REFER TO ROTARY DECK |

## 50IN FLAIL DRIVE ASSEMBLY




## 50IN FLAIL DRIVE ASSEMBLY

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                            |
|------|----------|------|--|
| 1    | 06504132 | 1    | MOTOR (M350-1 3/4" GEAR)               |
| 2    | TF3006   | 1    | BELT GUARD                             |
| 3    | TF3043   | 2    | SHEAVE                                 |
| 4    | TF3013   | 1    | BUSHING                                |
| 5    | TF3011   | 1    | BUSHING                                |
| 6    | TF3034   | 1    | IDLER PULLEY                           |
| 7    | TF3205   | 1    | IDLER ARM                              |
| 8    | TF3206   | 2    | IDLER PULLEY SPACER                    |
| 9    | TF3605   | 1    | IDLER ARM PIN WITH ZERK                |
| 10   | 6T3004   | 1    | R - CLIP                               |
| 11   | PT3611A  | 1    | CLEVIS                                 |
| 12   | 32481    | 1    | THREADED ROD                           |
| 13   | TF3620   | 1    | COMPRESSION SPRING                     |
| 14   | 21789    | 1    | CAPSCREW 5/8" X 3 1/2"                 |
| 15   | 21992    | 1    | LOCKWASHER 5/8"                        |
| 16   | 21775    | 1    | HEX NUT 5/8"                           |
| 17   | 21732    | 5    | CAPSCREW 1/2" X 1 3/4"                 |
| 18   | 21990    | 4    | LOCKWASHER 1/2"                        |
| 19   | 21725    | 4    | HEX NUT 1/2"                           |
| 20   | 6T2418   | 1    | LOCK NUT 1/2"                          |
| 21   | 21630    | 4    | CAPSCREW 3/8" X 1"                     |
| 22   | 21988    | 4    | LOCKWASHER 3/8"                        |
| 23   | 22016    | 4    | FLATWASHER 3/8"                        |
| 24   | 21584    | 6    | CAPSCREW 5/16" X 2"                    |
| 25   | 21987    | 6    | LOCKWASHER 5/16"                       |
| 26   | 27938    | 1    | FLATWASHER 1/2"                        |
| 27   | 21700    | 2    | HEX NUT 1/2" NF                        |
| 28   | TF3021   | 2    | BELT                                   |
| 29   | TF1125   | 1    | SQUARE KEY                             |
| 30   | TF1025   | 1    | SQUARE KEY MOTOR                       |
| 31   | TF4852   | 2    | FLANGE KIT                             |
| 32   | 34227    | 1    | PREFORMED TUBE                         |
| 33   | 31218    | 1    | HOSE - RETURN                          |
| 34   | 34331    | 1    | HOSE - PRESSURE                        |
| 35   | 24724    | 2    | SWIVEL FITTING                         |
| 36   | -----    | -    | CUTTER HEAD *REFER TO CUTTER HEAD ASSY |

COMMON BENGAL T4

## 50IN FLAIL MOWER ASSEMBLY



| ITEM | PART NO. | QTY. | DESCRIPTION   |
|------|----------|------|---|
| ---  | 34787    | 1    | FLAIL,BOOM,50,BRUSH,CPLT ASSY (LIGHT BRUSH/GRASS)     |
| ---  | 06742133 | 1    | FLAIL,BOOM,50,MD GRASS,CPLT ASSY (MEDIUM BRUSH/GRASS) |
| 1    | TF3003F  | 1    | CUTTER HEAD BONNET                                    |
| 2    | TF3004   | 1    | FRONT SHIELD  |


## 50IN FLAIL MOWER ASSEMBLY

### Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                           |
|------|----------|------|---------------------------------------|
| 3    | 34783    | 1    | TBF50 (LIGHT BRUSH/GRASS KNIFE ASSY)  |
| ---- | 06700115 | 1    | TBF50 (MEDIUM BRUSH/GRASS KNIFE ASSY) |
| 4    | 6T2419   | 24   | HEX NUT,9/16",NC,STOVER               |
| 5    | 06420182 | 24   | BUSHING                               |
| 6    | 34782    | 24   | CLEVIS (LIGHT BRUSH/GRASS KNIVES)     |
| 7    | 34786    | 24   | CAPSCREW,9/16" X 3-1/2",NC            |
| 8    | 34780    | 24   | KNIFE (LIGHT BRUSH/GRASS CUTTING)     |
| 9    | 31204    | 2    | STRING GUARD SET (2 PIECES PER SET)   |
| 10   | TF1018   | 2    | FLANGE BEARING,2-3/16"                |
| 11   | 21625    | 23   | HEX NUT,3/8",NC                       |
| 12   | 21988    | 7    | LOCKWASHER,3/8"                       |
| 13   | 22016    | 30   | FLATWASHER,3/8"                       |
| 14   | 21631    | 2    | CAPSCREW,3/8" X 1-1/4",NC             |
| 15   | 21630    | 5    | CAPSCREW,3/8" X 1",NC                 |
| 16   | 6T7031D  | 4    | PLOW BOLT,1/2" X 1-1/2",NC            |
| 17   | 21731    | 6    | CAPSCREW,1/2" X 1-1/2",NC             |
| 18   | 21990    | 18   | LOCKWASHER,1/2"                       |
| 19   | 21725    | 10   | HEX NUT,1/2",NC                       |
| 20   | TF1040   | 1    | CUTTER SHAFT GUARD                    |
| 21   | TF3007A  | 1    | COVER PLATE                           |
| 22   | 21825    | 1    | HEX NUT,5/8",NC                       |
| 23   | 21838    | 1    | CAPSCREW,3/4" X 3-1/2",NC             |
| 24   | TF3406   | 1    | GROUND ROLLER TIE ROD                 |
| 25   | TF1022   | 2    | FLANGE BEARING,1-3/8"                 |
| 26   | TF3407   | 2    | GROUND ROLLER ADJUSTMENT BRACKET      |
| 27   | TF3405   | 1    | GROUND ROLLER                         |
| 28   | 6T1023R  | 2    | NYLOCK NUT,1-1/8",NF                  |
| 29   | 6T2330   | 8    | CAPSCREW,7/16" X 1-1/2",SOCKET HEAD   |
| 30   | TB1008   | 1    | FLAP RETAINING BAR                    |
| 31   | 21633    | 9    | CAPSCREW,3/8" X 1-3/4",NC             |
| 32   | TB1006A  | 2    | DEFLECTOR FLAP                        |
| 33   | 6T2270   | 12   | PLOWBOLT,3/8" X 1",NC                 |
| 34   | TF3001   | 2    | SKID SHOE                             |
| 35   | 06530218 | 8    | CAPSCREW,1/2" X 1-3/4",NC             |
| 36   | TF1032   | 1    | FLANGE BEARING GREASE HOSE            |
| 37   | 06420183 | 24   | SPACER (MEDIUM BRUSHGRASS KNIVES)     |
| 38   | 06521007 | 48   | KNIFE (MEDIUM BRUSH/GRASS CUTTING)    |

COMMON BENGAL T4

## 50IN FLAIL MOWER ASSY, PASS-THROUGH KNIVES






## 50IN FLAIL MOWER ASSY, PASS-THROUGH KNIVES

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                         |
|------|----------|------|-------------------------------------|
| ---  | 34172    | 1    | FLAIL,BOOM,50,CPLT ASSY             |
| 1    | TF3003F  | 1    | CUTTER HEAD BONNET                  |
| 2    | TF3004   | 1    | FRONT SHIELD                        |
| 3    | 33717    | 1    | TBF50,CUTTERSHAFT,PASS THRU KNIVES  |
| 4    | TF3405   | 1    | GROUND ROLLER                       |
| 5    | TF3406   | 1    | GROUND ROLLER TIE ROD               |
| 6    | TB1006A  | 2    | DEFLECTOR FLAP                      |
| 7    | TB1008   | 1    | FLAP RETAINING BAR                  |
| 8    | TF3001   | 2    | SKID SHOE                           |
| 9    | TF3407   | 2    | GROUND ROLLER ADJUSTMENT BRACKET    |
| 10   | TF1022   | 2    | FLANGE BEARING,1-3/8"               |
| 11   | TF1018   | 2    | FLANGE BEARING,2-3/16"              |
| 12   | TF3007A  | 1    | COVER PLATE                         |
| 13   | TF1040   | 1    | CUTTER SHAFT GUARD                  |
| 14   | 33858    | 24   | SPACER,COLLAR                       |
| 15   | 33857    | 24   | SHOULDER,BUSHING                    |
| 16   | 46399.01 | 24   | KNIFE,FLAIL,FORGED                  |
| 17   | 33854    | 24   | CAPSCREW,5/8" X 4-1/2",NC           |
| 18   | 32674    | 24   | HEX NUT,5/8",NC                     |
| 19   | 21838    | 1    | CAPSCREW,3/4" X 3-1/2",NC           |
| 20   | 21825    | 1    | HEX NUT,5/8",NC                     |
| 21   | 21732    | 8    | CAPSCREW,1/2" X 1-3/4",NC           |
| 22   | 21731    | 6    | CAPSCREW,1/2" X 1-1/2",NC           |
| 23   | 21990    | 18   | LOCKWASHER,1/2"                     |
| 24   | 21725    | 10   | HEX NUT,1/2",NC                     |
| 25   | 6T2270   | 12   | PLOWBOLT,3/8" X 1",NC               |
| 26   | 21631    | 2    | CAPSCREW,3/8" X 1-1/4",NC           |
| 27   | 21630    | 5    | CAPSCREW,3/8" X 1",NC               |
| 28   | 21988    | 7    | LOCKWASHER,3/8"                     |
| 29   | 21625    | 23   | HEX NUT,3/8",NC                     |
| 30   | 22016    | 30   | FLATWASHER,3/8"                     |
| 31   | 21633    | 9    | CAPSCREW,3/8" X 1-3/4",NC           |
| 32   | 6T7031D  | 4    | PLOW BOLT,1/2" X 1-1/2",NC          |
| 33   | 6T2330   | 8    | CAPSCREW,7/16" X 1-1/2",NC,SCKT HD  |
| 34   | 6T1023R  | 2    | NYLOCK NUT,1-1/8",NF                |
| 35   | TF1032   | 1    | FLANGE BEARING GREASE HOSE          |
| 36   | 31204    | 2    | STRING GUARD SET (2 PIECES PER SET) |

COMMON BENGAL T4

# 63IN FLAIL DRIVE ASSEMBLY




## 63IN FLAIL DRIVE ASSEMBLY

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                      |
|------|----------|------|----------------------------------|
| 1    | 06504132 | 1    | MOTOR (M350-1 3/4 GEAR)          |
| 2    | 32569    | 1    | BELT GUARD                       |
| 3    | TF3044   | 1    | UPPER SHEAVE                     |
| 4    | TF3040   | 1    | LOWER SHEAVE                     |
| 5    | TF3013   | 1    | BUSHING                          |
| 6    | 28723    | 1    | BUSHING                          |
| 7    | 28679B   | 1    | MOTOR CHANNEL                    |
| 8    | PT3611A  | 1    | CLEVIS                           |
| 9    | 40496    | 1    | THREADED ROD                     |
| 10   | 28702    | 2    | BELT                             |
| 11   | TF3620A  | 1    | TENSIONER SPRING                 |
| 12   | 28572    | 1    | SQUARE KEY                       |
| 13   | 26142A   | 1    | SQUARE KEY                       |
| 14   | TF4852   | 2    | FLANGE KIT                       |
| 15   | 30308    | 1    | HOSE,1 X 69 - PRESSURE           |
| 16   | 30309    | 1    | HOSE,1 X 78 - RETURN             |
| 17   | 24724    | 2    | SWIVEL FITTING                   |
| 18   | TF1033   | 1    | GREASE ZERK                      |
| 19   | 27580    | 2    | BUSHING                          |
| 20   | 28682    | 1    | MOTOR CHANNEL WASHER             |
| 21   | 21732    | 5    | CAPSCREW 1/2" X 1 3/4"           |
| 22   | 21990    | 4    | LOCKWASHER 1/2"                  |
| 23   | 21725    | 4    | HEX NUT 1/2"                     |
| 24   | 6T2418   | 1    | STOVER NUT 1/2"                  |
| 25   | 21630    | 3    | CAPSCREW 3/8" X 1"               |
| 26   | 22016    | 2    | FLATWASHER 3/8"                  |
| 27   | 21988    | 3    | LOCKWASHER 3/8"                  |
| 28   | 21584    | 6    | CAPSCREW 5/16" X 2"              |
| 29   | 21987    | 6    | LOCKWASHER 5/16"                 |
| 30   | 27938    | 1    | FLATWASHER 1/2"                  |
| 31   | 21700    | 2    | HEX NUT 1/2" NF                  |
| 32   | -----    | -    | CUTTER HEAD *REFER TO MOWER ASSY |

## 63IN FLAIL MOWER ASSEMBLY




## 63IN FLAIL MOWER ASSEMBLY

Continued...

| ITEM  | PART NO. | QTY. | DESCRIPTION                               |
|-------|----------|------|---|
| ----- | 06200271 | -    | FLAIL,BOOM,63,GRASS,CPLT ASSY             |
| 1     | 28659H   | 1    | CUTTER HEAD BONNET                        |
| 2     | 28743    | -    | CUTTER SHAFT / KNIFE ASSY STANDARD GRASS  |
| ----- | 28642C   | 1    | CUTTER SHAFT,63,STD                       |
| 3     | 34011    | 36   | FLAIL KNIFE MOUNTING BOLT                 |
| 4     | TF1020   | 36   | FLAIL KNIFE MOUNTING CLEVIS               |
| 5     | 33713    | 72   | FLAIL KNIFE - STANDARD                    |
| 6     | 21677    | 36   | NYLOCK NUT                                |
| 7     | 28086A   | 2    | SKID SHOE                                 |
| 8     | 27975A   | 1    | CUTTER SHAFT GUARD                        |
| 9     | 21725    | 14   | HEX NUT 1/2"                              |
| 10    | 21990    | 14   | LOCKWASHER 1/2"                           |
| 11    | 21731    | 6    | CAPSCREW 1/2" X 1 1/2"                    |
| 12    | 06320240 | 1    | GROUND ROLLER                             |
| 13    | 33863    | 2    | STRING GUARD,STD                          |
| 14    | 06533006 | 8    | FLATWASHER,1/2",SAE,L9                    |
| 15    | 28700    | 1    | FLAP RETAINING BAR                        |
| 16    | 21633    | 11   | CAPSCREW 3/8" X 1 3/4"                    |
| 17    | 21988    | 28   | LOCKWASHER 3/8"                           |
| 18    | 28701    | 2    | DEFLECTOR FLAP                            |
| 19    | 21625    | 28   | HEX NUT 3/8"                              |
| 20    | TF1045B  | 2    | GROUND ROLLER STUB SHAFT                  |
| 21    | 6T2330   | 8    | CAPSCREW 7/16" X 1 1/2" SOCKET HEAD       |
| 22    | 28735    | 2    | ADJUSTABLE ROLLER BRACKET                 |
| 23    | 06520028 | 2    | BEARING,FLANGE,1-3/8,GRNDRLLR             |
| 24    | 06520029 | 2    | O-RING                                    |
| 25    | 06520027 | 2    | CAP,BEARING,GROUNDROLLER                  |
| 26    | 06530001 | 12   | CAPSCREW,SKT HD,8-32 X 1/2,SS             |
| 27    | 6T2331   | 8    | CAPSCREW 7/16" X 1" SOCKET HEAD           |
| 28    | 6T2270   | 10   | PLOW BOLT 3/8" X 1 1/4"                   |
| 29    | 06530217 | 8    | CAPSCREW 1/2" X 2",L9                     |
| 30    | 28683    | 2    | FLANGE BEARING                            |
| 31    | TF1032   | 1    | FLANGE BEARING GREASE HOSE                |
| 32    | 6T2615   | 7    | FENDER WASHER 3/8"                        |
| 33    | 6T2283   | 7    | CARRIAGE BOLT 3/8" X 1"                   |
| 34    | 28665A   | 1    | BAFFLE (INSIDE UPPER REAR OF CUTTER HEAD) |

COMMON BENGAL T4

# BOOM FLAIL PIVOT ASSEMBLY




## BOOM FLAIL PIVOT ASSEMBLY

### Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                               |
|------|----------|------|---|
| 1    | TF3015   | 1    | FLAIL PIVOT ASSY                          |
| 2    | TB1028   | 1    | PIVOT ARM ASSY                            |
| 3    | TB1033   | 1    | PIN CLEVIS                                |
| 4    | 06537021 | 2    | ROLL PIN                                  |
| 5    | TF3097   | 1    | PIN                                       |
| 6    | TF3090   | 1    | PIN                                       |
| 7    | TB1024   | 1    | PIN                                       |
| 8    | TB1027   | 1    | PIN                                       |
| 9    | 21688    | 1    | CAPSCREW 7/16" X 3 1/4"                   |
| 10   | 21677    | 1    | NYLOCK NUT 7/16"                          |
| 11   | 21635    | 3    | CAPSCREW 3/8" X 2 1/4"                    |
| 12   | 21627    | 4    | NYLOCK NUT 3/8"                           |
| 13   | TB5030   | 3    | BUSHING                                   |
| 14   | 6T3207   | 3    | GREASE ZERK                               |
| 15   | -----    | -    | SECONDARY BOOM *REFER TO BOOM ARM ASSY    |
| 16   | -----    | -    | CYLINDER - REFER TO BOOM ARM ASSY         |
| 17   | -----    | -    | FLAIL MOWER HEAD *REFER TO FLAIL ASSY     |
| 18   | 31723    | 1    | CLAMP KIT,TBF50 (USED ON 50" FLAIL)       |
| 19   | TB3031   | 2    | DOUBLE HOSE CLAMP (USED ON THE 63" FLAIL) |
| 20   | 21638    | 1    | CAPSCREW 3/8" X 3"                        |
| 21   | 35312    | 2    | SPLIT COLLAR                              |

## 3IN X 13-7/8 IN WELDED CYLINDER BREAKDOWN




**WARNING** - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.

| ITEM | PART NO. | QTY. | DESCRIPTION                               |
|------|----------|------|---|
| ---  | 06501029 | -    | CYLINDER,WELDED,3" X 13.87"               |
| 1    | 06501630 | 1    | PISTON ROD ASSY                           |
| 2    | 06501648 | 1    | BUTT & TUBE ASSY                          |
| 3    | 06501649 | 1    | PISTON                                    |
| 4    | 34574    | 1    | GLAND                                     |
| 5    | 34575    | 1    | LOCK NUT,1"-14 UNS (TORQUE TO 315 FT.LB.) |
| 6    | 34576    | 1    | SPACER                                    |
| 7    | 34577    | 1    | CHECK VALVE,KEPNER                        |
| 8    | 06501650 | 1    | ORIFICE, ZERO LEAK, 0225                  |
| 9    | 33761    | 1    | SEAL KIT,PACKING (ITEMS 12 THRU 19)       |
| 10   | -----    | 2    | GREASE ZERK                               |
| 12   | -----    | 1    | O - RING                                  |
| 13   | -----    | 1    | CAST IRON PISTON RING                     |
| 14   | -----    | 1    | CROWN SEAL                                |
| 15   | -----    | 1    | O - RING                                  |
| 16   | -----    | 1    | O - RING                                  |
| 17   | -----    | 1    | BACK - UP WASHER                          |
| 18   | -----    | 1    | U - CUP                                   |
| 19   | -----    | 1    | WIPER                                     |
| 20   | 34334    | -    | SPHERICAL BEARING (NOT SHOWN)             |




## 3IN X 18IN WELDED CYLINDER BREAKDOWN



**WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.**

| ITEM  | PART NO. | QTY. | DESCRIPTION                          |
|-------|----------|------|--------------------------------------|
| ----- | 06501023 | -    | HYDRAULIC CYLINDER COMPLETE          |
| 1     | 06501561 | 1    | ROD                                  |
| 2     | 06501562 | 1    | TUBE WELDMENT                        |
| 3     | 06501552 | 1    | PISTON                               |
| 4     | 06501563 | 1    | CYLINDER HEAD                        |
| 5     | 06501554 | 1    | CLEVIS                               |
| ----- | 06501564 | -    | SEAL REPAIR KIT (ITEMS 6 THROUGH 12) |


### 3-1/2IN X 20IN WELDED CYLINDER BREAKDOWN



**WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.**

| ITEM  | PART NO. | QTY. | DESCRIPTION                          |
|-------|----------|------|--------------------------------------|
| ----- | 06501024 | -    | HYDRAULIC CYLINDER COMPLETE          |
| 1     | 06501565 | 1    | ROD                                  |
| 2     | 06501566 | 1    | TUBE WELDMENT                        |
| 3     | 06501567 | 1    | PISTON                               |
| 4     | 06501568 | 1    | CYLINDER HEAD                        |
| 5     | TB3033   | -    | CLEVIS                               |
| ----- | 06501569 | -    | SEAL REPAIR KIT (ITEMS 6 THROUGH 12) |


## 4IN X 20IN WELDED CYLINDER BREAKDOWN



**WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.**

| ITEM  | PART NO. | QTY. | DESCRIPTION                          |
|-------|----------|------|--------------------------------------|
| ----- | 06501022 | -    | HYDRAULIC CYLINDER COMPLETE          |
| 1     | 06501556 | 1    | ROD                                  |
| 2     | 06501557 | 1    | TUBE WELDMENT                        |
| 3     | 06501558 | 1    | PISTON                               |
| 4     | 06501559 | 1    | CYLINDER HEAD                        |
| 5     | 6T0172   | 1    | CLEVIS                               |
| 5A    | 30172    | -    | CLEVIS (FOR EXTENDED BOOM)           |
| ----- | 06501560 | -    | SEAL REPAIR KIT (ITEMS 6 THROUGH 12) |

## 5IN X 20IN WELDED CYLINDER BREAKDOWN





**WARNING - MECHANICAL FASTENERS MUST BE TORQUED TO RECOMMENDED SPECIFICATIONS DURING REPAIR TO PREVENT PERSONAL INJURY OR EQUIPMENT DAMAGE.**

| ITEM  | PART NO. | QTY. | DESCRIPTION                          |
|-------|----------|------|--------------------------------------|
| ----- | 06501020 | -    | HYDRAULIC CYLINDER COMPLETE          |
| 1     | 06501544 | 1    | ROD                                  |
| 2     | 06501545 | 1    | TUBE WELDMENT                        |
| 3     | 06501546 | 1    | PISTON                               |
| 4     | 06501547 | 1    | CYLINDER HEAD                        |
| 5     | 06501548 | 1    | CLEVIS                               |
| ----- | 06501549 | -    | SEAL REPAIR KIT (ITEMS 6 THROUGH 12) |

## NOTES

## NOTES

## 5 SPOOL ELECTRONIC VALVE - OPEN STOW,3PS



| ITEM  | PART NO. | QTY. | DESCRIPTION         |
|-------|----------|------|---------------------|
| ----  | 06700224 | -    | VALVE, 5SP, OS      |
| ----- | 06502097 | -    | VALVE, SUB-ASSEMBLY |
| 1     | 06502074 | 1    | END PLATE           |
| 1S    | 06505013 | 1    | END PLATE SEAL KIT  |
| 2     | -----    | 5    | BONNET              |
| 2S    | 06505042 | 1    | BONNET SEAL KIT     |


## 5 SPOOL ELECTRONIC VALVE - OPEN STOW,3PS

**Continued...**

| ITEM | PART NO. | QTY. | DESCRIPTION                        |
|------|----------|------|------------------------------------|
| 2A   | 42197    | 1    | MAIN BOOM BONNET                   |
| 2B   | 42197    | 1    | SECONDARY BOOM BONNET              |
| 2C   | 42197    | 1    | DECK ROLL BONNET                   |
| 2D   | 42197    | 1    | BOOM SWIVEL BONNET                 |
| 2E   | 42197    | 1    | DECK SHIELD BONNET                 |
| 3    | 34308    | 1    | INLET SECTION                      |
| 3S   | 06505013 | 1    | INLET SECTION SEAL KIT             |
| 4    | -----    | 5    | ELECTRONIC ACCUATOR                |
| 4A   | 06502101 | 1    | MAIN BOOM ELECTRONIC ACCUATOR      |
| 4B   | 06502101 | 1    | SECONDARY BOOM ELECTRONIC ACCUATOR |
| 4C   | 06502100 | 1    | DECK ROLL ELECTRONIC ACCUATOR      |
| 4D   | 06502101 | 1    | BOOM SWIVEL ELECTRONIC ACCUATOR    |
| 4E   | 06502099 | 1    | DECK SHIELD ELECTRONIC ACCUATOR    |
| 5    | 42202    | 1    | TIE-BOLT KIT                       |
| 6    | -----    | 5    | SECTION                            |
| 6S   | 06505013 | 1    | SECTION SEAL KIT                   |
| 6A   | 42698    | 1    | MAIN BOOM SECTION                  |
| 6B   | 42698    | 1    | SEC BOOM SECTION                   |
| 6C   | 06502076 | 1    | DECK ROLL SECTION                  |
| 6D   | 42698    | 1    | BOOM SWIVEL SECTION                |
| 6E   | 06502077 | 1    | SHIELD SECTION                     |
| 7    | -----    | 5    | SPOOL                              |
| 7A   | 42697    | 1    | MAIN BOOM SPOOL                    |
| 7B   | 42697    | 1    | SEC BOOM SPOOL                     |
| 7C   | 4242106  | 1    | DECK ROLL SPOOL                    |
| 7D   | 06502073 | 1    | BOOM SWIVEL SPOOL                  |
| 7E   | 42201    | 1    | DECK SHIELD SPOOL                  |
| 8    | -----    | 10   | ANTI CAV/SHOCK RELIEF              |
| 8A1  | 06502084 | 1    | MAIN BOOM A PORT RELIEF            |
| 8A2  | 06502081 | 1    | MAIN BOOM B PORT RELIEF            |
| 8B1  | 42296    | 1    | SEC BOOM A PORT RELIEF             |
| 8B2  | 06502082 | 1    | SEC BOOM B PORT RELIEF             |
| 8C1  | 42295    | 1    | DECK ROLL A PORT RELIEF            |
| 8C2  | 06502082 | 1    | DECK ROLL B PORT RELIEF            |
| 8D1  | 06502070 | 1    | BOOM SWIVEL A PORT RELIEF          |
| 8D2  | 06502083 | 1    | BOOM SWIVEL B PORT RELIEF          |
| 8E1  | 06502081 | 1    | DECK SHIELD A PORT RELIEF          |
| 8E2  | 06502081 | 1    | DECK SHIELD B PORT RELIEF          |
| 9    | 33459    | 1    | HANDLE                             |

COMMON BENGAL T4

## 5 SPOOL ELECTRONIC VALVE - SIDE STOW



| ITEM  | PART NO. | QTY. | DESCRIPTION             |
|-------|----------|------|-------------------------|
| ----- | 06502096 | -    | VLV,5SP,32PVG,SIDE STOW |
| 1     | 06502074 | 1    | END PLATE               |
| 1S    | 06505013 | 1    | END PLATE SEAL KIT      |
| 2     | -----    | 5    | BONNET                  |
| 2S    | 06505042 | 1    | BONNET SEAL KIT         |
| 2A    | 42197    | 1    | MAIN BOOM BONNET        |
| 2B    | 42197    | 1    | SECONDARY BOOM BONNET   |
| 2C    | 42197    | 1    | DECK ROLL BONNET        |
| 2D    | 42197    | 1    | BOOM SWIVEL BONNET      |
| 2E    | 42197    | 1    | DECK SHIELD BONNET      |




## 5 SPOOL ELECTRONIC VALVE - SIDE STOW

Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                        |
|------|----------|------|------------------------------------|
| 3    | 34308    | 1    | INLET SECTION                      |
| 3S   | 06505013 | 1    | INLET SECTION SEAL KIT             |
| 4    | -----    | 5    | ELECTRONIC ACCUATOR                |
| 4A   | 06502101 | 1    | MAIN BOOM ELECTRONIC ACCUATOR      |
| 4B   | 06502101 | 1    | SECONDARY BOOM ELECTRONIC ACCUATOR |
| 4C   | 06502100 | 1    | DECK ROLL ELECTRONIC ACCUATOR      |
| 4D   | 06502101 | 1    | BOOM SWIVEL ELECTRONIC ACCUATOR    |
| 4E   | 06502099 | 1    | DECK SHIELD ELECTRONIC ACCUATOR    |
| 5    | 42202    | 1    | TIE-BOLT KIT                       |
| 6    | -----    | 5    | SECTION                            |
| 6S   | 06505013 | 1    | SECTION SEAL KIT                   |
| 6A   | 42698    | 1    | MAIN BOOM SECTION                  |
| 6B   | 42698    | 1    | SEC BOOM SECTION                   |
| 6C   | 06502076 | 1    | DECK ROLL SECTION                  |
| 6D   | 42698    | 1    | BOOM SWIVEL SECTION                |
| 6E   | 06502077 | 1    | SHIELD SECTION                     |
| 7    | -----    | 5    | SPOOL                              |
| 7A   | 42697    | 1    | MAIN BOOM SPOOL                    |
| 7B   | 42697    | 1    | SEC BOOM SPOOL                     |
| 7C   | 4242106  | 1    | DECK ROLL SPOOL                    |
| 7D   | 06502073 | 1    | BOOM SWIVEL SPOOL                  |
| 7E   | 42201    | 1    | DECK SHIELD SPOOL                  |
| 8    | -----    | 10   | ANTI CAV/SHOCK RELIEF              |
| 8A1  | 42650    | 1    | MAIN BOOM A PORT RELIEF            |
| 8A2  | 06502069 | 1    | MAIN BOOM B PORT RELIEF            |
| 8B1  | 42650    | 1    | SEC BOOM A PORT RELIEF             |
| 8B2  | 42295    | 1    | SEC BOOM B PORT RELIEF             |
| 8C1  | 42296    | 1    | DECK ROLL A PORT RELIEF            |
| 8C2  | 42295    | 1    | DECK ROLL B PORT RELIEF            |
| 8D1  | 42295    | 1    | BOOM SWIVEL A PORT RELIEF          |
| 8D2  | 42295    | 1    | BOOM SWIVEL B PORT RELIEF          |
| 8E1  | 06502069 | 1    | DECK SHIELD A PORT RELIEF          |
| 8E2  | 06502069 | 1    | DECK SHIELD B PORT RELIEF          |
| 9    | 33459    | 1    | HANDLE                             |

COMMON BENGAL T4

# FRONT HYDRAULIC PUMP



©2015 Alamo Group Inc.


Parts Section 6-52

## FRONT HYDRAULIC PUMP

### Continued...

| ITEM | PART NO. | QTY. | DESCRIPTION                           |
|------|----------|------|---------------------------------------|
| ---  | 23152    | 1    | PUMP ASSEMBLY,1-3/4",COMPLETE         |
| 1    | 22766    | 1    | SHAFT END COVER                       |
| 2    | 22779    | 1    | PORT END COVER                        |
| 3    | 22774    | 1    | GEAR HOUSING,1-3/4"                   |
| 4    | 22771    | 1    | GEAR SET                              |
| 5    | 23824    | 4    | CAPSCREW                              |
| 6    | 06504078 | 2    | SCREW,DRIVE                           |
| 7    | 22773    | 4    | DOWEL PINS                            |
| 8    | 06504077 | 1    | NAMEPLATE                             |
| 9    | 22770    | 2    | THRUST PLATE                          |
| 10   | 22767    | 1    | PLUG                                  |
| 11   | 06504075 | 2    | SEAL,BK-UP                            |
| 12   | 06504074 | 2    | SEAL,CHAN                             |
| 13   | 22765    | 1    | SEAL,LIP                              |
| 14   | 06504076 | 2    | SEAL,SQ-R                             |
| 15   | 02961917 | 4    | WASHER                                |
| ---  | 24150    | 1    | SEAL KIT (INCLUDES 11, 12, 13 AND 14) |

## 50IN AND 60IN ROTARY MOTOR BREAKDOWN




## 50IN AND 60IN ROTARY MOTOR BREAKDOWN

Continued...

| ITEM  | PART NO. | QTY. | DESCRIPTION          |
|-------|----------|------|----------------------|
|       | 06504011 | -    | MOTOR ASSEMBLY,TRB60 |
|       | 06504012 | -    | MOTOR ASSEMBLY,TRB50 |
| 1     | 22790    | 1    | HOUSING, SEC         |
| 2     | 06504088 | 1    | HOUSING, PEC         |
| 3     | 06504062 | 1    | HOUSING, GEAR,TRB60  |
| ----- | 06504089 | -    | HOUSING, GEAR,TRB50  |
| 4     | 06504090 | 1    | SET, GEAR SHAFT      |
| 5     | 06504104 | 4    | CAP SCREW,TRB60      |
| ----- | 06504091 | -    | CAP SCREW,TRB50      |
| 6     | 06504078 | 2    | SCREW, DRIVE         |
| 7     | 06504092 | 1    | KEY                  |
| 8     | 06504093 | 4    | PIN, DOWEL           |
| 9     | 06504094 | 1    | NAME PLATE           |
| 10    | 06504095 | 2    | THRPL                |
| 11    | 2961940  | 1    | PLUG, ODT            |
| 12    | 2962200  | 1    | RING, SNAP           |
| 13    | 06504096 | 1    | O RING               |
| 14    | 6T5101   | 1    | SEAL, LIP            |
| 15    | 06504097 | 1    | SEAL, LIP            |
| 16    | 22797    | 2    | SEAL, SQ-R           |
| 17    | 06504098 | 4    | SEAL, SIDE CHAN      |
| 18    | 06504099 | 4    | SEAL, END CHAN       |
| 19    | 06504100 | 2    | SEAL, BK-UP          |
| 20    | 06504101 | 1    | RTNR, SEAL           |
| 21    | 6T5809   | 2    | CHECK ASS'Y          |
| 22    | 06504102 | 4    | WASHER               |
| ----- | 06504103 | -    | SEAL KIT             |

COMMON BENGAL T4

| FLAIL MOTOR BREAKDOWN |  |
|-----------------------|--|
|-----------------------|--|



COMMON BENGAL T4


## FLAIL MOTOR BREAKDOWN

**Continued...**

| ITEM | PART NO. | QTY. | DESCRIPTION                       |
|------|----------|------|-----------------------------------|
| *    | 06504132 | -    | MOTOR ASSEMBLY 350 - TBF50, TBF63 |
| 1    | 06504141 | 1    | SHAFT END COVER                   |
| 2    | 06504040 | 1    | PORT END COVER                    |
| 3    | 06504041 | 1    | GEAR HOUSING                      |
| 4    | 06504117 | 1    | MATCHED GEAR SET                  |
| 5    | TF4402   | 1    | BALL BEARING                      |
| 6    | 06504043 | 4    | CAP SCREW                         |
| 7    | 06504044 | 2    | SET SCREW                         |
| 8    | 06504028 | 1    | KEY                               |
| 9    | 06504045 | 4    | DOWEL PIN                         |
| 10   | *        | 1    | NAMEPLATE                         |
| 11   | 763759   | 1    | THRUSTPLATE                       |
| 12   | 2961940  | 1    | PLUG, ODT (0.25)                  |
| 13   | TF4401   | 1    | SNAP RING                         |
| 14   | 06504142 | 1    | LIP SEAL                          |
| 15   | TF4410   | 2    | GASKET SEAL                       |
| 16   | 06504046 | 4    | SIDE SEAL                         |
| 17   | 06504047 | 4    | END SEAL                          |
| 18   | TF4407   | 2    | BACK-UP SEAL                      |
| 19   | 06504122 | 1    | SEAL RETAINER                     |
| 20   | 6T5809   | 2    | CHECK ASSEMBLY                    |
| 21   | 2961917  | 4    | WASHER                            |
| 22   | 06504140 | 1    | SHAFT                             |
| 23   | 06504139 | 1    | BREATHER                          |
| 24   | 06504121 | 1    | SPACER, BRG                       |
| 25   | 06504119 | 1    | SNAP RING                         |
| *    | 06504116 | -    | SEAL KIT                          |

COMMON BENGAL T4

## RESERVOIR TANK FILTER ASSEMBLY




| ITEM  | PART NO. | QTY. | DESCRIPTION                       |
|-------|----------|------|-----------------------------------|
| ----- | 06505044 | -    | FILTER ASSY SAE 10 MICRON         |
| 1     | 28583    | 4    | CAPSCREW, 8MM X 25MM (1.25 PITCH) |
| 2     | 06505045 | 1    | COVER                             |
| 3     | 06505046 | 1    | SEAL KIT                          |
| 4     | 06505047 | 1    | SPRING                            |
| 5     | 06505048 | 1    | BYPASS                            |
| 6     | 35259    | 1    | FILTER, 10 MIC, RETURN LINE       |
| 7     | 06505049 | 1    | CAN/BODY                          |

COMMON BENGAL T4




## PUMP AND GRILL GUARD OPTIONS




| ITEM | PART NO. | QTY. | DESCRIPTION                 |
|------|----------|------|-----------------------------|
| 1    | 32430    | 1    | UNIVERSAL PUMP GUARD        |
| 2    | 32737    | 1    | UNIVERSAL GRILL GUARD       |
| 3    | 21833    | 4    | CAPSCREW, 3/4" X 2-1/4", NC |
| 4    | 22021    | 2    | FLATWASHER, 3/4"            |
| 5    | 21993    | 4    | LOCKWASHER, 3/4"            |
| 6    | 21825    | 4    | HEX NUT, 3/4", NC           |

## BOOM TRAVEL LOCK




| ITEM  | PART NO. | QTY. | DESCRIPTION                             |
|-------|----------|------|---|
| 1     | 06510050 | 1    | HYDRAULIC TRAVEL LOCK VALVE             |
| 2     | 31329    | 1    | ADAPTER - STANDARD BOOM                 |
| ----- | 31611    | 1    | ADAPTER - EXTENDED BOOM                 |
| 3     | 34532    | 1    | SWITCH,TRAVEL LOCK                      |
| 4     | -----    | -    | MAIN BOOM CYLINDER *REFER TO BOOM ASSY  |
| 5     | -----    | -    | HOSE / FITTINGS *REFER TO BOOM HYD ASSY |
| 6     | 06510092 | 1    | COIL ,TRAVEL LOCK                       |

## MANUAL LIFT VALVE SWITCH BOX




| ITEM | PART NO. | QTY. | DESCRIPTION                   |
|------|----------|------|-------------------------------|
| 1    | 06514012 | 1    | SWBX,ALUM,BLK,06510100        |
| 2    | 35226    | 1    | SWITCH,MOWER,COLEHERSEE       |
| 3    | 33811    | 1    | SWITCH,MASTER/DECK FLOAT      |
| 4    | 34532    | 1    | SWITCH,TRVL LCK               |
| 5    | 06514014 | 1    | BREAKER,10A,SWBX              |
| 6    | 6T3923   | 1    | INDICTATOR LIGHT,ON,RED       |
| 7    | 34540    | 1    | STRAIN RELIEF,3/4,BLACK,NYLON |
| 8    | 06550019 | 1    | DECAL,SWTCHBX,BOOM,CG         |
| 9    | 02964063 | 1    | KNOB,RED                      |
| 10   | 35227    | 1    | RELAY,DP,DT,12V,LY2F,35226    |

# MANUAL LIFT VALVE SCHEMATIC




## ELECTRONIC LIFT VALVE SWITCH BOX




| ITEM | PART NO. | QTY. | DESCRIPTION                    |
|------|----------|------|--------------------------------|
| 1    | 06510196 | 1    | SWBX,ASSY                      |
| 2    | 33811    | 2    | SWITCH,MASTER/DECK FLOAT       |
| 3    | 33813    | 1    | SWITCH,SFTY SHIELD             |
| 4    | 34532    | 1    | SWITCH,TRVL LCK                |
| 5    | 34540    | 1    | STRAIN RELIEF,3/4",BLACK,NYLON |
| 6    | 6T3923   | 1    | INDICTATOR LIGHT,ON,RED        |
| 7    | 06514006 | 1    | BREAKER,15A,SWBX               |
| 8    | 06550044 | 1    | DECAL,SWBX,06510047            |
| 9    | 35226    | 1    | SWITCH,MOWER,COLEHERSEE        |
| 10   | 02964063 | 1    | KNOB,RED                       |
| 11   | 35227    | 1    | RELAY,DP,DT,12V,LY2F,35226     |

# ELECTRONIC LIFT VALVE SCHEMATIC




## SOLENOID SWITCH BOX AND WIRING



| ITEM | PART NO. | QTY. | DESCRIPTION                  |
|------|----------|------|------------------------------|
| 1    | -----    | -    | SWITCH BOX                   |
| 2    | RE37651  | 1    | PLUG,AUX PWR                 |
| 3    | 24204    | -    | FUSE HOLDER,IN-LINE (OPTION) |
| 4    | 6T3965   | -    | FUSE,3AMP (OPTION)           |
| 5    | 6T3934   | -    | TEMPERATURE GAUGE (OPTION)   |
| 6    | 6T3931   | -    | TEMPERATURE SENSOR (OPTION)  |


## BRAKE VALVE ASSEMBLY



| ITEM | PART NO. | QTY. | DESCRIPTION                                      |
|------|----------|------|--|
| ---  | 06510083 | 1    | BRAKE VALVE, ASSY                                |
| 1    | 34092    | 1    | BRAKE VALVE, BLANK                               |
| 2    | 34094    | 2    | LOGIC ELEMENT                                    |
| 3    | 34095    | 1    | RELIEF VALVE, 3000 PSI                           |
| 4    | 06510095 | 1    | METRI PAK COIL                                   |
| 5    | 34093    | 1    | CARTRIDGE, 2 POSITION, 3 WAY (WITH NUT & WASHER) |
| 6    | 34091    | 1    | RELIEF VALVE, 2600 PSI                           |
| ---  | 34096    | 2    | RELIEF SEAL KIT                                  |
| ---- | 34097    | 1    | SOLENOID SEAL KIT                                |
| ---  | 34098    | 2    | ELEMENT SEAL KIT                                 |



## BRAKE VALVE HYDRAULIC SCHEMATIC



### BRAKE VALVE TROUBLESHOOTING

#### FAILURE MODE:

- MOWER WILL NOT START - system pressure is low (engine not lugging).
- MOWER WILL NOT START - system pressure is high (engine lugging). "MR" port will be high pressure.
- MOWER WILL NOT ROTATE AT FULL SPEED - limited power.
- MOWER BLADE WILL NOT STOP - blade will not stop in proper time.

#### CHECK STEPS

1 thru 6

7


3 thru 5

7 thru 9

#### CORRECTIVE STEPS:


1. Check for voltage at solenoid (item 6), voltage must be between 10.2 volts and 13.8 volts.
2. Remove, inspect solenoid and cartridge (items 4, 6) for wear or contamination.
3. Remove, inspect logic elements near "P" port (item 3) for wear or contamination.
4. Remove, inspect 3000 psi relief valve (item 2) for wear or contamination.
5. Remove and inspect orifices near "P" port for contamination.
6. Remove "P" port hose and fitting, visually inspect for contamination, check ball for movement.
7. Remove and inspect orifices near "MR" port for contamination.
8. Remove, inspect 2600 psi relief valve (item 5) for wear or contamination.
9. Remove, inspect logic element near "MR" port (item 3) for wear or contamination.

## Joystick Electrical Troubleshooting guide



# HYDRAULIC TROUBLESHOOTING GUIDE

## Hydraulic Troubleshooting guide



**Notes:** If one function is slow, try operating another function at the same time and see if the slow function speeds up.

**On a closed center circuit, the following could be at fault as well:**

Tractor standby pressure in pump is low - should not be less than 200 PSI

**Cannot build pressure in any section of the valve**

Main inlet section may have a faulty relief valve, blocked orifice or filter - you must change out inlet section if this occurs  
Internal hydraulic pilot pressure insufficient

### **JOYSTICK TROUBLESHOOTING**

#### **Boom operation not responding to joystick movement.**

Isolate hydraulic vs. electronic symptom.

Turn off electronic master switch (preventing electronic actuator on valve from attempting to hold spool in neutral position). With tractor engine running, operate the valve section with the manual handle. If function operates normally, continue with electronic inspection. If function does not operate normally, continue with hydraulic inspection.

#### **Electronic inspection.**

Connect a voltmeter to the cable connector of the valve section that is not operating. This will allow you to measure supply and signal voltage when the joystick is operated.

Main, Secondary, and Swivel Valves – signal voltage should be 50% of supply voltage with joystick in Neutral position, up to 75% of supply voltage in B direction, down to 25% of supply voltage in A direction. Signal voltage should change smoothly with lever movement.

Pin #1 – Signal Voltage, Pin #4 – Power Voltage, Pin #3 – Ground

Deck Roll Valve or Float Valve – signal voltage should be 50% of supply voltage with joystick in Neutral position, up to 65% of supply voltage in B direction, down to 35% of supply voltage in A direction. Signal voltage should change smoothly with lever movement. Signal voltage should be approximately 75% of supply voltage when float switch is operated.

Pin #1 – Signal Voltage, Pin #4 – Power Voltage, Pin #3 – Ground

Shield Valve or On/Off Valve – Voltage on pin #1 should be equal to supply voltage when switch is operated in A direction. Voltage on pin #4 should be equal to supply voltage when switch is operated in B direction.

Pin #1 – Signal Voltage (Shield Open), Pin #4 – Signal Voltage (Shield Close), Pin #3 – Ground

If none of the valve will operate with electrical signal, verify that there is oil pressure at the valve inlet. Electrical Valves must have pilot supply oil to move the spools.

#### **Possible electronic problems.**

Open circuit (broken wire, bad connection or loose connection in switchbox).

Shorted to positive, ground, or other.

Incorrect voltage signal from joystick.

**Continued on next sheet**

## TROUBLESHOOTING - CONTINUED

### Hydraulic inspection.

Install 3 pressure gauges, on the valve inlet (use M port, or tee into hose supplying oil from the pump to the inlet), on the workport that is not operating, and on the LS port.

With the spools in Neutral

Gear pump – P should be approximately 200 psi, LS = 0, workport – pressure on cylinder or function.

LS pump – P should equal pump standby pressure, LS = 0, workport – pressure on cylinder or function.

Pressure Comp pump – P should equal pump standby pressure, LS = 0, workport – pressure on cylinder or function.

Gear pump – P should be approximately 200 psi higher than LS, LS should equal workport, workport – pressure on cylinder or function.

LS pump – P should be LS + standby, LS should equal workport, workport – pressure on cylinder or function.

Pressure Comp pump – P should equal pump standby pressure, LS should equal workport, workport – pressure on cylinder or function.

Operate one spool, measure pressures with function at end of travel or stop

Gear pump – P should equal valve relief setting or workport shock valve setting. LS should equal workport. Workport should equal relief setting or workport shock valve setting.

LS pump – P should equal valve relief setting, pump max pressure setting, or workport shock valve setting. LS should equal workport. Workport should equal relief setting, pump max pressure setting, or workport shock valve setting.

Pressure Comp pump – P should equal pump standby pressure, LS should equal workport. Workport should equal pump standby pressure or workport shock valve setting.

Operate more than one spool.

Gear pump – P should be approximately 200 psi higher than LS. LS should equal highest workport pressure. Workport – pressure on cylinder or function.

LS pump – P should be LS + standby pressure. LS should equal highest workport pressure. Workport – pressure on cylinder or function.

Pressure Comp pump. P should equal pump standby pressure. LS should equal highest workport pressure. Workport – pressure on cylinder or function.


### Possible hydraulic problems.

Cylinder leak.

LS signal leaking to tank before reaching pump LS port.

Hydraulic system or pump not supplying flow to valve.

# WHEEL WEIGHT - BENGAL 18



| ITEM | PART NO. | QTY. | DESCRIPTION            |
|------|----------|------|------------------------|
| 1    | 30687    | 1    | 500# WHEEL WEIGHT      |
| 2    | 21956    | 4    | CAPSCREW,3/4" X 13",NC |
| 3    | 22021    | 8    | FLATWASHER,3/4"        |
| 4    | 21993    | 4    | LOCKWASHER,3/4"        |
| 5    | 21825    | 4    | HEX NUT,3/4",NC        |

COMMON BENGAL T4

# **WARRANTY SECTION**





## WARRANTY INFORMATION

Tiger Corporation, 3301 N. Louise, Sioux Falls, South Dakota, warrants to the original Retail Customer, the new Tiger equipment is free of defects in material and workmanship. Any part of equipment that in Tiger's judgement, show evidence of such defects will be repaired or replaced without charge, provided that the failure of part(s) shall have occurred within twelve (12) months from the date of delivery of said equipment to the Retail Customer. Expendable components such as knives, oil, chain sprockets, skid shoes, knife mounting disks and the like are excluded but not limited to this warranty.

The Retail Customer must pay the transportation cost to and from the Tiger Dealer's service shop for warranty service. Warranty service will be performed by the Tiger Dealer from whom the equipment was purchased, during service shop regularly scheduled days and hours of operation.

All Tiger obligation under this warranty shall be terminated if the equipment is modified or altered in ways not approved in writing by Tiger, if repair parts other than genuine Tiger repair parts have been used, or if the equipment has been subject to misuse, neglect, accident, improper maintenance or improper operation.

Tiger Corporation reserves the right to make improvements in design or changes in specification at any time without incurring any obligation to owners of equipment previously sold.

No agent or person has authority to alter, add to or waive the above warranties which are agreed to be in the only warranties, representations or promises, expressed or implied, as to the quality or performance of the products covered and which do not include any implied warranty of merchantability or fitness. In no event will Tiger be liable for incidental or consequential damages or injuries, including, but not limited to, loss of profits, rental or substitute equipment or other commercial loss.

### **THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THOSE EXPRESSED HEREIN.**

It is the Purchasers obligation to sign the warranty registration form **AFTER** he / she has Read and Understands the Operation and Safety Instructions stated within this manual.

## ONE LAST WORD

This manual cannot possibly cover all of the potentially hazardous situations you will encounter. By being familiar with the safety rules, operating and maintenance instructions in this manual you can help prevent accidents. The objective of this manual is to help make you a better operator. Remember, **SAFETY IS YOU!**



1012

Your safety and the safety of those around you depends on **YOU**. Common sense should play a large role in the operation of this machine.

Since we at Tiger Corporation are constantly striving to improve our products, we reserve the right to change specifications or design at any time.

## TO THE OWNER / OPERATOR / DEALER



To keep your implement running efficiently and safely, read your manual thoroughly and follow these directions and the Safety Messages in this manual and on the machine. The table of contents clearly identifies each section where you can easily find the information you need.

The Occupational Safety and Health Act (OSHA 1928.51 subpart C) makes the following minimum requirements for tractor operators.

### **OWNER REQUIREMENTS:**

1. Provide a Roll-Over-Protective Structure that meets the requirements of this Standard; and
2. Provide Seatbelts that meet the requirements of this Standard and SAE J3C; and
3. Ensure that each employee uses such Seatbelt while the tractor is moving; and
4. Ensure that each employee tightens the Seatbelt sufficiently to confine the employee to the protected area provided by the ROPS.

### **OPERATOR REQUIREMENTS:**

1. Securely fasten seatbelt if the tractor has a ROPS.
2. Where possible, avoid operating the tractor near steep ditches, embankments, and holes.
3. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.
4. Stay off slopes too steep for safe operation.
5. Watch where you are going – especially at row ends, on roads, and around trees.
6. Do Not permit others to ride.
7. Operate the tractor smoothly – no jerky turns, starts, or stops.
8. Hitch only to the draw-bar and hitch points recommended by the tractor manufacturer.
9. When the tractor is stopped, set brakes securely and use park lock, if available



Printed in USA  
© Tiger Corporation